

X41 Tablet Setup Poster

P/N 39T9257

11/15/2005

Size : 11x13 inches

Color : 2 color job = ■ Process Black (This plate must be printed in PMS Process Black C)

■ Process Magenta (This plate must be printed in PMS 032cvc)

Font : IBM Fonts and Helvetica Neue Family

Material : 100 gsm gloss art paper (Use 100% recycled paper in only Japan.)

Blue line shows die-cut. DO NOT PRINT.

Please change the barcode No.



Please change printing country name if the poster is printed in other than China.

ThinkPad®

설치 가이드

제품을 처음 설치할 때 다음의 지시 사항을 따르십시오.
더 자세한 정보를 보려면 Access IBM 버튼을 누르십시오.

1 제품의 포장을 열고 내용물을 확인하십시오.




* 목록에 없거나, 누락되었거나, 손상된 부품과 복구 CD에 관해서는 뒷면을 참고하십시오.

참고: 컴퓨터를 사용하기 전에 사용 설명서에 수록된 안전 관련 사항을 읽으십시오.


2 배터리를 장착하십시오.

배터리는 장착 즉시 사용할 수 있습니다.

참고: 일부 모델의 경우, 그림과 다른 배터리가 장착될 수 있습니다.



3 전원을 연결하십시오.



4 컴퓨터의 전원을 켜십시오.



5 트랙포인트를 이용하여 포인터를 이동하거나 원하는 항목을 선택하십시오.

포인터를 움직이려면 트랙포인트 캡을 손가락 끝으로 원하는 진행 방향으로 미십시오.

6 화면의 지시에 따라 운영 체제를 설정하십시오.

이 과정에는 수 분 정도의 시간이 소요됩니다. 과정이 진행되는 동안, 컴퓨터가 수 차례 재시작할 것입니다.

7 더 자세한 정보를 보려면 Access IBM 버튼을 누르십시오.




8 태블릿 전환

래치를 밀고 LCD 화면을 여십시오.
LCD 화면을 시계 방향으로 180도 회전시키십시오.
LCD 화면을 닫고 래치를 누르십시오.



ThinkVantageDesign



태블릿 디지털 펜 보관함
펜을 사용하지 않을 경우 이곳에 보관할 수 있습니다.

Fn 키
파란색 아이콘이 인쇄된 키와 함께 사용하면 ThinkPad 컴퓨터의 특수 기능을 수행할 수 있습니다.

한 손으로 조작할 수 있는 원터치 방식의 래치

P/N: 39T9257