

**SDK-86**  
**MCS-86™ SYSTEM DESIGN KIT**  
**MONITOR LISTINGS**

Manual Order Number: 9800699-03 Rev. C

Additional copies of this manual or other Intel literature may be obtained from:

Literature Department  
Intel Corporation  
3065 Bowers Avenue  
Santa Clara, CA 95051

The information in this document is subject to change without notice.

Intel Corporation makes no warranty of any kind with regard to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. Intel Corporation assumes no responsibility for any errors that may appear in this document. Intel Corporation makes no commitment to update nor to keep current the information contained in this document.

Intel Corporation assumes no responsibility for the use of any circuitry other than circuitry embodied in an Intel product. No other circuit patent licenses are implied.

Intel software products are copyrighted by and shall remain the property of Intel Corporation. Use, duplication or disclosure is subject to restrictions stated in Intel's software license, or as defined in ASPR 7-104.9(a)(9).

No part of this document may be copied or reproduced in any form or by any means without the prior written consent of Intel Corporation.

The following are trademarks of Intel Corporation and may be used only to identify Intel products:

i  
ICE  
iCS  
Insite  
Intel  
Inteleview  
Inteltec

iSBC  
Library Manager  
MCS  
Megachassis  
Micromap  
Multibus

Multimodule  
PROMPT  
Promware  
RMX  
UPI  
 $\mu$ Scope

and the combination of ICE, iCS, iSBC, MCS, or RMX and a numerical suffix.



## PREFACE

This manual contains the source listing for version 1.1 of the keypad monitor program and version 1.2 of the serial monitor program. Two listings are provided for each monitor program; a PL/M-86 source listing and an expanded source listing containing the assembly language equivalent of each PL/M instruction.





# SDK-86 KEYPAD MONITOR PL/M-86 SOURCE LISTING

PL/M-86 COMPILER      SDK86 KEYPAD MONITOR

PAGE 1

ISIS-II PL/M-86 V1.0 COMPILATION OF MODULE MONITOR  
 OBJECT MODULE PLACED IN :F1:KEYPAD.OBJ  
 COMPILER INVOKED BY: :F2:PLM86 :F1:KEYPAD.PLM LARGE OPTIMIZE(2)

```
$TITLE('SDK86 KEYPAD MONITOR')
$NOINTVECTOR
```

```
/* *****
*****
```

```
SDK-86 KEYPAD MONITOR, V1.1
30 JUNE 1978
```

```
(C) 1978 INTEL CORPORATION. ALL RIGHTS RESERVED. NO PART OF
THIS PROGRAM OR PUBLICATION MAY BE REPRODUCED, TRANSMITTED,
TRANSCRIBED, STORED IN A RETRIEVAL SYSTEM, OR TRANSLATED INTO ANY
LANGUAGE, IN ANY FORM OR BY ANY MEANS, ELECTRONIC, MECHANICAL,
MAGNETIC, OPTICAL, CHEMICAL, MANUAL OR OTHERWISE, WITHOUT THE PRIOR
WRITTEN PERMISSION OF INTEL CORPORATION, 3065 BOWERS AVENUE, SANTA
CLARA, CALIFORNIA, 95051.
```

```
*****
*****
```

ABSTRACT

```
=====
THIS PROGRAM IS THE ROM BASED KEYPAD MONITOR FOR THE SDK-86.
IT PROVIDES THE USER WITH A MODERATE LEVEL OF CAPABILITY TO
EXAMINE/MODIFY MEMORY AND REGISTERS AND CONTROL PROGRAM EXECUTION.
```

ENVIRONMENT

```
=====
THE SDK KEYPAD MONITOR COMMUNICATES WITH THE USER VIA THE ONBOARD
KEYBOARD AND 7 SEGMENT DISPLAY.
```

PROGRAM ORGANIZATION

```
=====
THE PROGRAM IS DIVIDED INTO 1 DATA AND 2 CODE MODULES:
1. DATA DECLARATION MODULE.      GLOBAL DATA DECLARATIONS.
2. COMMON ROUTINES.                LOWER LEVEL PROCEDURES
3. COMMAND MODULE.                 INDIVIDUAL COMMANDS AND OUTER BLOCK
```

CALLING GRAPH

```
=====
>>COMMAND DISPATCH MODULE (OUTER BLOCK)
      INDIVIDUAL COMMAND PROCEDURES
      COMMON ROUTINES
```

GLOBAL DATA STRUCTURES

```
=====
THE MONITOR MAINTAINS THE USER'S MACHINE STATE (REGISTERS) IN A
WORD ARRAY. THE REGISTERS ARE SAVED FROM THE USER'S STACK
AS PUSHED BY PLM86 INTERRUPT PROCEDURE.
POINTERS TO THE SDK-86 2**20 ADDRESS SPACE ARE IMPLEMENTED WITH
POINTER STRUCTURES ALLOCATED AS 2 WORD STRUCTURES.
```

```

*/
1      MONITOR:DO;          /* BEGINNING OF MODULE */
/* *****
*****

GLOBAL DATA DECLARATIONS MODULE
=====

ABSTRACT
=====
THIS MODULE CONTAINS ALL THE GLOBAL DATA DECLARATIONS AND
LITERALS (EQUATES).

MODULE ORGAINIZATION
=====
THE MODULE IS DIVIDED INTO 5 SECTIONS:
1. UTILITY SECTION          GLOBAL FLAGS, VARIABLES, EQUATES
2. I/O SECTION             I/O PORTS, MASKS, AND SPECIAL CHARS
3. MEMORY ARGUMENTS SECTIONS STRUCTURES FOR MEDIUM POINTERS
4. REGISTER SECTION        USER REGISTER SAVE AREA
5. BOOT AND 8089 SECTION    BOOTSTRAP AND 8089 DESCRIPTOR
*/

/*****
*   UTILITY SECTION   *
*****/

2  1  DECLARE INT$VECTOR(5)  POINTER;          /* INTERRUPT VECTORS */
3  1  DECLARE MONITOR$STACKPTR WORD,          /* MONITOR SS SAVE */
      MONITOR$STACKBASE WORD;

4  1  DECLARE COPYRIGHT(*) BYTE DATA ('(C) 1978 INTEL CORP');
5  1  DECLARE BRK1$FLAG      BYTE,          /* TRUE IF BREAK SET */
      BRK1$SAVE            BYTE,          /* INST BREAK SAVE */
      CHAR                 BYTE,          /* ONE CHAR LOOK AHEAD */
      DISP(4)              BYTE,          /* DISPLAY ARRAY */
      I                     BYTE,
      END$OFF               WORD,          /* END OFFSET ADDRESS */
      WORD$MODE             BYTE,
      LAST$COMMAND          BYTE;

6  1  DECLARE TRUE          LITERALLY 'OFFH',
      FALSE                LITERALLY 'OOOH',
      ADDR$FIELD           LITERALLY '1',          /* ADDR FIELD WORD OUTPUT */
      DATA$FIELD          LITERALLY '0',          /* DATA FIELD WORD OUTPUT */
      DATA$BYTE           LITERALLY '-1',          /* DATA FIELD BYTE OUTPUT */
      BLANK                 LITERALLY '1',
      NOBLANK               LITERALLY '0',
      BREAK$INST           LITERALLY 'OCCH',          /* BREAKPOINT TRAP */
      STEP$TRAP            LITERALLY '0100H',          /* SS TRAP FLAG MASK */
      USER$INIT$SP        LITERALLY '100H',          /* USER STACK INITIAL */

```

```

GO$COMMAND      LITERALLY '2',      /* GO COMMAND CODE */
SS$COMMAND      LITERALLY '3';
    
```

```

/*****
 * I/O DECLARATIONS SECTION *
 *****/
    
```

```

7 1  DECLARE
      KB$STAT$PORT      LITERALLY 'OFFEAH',      /* STATUS/COMMAND PORT */
      KB$DATA$PORT      LITERALLY 'OFFE8H',      /* DATA PORT */
      KB$INIT$MODE      LITERALLY '00H',        /* 8 8-BIT, LEFT ENTRY,
      ENCODE, 2 KEY LOCKOUT */
      KB$INIT$SCAN      LITERALLY '39H',        /* 10MS SCAN RATE */
      KB$INRDY          LITERALLY '07H',        /* IN CHAR RDY MASK */
      KB$CMND$PMT(*)    BYTE DATA (40H,00H,00H,00H), /* '-' */
      KB$SIGNON(*)     BYTE DATA (40H,00H,7FH,7DH), /* '86' */
      KB$VERSION(*)    BYTE DATA (00H,00H,86H,06H), /* '1.1' */
      KB$REG$PMT(*)    BYTE DATA (50H,00H,00H,00H), /* 'R' */
      KB$ERR$MSG(*)    BYTE DATA (40H,79H,50H,50H), /* '-ERR' */
      KB$EXEC(*)       BYTE DATA (79H,00H,00H,00H), /* 'E' */
      KB$BRK1(*)       BYTE DATA (7CH,50H,00H,00H), /* 'BR' */
      KB$BLANKS(*)     BYTE DATA (00H,00H,00H,00H), /* ' ' */
      LED(*)           BYTE DATA
      (3FH,06H,5BH,4FH,66H,6DH,7DH,07H,        /* '0'-'7' */
       7FH,6FH,77H,7CH,39H,5EH,79H,71H);      /* '8'-'F' */
    
```

```

8 1  DECLARE
      KBPER             LITERALLY '10H',        /* PERIOD */
      KBKOM             LITERALLY '11H',        /* COMMA */
      KBREGKEY          LITERALLY '15H',        /* REGISTER KEY */
      KBCOL             LITERALLY '14H',        /* COLON (SEGMENT) */
      KBPLUS            LITERALLY '13H',        /* PLUS KEY */
      KBMINUS           LITERALLY '12H',        /* MINUS KEY */
    
```

```

/*****
 * POINTER SECTION *
 *****/
    
```

```

9 1  DECLARE
      MEMORY$ARG1$PTR  POINTER,                /* ARGUMENT 1 */
      ARG1 STRUCTURE (OFF WORD, SEG WORD)
      AT (@MEMORY$ARG1$PTR),
      MEMORY$ARG1 BASED MEMORY$ARG1$PTR BYTE,
      MEMORY$WORD$ARG1 BASED MEMORY$ARG1$PTR WORD,

      MEMORY$ARG3$PTR  POINTER,                /* ARGUMENT 3 */
      ARG3 STRUCTURE (OFF WORD, SEG WORD)
      AT (@MEMORY$ARG3$PTR),
      MEMORY$ARG3 BASED MEMORY$ARG3$PTR BYTE,

      MEMORY$BRK1$PTR  POINTER,                /* BREAKPOINT */
      BRK1 STRUCTURE (OFF WORD, SEG WORD)
      AT (@MEMORY$BRK1$PTR),
      MEMORY$BRK1 BASED MEMORY$BRK1$PTR BYTE,

      MEMORY$CSIP$PTR  POINTER,                /* CS:IP INSTRUCTION */
      CSIP STRUCTURE (OFF WORD, SEG WORD)
      AT (@MEMORY$CSIP$PTR),
    
```

```

MEMORY$CSIP BASED MEMORY$CSIP$PTR BYTE,

MEMORY$USERSTACK$PTR POINTER,          /* USER'S STACK */
USERSTACK STRUCTURE (OFF WORD, SEG WORD)
  AT (@MEMORY$USERSTACK$PTR),
MEMORY$USERSTACK BASED MEMORY$USERSTACK$PTR WORD;

```

```

/*****
* REGISTER SECTION *
*****/

```

```

10 1 DECLARE
KB$REG(*) BYTE DATA
  (00H,77H,00H,7CH,00H,39H,00H,5EH, /* AXBXCXDX */
  6DH,73H,7CH,73H,6DH,30H,5EH,30H, /* SPBPSIDI */
  39H,6DH,5EH,6DH,6DH,6DH,79H,6DH, /* CSDSSSES */
  30H,73H,71H,38H), /* IPFL */
REG$SAV(14) WORD, /* USER'S SAVED REGS */
REG$ORD(*) BYTE DATA
  (7,6,1,3,2,0,9,11,12,8,13), /* STACKED REG ORDER */
SP LITERALLY 'REG$SAV( 4)',
BP LITERALLY 'REG$SAV( 5)',
CS LITERALLY 'REG$SAV( 8)',
DS LITERALLY 'REG$SAV( 9)',
SS LITERALLY 'REG$SAV(10)',
ES LITERALLY 'REG$SAV(11)',
IP LITERALLY 'REG$SAV(12)',
FL LITERALLY 'REG$SAV(13)';

```

```

/*****
* BOOTSTRAP JUMP AND 8089 VECTOR *
*****/

```

```

/* THIS BOOT CONSISTS OF A LONG JUMP TO THE BEGINNING OF THE MONITOR
AT FFOO+XXXX WHERE XXXX IS THE STARTING ADDRESS OFFSET (IP) AND
MUST BE DETERMINED AFTER EACH COMPILE. */

```

```

11 1 DECLARE
START$ADDR LITERALLY '009CH', /* STARTING ADDRESS */
BOOT1(*) BYTE AT (OFFF0H) DATA (0EAH), /* LONG JUMP OPCODE */
BOOT2(*) WORD AT (OFFF1H) DATA (START$ADDR),
BOOT3(*) WORD AT (OFFF3H) DATA (OFF00H); /* SEGMENT ADDRESS */

```

```

/* THIS TWO-WORD DATA IS A JUMP TO THE STARTING ADDRESS AND IS LOCATED
AT THE FIRST LOCATION OF ROM (NO OTHER DATA OR CONSTANT DECLARATIONS
MAY PRECEDE IT). THE JUMP IS ACTUALLY TO (START-ADDR)-4 SINCE THE
INSTRUCTION IS A RELATIVE JUMP OF LENGTH 3. */

```

```

12 1 DECLARE
BOOT4(*) WORD DATA (0E990H,START$ADDR-4); /* NOP,JMP START-ADDR */

```

```

/* THIS BLOCK OF ROM AT FFFF6-FFFFA IS INITIALIZED FOR THE 8089
DEVICE AND POINTS TO A BLOCK OF RAM AT LOCATION 100H. */

```

```

13 1 DECLARE
BLOCK$8089 WORD AT (OFFF6H) DATA (00001H),
BLOCK$8089$PTR POINTER AT (OFFF8H) DATA (00100H);

```



```
/* *****
*****
```

COMMON PROCEDURES

=====

ABSTRACT

=====

THIS MODULE CONTAINS THOSE LOWER LEVEL PROCEDURES CALLED BY HIGHER LEVEL ROUTINES.

MODULE ORGANIZATION

=====

THIS MODULE CONTAINS THE FOLLOWING SECTIONS:

1. BASIC I/O SECTION

KB\$DISPLAY	DISPLAY TO LED FIELDS
KB\$BLANK\$DATA\$FIELD	BLANK DATA FIELD WITH PROMPTS
KB\$BLANK\$ADDR\$FIELD	BLANK ADDRESS FIELD WITH PROMPTS
KB\$OUT\$BYTE	OUTPUT A BYTE TO DISPLAY
KB\$OUT\$WORD	OUTPUT A WORD TO DISPLAY
KB\$GET\$CHAR	INPUT A CHAR FROM KEYPAD

2. ARGUMENT EXPRESSION EVALUATOR

KB\$GET\$EXPR	GET WORD EXPRESSION
KB\$GET\$ADDR	GET ADDRESS EXPRESSION
KB\$UPDATE\$IP	GET OPTIONAL CS:IP

3. INTERRUPT AND RESTORE/EXECUTE ROUTINES

SAVE\$REGISTERS	SAVES USERS REGISTERS
RESTORE\$EXECUTE	RESTORE MACHINE STATE AND EXEC
INTERRUPR1\$ENTRY	INTERRUPT FOR SINGLE STEP
INTERRUPT3\$ENTRY	INTERRUPT ROUTINE FOR GO
INIT\$INT\$VECTOR	INITIALIZES INTERRUPT VECTORS

\*/

```
/* *****
* BASIC I/O SECTION *
***** */
```

```
14 1 KB$DISPLAY:
/* THIS ROUTINE DISPLAYS THE CONTENTS OF THE ARRAY POINTED TO BY
THE FIRST PARM TO THE FIELD SPECIFIED BY THE SECOND (ADDR OR
DATA). THE NUMBER OF DECIMAL POINTS OR PROMPTS IS DETERMINED
BY THE THIRD PARAMETER */
PROCEDURE (PTR, FIELD, PROMPTS);
15 2 DECLARE PTR POINTER, (FIELD, PROMPTS, T) BYTE,
DISPLAY BASED PTR (1) BYTE;
16 2 IF FIELD=ADDR$FIELD THEN
17 2 OUTPUT(KB$STAT$PORT) = 94H; /* ADDRESS FIELD */
ELSE
18 2 OUTPUT(KB$STAT$PORT) = 90H; /* DATA FIELD */
19 2 DO I=0 TO 3;
20 3 T = DISPLAY(3-I); /* DISPLAY BACKWARDS! */
21 3 IF PROMPTS>I THEN T = T OR 80H;
23 3 OUTPUT(KB$DATA$PORT) = T;
24 3 END;
25 2 END;
```

```
26 1 KB$BLANK$DATA$FIELD:
```

PL/M-86 COMPILER      SDK86 KEYPAD MONITOR

```

                /* THIS ROUTINE BLANKS THE DATA FIELD OF THE DISPLAY WITH THE
                NUMBER OF PROMPTS (DECIMAL POINTS) AS SPECIFIED BY THE PARAMETER. */
                PROCEDURE(PROMPTS);
27    2            DECLARE PROMPTS BYTE;
28    2            CALL KB$DISPLAY(@KB$BLANKS,DATA$FIELD,PROMPTS);
29    2            END;

30    1            KB$BLANK$ADDR$FIELD:
                /* THIS PROCEDURE BLANKS THE ADDRESS FIELD OF THE DISPALY WITH THE
                NUMBER OF PROMPTS SPECIFIED BY THE PARAMETER 'PROMPTS'. */
                PROCEDURE(PROMPTS);
31    2            DECLARE PROMPTS BYTE;
32    2            CALL KB$DISPLAY(@KB$BLANKS,ADDR$FIELD,PROMPTS);
33    2            END;

34    1            KB$OUT$BYTE:
                /* THIS ROUTINE OUTPUTS THE BYTE INPUT FROM THE FIRST PARAMETER
                TO THE DATA FIELD WITH THE NUMBER OF PROMPTS SPECIFIED BY THE
                SECOND PARAMETER. */
                PROCEDURE(B,PROMPTS);
35    2            DECLARE (B,PROMPTS) BYTE;
36    2            DISP(0),DISP(1) = 0;                                /* FIRST TWO BLANK */
37    2            DISP(2) = LED(SHR(B,4) AND OFH);
38    2            DISP(3) = LED(B AND OFH);
39    2            CALL KB$DISPLAY(@DISP,DATA$FIELD,PROMPTS);
40    2            END;

41    1            KB$OUT$WORD:
                /* THIS ROUTINE OUTPUTS THE FIRST PARM TO THE FIELD SPECIFIED
                BY THE SECOND WITH THE NUMBER OF PROMPTS SPECIFIED BY THE THIRD.
                LEADING ZERO BLANKING IS PERFORMED IF SPECIFIED BY THE FOURTH
                PARAMETER. */
                PROCEDURE(W,FIELD,PROMPTS,BLANKING);
42    2            DECLARE W WORD, (FIELD,PROMPTS,BLANKING) BYTE;
43    2            DO I=0 TO 3;
44    3            DISP(I) = LED(SHR(W,{3-I}*4) AND 000FH);
45    3            END;
46    2            IF BLANKING=BLANK THEN                            /* BLANK LEADING 0'S */
47    2            DO;
48    3            I = 0;
49    3            DO WHILE DISP(I)=3FH AND I<3;
50    4            DISP(I) = 0;
51    4            I = I + 1;
52    4            END;
53    3            END;
54    2            CALL KB$DISPLAY(@DISP,FIELD,PROMPTS);
55    2            END;

56    1            KB$GET$CHAR:
                /* READS ONE CHARACTER FROM THE FIFO OF THE 8279. WAITS UNTIL
                CHARACTER IS AVAILABLE AND THEN RETURNS THE CHARACTER IN GLOBAL
                VARIABLE 'CHAR'. */
                PROCEDURE;
57    2            DO WHILE (INPUT(KB$STAT$PORT) AND KB$INRDY)=0; END;
59    2            OUTPUT(KB$STAT$PORT) = 040H;                    /* ENABLE INPUT DATA */
60    2            CHAR = INPUT(KB$DATA$PORT);                    /* READ CHARACTER */
61    2            END;

```



PL/M-86 COMPILER      SDK86 KEYPAD MONITOR

```

98   3           RETURN W;
99   3           IF CHAR=KBPLUS OR CHAR=KBMINUS THEN
100  3           OPER = CHAR;
           ELSE
101  3           GOTO ERROR;
102  3           CALL KB$GET$CHAR;                    /* GET NEXT CHAR */
103  3           END;
104  2           END;

105  1   KB$GET$ADDR:
           /* THIS ROUTINE GATHERS CHARACTERS FROM THE INPUT STREAM AND
           FORMS AN ADDRESS EXPRESSION OF SEGMENT PART AND OFFSET PART.
           THE FIRST CHARACTER HAS ALREADY BEEN READ INTO GLOBAL 'CHAR'.
           IF NO SEGMENT IS ENTERED, THE SECOMD PARM DEFAULT IS USED, THE
           ADDRESS EXPRESSION IS DISPLAYED IN THE ADDRESS FIELD WITH THE
           NUMBER OF PROMPTS SPECIFIED BY THE THIRD PARM. */
           PROCEDURE(PTR,DEFAULT$BASE,PROMPTS);
106  2   DECLARE PTR POINTER, DEFAULT$BASE WORD, PROMPTS BYTE,
           ARG BASED PTR STRUCTURE (OFF WORD, SEG WORD);
107  2   ARG.SEG = DEFAULT$BASE;
108  2   ARG.OFF = KB$GET$EXPR(ADDR$FIELD,PROMPTS,BLANK);
109  2   IF CHAR=KBCOL THEN                         /* SEGMENT SPEC'D */
110  2   DO;
111  3   CALL KB$GET$CHAR;
112  3   ARG.SEG = ARG.OFF;
113  3   ARG.OFF = KB$GET$EXPR(ADDR$FIELD,PROMPTS,BLANK);
114  3   IF CHAR=KBCOL THEN GOTO ERROR;
116  3   END;
117  2   END;

118  1   KB$UPDATE$IP:
           /* THIS ROUTINE IS CALLED BY SINGLE STEP AND GO TO OUTPUT THE CURRENT
           CS:IP AND THE CURRENT INSTRUCTION BYTE. CS:IP IS OPENED FOR
           OPTIONAL INPUT. */
           PROCEDURE;
119  2   CALL KB$OUT$WORD(IP,ADDR$FIELD,1,BLANK);     /* DISPLAY IP */
120  2   CSIP.OFF = IP;
121  2   CSIP.SEG = CS;
122  2   CALL KB$OUT$BYTE(MEMORY$CSIP,0);
123  2   CALL KB$GET$CHAR;
124  2   IF CHAR<>KBCOM AND CHAR<>KBPER THEN
125  2   DO;                                         /* CHANGE CS:IP */
126  3   CALL KB$BLANK$ADDR$FIELD(1);
127  3   CALL KB$BLANK$DATA$FIELD(0);
128  3   CALL KB$GET$ADDR(@CSIP,CS,1);
129  3   END;
130  2   END;

           /*****
           *    INTERRUPT AND RESTORE/EXECUTE SECTION    *
           *****/

131  1   SAVE$REGISTERS:
           /* THIS ROUTINE IS USED TO SAVE THE STACKED USER'S REGISTERS IN THE
           MONITOR'S SAVE AREA. */
           PROCEDURE;

```

PL/M-86 COMPILER      SDK86 KEYPAD MONITOR

```

132 2      BP = MEMORY$USERSTACK;
133 2      USERSTACK.OFF = USERSTACK.OFF + 4;
134 2      DO I=0 TO 10;                               /* POP REGISTERS OFF OF STACK */
135 3          REG$SAV(REG$ORD(I)) = MEMORY$USERSTACK;
136 3          USERSTACK.OFF = USERSTACK.OFF + 2;
137 3      END;
138 2      SS = USERSTACK.SEG;
139 2      SP = USERSTACK.OFF;
140 2      END;

141 1      RESTORE$EXECUTE:
        /* THIS PROCEDURE RESTORES THE STATE OF THE USER MACHINE AND
        PASSES CONTROL BACK TO THE USER PROGRAM. IT CONTAINS A
        MACHINE LANGUAGE SUBROUTINE TO PERFORM THE POPPING OF THE
        USER REGISTERS AND TO EXECUTE AN 'IRET' TO TRANSFER CONTROL
        TO THE USER'S PROGRAM. */
        PROCEDURE;
142 2      DECLARE RESTORE$EXECUTE$CODE(*) BYTE DATA
        (08BH,0ECH,          /* MOV BP,SP          */
         08BH,046H,002H,     /* MOV AX,/BP/.PARAM2 */
         08BH,05EH,004H,     /* MOV BX,/BP/.PARAM1 */
         08EH,0D0H,          /* MOV SS,AX          */
         08BH,0E3H,          /* MOV SP,BX          */
         05DH,               /* POP BP             */
         05FH,               /* POP DI             */
         05EH,               /* POP SI             */
         05BH,               /* POP BX             */
         05AH,               /* POP DX             */
         059H,               /* POP CX             */
         058H,               /* POP AX             */
         01FH,               /* POP DS             */
         007H,               /* POP ES             */
         0CFH),              /* IRET              */
        RESTORE$EXECUTE$CODE$PTR WORD DATA (.RESTORE$EXECUTE$CODE);

143 2      USERSTACK.SEG = SS;
144 2      USERSTACK.OFF = SP;
145 2      DO I=0 TO 10;                               /* PUSH USER'S REGISTERS ONTO HIS STACK */
146 3          USERSTACK.OFF = USERSTACK.OFF - 2;
147 3          MEMORY$USERSTACK = REG$SAV(REG$ORD(10-I));
148 3      END;
149 2      USERSTACK.OFF = USERSTACK.OFF - 2;
150 2      MEMORY$USERSTACK = BP;
151 2      CALL RESTORE$EXECUTE$CODE$PTR(USERSTACK.OFF,USERSTACK.SEG);
152 2      END;

153 1      INTERRUPT1$ENTRY:
        /* THIS PROCEDURE IS CALLED WHEN THE CPU IS INTERRUPTED BY EXECUTING
        AN INSTRUCTION WITH THE TRAP BIT SET (SINGLE STEP). */
        PROCEDURE INTERRUPT 1;
154 2          USERSTACK.OFF = STACKPTR;                /* SAVE USER STACK INFO */
155 2          USERSTACK.SEG = STACKBASE;
156 2          STACKPTR = MONITOR$STACKPTR;
157 2          STACKBASE = MONITOR$STACKBASE;
158 2          CALL SAVE$REGISTERS;
159 2          FL = FL AND (NOT STEP$TRAP);              /* CLEAR STEP FLAG */
160 2          IF LAST$COMMAND<>SS$COMMAND THEN

```

PL/M-86 COMPILER      SDK86 KEYPAD MONITOR

```

161 2          CALL RESTORE$EXECUTE;          /* CONTINUE IF NOT SS */
162 2          CALL KB$UPDATE$IP;
163 2          IF CHAR=KBCOM THEN
164 2              DO;
165 3              IP = CSIP.OFF;
166 3              CS = CSIP.SEG;
167 3              FL = FL OR STEP$TRAP;      /* SET STEP FLAG */
168 3              CALL RESTORE$EXECUTE;
169 3              END;
170 2          IF CHAR<>KBPER THEN GOTO ERROR;
172 2          GOTO AFTER$COMMAND;
173 2          END;

174 1          INTERRUPT3$ENTRY:
/* THIS PROCEDURE IS CALLED WHEN THE CPU EXECUTES A 'INT 3' INSTRUCTION.
   THE MONITOR INSERTS THIS (OCCH) FOR A BREAKPOINT. ALSO AN EXTERNAL
   INTERRUPT OR A USER SOFTWARE INTERRUPT MAY CAUSE THIS PROCEDURE TO BE
   CALLED. */
          PROCEDURE INTERRUPT 3;
175 2          USERSTACK.OFF = STACKPTR;      /* SAVE USER STACK INFO */
176 2          USERSTACK.SEG = STACKBASE;
177 2          STACKPTR = MONITOR$STACKPTR;
178 2          STACKBASE = MONITOR$STACKBASE;
179 2          CALL SAVE$REGISTERS;
180 2          GOTO AFTER$INTERRUPT;
181 2          END;

182 1          INIT$INT$VECTOR:
/* THIS ROUTINE INITIALIZES AN INTERRUPT VECTOR AS FOLLOWS: THE OFFSET
   FROM THE ADDRESS OF 'INT$ROUTINE' CORRECTED BY THE APPROPRIATE
   NUMBER OF BYTES FOR THE INTERRUPT PLM PROLOGUE. THE SEGMENT FROM THE
   CURRENT CS REGISTER IS DETERMINED BY A MACHINE LANGUAGE CODED
   SUBROUTINE. */
          PROCEDURE(INT$VECTOR$PTR,INT$ROUTINE$OFFSET);
183 2          DECLARE INT$VECTOR$PTR POINTER, INT$ROUTINE$OFFSET WORD,
          VECTOR BASED INT$VECTOR$PTR STRUCTURE (OFF WORD, SEG WORD),
          CORRECTION LITERALLY '19H', /* OFFSET FOR PROLOGUE */
          INIT$INT$VECTOR$CODE(*) BYTE DATA
          (055H, /* PUSH BP */ /*
            08BH,0ECH, /* MOV BP,SP */ /*
            08CH,0C8H, /* MOV AX,CS */ /*
            0C4H,05EH,004H, /* LES BX,/BP/, .PARAM1 */ /*
            026H,089H,007H, /* MOV ES:W/BX/, AX */ /*
            05DH, /* POP BP */ /*
            0C2H,004H,000H), /* RET 4 */ /*
          INIT$INT$VECTOR$CODE$PTR WORD DATA (.INIT$INT$VECTOR$CODE);

184 2          CALL INIT$INT$VECTOR$CODE$PTR(@VECTOR.SEG); /* SEGMENT PORTION */
185 2          VECTOR.OFF = INT$ROUTINE$OFFSET - CORRECTION; /* OFFSET PORTION */
186 2          END;

```

```

/* *****
   *****

```

COMMAND MODULE  
=====

ABSTRACT

=====

THIS MODULE CONTAINS ALL THE COMMANDS IMPLEMENTED AS INDIVIDUAL PROCEDURES AND CALLED FROM THE OUTER BLOCK OF THE COMMAND DISPATCH LOOP.

MODULE ORGANIZATION

=====

THIS MODULE CONTAINS THE FOLLOWING SECTIONS:

1. COMMANDS SECTION

KB\$GO	GO
KB\$SINGLE\$STEP	SINGLE STEP
KB\$EXAM\$MEM	SUBSTITUTE MEMORY
KB\$EXAM\$REG	EXAMINE REGISTER
KB\$MOVE	MOVE
KB\$INPUT	INPUT PORT
KB\$OUTPUT	OUTPUT PORT

2. COMMAND DISPATCH (OUTER BLOCK, MAIN PROGRAM LOOP)

NEXT\$COMMAND	DISPATCH
ERROR	ERROR ROUTINE

\*/

/\*

\* COMMANDS SECTION \*

\*/

187 1

KB\$GO:

/\* IMPLEMENTS THE 'GO' COMMAND. DISPLAYS IP AND CURRENT INSTRUCTION BYTE AND OPENS CS:IP FOR INPUT AND ONE OPTIONAL BREAKPOINT. BEGINS EXECUTION WHEN A PERIOD IS DEPRESSED AND DISPLAYS 'E' IN THE ADDRESS FIELD. UPON ENCOUNTERING A BREAKPOINT, 'BR' IS DISPLAYED IN THE DATA FIELD. \*/

PROCEDURE;

```

188 2     CALL KB$UPDATE$IP;                /* OPTIONAL CHANGE CS:IP */
189 2     IF CHAR=KBCOM THEN
190 2         DO;                          /* BREAKPOINT */
191 3         CALL KB$BLANK$ADDR$FIELD(1);
192 3         CALL KB$BLANK$DATA$FIELD(0);
193 3         CALL KB$GET$CHAR;
194 3         CALL KB$GET$ADDR(@BRK1,CSIP.SEG,1);
195 3         IF CHAR<>KBPER THEN GOTO ERROR;
197 3         BRK1$SAVE = MEMORY$BRK1;
198 3         MEMORY$BRK1 = BREAK$INST;
199 3         IF MEMORY$BRK1<>BREAK$INST THEN GOTO ERROR;
201 3         BRK1$FLAG = TRUE;
202 3         END;
203 2     ELSE
206 2         IF CHAR<>KBPER THEN GOTO ERROR;
207 2         CALL KB$DISPLAY(@KB$EXEC,ADDR$FIELD,0);
208 2         CALL KB$BLANK$DATA$FIELD(0);
209 2         IP = CSIP.OFF;
210 2         CS = CSIP.SEG;
211 2         FL = FL AND (NOT STEP$TRAP);
212 1     CALL RESTORE$EXECUTE;
211 2     END;

```

212 1

KB\$SINGLE\$STEP:

```

                /* IMPLEMENTS THE SINGLE STEP COMMAND. DISPLAYS IP AND THE
                CURRENT INSTRUCTION WORD. OPENS CS:IP FOR INPUT. DEPRESSING
                COMMA CAUSES THE MONITOR TO SINGLE STEP THE INSTRUCTION,
                AND PERIOD TERMINATES THE COMMAND. */
213  2          PROCEDURE;
                CALL KB$update$IP;                    /* OPTIONAL CHANGE OF CS:IP */
214  2          IF CHAR<>KBCOM THEN GOTO ERROR;
216  2          IP = CSIP.OFF;
217  2          CS = CSIP.SEG;
218  2          FL = FL OR STEP$TRAP;                /* SET TRAP FLAG BIT IN PSW */
219  2          CALL RESTORE$EXECUTE;
220  2          END;

221  1          KB$EXAM$MEM:
                /* IMPLEMENTS THE EXAMINE MEMORY COMMAND. PROMPTS FOR AN
                ADDRESS AND THEN DISPLAYS THE BYTE OR WORD AT THAT LOCATION.
                IT THEN IS OPTIONALLY OPENED FOR INPUT. COMMA INCREMENTS TO
                THE NEXT LOCATION. PERIOD TERMINATES. */
                PROCEDURE;
222  2          DECLARE W WORD;
223  2          CALL KB$BLANK$ADDR$FIELD(1);            /* PROMPT FOR ADDRESS */
224  2          CALL KB$GET$CHAR;
225  2          CALL KB$GET$ADDR(@ARG1,CS,1);         /* GET ADDRESS */
226  2          IF CHAR<>KBCOM THEN GOTO ERROR;
228  2          DO WHILE TRUE;
229  3          CALL KB$OUT$WORD(ARG1.OFF,ADDR$FIELD,0,BLANK); /* CLEAR PROMPT */
230  3          IF WORD$MODE THEN
231  3          CALL KB$OUT$WORD(MEMORY$WORD$ARG1,DATA$FIELD,1,NOBLANK);
                ELSE
232  3          CALL KB$OUT$BYTE(MEMORY$ARG1,1);
233  3          CALL KB$GET$CHAR;
234  3          IF CHAR=KBPER THEN RETURN;
236  3          IF CHAR<>KBCOM THEN
237  3          IF WORD$MODE THEN
238  3          DO;
239  4          W = KB$GET$EXPR(DATA$FIELD,1,NOBLANK);
240  4          IF (CHAR<>KBCOM) AND (CHAR<>KBPER) THEN GOTO ERROR;
242  4          MEMORY$WORD$ARG1 = W;
243  4          IF MEMORY$WORD$ARG1<>W THEN GOTO ERROR;
245  4          END;
                ELSE
246  3          DO;
247  4          W = KB$GET$EXPR(DATA$BYTE,1,NOBLANK);
248  4          IF (CHAR<>KBCOM) AND (CHAR<>KBPER) THEN GOTO ERROR;
250  4          MEMORY$ARG1 = LOW(W);
251  4          IF MEMORY$ARG1<>LOW(W) THEN GOTO ERROR;
253  4          END;
                IF CHAR=KBPER THEN RETURN;
256  3          IF WORD$MODE THEN
257  3          ARG1.OFF = ARG1.OFF + 2;
                ELSE
258  3          ARG1.OFF = ARG1.OFF + 1;
259  3          END;
260  2          END;

261  1          KB$EXAM$REG:
                /* IMPLEMENTS THE EXAMINE REGISTER COMMAND. PROMPTS FOR A VALID

```



```

REGISTER KEY AND DISPLAYS THE VALUE OF THAT REGISTER WHICH IS
OPTIONALLY OPENED FOR INPUT. COMMA INCREMENTS TO NEXT REGISTER
UNLESS IT IS 'FL' WHICH TERMINATES AS DOES PERIOD. */
PROCEDURE;
262 2   DECLARE I BYTE, SAVE WORD;
263 2   CALL KB$BLANK$ADDR$FIELD(1);
264 2   CALL KB$GET$CHAR;
265 2   IF CHAR>ODH THEN GOTO ERROR;           /* INVALID REG KEY */
266 2   I = CHAR;
267 2   DO WHILE TRUE;
268 2       DISP(0),DISP(1) = 0;               /* DISPLAY REG NAME */
269 3       DISP(2) = KB$REG(I*2);
270 3       DISP(3) = KB$REG(I*2+1);
271 3       CALL KB$DISPLAY(@DISP,ADDR$FIELD,0);
272 3       CALL KB$OUT$WORD(REG$SAV(I),DATA$FIELD,1,NOBLANK); /* VALUE */
273 3       CALL KB$GET$CHAR;
274 3       IF CHAR<>KBCOM AND CHAR<>KBPER THEN
275 3           DO;
276 3               SAVE = KB$GET$EXPR(DATA$FIELD,1,NOBLANK); /* UPDATE */
277 4               IF CHAR<>KBCOM AND CHAR<>KBPER THEN GOTO ERROR;
278 4               REG$SAV(I) = SAVE;
280 4               END;
281 4               IF CHAR=KBPER OR I=13 THEN RETURN;           /* DONE? */
282 3               I = I + 1;
283 3           END;
284 3       END;
285 3   END;
286 2   END;

287 1   KB$MOVE:
      /* IMPLEMENTS THE MOVE COMMAND. PROMPTS FOR 3 ARGUMENTS AND MOVES
      THE BLOCK OF MEMORY SPECIFIED BY ARG1-ARG2 TO ARG3. IF THERE IS
      A DIFFERENCE WHEN READ BACK, THEN ERROR. */
      PROCEDURE;
288 2       CALL KB$BLANK$ADDR$FIELD(3);           /* FIRST ARGUMENT */
289 2       CALL KB$GET$CHAR;
290 2       CALL KB$GET$ADDR(@ARG1,CS,3);
291 2       IF CHAR<>KBCOM THEN GOTO ERROR;
292 2       CALL KB$BLANK$ADDR$FIELD(2);           /* SECOND ARGUMENT */
293 2       CALL KB$GET$CHAR;
294 2       END$OFF = KB$GET$EXPR(ADDR$FIELD,2,BLANK);
295 2       IF END$OFF<ARG1.OFF THEN GOTO ERROR;
296 2       IF CHAR<>KBCOM THEN GOTO ERROR;
297 2       CALL KB$BLANK$ADDR$FIELD(1);           /* THIRD ARGUMENT */
298 2       CALL KB$GET$CHAR;
299 2       CALL KB$GET$ADDR(@ARG3,ARG1.SEG,1);
300 2       IF CHAR<>KBPER THEN GOTO ERROR;
301 2   LOOP:
302 2       MEMORY$ARG3 = MEMORY$ARG1;
303 2       IF MEMORY$ARG3<>MEMORY$ARG1 THEN GOTO ERROR;
304 2       IF ARG1.OFF = END$OFF THEN RETURN;
305 2       ARG1.OFF = ARG1.OFF + 1;
306 2       ARG3.OFF = ARG3.OFF + 1;
307 2       GOTO LOOP;
308 2   END;

314 1   KB$INPUT:
      /* PROMPTS FOR A PORT WORD IN THE ADDRESS FIELD. WHEN A COMMA
      IS ENTERED THE BYTE OR WORD IS DISPLAYED IN THE DATA FIELD.

```

PL/M-86 COMPILER      SDK86 KEYPAD MONITOR

```

                THIS MAY BE REPEATED FOR MULTIPLE READING OF THE PORT. PERIOD
                TERMINATES THE COMMAND. */
PROCEDURE;
315  2      DECLARE PORT WORD;
316  2      CALL KB$BLANK$ADDR$FIELD(1);                /* PROMPT FOR PORT */
317  2      CALL KB$GET$CHAR;
318  2      PORT = KB$GET$EXPR(ADDR$FIELD,1,BLANK);    /* GET PORT NUMBER */
319  2      CALL KB$OUT$WORD(PORT,ADDR$FIELD,0,BLANK); /* REMOVE PROMPT */
320  2
LOOP:
322  2      IF CHAR<>KBCOM THEN GOTO ERROR;
323  2      IF WORD$MODE THEN
                CALL KB$OUT$WORD(INWORD(PORT),DATA$FIELD,0,NOBLANK);
                ELSE
324  2          CALL KB$OUT$BYTE(INPUT(PORT),0);
325  2          CALL KB$GET$CHAR;
326  2          IF CHAR=KBPER THEN RETURN;
328  2          GOTO LOOP;
329  2      END;
330  1      KB$OUTPUT:
                /* PROMPTS FOR A PORT WORD IN THE ADDRESS FIELD AND A BYTE OR
                WORD DATUM IN THE DATA FIELD. THIS DATUM IS OUTPUT A SINGLE TIME
                TO THE SPECIFIED PORT. */
PROCEDURE;
331  2      DECLARE (DATUM,PORT) WORD;
332  2      CALL KB$BLANK$ADDR$FIELD(1);                /* PROMPT FOR PORT */
333  2      CALL KB$GET$CHAR;
334  2      PORT = KB$GET$EXPR(ADDR$FIELD,1,BLANK);
335  2      IF CHAR<>KBCOM THEN GOTO ERROR;
337  2      CALL KB$OUT$WORD(PORT,ADDR$FIELD,0,BLANK); /* REMOVE PROMPT */
338  2      CALL KB$BLANK$DATA$FIELD(1);                /* PROMPT FOR DATUM */
339  2      CALL KB$GET$CHAR;
340  2
LOOP:
341  2      IF WORD$MODE THEN
                DATUM = KB$GET$EXPR(DATA$FIELD,1,NOBLANK); /* GET DATUM WORD */
                ELSE
342  2          DATUM = KB$GET$EXPR(DATA$BYTE,1,NOBLANK); /* GET DATUM BYTE */
343  2          IF CHAR=KBCOL THEN GOTO ERROR;
345  2          IF WORD$MODE THEN
                OUTWORD(PORT) = DATUM;
                ELSE
347  2          OUTPUT(PORT) = LOW{DATUM};
348  2          IF CHAR=KBCOM THEN                        /* MULTIPLE OUTPUTS */
349  2              DO;
350  3              CALL KB$BLANK$DATA$FIELD(1);
351  3              CALL KB$GET$CHAR;
352  3              IF CHAR<>KBPER THEN GOTO LOOP;
354  3              END;
355  2          END;
                END;

                /*****
                *   COMMAND DISPATCH MAIN PROGRAM LOOP   *
                *****/

356  1      DISABLE;
357  1      OUTPUT(KB$STAT$PORT) = KB$INIT$MODE;        /* INIT 8279 */

```

PL/M-86 COMPILER      SDK86 KEYPAD MONITOR

```

358 1      OUTPUT(KB$STAT$PORT) = KB$INIT$SCAN;
359 1      CALL KB$DISPLAY(@KB$SIGNON,ADDR$FIELD,0); /* SIGN ON MESSAGE */
360 1      CALL KB$DISPLAY(@KB$VERSION,DATA$FIELD,0); /* VERSION NUMBER */

          /* INITIALIZE USER'S REGISTERS */
361 1      CS,SS,DS,ES,FL,IP = 0;
362 1      SP = USER$INIT$SP;

363 1      CALL INIT$INT$VECTOR(@INT$VECTOR(1),.INTERRUPT1$ENTRY);
364 1      CALL INIT$INT$VECTOR(@INT$VECTOR(2),.INTERRUPT3$ENTRY);
365 1      CALL INIT$INT$VECTOR(@INT$VECTOR(3),.INTERRUPT3$ENTRY);
366 1      BRK1$FLAG = FALSE;
367 1      MONITOR$STACKBASE = STACKBASE; /* SAVE MONITOR STACK VALUES */
368 1      MONITOR$STACKPTR = STACKPTR;
369 1      GOTO AFTER$error;

370 1      NEXT$COMMAND:
          /* THIS IS THE PERPETUAL COMMAND LOOP WHICH DISPATCHES TO EACH
          COMMAND WHICH IS A SEPARATE PROCEDURE. */

          CALL KB$DISPLAY(@KB$CMND$PMT,ADDR$FIELD,0);
371 1      AFTER$error:
          CALL KB$GET$CHAR;
372 1      CALL KB$BLANK$ADDR$FIELD(0);
373 1      CALL KB$BLANK$DATA$FIELD(0);
374 1      IF (LAST$COMMAND:=CHAR)>09H THEN GOTO ERROR;
376 1      WORD$MODE = FALSE;
377 1      DO CASE CHAR;
378 2          CALL KB$EXAM$MEM;
379 2          CALL KB$EXAM$REG;
380 2          CALL KB$GO;
381 2          CALL KB$SINGLE$STEP;
382 2          CALL KB$INPUT;
383 2          CALL KB$OUTPUT;
384 2          CALL KB$MOVE;
385 2          DO; WORD$MODE = TRUE; CALL KB$EXAM$MEM; END;
389 2          DO; WORD$MODE = TRUE; CALL KB$INPUT; END;
393 2          DO; WORD$MODE = TRUE; CALL KB$OUTPUT; END;
397 2      END;

398 1      AFTER$COMMAND:
          CALL KB$BLANK$DATA$FIELD(0);
399 1      GOTO NEXT$COMMAND;

400 1      ERROR:
          /* THIS ROUTINE HANDLES ALL ERRORS DETECTED BY THE MONITOR AND WILL
          OUTPUT THE ERROR MESSAGE TO THE DISPLAY AND THEN JUMP TO
          'AFTER$error' TO GET ANOTHER COMMAND. */

          CALL KB$DISPLAY(@KB$ERR$MSG,ADDR$FIELD,0);
401 1      CALL KB$BLANK$DATA$FIELD(0);
402 1      GOTO AFTER$error;

403 1      AFTER$INTERRUPT:
          /* THIS ROUTINE CHECKS FOR THE LAST COMMAND WHEN THE MONITOR IS
          REENTERED VIA THE INTERRUPT VECTOR. */

```

```

      IF BRK1$FLAG THEN
404 1      DO;
405 2      MEMORY$BRK1 = BRK1$SAVE;
406 2      BRK1$FLAG = FALSE;
407 2      IF ((IP-1) AND 000FH)=(BRK1.OFF AND 000FH) AND
          (SHR(IP-1,4)+CS)=(SHR(BRK1.OFF,4)+BRK1.SEG) THEN
408 2      DO;
409 3      IP = IP - 1;
410 3      CALL KB$DISPLAY(@KB$BRK1,DATA$FIELD,0);
411 3      GOTO NEXT$COMMAND;
412 3      END;
413 2      END;
414 1      GOTO AFTER$COMMAND;

415 1      END MONITOR; /* END OF MODULE */
      EOF
```

## MODULE INFORMATION:

```

      CODE AREA SIZE      = 0B82H  2946D
      CONSTANT AREA SIZE = 0000H   0D
      VARIABLE AREA SIZE = 0065H  101D
      MAXIMUM STACK SIZE = 0050H   80D
      865 LINES READ
      0 PROGRAM ERROR(S)
```

END OF PL/M-86 COMPILATION



# SDK-86 KEYPAD MONITOR EXPANDED SOURCE LISTING

P /M-86 COMPILER SDK86 KEYPAD MONITOR

PAGE 1

ISIS-II PL/M-86 V1.0 COMPILATION OF MODULE MONITOR  
NO OBJECT MODULE REQUESTED  
COMPILER INVOKED BY: :F1:PLM86 :F1:KEYPAD.PLM LARGE OPTIMIZE(2) PAGESWIDTH(95) &  
CODE XREF NOOBJECT PRINT(:F1:KEYPAD.PRT)

\$TITLE('SDK86 KEYPAD MONITOR')  
\$NOINTVECTOR

/\* \*\*\*\*\*  
\*\*\*\*\*

SDK-86 KEYPAD MONITOR, V1.1  
30 JUNE 1978

(C) 1978 INTEL CORPORATION. ALL RIGHTS RESERVED. NO PART OF  
OF THIS PROGRAM OR PUBLICATION MAY BE REPRODUCED, TRANSMITTED,  
TRANSCRIBED, STORED IN A RETRIEVAL SYSTEM, OR TRANSLATED INTO ANY  
LANGUAGE, IN ANY FORM OR BY ANY MEANS, ELECTRONIC, MECHANICAL,  
MAGNETIC, OPTICAL, CHEMICAL, MANUAL OR OTHERWISE, WITHOUT THE PRIOR  
WRITTEN PERMISSION OF INTEL CORPORATION, 3065 BOWERS AVENUE, SANTA  
CLARA, CALIFORNIA, 95051.

\*\*\*\*\*  
\*\*\*\*\*

#### ABSTRACT

=====

THIS PROGRAM IS THE ROM BASED KEYPAD MONITOR FOR THE SDK-86.  
IT PROVIDES THE USER WITH A MODERATE LEVEL OF CAPABILITY TO  
EXAMINE/MODIFY MEMORY AND REGISTERS AND CONTROL PROGRAM EXECUTION.

#### ENVIRONMENT

=====

THE SDK KEYPAD MONITOR COMMUNICATES WITH THE USER VIA THE ONBOARD  
KEYBOARD AND 7 SEGMENT DISPLAY.

#### PROGRAM ORGANIZATION

=====

THE PROGRAM IS DIVIDED INTO 1 DATA AND 2 CODE MODULES:

1. DATA DECLARATION MODULE. GLOBAL DATA DECLARATIONS.
2. COMMON ROUTINES. LOWER LEVEL PROCEDURES
3. COMMAND MODULE. INDIVIDUAL COMMANDS AND OUTER BLOCK

#### CALLING GRAPH

=====

>>COMMAND DISPATCH MODULE (OUTER BLOCK)  
INDIVIDUAL COMMAND PROCEDURES  
COMMON ROUTINES

#### GLOBAL DATA STRUCTURES

=====

THE MONITOR MAINTAINS THE USER'S MACHINE STATE (REGISTERS) IN A  
WORD ARRAY. THE REGISTERS ARE SAVED FROM THE USER'S STACK  
AS PUSHED BY PLM86 INTERRUPT PROCEDURE.  
POINTERS TO THE SDK-86 2\*\*20 ADDRESS SPACE ARE IMPLEMENTED WITH

POINTER STRUCTURES ALLOCATED AS 2 WORD STRUCTURES.

```

*/
1  MONITOR:DO;                /* BEGINNING OF MODULE */

/* *****
*****

GLOBAL DATA DECLARATIONS MODULE
=====

ABSTRACT
=====
THIS MODULE CONTAINS ALL THE GLOBAL DATA DECLARATIONS AND
LITERALS (EQUATES).

MODULE ORGAINIZATION
=====
THE MODULE IS DIVIDED INTO 5 SECTIONS:
1. UTILITY SECTION          GLOBAL FLAGS,VARIABLES,EQUATES
2. I/O SECTION             I/O PORTS,MASKS,AND SPECIAL CHARS
3. MEMORY ARGUMENTS SECTIONS STRUCTURES FOR MEDIUM POINTERS
4. REGISTER SECTION        USER REGISTER SAVE AREA
5. BOOT AND 8089 SECTION   BOOTSTRAP AND 8089 DESCRIPTOR
*/

/* *****
*   UTILITY SECTION   *
*****/

2  1  DECLARE
      INT$VECTOR(5)    POINTER;          /* INTERRUPT VECTORS */
3  1  DECLARE
      MONITOR$STACKPTR WORD,
      MONITOR$STACKBASE WORD;          /* MONITOR SS SAVE */

4  1  DECLARE
      COPYRIGHT(*) BYTE DATA ('(C) 1978 INTEL CORP');
5  1  DECLARE
      BRK1$FLAG        BYTE,          /* TRUE IF BREAK SET */
      BRK1$SAVE        BYTE,          /* INST BREAK SAVE */
      CHAR             BYTE,          /* ONE CHAR LOOK AHEAD */
      DISP(4)         BYTE,          /* DISPLAY ARRAY */
      I               BYTE,
      END$OFF         WORD,          /* END OFFSET ADDRESS */
      WORD$MODE       BYTE,
      LAST$COMMAND    BYTE;

6  1  DECLARE
      TRUE            LITERALLY 'OFFH',
      FALSE           LITERALLY '000H',
      ADDR$FIELD      LITERALLY '1',          /* ADDR FIELD WORD OUTPUT */
      DATA$FIELD     LITERALLY '0',          /* DATA FIELD WORD OUTPUT */
      DATA$BYTE      LITERALLY '-1',        /* DATA FIELD BYTE OUTPUT */
      BLANK           LITERALLY '1',
      NOBLANK         LITERALLY '0',
      BREAK$INST      LITERALLY 'OCCH',      /* BREAKPOINT TRAP */
      STEP$TRAP       LITERALLY '0100H',    /* SS TRAP FLAG MASK */

```

```

USER$INIT$SP      LITERALLY '100H',      /* USER STACK INITIAL */
GO$COMMAND        LITERALLY '2',        /* GO COMMAND CODE */
SS$COMMAND        LITERALLY '3';
    
```

```

/*****
 * I/O DECLARATIONS SECTION *
 *****/
    
```

```

7 1 DECLARE
    KB$STAT$PORT  LITERALLY 'OFFEAH',      /* STATUS/COMMAND PORT */
    KB$DATA$PORT  LITERALLY 'OFFE8H',      /* DATA PORT */
    KB$INIT$MODE  LITERALLY '00H',        /* 8 8-BIT, LEFT ENTRY,
                                           ENCODE, 2 KEY LOCKOUT */
    KB$INIT$SCAN  LITERALLY '39H',        /* 10MS SCAN RATE */
    KB$INRDY      LITERALLY '07H',        /* IN CHAR RDY MASK */
    KB$CMND$PMT(*) BYTE DATA (40H,00H,00H,00H), /* '- ' */
    KB$SIGNON(*)  BYTE DATA (40H,00H,7FH,7DH), /* '- 86' */
    KB$VERSION(*) BYTE DATA (00H,00H,86H,06H), /* ' 1.1' */
    KB$REG$PMT(*) BYTE DATA (50H,00H,00H,00H), /* 'R ' */
    KB$ERR$MSG(*)  BYTE DATA (40H,79H,50H,50H), /* '-ERR' */
    KB$EXEC(*)     BYTE DATA (79H,00H,00H,00H), /* 'E ' */
    KB$BRK1(*)     BYTE DATA (7CH,50H,00H,00H), /* 'BR ' */
    KB$BLANKS(*)   BYTE DATA (00H,00H,00H,00H), /* ' ' */
    LED(*)         BYTE DATA
    (3FH,06H,5BH,4FH,66H,6DH,7DH,07H,      /* '0-'7' */
     7FH,6FH,77H,7CH,39H,5EH,79H,71H);    /* '8-'F' */
    
```

```

8 1 DECLARE
    KBPER          LITERALLY '10H',        /* PERIOD */
    KBKOM          LITERALLY '11H',        /* COMMA */
    KBREGKEY       LITERALLY '15H',        /* REGISTER KEY */
    KBCOL          LITERALLY '14H',        /* COLON (SEGMENT) */
    KBPLUS         LITERALLY '13H',        /* PLUS KEY */
    KBMINUS        LITERALLY '12H',        /* MINUS KEY */
    
```

```

/*****
 * POINTER SECTION *
 *****/
    
```

```

9 1 DECLARE
    MEMORY$ARG1$PTR POINTER,              /* ARGUMENT 1 */
    ARG1 STRUCTURE (OFF WORD, SEG WORD)
    AT (@MEMORY$ARG1$PTR),
    MEMORY$ARG1 BASED MEMORY$ARG1$PTR BYTE,
    MEMORY$WORD$ARG1 BASED MEMORY$ARG1$PTR WORD,

    MEMORY$ARG3$PTR POINTER,              /* ARGUMENT 3 */
    ARG3 STRUCTURE (OFF WORD, SEG WORD)
    AT (@MEMORY$ARG3$PTR),
    MEMORY$ARG3 BASED MEMORY$ARG3$PTR BYTE,

    MEMORY$BRK1$PTR POINTER,              /* BREAKPOINT */
    BRK1 STRUCTURE (OFF WORD, SEG WORD)
    AT (@MEMORY$BRK1$PTR),
    MEMORY$BRK1 BASED MEMORY$BRK1$PTR BYTE,

    MEMORY$CSIP$PTR POINTER,              /* CS:IP INSTRUCTION */
    CSIP STRUCTURE (OFF WORD, SEG WORD)
    
```

```

        AT (@MEMORY$CSIP$PTR),
        MEMORY$CSIP BASED MEMORY$CSIP$PTR BYTE,

        MEMORY$USERSTACK$PTR POINTER,          /* USER'S STACK */
        USERSTACK STRUCTURE (OFF WORD, SEG WORD)
        AT (@MEMORY$USERSTACK$PTR),
        MEMORY$USERSTACK BASED MEMORY$USERSTACK$PTR WORD;

```

```

/*****
*   REGISTER SECTION
*****/

```

```

10  1  DECLARE
        KB$REG(*)      BYTE DATA
        (00H,77H,00H,7CH,00H,39H,00H,5EH,      /* AXBXCXDX */
         6DH,73H,7CH,73H,6DH,30H,5EH,30H,      /* SPBPSIDI */
         39H,6DH,5EH,6DH,6DH,6DH,79H,6DH,      /* CSDSSSES */
         30H,73H,71H,38H),                      /* IPFL */
        REG$SAV(14)    WORD,                      /* USER'S SAVED REGS */
        REG$ORD(*)     BYTE DATA
        (7,6,1,3,2,0,9,11,12,8,13),             /* STACKED REG ORDER */
        SP             LITERALLY 'REG$SAV( 4)',
        BP             LITERALLY 'REG$SAV( 5)',
        CS             LITERALLY 'REG$SAV( 8)',
        DS             LITERALLY 'REG$SAV( 9)',
        SS             LITERALLY 'REG$SAV(10)',
        ES             LITERALLY 'REG$SAV(11)',
        IP             LITERALLY 'REG$SAV(12)',
        FL             LITERALLY 'REG$SAV(13)';

/*****
*   BOOTSTRAP JUMP AND 8089 VECTOR
*****/

/* THIS BOOT CONSISTS OF A LONG JUMP TO THE BEGINNING OF THE MONITOR
   AT FFO0+XXXX WHERE XXXX IS THE STARTING ADDRESS OFFSET (IP) AND
   MUST BE DETERMINED AFTER EACH COMPILE. */
11  1  DECLARE
        START$ADDR    LITERALLY '009CH',          /* STARTING ADDRESS */
        BOOT1(*)      BYTE AT (OFFF0H) DATA (0EAH), /* LONG JUMP OPCODE */
        BOOT2(*)      WORD AT (OFFF1H) DATA (START$ADDR),
        BOOT3(*)      WORD AT (OFFF3H) DATA (OFF00H); /* SEGMENT ADDRESS */

/* THIS TWO-WORD DATA IS A JUMP TO THE STARTING ADDRESS AND IS LOCATED
   AT THE FIRST LOCATION OF ROM (NO OTHER DATA OR CONSTANT DECLARATIONS
   MAY PRECEDE IT). THE JUMP IS ACTUALLY TO (START-ADDR)-4 SINCE THE
   INSTRUCTION IS A RELATIVE JUMP OF LENGTH 3. */
12  1  DECLARE
        BOOT4(*)      WORD DATA (0E990H,START$ADDR-4); /* NOP,JMP START-ADDR */

/* THIS BLOCK OF ROM AT FFFF6-FFFFA IS INITIALIZED FOR THE 8089
   DEVICE AND POINTS TO A BLOCK OF RAM AT LOCATION 100H. */
13  1  DECLARE
        BLOCK$8089    WORD      AT (OFFF6H) DATA (00001H),
        BLOCK$8089$PTR POINTER AT (OFFF8H) DATA (00100H);

```



/\* \*\*\*\*\*  
 \*\*\*\*\*

COMMON PROCEDURES  
 =====

ABSTRACT  
 =====  
 THIS MODULE CONTAINS THOSE LOWER LEVEL PROCEDURES CALLED BY HIGHER  
 LEVEL ROUTINES.

MODULE ORGANIZATION  
 =====  
 THIS MODULE CONTAINS THE FOLLOWING SECTIONS:

1. BASIC I/O SECTION
  - KB\$DISPLAY DISPLAY TO LED FIELDS
  - KB\$BLANK\$DATA\$FIELD BLANK DATA FIELD WITH PROMPTS
  - KB\$BLANK\$ADDR\$FIELD BLANK ADDRESS FIELD WITH PROMPTS
  - KB\$OUT\$BYTE OUTPUT A BYTE TO DISPLAY
  - KB\$OUT\$WORD OUTPUT A WORD TO DISPLAY
  - KB\$GET\$CHAR INPUT A CHAR FROM KEYPAD
2. ARGUMENT EXPRESSION EVALUATOR
  - KB\$GET\$EXPR GET WORD EXPRESSION
  - KB\$GET\$ADDR GET ADDRESS EXPRESSION
  - KB\$UPDATE\$IP GET OPTIONAL CS:IP
3. INTERRUPT AND RESTORE/EXECUTE ROUTINES
  - SAVE\$REGISTERS SAVES USERS REGISTERS
  - RESTORE\$EXECUTE RESTORE MACHINE STATE AND EXEC
  - INTERRUPT1\$ENTRY INTERRUPT FOR SINGLE STEP
  - INTERRUPT3\$ENTRY INTERRUPT ROUTINE FOR GO
  - INIT\$INT\$VECTOR INITIALIZES INTERRUPT VECTORS

\*/

/\* \*\*\*\*\*  
 \* BASIC I/O SECTION \*  
 \*\*\*\*\* \*/

```

14 1  KB$DISPLAY:
                                     ; STATEMENT # 14
/* THIS ROUTINE DISPLAYS THE CONTENTS OF THE ARRAY POINTED TO BY
   THE FIRST PARAM TO THE FIELD SPECIFIED BY THE SECOND (ADDR OR
   DATA). THE NUMBER OF DECIMAL POINTS OR PROMPTS IS DETERMINED
   BY THE THIRD PARAMETER */
      KBDISPLAY PROC NEAR
0251 55          PUSH BP
0252 8BEC        MOV BP,SP
      PROCEDURE (PTR,FIELD,PROMPTS);
15 2          DECLARE PTR POINTER, (FIELD,PROMPTS,T) BYTE,
              DISPLAY BASED PTR (1) BYTE;
16 2          IF FIELD=ADDR$FIELD THEN
                                     ; STATEMENT # 16
0254 807E0601   CMP [BP].FIELD,1H
0258 7507       JNZ @1
17 2          OUTPUT(KB$STAT$PORT) = 94H; /* ADDRESS FIELD */
                                     ; STATEMENT # 17
025A BAEAFF     MOV DX,OFFEAH
  
```

```

025D B094          MOV     AL,94H
025F EB05          JMP     @103
                @1:
ELSE
18  2              OUTPUT(KB$STAT$PORT) = 90H;          /* DATA FIELD */
                ; STATEMENT # 18
0261 BAEAFF        MOV     DX,OFFEAH
0264 B090          MOV     AL,90H
                @103:
19  2              OUT     DX
                DO I=0 TO 3;
                ; STATEMENT # 19
0267 C6065F0000    MOV     I,0H
                @82:
026C 803E5F0003    CMP     I,3H
0271 7730          JA      @83
20  3              T = DISPLAY(3-I);          /* DISPLAY BACKWARDS! */
                ; STATEMENT # 20
0273 B003          MOV     AL,3H
0275 2A065F00      SUB     AL,I
0279 B400          MOV     AH,0H
027B 89C6          MOV     SI,AX
027D C45E08        LES     BX,[BP].PTR
0280 268A08        MOV     CL,ES:[BX].DISPLAY[SI]
0283 880E6200      MOV     T,CL
21  3              IF PROMPTS>I THEN T = T OR 80H;
                ; STATEMENT # 21
0287 8A4604        MOV     AL,[BP].PROMPTS
028A 3A065F00      CMP     AL,I
028E 7605          JBE     @3
                ; STATEMENT # 22
0290 800E620080    OR      T,80H
                @3:
23  3              OUTPUT(KB$DATA$PORT) = T;
                ; STATEMENT # 23
0295 BAE8FF        MOV     DX,OFFE8H
0298 A06200        MOV     AL,T
029B EE           OUT     DX
24  3              END;
                ; STATEMENT # 24
029C 80065F0001    ADD     I,1H
02A1 75C9          JNZ     @82
                @83:
25  2              END;
                ; STATEMENT # 25
02A3 5D           POP     BP
02A4 C20800        RET     8H
                KBDISPLAY ENDP
26  1              KB$BLANK$DATA$FIELD:
                ; STATEMENT # 26
                /* THIS ROUTINE BLANKS THE DATA FIELD OF THE DISPLAY WITH THE
                NUMBER OF PROMPTS (DECIMAL POINTS) AS SPECIFIED BY THE PARAMETER. */
                KBBLANKDATAFIELD PROC NEAR
02A7 55           PUSH    BP
02A8 8BEC        MOV     BP,SP
                PROCEDURE(PROMPTS);

```

```

27 2          DECLARE PROMPTS BYTE;
28 2          CALL KB$DISPLAY(@KB$BLANKS,DATA$FIELD,PROMPTS);
                ; STATEMENT # 28
02AA 2E8D063700    LEA    AX,CS:KBBLANKS
02AF 0E            PUSH   CS    ; 1
02B0 50            PUSH   AX    ; 2
02B1 B000          MOV    AL,0H
02B3 50            PUSH   AX    ; 3
02B4 FF7604        PUSH  [BP].PROMPTS; 4
02B7 E897FF        CALL  KBDISPLAY
29 2          END;
                ; STATEMENT # 29
02BA 5D            POP    BP
02BB C20200        RET    2H
                KBLANKDATAFIELD    ENDP

30 1          KB$BLANK$ADDR$FIELD:
                ; STATEMENT # 30
                /* THIS PROCEDURE BLANKS THE ADDRESS FIELD OF THE DISPALY WITH THE
                NUMBER OF PROMPTS SPECIFIED BY THE PARAMETER 'PROMPTS'. */
                KBLANKADDRFIELD    PROC NEAR
02BE 55            PUSH   BP
02BF 8BEC          MOV    BP,SP
                PROCEDURE(PROMPTS);
31 2          DECLARE PROMPTS BYTE;
32 2          CALL KB$DISPLAY(@KB$BLANKS,ADDR$FIELD,PROMPTS);
                ; STATEMENT # 32
02C1 2E8D063700    LEA    AX,CS:KBBLANKS
02C6 0E            PUSH   CS    ; 1
02C7 50            PUSH   AX    ; 2
02C8 B001          MOV    AL,1H
02CA 50            PUSH   AX    ; 3
02CB FF7604        PUSH  [BP].PROMPTS; 4
02CE E880FF        CALL  KBDISPLAY
33 2          END;
                ; STATEMENT # 33
02D1 5D            POP    BP
02D2 C20200        RET    2H
                KBLANKADDRFIELD    ENDP

34 1          KB$OUT$BYTE:
                ; STATEMENT # 34
                /* THIS ROUTINE OUTPUTS THE BYTE INPUT FROM THE FIRST PARAMETER
                TO THE DATA FIELD WITH THE NUMBER OF PROMPTS SPECIFIED BY THE
                SECOND PARAMETER. */
                KBOUTBYTE    PROC NEAR
02D5 55            PUSH   BP
02D6 8BEC          MOV    BP,SP
                PROCEDURE(B,PROMPTS);
35 2          DECLARE (B,PROMPTS) BYTE;
36 2          DISP(0),DISP(1) = 0;
                /* FIRST TWO BLANK */
                ; STATEMENT # 36
02D8 B000          MOV    AL,0H
02DA A25B00        MOV    DISP,AL
02DD A25C00        MOV    DISP+1H,AL
37 2          DISP(2) = LED(SHR(B,4) AND 0FH);
                ; STATEMENT # 37

```

```

02E0 8A5E06      MOV     BL,[BP].B
02E3 B104         MOV     CL,4H
02E5 D2EB       SHR     BL,CL
02E7 80E30F     AND     BL,OFH
02EA B700         MOV     BH,0H
02EC 2E8A4F3B   MOV     CL,CS:LED[BX]
02F0 880E5D00   MOV     DISP+2H,CL
38 2          DISP(3) = LED(B AND OFH);
                                ; STATEMENT # 38
02F4 8A5E06      MOV     BL,[BP].B
02F7 80E30F     AND     BL,OFH
02FA B700         MOV     BH,0H
02FC 2E8A4F3B   MOV     CL,CS:LED[BX]
0300 880E5E00   MOV     DISP+3H,CL
39 2          CALL KB$DISPLAY(@DISP,DATA$FIELD,PROMPTS);
                                ; STATEMENT # 39
0304 8D0E5B00   LEA    CX,DISP
0308 1E          PUSH   DS      ; 1
0309 51          PUSH   CX      ; 2
030A 50          PUSH   AX      ; 3
030B FF7604     PUSH   [BP].PROMPTS; 4
030E E840FF     CALL   KBDISPLAY
40 2          END;
                                ; STATEMENT # 40
0311 5D          POP    BP
0312 C20400     RET     4H
                                KBOUByte      ENDP
41 1          KB$OUT$WORD:
                                ; STATEMENT # 41
                                /* THIS ROUTINE OUTPUTS THE FIRST PARM TO THE FIELD SPECIFIED
                                BY THE SECOND WITH THE NUMBER OF PROMPTS SPECIFIED BY THE THIRD.
                                LEADING ZERO BLANKING IS PERFORMED IF SPECIFIED BY THE FOURTH
                                PARAMETER. */
                                KBOUTWORD      PROC NEAR
0315 55          PUSH   BP
0316 8BEC       MOV     BP,SP
                                PROCEDURE(W,FIELD,PROMPTS,BLANKING);
42 2          DECLARE W WORD, (FIELD,PROMPTS,BLANKING) BYTE;
43 2          DO I=0 TO 3;
                                ; STATEMENT # 43
0318 C6065F0000   MOV     I,0H
                                @84:
031D 803E5F0003   CMP     I,3H
0322 7729       JA     @85
44 3          DISP(I) = LED(SHR(W,{3-I}*4) AND 000FH);
                                ; STATEMENT # 44
0324 B003         MOV     AL,3H
0326 2A065F00   SUB     AL,I
032A B104         MOV     CL,4H
032C F6E1         MUL     CL
032E 89C1         MOV     CX,AX
0330 8B5E0A     MOV     BX,[BP].W
0333 D3EB       SHR     BX,CL
0335 81E30F00   AND     BX,OFH
0339 2E8A473B   MOV     AL,CS:LED[BX]
033D 8A1E5F00   MOV     BL,I

```

```

0341 B700      MOV     BH,0H
0343 88475B    MOV     DISP[BX],AL
45  3          END;
                                ; STATEMENT # 45
0346 80065F0001 ADD     I,1H
034B 75D0      JNZ     @84
                                ; STATEMENT # 46
46  2          @85:
                IF BLANKING=BLANK THEN /* BLANK LEADING 0'S */
                                ; STATEMENT # 46
034D 807E0401  CMP     [BP].BLANKING,1H
0351 7535      JNZ     @4
47  2          DO;
48  3          I = 0;
                                ; STATEMENT # 48
0353 C6065F0000 MOV     I,0H
49  3          DO WHILE DISP(I)=3FH AND I<3;
                                ; STATEMENT # 49
                @86:
0358 8A1E5F00  MOV     BL,I
035C B700      MOV     BH,0H
035E 807F5B3F  CMP     DISP[BX],3FH
0362 B0FF      MOV     AL,OFFH
0364 7401      JZ      $+3H
0366 40        INC     AX
0367 50        PUSH    AX ; 1
0368 80FB03    CMP     BL,3H
036B B0FF      MOV     AL,OFFH
036D 7201      JB      $+3H
036F 40        INC     AX
0370 59        POP     CX ; 1
0371 22C1     AND     AL,CL
0373 D0D8     RCR     AL,1
0375 7311     JNB     @4
50  4          DISP(I) = 0;
                                ; STATEMENT # 50
0377 8A1E5F00  MOV     BL,I
037B B700      MOV     BH,0H
037D C6475B00  MOV     DISP[BX],0H
51  4          I = I + 1;
                                ; STATEMENT # 51
0381 80065F0001 ADD     I,1H
52  4          END;
                                ; STATEMENT # 52
0386 EBD0      JMP     @86
53  3          END;
54  2          @4:
                CALL KB$DISPLAY(@DISP, FIELD, PROMPTS);
                                ; STATEMENT # 54
0388 8D065B00  LEA     AX,DISP
038C 1E        PUSH    DS ; 1
038D 50        PUSH    AX ; 2
038E FF7608    PUSH    [BP].FIELD; 3
0391 FF7606    PUSH    [BP].PROMPTS; 4
0394 E8BAFE    CALL    KBDISPLAY
55  2          END;
                                ; STATEMENT # 55
0397 5D        POP     BP

```

```

0398 C20800          RET      8H
          KBOUTWORD      ENDP

56  1      KB$GET$CHAR:
          ; STATEMENT # 56
          /* READS ONE CHARACTER FROM THE FIFO OF THE 8279. WAITS UNTIL
          CHARACTER IS AVAILABLE AND THEN RETURNS THE CHARACTER IN GLOBAL
          VARIABLE 'CHAR'. */
          KBGETCHAR      PROC NEAR
039B 55             PUSH     BP
039C 8BEC           MOV      BP,SP
          PROCEDURE;
57  2      DO WHILE (INPUT(KB$STAT$PORT) AND KB$INRDY)=0; END;
          ; STATEMENT # 57
          @88:
039E BAEAFF         MOV      DX,OFFEAH
03A1 EC             IN        DX
03A2 A807           TEST     AL,7H
03A4 74F8           JZ       @88
59  2      OUTPUT(KB$STAT$PORT) = 040H;          /* ENABLE INPUT DATA */
          ; STATEMENT # 59
03A6 BAEAFF         MOV      DX,OFFEAH
03A9 B040           MOV      AL,40H
03AB EE             OUT      DX
60  2      CHAR = INPUT(KB$DATA$PORT);          /* READ CHARACTER */
          ; STATEMENT # 60
03AC BAE8FF         MOV      DX,OFFE8H
03AF EC             IN        DX
03B0 A25A00         MOV      CHAR,AL
61  2      END;
          ; STATEMENT # 61
03B3 5D             POP      BP
03B4 C3             RET
          KBGETCHAR      ENDP

```

```

/*****
* ARGUMENT EXPRESSION EVALUATOR SECTION
*****/

```

```

62  1      KB$GET$EXPR:
          ; STATEMENT # 62
          /* THIS ROUTINE GATHERS CHARACTERS FROM THE INPUT STREAM
          AND FORMS A WORD EXPRESSION WHICH IS RETURNED AS THE VALUE
          OF THE PROCEDURE. THE CHARACTERS INPUT ARE ECHOED TO THE
          ADDRESS OR DATA FIELD AS SPECIFIED BY THE FIRST PARAMETER.
          IF THE FIRST PARM IS 0 (ADDR) OR 1 (DATA) THEN THE EXPRESSION IS
          OUTPUT AS A WORD AND IF -1 (DATA$BYTE) THEN AS A BYTE ALWAYS IN
          DATA FIELD. THE NUMBER OF PROMPTS BY THE SECOND PARM, AND LEADING
          ZERO BLANKING BY THE THIRD. EXPRESSION ARE TERMINATED WITH
          A COMMA, PERIOD OR COLON. 'CHAR' WILL CONTAIN ONE OF THESE
          ON EXIT. */
          KBGETEXPR      PROC NEAR
03B5 55             PUSH     BP
03B6 8BEC           MOV      BP,SP
          PROCEDURE (FIELD,PROMPTS,BLANKING) WORD;
63  2      DECLARE (FIELD,PROMPTS,BLANKING) BYTE,

```

```

        (SAVE,W) WORD, OPER BYTE;
64  2      OPER = KBPLUS;
        ; STATEMENT # 64
        03B8 C606630013      MOV      OPER,13H
65  2      W = 0;
        ; STATEMENT # 65
        03BD C7064C000000    MOV      W,0H
66  2      DO WHILE TRUE;
        ; STATEMENT # 66
        @90:
67  3      IF CHAR=KBREGKEY THEN
        ; STATEMENT # 67
        03C3 803E5A0015      CMP      CHAR,15H
        03C8 7560              JNZ      @5
68  3      DO;
        ; STATEMENT # 69
69  4      CALL KB$DISPLAY(@KB$REG$PMT,FIELD,PROMPTS);
        ; STATEMENT # 69
        03CA 2E8D062700      LEA      AX,CS:KBREGPMT
        03CF 0E              PUSH     CS      ; 1
        03D0 50              PUSH     AX      ; 2
        03D1 FF7608          PUSH     [BP].FIELD; 3
        03D4 FF7606          PUSH     [BP].PROMPTS; 4
        03D7 E877FE          CALL     KBDISPLAY
70  4      CALL KB$GET$CHAR;
        ; STATEMENT # 70
        03DA E8BEFF          CALL     KBGETCHAR
71  4      IF CHAR>0DH THEN GOTO ERROR;
        ; STATEMENT # 71
        03DD 803E5A000D      CMP      CHAR,0DH
        03E2 7603              JBE      $+5H
        03E4 E9D5FD          JMP      ERROR
73  4      SAVE = REG$SAV(CHAR);
        ; STATEMENT # 73
        03E7 8A1E5A00          MOV      BL,CHAR
        03EB B700              MOV      BH,0H
        03ED D1E3              SHL     BX,1
        03EF 8B472E          MOV      AX,REGSAV[BX]
        03F2 A34A00          MOV      SAVE,AX
74  4      IF FIELD=DATA$BYTE THEN
        ; STATEMENT # 74
        03F5 807E08FF          CMP      [BP].FIELD,OFFH
        03F9 750C              JNZ      @7
75  4      CALL KB$OUT$BYTE(LOW(SAVE),PROMPTS);
        ; STATEMENT # 75
        03FB A14A00          MOV      AX,SAVE
        03FE 50              PUSH     AX      ; 1
        03FF FF7606          PUSH     [BP].PROMPTS; 2
        0402 E8D0FE          CALL     KBOUTBYTE
        0405 EB10              JMP      @8
        @7:
        ELSE
76  4      CALL KB$OUT$WORD(SAVE,FIELD,PROMPTS,BLANKING);
        ; STATEMENT # 76
        0407 FF364A00          PUSH     SAVE      ; 1
        040B FF7608          PUSH     [BP].FIELD; 2
        040E FF7606          PUSH     [BP].PROMPTS; 3
        0411 FF7604          PUSH     [BP].BLANKING; 4

```

```

0414 E8FEFE          CALL    KBOUTWORD
77  4                @8:
                    CALL KB$GET$CHAR;
                                ; STATEMENT # 77
0417 E881FF          CALL    KBGETCHAR
78  4                END;
                                ; STATEMENT # 78

                    @6:
041A 803E630013      CMP     OPER,13H
041F 7559             JNZ    @13
0421 A14A00           MOV     AX,SAVE
0424 01064C00        ADD     W,AX
0428 EB57             JMP     @14

                    @5:
ELSE
80  4                DO;
                                /* NUMBER */
                                /* INVALID DIGIT */
                                ; STATEMENT # 80
042A 803E5A000F      CMP     CHAR,OFH
042F 7603             JBE     $+5H
0431 E988FD           JMP     ERROR
82  4                SAVE = 0;
                                ; STATEMENT # 82
0434 C7064A000000    MOV     SAVE,0H
83  4                DO WHILE CHAR<=OFH;
                                ; STATEMENT # 83

                    @92:
043A 803E5A000F      CMP     CHAR,OFH
043F 77D9             JA     @6
84  5                SAVE = SHL(SAVE,4) + DOUBLE(CHAR);
                                ; STATEMENT # 84
0441 A14A00           MOV     AX,SAVE
0444 B104             MOV     CL,4H
0446 D3E0             SHL    AX,CL
0448 8A0E5A00        MOV     CL,CHAR
044C B500             MOV     CH,0H
044E 03C1             ADD     AX,CX
0450 A34A00           MOV     SAVE,AX
85  5                IF FIELD=DATA$BYTE THEN
                                ; STATEMENT # 85
0453 807E08FF        CMP     [BP].FIELD,OFFH
0457 750C             JNZ    @11
86  5                CALL KB$OUT$BYTE(LOW(SAVE),PROMPTS);
                                ; STATEMENT # 86
0459 A14A00           MOV     AX,SAVE
045C 50               PUSH   AX ; 1
045D FF7606           PUSH   [BP].PROMPTS; 2
0460 E872FE          CALL   KBOUTBYTE
0463 EB10             JMP     @12

                    @11:
ELSE
87  5                CALL KB$OUT$WORD(SAVE,FIELD,PROMPTS,BLANKING);
                                ; STATEMENT # 87
0465 FF364A00        PUSH   SAVE ; 1
0469 FF7608          PUSH   [BP].FIELD; 2
046C FF7606          PUSH   [BP].PROMPTS; 3
046F FF7604          PUSH   [BP].BLANKING; 4

```



```

0472 E8A0FE          CALL    KBOUTWORD
88  5              @12:
                CALL KB$GET$CHAR;
                ; STATEMENT # 88
0475 E823FF          CALL    KBGETCHAR
89  5              END;
                ; STATEMENT # 89
0478 EBC0           JMP     @92
90  4              END;
91  3              IF OPER=KBPLUS THEN          /* EVAL PREV OPER */
92  3              W = W + SAVE;
                ; STATEMENT # 92
                @13:
                ELSE
93  3              W = W - SAVE;
                ; STATEMENT # 93
047A A14A00          MOV     AX,SAVE
047D 29064C00        SUB     W,AX
                @14:
94  3              IF FIELD=DATA$BYTE THEN
                ; STATEMENT # 94
0481 807E08FF        CMP     [BP].FIELD,OFFH
0485 750C            JNZ     @15
95  3              CALL KB$OUT$BYTE(LOW(W),PROMPTS);
                ; STATEMENT # 95
0487 A14C00          MOV     AX,W
048A 50              PUSH    AX          ; 1
048B FF7606          PUSH    [BP].PROMPTS; 2
048E E844FE          CALL    KBOUTBYTE
0491 EB10            JMP     @16
                @15:
96  3              ELSE
                CALL KB$OUT$WORD(W,FIELD,PROMPTS,BLANKING);
                ; STATEMENT # 96
0493 FF364C00        PUSH    W          ; 1
0497 FF7608          PUSH    [BP].FIELD; 2
049A FF7606          PUSH    [BP].PROMPTS; 3
049D FF7604          PUSH    [BP].BLANKING; 4
04A0 E872FE          CALL    KBOUTWORD
                @16:
97  3              IF CHAR=KBCOM OR CHAR=KBPER OR CHAR=KBCOL THEN
                ; STATEMENT # 97
04A3 A05A00          MOV     AL,CHAR
04A6 3C11            CMP     AL,11H
04A8 B0FF            MOV     AL,OFFH
04AA 7401            JZ     $+3H
04AC 40              INC     AX
04AD 50              PUSH    AX          ; 1
04AE 803E5A0010      CMP     CHAR,10H
04B3 B0FF            MOV     AL,OFFH
04B5 7401            JZ     $+3H
04B7 40              INC     AX
04B8 59              POP     CX          ; 1
04B9 0AC1            OR     AL,CL
04BB 50              PUSH    AX          ; 1
04BC 803E5A0014      CMP     CHAR,14H
04C1 B0FF            MOV     AL,OFFH

```

```

04C3 7401          JZ      $+3H
04C5 40           INC     AX
04C6 59           POP     CX      ; 1
04C7 0AC1         OR      AL,CL
04C9 D0D8         RCR     AL,1
04CB 7305         JNB     @17
98 3              RETURN W;
                                ; STATEMENT # 98
04CD A14C00        MOV     AX,W
04D0 EB2B         JMP     @2
                                @17:
99 3              IF CHAR=KBPLUS OR CHAR=KBMINUS THEN
                                ; STATEMENT # 99
04D2 803E5A0013   CMP     CHAR,13H
04D7 B0FF         MOV     AL,OFFH
04D9 7401          JZ      $+3H
04DB 40           INC     AX
04DC 50           PUSH    AX      ; 1
04DD 803E5A0012   CMP     CHAR,12H
04E2 B0FF         MOV     AL,OFFH
04E4 7401          JZ      $+3H
04E6 40           INC     AX
04E7 59           POP     CX      ; 1
04E8 0AC1         OR      AL,CL
04EA D0D8         RCR     AL,1
04EC 7203         JB      $+5H
04EE E9CBFC        JMP     ERROR
100 3             OPER = CHAR;
                                ; STATEMENT # 100
04F1 A05A00        MOV     AL,CHAR
04F4 A26300        MOV     OPER,AL
                                ELSE
101 3             GOTO ERROR;
102 3             CALL KB$GET$CHAR;
                                /* GET NEXT CHAR */
                                ; STATEMENT # 102
04F7 E8A1FE        CALL    KBGETCHAR
103 3             END;
                                ; STATEMENT # 103
04FA E9C6FE        JMP     @90
104 2             END;
                                ; STATEMENT # 104
                                @2:
04FD 5D           POP     BP
04FE C20600        RET     6H
                                KBGETEXPR      ENDP
105 1             KB$GET$ADDR:
                                ; STATEMENT # 105
/* THIS ROUTINE GATHERS CHARACTERS FROM THE INPUT STREAM AND
FORMS AN ADDRESS EXPRESSION OF SEGMENT PART AND OFFSET PART.
THE FIRST CHARACTER HAS ALREADY BEEN READ INTO GLOBAL 'CHAR'.
IF NO SEGMENT IS ENTERED, THE SECOMD PARM DEFAULT IS USED, THE
ADDRESS EXPRESSION IS DISPLAYED IN THE ADDRESS FIELD WITH THE
NUMBER OF PROMPTS SPECIFIED BY THE THIRD PARM. */
                                KBGETADDR      PROC NEAR
0501 55          PUSH    BP

```

```

0502 8BEC          MOV     BP,SP
PROCEDURE(PTR,DEFAULT$BASE,PROMPTS);
106  2            DECLARE PTR POINTER, DEFAULT$BASE WORD, PROMPTS BYTE,
ARG BASED PTR STRUCTURE (OFF WORD, SEG WORD);
107  2            ARG.SEG = DEFAULT$BASE;
; STATEMENT # 107
0504 8B4606        MOV     AX,[BP].DEFAULTBASE
0507 C45E08        LES     BX,[BP].PTR
050A 26894702      MOV     ES:ARG[BX+2H],AX
108  2            ARG.OFF = KB$GET$EXPR(ADDR$FIELD,PROMPTS,BLANK);
; STATEMENT # 108
050E B001          MOV     AL,1H
0510 50            PUSH    AX ; 1
0511 FF7604        PUSH    [BP].PROMPTS; 2
0514 50            PUSH    AX ; 3
0515 E89DFE        CALL   KBGETEXPR
0518 C45E08        LES     BX,[BP].PTR
051B 268907        MOV     ES:ARG[BX],AX
109  2            IF CHAR=KBCOL THEN /* SEGMENT SPEC'D */
; STATEMENT # 109
051E 803E5A0014    CMP     CHAR,14H
0523 7527          JNZ     @20
110  2            DO;
111  3            CALL   KB$GET$CHAR;
; STATEMENT # 111
0525 E873FE        CALL   KBGETCHAR
112  3            ARG.SEG = ARG.OFF;
; STATEMENT # 112
0528 C45E08        LES     BX,[BP].PTR
052B 268B07        MOV     AX,ES:ARG[BX]
052E 26894702      MOV     ES:ARG[BX+2H],AX
113  3            ARG.OFF = KB$GET$EXPR(ADDR$FIELD,PROMPTS,BLANK);
; STATEMENT # 113
0532 B001          MOV     AL,1H
0534 50            PUSH    AX ; 1
0535 FF7604        PUSH    [BP].PROMPTS; 2
0538 50            PUSH    AX ; 3
0539 E879FE        CALL   KBGETEXPR
053C C45E08        LES     BX,[BP].PTR
053F 268907        MOV     ES:ARG[BX],AX
114  3            IF CHAR=KBCOL THEN GOTO ERROR;
; STATEMENT # 114
0542 803E5A0014    CMP     CHAR,14H
0547 7503          JNZ     $+5H
0549 E970FC        JMP     ERROR
; STATEMENT # 115
116  3            END;
@20:
117  2            END;
; STATEMENT # 117
054C 5D            POP     BP
054D C20800        RET     8H
KBGETADDR        ENDP
118  1            KB$UPDATE$IP:
; STATEMENT # 118
/* THIS ROUTINE IS CALLED BY SINGLE STEP AND GO TO OUTPUT THE CURRENT

```

CS:IP AND THE CURRENT INSTRUCTION BYTE. CS:IP IS OPENED FOR  
 OPTIONAL INPUT. \*/

```

        KBUPDATEIP      PROC NEAR
0550 55          PUSH    BP
0551 8BEC        MOV     BP,SP
        PROCEDURE;
119  2          CALL    KB$OUT$WORD(IP,ADDR$FIELD,1,BLANK); /* DISPLAY IP */
                                ; STATEMENT # 119
0553 FF364600    PUSH    REGSAV+18H; 1
0557 B001        MOV     AL,1H
0559 50          PUSH    AX ; 2
055A 50          PUSH    AX ; 3
055B 50          PUSH    AX ; 4
055C E8B6FD      CALL    KBOUTWORD
120  2          CSIP.OFF = IP;
                                ; STATEMENT # 120
055F A14600      MOV     AX,REGSAV+18H
0562 A32600      MOV     CSIP,AX
121  2          CSIP.SEG = CS;
                                ; STATEMENT # 121
0565 A13E00      MOV     AX,REGSAV+10H
0568 A32800      MOV     CSIP+2H,AX
122  2          CALL    KB$OUT$BYTE(MEMORY$CSIP,0);
                                ; STATEMENT # 122
056B C41E2600    LES     BX,MEMORYCSIPPTR
056F 26FF37      PUSH   ES:MEMORYCSIP[BX]
0572 B000        MOV     AL,0H
0574 50          PUSH    AX ; 2
0575 E85DFD      CALL    KBOUTBYTE
123  2          CALL    KB$GET$CHAR;
                                ; STATEMENT # 123
0578 E820FE      CALL    KBGETCHAR
124  2          IF CHAR<>KBCOM AND CHAR<>KBPER THEN
                                ; STATEMENT # 124
057B 803E5A0011 CMP    CHAR,11H
0580 B0FF        MOV     AL,OFFH
0582 7501      JNZ    $+3H
0584 40          INC     AX
0585 50          PUSH    AX ; 1
0586 803E5A0010 CMP    CHAR,10H
058B B0FF        MOV     AL,OFFH
058D 7501      JNZ    $+3H
058F 40          INC     AX
0590 59          POP     CX ; 1
0591 22C1      AND    AL,CL
0593 D0D8      RCR    AL,1
0595 731C      JNB    @22
125  2          DO; /* CHANGE CS:IP */
126  3          CALL    KB$BLANK$ADDR$FIELD(1);
                                ; STATEMENT # 126
0597 B001        MOV     AL,1H
0599 50          PUSH    AX ; 1
059A E821FD      CALL    KBBLANKADDRFIELD
127  3          CALL    KB$BLANK$DATA$FIELD(0);
                                ; STATEMENT # 127
059D B000        MOV     AL,0H
059F 50          PUSH    AX ; 1
    
```

```

128 3 05A0 E804FD CALL KBBLANKDATAFIELD
      CALL KB$GET$ADDR(@CSIP,CS,1);
      ; STATEMENT # 128
05A3 8D062600 LEA AX,CSIP
05A7 1E PUSH DS ; 1
05A8 50 PUSH AX ; 2
05A9 FF363E00 PUSH REGSAV+10H; 3
05AD B001 MOV AL,1H
05AF 50 PUSH AX ; 4
05B0 E84EFF CALL KBGETADDR
129 3 END;
      @22:
130 2 END;
      ; STATEMENT # 130
05B3 5D POP BP
05B4 C3 RET
      KBUPDATEIP ENDP

/*****
* INTERRUPT AND RESTORE/EXECUTE SECTION *
*****/

131 1 SAVE$REGISTERS:
      ; STATEMENT # 131
      /* THIS ROUTINE IS USED TO SAVE THE STACKED USER'S REGISTERS IN THE
      MONITOR'S SAVE AREA. */
      SAVEREGISTERS PROC NEAR
05B5 55 PUSH BP
05B6 8BEC MOV BP,SP
      PROCEDURE;
132 2 BP = MEMORY$USERSTACK;
      ; STATEMENT # 132
05B8 C41E2A00 LES BX,MEMORYUSERSTACKPTR
05BC 268B07 MOV AX,ES:MEMORYUSERSTACK[BX]
05BF A33800 MOV REGSAV+0AH,AX
133 2 USERSTACK.OFF = USERSTACK.OFF + 4;
      ; STATEMENT # 133
05C2 83062A0004 ADD USERSTACK,4H
134 2 DO I=0 TO 10; /* POP REGISTERS OFF OF STACK */
      ; STATEMENT # 134
05C7 C6065F0000 MOV I,0H
      @94:
05CC 803E5F000A CMP I,0AH
05D1 7724 JA @95
135 3 REG$SAV(REG$ORD(I)) = MEMORY$USERSTACK;
      ; STATEMENT # 135
05D3 8A1E5F00 MOV BL,I
05D7 B700 MOV BH,0H
05D9 2E8A5F67 MOV BL,CS:REGORD[BX]
05DD B700 MOV BH,0H
05DF D1E3 SHL BX,1
05E1 C4362A00 LES SI,MEMORYUSERSTACKPTR
05E5 268B04 MOV AX,ES:MEMORYUSERSTACK[SI]
05E8 89472E MOV REGSAV[BX],AX
136 3 USERSTACK.OFF = USERSTACK.OFF + 2;
      ; STATEMENT # 136

```

```

137 3 05EB 83062A0002 ADD USERSTACK,2H
      END;
      ; STATEMENT # 137
05F0 80065F0001 ADD I,1H
05F5 75D5 JNZ @94
      @95:
138 2 SS = USERSTACK.SEG;
      ; STATEMENT # 138
05F7 A12C00 MOV AX,USERSTACK+2H
05FA A34200 MOV REGSAV+14H,AX
139 2 SP = USERSTACK.OFF;
      ; STATEMENT # 139
05FD A12A00 MOV AX,USERSTACK
0600 A33600 MOV REGSAV+8H,AX
140 2 END;
      ; STATEMENT # 140
0603 5D POP BP
0604 C3 RET
      SAVEREGISTERS ENDP

141 1 RESTORE$EXECUTE:
      ; STATEMENT # 141
/* THIS PROCEDURE RESTORES THE STATE OF THE USER MACHINE AND
PASSES CONTROL BACK TO THE USER PROGRAM. IT CONTAINS A
MACHINE LANGUAGE SUBROUTINE TO PERFORM THE POPPING OF THE
USER REGISTERS AND TO EXECUTE AN 'IRET' TO TRANSFER CONTROL
TO THE USER'S PROGRAM. */
RESTORE$EXECUTE PROC NEAR
0605 55 PUSH BP
0606 8BEC MOV BP,SP
PROCEDURE;
142 2 DECLARE RESTORE$EXECUTE$CODE(*) BYTE DATA
      (08BH,0ECH, /* MOV BP,SP */
      08BH,046H,002H, /* MOV AX,/BP/.PARM2 */
      08BH,05EH,004H, /* MOV BX,/BP/.PARM1 */
      08EH,0DOH, /* MOV SS,AX */
      08BH,0E3H, /* MOV SP,BX */
      05DH, /* POP BP */
      05FH, /* POP DI */
      05EH, /* POP SI */
      05BH, /* POP BX */
      05AH, /* POP DX */
      059H, /* POP CX */
      058H, /* POP AX */
      01FH, /* POP DS */
      007H, /* POP ES */
      0CFH), /* IRET */
      RESTORE$EXECUTE$CODE$PTR WORD DATA (.RESTORE$EXECUTE$CODE);

143 2 USERSTACK.SEG = SS;
      ; STATEMENT # 143
0608 A14200 MOV AX,REGSAV+14H
060B A32C00 MOV USERSTACK+2H,AX
144 2 USERSTACK.OFF = SP;
      ; STATEMENT # 144
060E A13600 MOV AX,REGSAV+8H
0611 A32A00 MOV USERSTACK,AX

```

```

145  2          DO I=0 TO 10;          /* PUSH USER'S REGISTERS ONTO HIS STACK */
                                           ; STATEMENT # 145
      0614 C6065F0000      MOV      I,0H
                                           @96:
      0619 803E5F000A      CMP      I,0AH
      061E 7726             JA       @97
146  3          USERSTACK.OFF = USERSTACK.OFF - 2;
                                           ; STATEMENT # 146
      0620 832E2A0002      SUB      USERSTACK,2H
147  3          MEMORY$USERSTACK = REG$SAV(REG$ORD(10-I));
                                           ; STATEMENT # 147
      0625 B30A             MOV      BL,0AH
      0627 2A1E5F00        SUB      BL,I
      062B B700             MOV      BH,0H
      062D 2E8A5F67        MOV      BL,CS:REGORD[BX]
      0631 B700             MOV      BH,0H
      0633 D1E3             SHL      BX,1
      0635 8B472E          MOV      AX,REGSAV[BX]
      0638 C41E2A00        LES     BX,MEMORYUSERSTACKPTR
      063C 268907          MOV      ES:MEMORYUSERSTACK[BX],AX
148  3          END;
                                           ; STATEMENT # 148
      063F 80065F0001      ADD      I,1H
      0644 75D3             JNZ     @96
                                           @97:
149  2          USERSTACK.OFF = USERSTACK.OFF - 2;
                                           ; STATEMENT # 149
      0646 832E2A0002      SUB      USERSTACK,2H
150  2          MEMORY$USERSTACK = BP;
                                           ; STATEMENT # 150
      064B A13800           MOV      AX,REGSAV+0AH
      064E C41E2A00        LES     BX,MEMORYUSERSTACKPTR
      0652 268907          MOV      ES:MEMORYUSERSTACK[BX],AX
151  2          CALL RESTORE$EXECUTE$CODE$PTR(USERSTACK.OFF,USERSTACK.SEG);
                                           ; STATEMENT # 151
      0655 FF362A00        PUSH     USERSTACK; 1
      0659 FF362C00        PUSH     USERSTACK+2H; 2
      065D 2EFF160400      CALL    CS:RESTOREEXECUTE$CODEPTR
152  2          END;
                                           ; STATEMENT # 152
      0662 5D             POP      BP
      0663 C3             RET
      RESTOREEXECUTE      ENDP
153  1          INTERRUPT1$ENTRY:
                                           ; STATEMENT # 153
      /* THIS PROCEDURE IS CALLED WHEN THE CPU IS INTERRUPTED BY EXECUTING
      AN INSTRUCTION WITH THE TRAP BIT SET (SINGLE STEP). */
      0664 06             PUSH     ES
      0665 1E             PUSH     DS
      0666 2E8E1E9A00      MOV     DS,CS:@@DATA$FRAME
      066B 50             PUSH     AX
      066C 51             PUSH     CX
      066D 52             PUSH     DX
      066E 53             PUSH     BX
      066F 56             PUSH     SI
      0670 57             PUSH     DI

```

```

0671 E80900      CALL    INTERRUPT1ENTRY
0674 5F          POP     DI
0675 5E          POP     SI
0676 5B          POP     BX
0677 5A          POP     DX
0678 59          POP     CX
0679 58          POP     AX
067A 1F          POP     DS
067B 07          POP     ES
067C CF          IRET
                INTERRUPT1ENTRY      PROC NEAR
067D 55          PUSH    BP
067E 8BEC        MOV     BP,SP
                PROCEDURE INTERRUPT 1;
154 2           USERSTACK.OFF = STACKPTR;          /* SAVE USER STACK INFO */
                ; STATEMENT # 154
0680 89E0        MOV     AX,SP
0682 A32A00      MOV     USERSTACK,AX
155 2           USERSTACK.SEG = STACKBASE;
                ; STATEMENT # 155
0685 8CD0        MOV     AX,SS
0687 A32C00      MOV     USERSTACK+2H,AX
156 2           STACKPTR = MONITOR$STACKPTR;
                ; STATEMENT # 156
068A A11400      MOV     AX,MONITORSTACKPTR
068D 89C4        MOV     SP,AX
157 2           STACKBASE = MONITOR$STACKBASE;
                ; STATEMENT # 157
068F A11600      MOV     AX,MONITORSTACKBASE
0692 8ED0        MOV     SS,AX
158 2           CALL SAVE$REGISTERS;
                ; STATEMENT # 158
0694 E81EFF      CALL    SAVEREGISTERS
159 2           FL = FL AND (NOT STEP$TRAP);          /* CLEAR STEP FLAG */
                ; STATEMENT # 159
0697 81264800FFE AND     REGSAV+1AH,0FEFFH
160 2           IF LAST$COMMAND<>SS$COMMAND THEN
                ; STATEMENT # 160
069D 803E610003  CMP     LASTCOMMAND,3H
06A2 7403        JZ     @23
161 2           CALL RESTORE$EXECUTE;          /* CONTINUE IF NOT SS */
                ; STATEMENT # 161
06A4 E85EFF      CALL    RESTOREEXECUTE
                @23:
162 2           CALL KB$UPDATE$IP;
                ; STATEMENT # 162
06A7 E8A6FE      CALL    KBUPDATEIP
163 2           IF CHAR=KBCOM THEN
                ; STATEMENT # 163
06AA 803E5A0011  CMP     CHAR,11H
06AF 7515        JNZ    @24
164 2           DO;
165 3           IP = CSIP.OFF;
                ; STATEMENT # 165
06B1 A12600      MOV     AX,CSIP
06B4 A34600      MOV     REGSAV+18H,AX
166 3           CS = CSIP.SEG;

```



```

; STATEMENT # 166
06B7 A12800      MOV     AX,CSIP+2H
167  3 06BA A33E00      MOV     REGSAV+10H,AX
      FL = FL OR STEP$TRAP;      /* SET STEP FLAG */
; STATEMENT # 167
168  3 06BD 810E4800000i OR     REGSAV+1AH,100H
      CALL RESTORE$EXECUTE;
; STATEMENT # 168
169  3 06C3 E83FFF      CALL     RESTOREEXECUTE
      END;
170  2          @24:
      IF CHAR<>KBPER THEN GOTO ERROR;
; STATEMENT # 170
06C6 803E5A0010  CMP     CHAR,10H
06CB 7403          JZ      $+5H
172  2 06CD E9ECFA      JMP     ERROR
      GOTO AFTER$COMMAND;
; STATEMENT # 172
173  2 06D0 E9D6FA      JMP     AFTERCOMMAND
      END;
      INTERRUPT1$ENTRY      ENDP
174  1          INTERRUPT3$ENTRY:
; STATEMENT # 174
      /* THIS PROCEDURE IS CALLED WHEN THE CPU EXECUTES A 'INT 3' INSTRUCTION.
      THE MONITOR INSERTS THIS (OCCH) FOR A BREAKPOINT. ALSO AN EXTERNAL
      INTERRUPT OR A USER SOFTWARE INTERRUPT MAY CAUSE THIS PROCEDURE TO BE
      CALLED. */
06D3 06          PUSH    ES
06D4 1E          PUSH    DS
06D5 2E8E1E9A00  MOV     DS,CS:@@DATA$FRAME
06DA 50          PUSH    AX
06DB 51          PUSH    CX
06DC 52          PUSH    DX
06DD 53          PUSH    BX
06DE 56          PUSH    SI
06DF 57          PUSH    DI
06E0 E80900      CALL    INTERRUPT3$ENTRY
06E3 5F          POP     DI
06E4 5E          POP     SI
06E5 5B          POP     BX
06E6 5A          POP     DX
06E7 59          POP     CX
06E8 58          POP     AX
06E9 1F          POP     DS
06EA 07          POP     ES
06EB CF          IRET
      INTERRUPT3$ENTRY      PROC NEAR
06EC 55          PUSH    BP
06ED 8BEC        MOV     BP,SP
      PROCEDURE INTERRUPT 3;
175  2          USERSTACK.OFF = STACKPTR;      /* SAVE USER STACK INFO */
; STATEMENT # 175
06EF 89E0          MOV     AX,SP
176  2 06F1 A32A00      MOV     USERSTACK,AX
      USERSTACK.SEG = STACKBASE;
; STATEMENT # 176

```

```

06F4 8CDO      MOV     AX,SS
06F6 A32C00    MOV     USERSTACK+2H,AX
177  2        STACKPTR = MONITOR$STACKPTR;
                                ; STATEMENT # 177
06F9 A11400    MOV     AX,MONITORSTACKPTR
06FC 89C4      MOV     SP,AX
178  2        STACKBASE = MONITOR$STACKBASE;
                                ; STATEMENT # 178
06FE A11600    MOV     AX,MONITORSTACKBASE
0701 8ED0      MOV     SS,AX
179  2        CALL SAVE$REGISTERS;
                                ; STATEMENT # 179
0703 E8AFFE    CALL    SAVEREGISTERS
180  2        GOTO AFTER$INTERRUPT;
                                ; STATEMENT # 180
0706 E9D6FA    JMP     AFTERINTERRUPT
181  2        END;
                                INTERRUPT3ENTRY      ENDP

182  1        INIT$INT$VECTOR:
                                ; STATEMENT # 182
                                /* THIS ROUTINE INITIALIZES AN INTERRUPT VECTOR AS FOLLOWS: THE OFFSET
                                FROM THE ADDRESS OF 'INT$ROUTINE' CORRECTED BY THE APPROPRIATE
                                NUMBER OF BYTES FOR THE INTERRUPT PLM PROLOGUE. THE SEGMENT FROM THE
                                CURRENT CS REGISTER IS DETERMINED BY A MACHINE LANGUAGE CODED
                                SUBROUTINE. */
                                INITINTVECTOR      PROC NEAR
0709 55        PUSH    BP
070A 8BEC      MOV     BP,SP
183  2        PROCEDURE(INT$VECTOR$PTR,INT$ROUTINE$OFFSET);
                                DECLARE INT$VECTOR$PTR POINTER, INT$ROUTINE$OFFSET WORD,
                                VECTOR BASED INT$VECTOR$PTR STRUCTURE (OFF WORD, SEG WORD),
                                CORRECTION LITERALLY '19H', /* OFFSET FOR PROLOGUE */
                                INIT$INT$VECTOR$CODE(*) BYTE DATA
                                (055H, /* PUSH BP */
                                08BH,0ECH, /* MOV BP,SP */
                                08CH,0C8H, /* MOV AX,CS */
                                0C4H,05EH,004H, /* LES BX,/BP/.PARAM1 */
                                026H,089H,007H, /* MOV ES:W/BX/,AX */
                                05DH, /* POP BP */
                                0C2H,004H,000H), /* RET 4 */
                                INIT$INT$VECTOR$CODE$PTR WORD DATA (.INIT$INT$VECTOR$CODE);

184  2        CALL INIT$INT$VECTOR$CODE$PTR(@VECTOR.SEG); /* SEGMENT PORTION */
                                ; STATEMENT # 184
070C C45E06    LES     BX,[BP].INTVECTORPTR
070F 268D4702  LEA    AX,ES:VECTOR[BX+2H]
0713 06        PUSH   ES ; 1
0714 50        PUSH   AX ; 2
0715 2EFF160600 CALL   CS:INITINTVECTORCODEPTR
185  2        VECTOR.OFF = INT$ROUTINE$OFFSET - CORRECTION; /* OFFSET PORTION */
                                ; STATEMENT # 185
071A 8B4604    MOV     AX,[BP].INTROUTINEOFFSET
071D 83E819    SUB     AX,19H
0720 C45E06    LES     BX,[BP].INTVECTORPTR
0723 268907    MOV     ES:VECTOR[BX],AX
186  2        END;

```

```

                                ; STATEMENT # 186
0726 5D          POP          BP
0727 C20600     RET          6H
                                INITINTVECTOR      ENDP
    
```

```

/* *****
*****
    
```

COMMAND MODULE  
=====

ABSTRACT  
=====

THIS MODULE CONTAINS ALL THE COMMANDS IMPLEMENTED AS INDIVIDUAL PROCEDURES AND CALLED FROM THE OUTER BLOCK OF THE COMMAND DISPATCH LOOP.

MODULE ORGANIZATION  
=====

THIS MODULE CONTAINS THE FOLLOWING SECTIONS:

1. COMMANDS SECTION

```

KB$GO          GO
KB$SINGLE$STEP SINGLE STEP
KB$EXAM$MEM    SUBSTITUTE MEMORY
KB$EXAM$REG    EXAMINE REGISTER
KB$MOVE        MOVE
KB$INPUT       INPUT PORT
KB$OUTPUT      OUTPUT PORT
    
```

2. COMMAND DISPATCH (OUTER BLOCK, MAIN PROGRAM LOOP)

```

NEXT$COMMAND   DISPATCH
ERROR          ERROR ROUTINE
    
```

\*/

```

/* *****
*   COMMANDS SECTION
* *****
    
```

```

187  1  KB$GO:
                                ; STATEMENT # 187
                                /* IMPLEMENTS THE 'GO' COMMAND. DISPLAYS IP AND CURRENT INSTRUCTION
                                BYTE AND OPENS CS:IP FOR INPUT AND ONE OPTIONAL BREAKPOINT.
                                BEGINS EXECUTION WHEN A PERIOD IS DEPRESSED AND DISPLAYS 'E' IN
                                THE ADDRESS FIELD. UPON ENCOUNTERING A BREAKPOINT, 'BR' IS
                                DISPLAYED IN THE DATA FIELD. */
                                KBGO          PROC NEAR
072A 55          PUSH        BP
072B 8BEC        MOV         BP,SP
                                PROCEDURE;
188  2          CALL KB$UPDATE$IP;
                                /* OPTIONAL CHANGE CS:IP */
                                ; STATEMENT # 188
072D E820FE     CALL        KBUPDATEIP
189  2          IF CHAR=KBCOM THEN
                                ; STATEMENT # 139
0730 803E5A0011 CMP         CHAR,11H
0735 754B        JNZ         @26
190  2          DO;
                                /* BREAKPOINT */
191  3          CALL KB$BLANK$ADDR$FIELD(1);
    
```

```

; STATEMENT # 191
0737 B001      MOV     AL,1H
0739 50        PUSH    AX      ; 1
192 3 073A E881FB CALL    KBBLANKADDRFIELD
      CALL KB$BLANK$DATA$FIELD(0);
; STATEMENT # 192
073D B000      MOV     AL,0H
073F 50        PUSH    AX      ; 1
193 3 0740 E864FB CALL    KBBLANKDATAFIELD
      CALL KB$GET$CHAR;
; STATEMENT # 193
194 3 0743 E855FC CALL    KBGETCHAR
      CALL KB$GET$ADDR(@BRK1,CSIP.SEG,1);
; STATEMENT # 194
0746 8D062200 LEA     AX,BRK1
074A 1E        PUSH    DS      ; 1
074B 50        PUSH    AX      ; 2
074C FF362800   PUSH    CSIP+2H ; 3
0750 B001      MOV     AL,1H
0752 50        PUSH    AX      ; 4
195 3 0753 E8ABFD CALL    KBGETADDR
      IF CHAR<>KBPER THEN GOTO ERROR;
; STATEMENT # 195
0756 803E5A0010 CMP     CHAR,10H
075B 7403      JZ      $+5H
197 3 075D E95CFA JMP     ERROR
      BRK1$SAVE = MEMORY$BRK1;
; STATEMENT # 197
0760 C41E2200   LES     BX,MEMORYBRK1PTR
0764 268A07   MOV     AL,ES:MEMORYBRK1[BX]
0767 A25900   MOV     BRK1SAVE,AL
198 3 MEMORY$BRK1 = BREAK$INST;
; STATEMENT # 198
199 3 076A 26C607CC MOV     ES:MEMORYBRK1[BX],OCCH
      IF MEMORY$BRK1<>BREAK$INST THEN GOTO ERROR;
; STATEMENT # 199
076E C41E2200   LES     BX,MEMORYBRK1PTR
0772 26803FCC  CMP     ES:MEMORYBRK1[BX],OCCH
0776 7403      JZ      $+5H
201 3 0778 E941FA JMP     ERROR
      BRK1$FLAG = TRUE;
; STATEMENT # 201
202 3 077B C6065800FF MOV     BRK1FLAG,OFFH
      END;
; STATEMENT # 202
0780 EBOA      JMP     @29
      @26:
203 2 ELSE
      IF CHAR<>KBPER THEN GOTO ERROR;
; STATEMENT # 203
0782 803E5A0010 CMP     CHAR,10H
0787 7403      JZ      $+5H
0789 E930FA JMP     ERROR
; STATEMENT # 204
      @29:
      CALL KB$DISPLAY(@KB$EXEC,ADDR$FIELD,0);
; STATEMENT # 205

```

```

078C 2E8D062F00      LEA    AX,CS:KBEXEC
0791 0E                PUSH   CS      ; 1
0792 50                PUSH   AX      ; 2
0793 B001              MOV    AL,1H
0795 50                PUSH   AX      ; 3
0796 B000              MOV    AL,0H
0798 50                PUSH   AX      ; 4
0799 E8B5FA           CALL   KBDISPLAY
206  2                CALL  KB$BLANK$DATA$FIELD(0);
                                ; STATEMENT # 206
079C B000              MOV    AL,0H
079E 50                PUSH   AX      ; 1
079F E805FB           CALL   KBBLANKDATAFIELD
207  2                IP = CSIP.OFF;
                                ; STATEMENT # 207
07A2 A12600           MOV    AX,CSIP
07A5 A34600           MOV    REGSAV+18H,AX
208  2                CS = CSIP.SEG;
                                ; STATEMENT # 208
07A8 A12800           MOV    AX,CSIP+2H
07AB A33E00           MOV    REGSAV+10H,AX
209  2                FL = FL AND (NOT STEP$TRAP);
                                ; STATEMENT # 209
07AE 81264800FFFE    AND    REGSAV+1AH,OFEFFH
210  2                CALL  RESTORE$EXECUTE;
                                ; STATEMENT # 210
07B4 E84EFE           CALL   RESTOREEXECUTE
211  2                END;
                                ; STATEMENT # 211
07B7 5D                POP    BP
07B8 C3                RET
                                KBGO      ENDP
212  1                KB$SINGLE$STEP:
                                ; STATEMENT # 212
                                /* IMPLEMENTS THE SINGLE STEP COMMAND. DISPLAYS IP AND THE
                                CURRENT INSTRUCTION WORD. OPENS CS:IP FOR INPUT. DEPRESSING
                                COMMA CAUSES THE MONITOR TO SINGLE STEP THE INSTRUCTION,
                                AND PERIOD TERMINATES THE COMMAND. */
                                KBSINGLESTEP      PROC NEAR
07B9 55                PUSH   BP
07BA 8BEC              MOV    BP,SP
213  2                PROCEDURE;
                                CALL  KB$UPDATE$IP;      /* OPTIONAL CHANGE OF CS:IP */
                                ; STATEMENT # 213
214  2                07BC E891FD           CALL   KBUPDATEIP
                                IF CHAR<>KBCOM THEN GOTO ERROR;
                                ; STATEMENT # 214
07BF 803E5A0011       CMP    CHAR,11H
07C4 7403              JZ     $+5H
07C6 E9F3F9              JMP    ERROR
                                IP = CSIP.OFF;
                                ; STATEMENT # 216
217  2                07C9 A12600           MOV    AX,CSIP
                                07CC A34600           MOV    REGSAV+18H,AX
                                CS = CSIP.SEG;
                                ; STATEMENT # 217

```

```

07CF A12800      MOV     AX,CSIP+2H
07D2 A33E00      MOV     REGSAV+10H,AX
218  2          FL = FL OR STEP$TRAP; /* SET TRAP FLAG BIT IN PSW */
                                ; STATEMENT # 218
07D5 810E4800001 OR     REGSAV+1AH,100H
219  2          CALL RESTORE$EXECUTE;
                                ; STATEMENT # 219
07DB E827FE      CALL   RESTORE$EXECUTE
220  2          END;
                                ; STATEMENT # 220
07DE 5D          POP     BP
07DF C3          RET
                                KBSINGLESTEP      ENDP

221  1          KB$EXAM$MEM:
                                ; STATEMENT # 221
                                /* IMPLEMENTS THE EXAMINE MEMORY COMMAND. PROMPTS FOR AN
                                ADDRESS AND THEN DISPLAYS THE BYTE OR WORD AT THAT LOCATION.
                                IT THEN IS OPTIONALLY OPENED FOR INPUT. COMMA INCREMENTS TO
                                THE NEXT LOCATION. PERIOD TERMINATES. */
                                KBEXAMMEM      PROC NEAR
07E0 55          PUSH   BP
07E1 8BEC      MOV     BP,SP
                                PROCEDURE;
222  2          DECLARE W WORD;
223  2          CALL KB$BLANK$ADDR$FIELD(1); /* PROMPT FOR ADDRESS */
                                ; STATEMENT # 223
07E3 B001      MOV     AL,1H
07E5 50          PUSH   AX ; 1
07E6 E8D5FA      CALL   KBBLANKADDRFIELD
224  2          CALL KB$GET$CHAR;
                                ; STATEMENT # 224
07E9 E8AFFB      CALL   KBGETCHAR
225  2          CALL KB$GET$ADDR(@ARG1,CS,1); /* GET ADDRESS */
                                ; STATEMENT # 225
07EC 8D061A00    LEA   AX,ARG1
07F0 1E          PUSH   DS ; 1
07F1 50          PUSH   AX ; 2
07F2 FF363E00    PUSH   REGSAV+10H; 3
07F6 B001      MOV     AL,1H
07F8 50          PUSH   AX ; 4
07F9 E805FD      CALL   KBGETADDR
226  2          IF CHAR<>KBCOM THEN GOTO ERROR;
                                ; STATEMENT # 226
07FC 803E5A0011  CMP    CHAR,11H
0801 7403      JZ     $+5H
0803 E9B6F9      JMP    ERROR
228  2          DO WHILE TRUE;
                                ; STATEMENT # 228
                                @98:
229  3          CALL KB$OUT$WORD(ARG1.OFF,ADDR$FIELD,0,BLANK); /* CLEAR PROMPT */
                                ; STATEMENT # 229
0806 FF361A00    PUSH   ARG1 ; 1
080A B001      MOV     AL,1H
080C 50          PUSH   AX ; 2
080D B100      MOV     CL,0H
080F 51          PUSH   CX ; 3

```

```

0810 50          PUSH   AX          ; 4
0811 E801FB      CALL    KBOUTWORD
230 3          IF WORD$MODE THEN
                                ; STATEMENT # 230
0814 A06000      MOV     AL,WORDMODE
0817 D0D8        RCR     AL,1
0819 7313        JNB    @33
231 3          CALL KB$OUT$WORD(MEMORY$WORD$ARG1,DATA$FIELD,1,NOBLANK);
                                ; STATEMENT # 231
081B C41E1A00    LES     BX,MEMORYARG1PTR
081F 26FF37      PUSH   ES:MEMORYWORDARG1[BX]
0822 B000        MOV     AL,0H
0824 50          PUSH   AX          ; 2
0825 B101        MOV     CL,1H
0827 51          PUSH   CX          ; 3
0828 50          PUSH   AX          ; 4
0829 E8E9FA      CALL    KBOUTWORD
082C EB0D        JMP     @34
                                @33:
                                ELSE
232 3          CALL KB$OUT$BYTE(MEMORY$ARG1,1);
                                ; STATEMENT # 232
082E C41E1A00    LES     BX,MEMORYARG1PTR
0832 26FF37      PUSH   ES:MEMORYARG1[BX]
0835 B001        MOV     AL,1H
0837 50          PUSH   AX          ; 2
0838 E89AFA      CALL    KBOUTBYTE
                                @34:
233 3          CALL KB$GET$CHAR;
                                ; STATEMENT # 233
083B E85DFB      CALL    KBGETCHAR
234 3          IF CHAR=KBPER THEN RETURN;
                                ; STATEMENT # 234
083E 803E5A0010  CMP     CHAR,10H
0843 7502        JNZ    @35
                                ; STATEMENT # 235
0845 5D          POP     BP
0846 C3          RET
                                @35:
236 3          IF CHAR<>KBCOM THEN
                                ; STATEMENT # 236
0847 803E5A0011  CMP     CHAR,11H
084C 7503        JNZ    $+5H
084E E99100      JMP     @36
237 3          IF WORD$MODE THEN
                                ; STATEMENT # 237
0851 A06000      MOV     AL,WORDMODE
0854 D0D8        RCR     AL,1
0856 7343        JNB    @37
238 3          DO;
239 4          W = KB$GET$EXPR(DATA$FIELD,1,NOBLANK);
                                ; STATEMENT # 239
0858 B000        MOV     AL,0H
085A 50          PUSH   AX          ; 1
085B B101        MOV     CL,1H
085D 51          PUSH   CX          ; 2
085E 50          PUSH   AX          ; 3

```

```

085F E853FB      CALL    KBGETEXPR
0862 A34E00      MOV     W,AX
240  4          IF (CHAR<>KBKOM) AND (CHAR<>KBPER) THEN GOTO ERROR;
                                ; STATEMENT # 240
0865 803E5A0011  CMP     CHAR,11H
086A B0FF        MOV     AL,OFFH
086C 7501        JNZ    $+3H
086E 40          INC     AX
086F 50          PUSH   AX          ; 1
0870 803E5A0010  CMP     CHAR,10H
0875 B0FF        MOV     AL,OFFH
0877 7501        JNZ    $+3H
0879 40          INC     AX
087A 59          POP     CX          ; 1
087B 22C1        AND    AL,CL
087D D0D8        RCR    AL,1
087F 7303        JNB    $+5H
242  4          0881 E938F9      JMP     ERROR
                                MEMORY$WORD$ARG1 = W;
                                ; STATEMENT # 242
0884 A14E00      MOV     AX,W
0887 C41E1A00    LES    BX,MEMORYARG1PTR
088B 268907      MOV     ES:MEMORYWORDARG1[BX],AX
243  4          IF MEMORY$WORD$ARG1<>W THEN GOTO ERROR;
                                ; STATEMENT # 243
088E C41E1A00    LES    BX,MEMORYARG1PTR
0892 268B07      MOV     AX,ES:MEMORYWORDARG1[BX]
0895 3B064E00    CMP    AX,W
0899 EB42        JMP     @9
245  4          END;
                                ; STATEMENT # 245
@37:
ELSE
246  3          DO;
247  4          W = KB$GET$EXPR(DATA$BYTE,1,NOBLANK);
                                ; STATEMENT # 247
089B B0FF        MOV     AL,OFFH
089D 50          PUSH   AX          ; 1
089E B001        MOV     AL,1H
08A0 50          PUSH   AX          ; 2
08A1 B000        MOV     AL,0H
08A3 50          PUSH   AX          ; 3
08A4 E80EFB      CALL    KBGETEXPR
08A7 A34E00      MOV     W,AX
248  4          IF (CHAR<>KBKOM) AND (CHAR<>KBPER) THEN GOTO ERROR;
                                ; STATEMENT # 248
08AA 803E5A0011  CMP     CHAR,11H
08AF B0FF        MOV     AL,OFFH
08B1 7501        JNZ    $+3H
08B3 40          INC     AX
08B4 50          PUSH   AX          ; 1
08B5 803E5A0010  CMP     CHAR,10H
08BA B0FF        MOV     AL,OFFH
08BC 7501        JNZ    $+3H
08BE 40          INC     AX
08BF 59          POP     CX          ; 1
08C0 22C1        AND    AL,CL

```



```

250 4 08C2 D0D8 RCR AL,1
      08C4 7303 JNB $+5H
      08C6 E9F3F8 JMP ERROR
      MEMORY$ARG1 = LOW(W);
      ; STATEMENT # 250
      08C9 A14E00 MOV AX,W
      08CC C41E1A00 LES BX,MEMORYARG1PTR
      08D0 268807 MOV ES:MEMORYARG1[BX],AL
251 4 IF MEMORY$ARG1<>LOW(W) THEN GOTO ERROR;
      ; STATEMENT # 251
      08D3 A14E00 MOV AX,W
      08D6 C41E1A00 LES BX,MEMORYARG1PTR
      08DA 263807 CMP ES:MEMORYARG1[BX],AL
      @9:
      08DD 7403 JZ $+5H
      08DF E9DAF8 JMP ERROR
      ; STATEMENT # 252
253 4 END;
      @36:
254 3 IF CHAR=KBPER THEN RETURN;
      ; STATEMENT # 254
      08E2 803E5A0010 CMP CHAR,10H
      08E7 7502 JNZ @43
      ; STATEMENT # 255
      08E9 5D POP BP
      08EA C3 RET
      @43:
256 3 IF WORD$MODE THEN
      ; STATEMENT # 256
      08EB A06000 MOV AL,WORDMODE
      08EE D0D8 RCR AL,1
      08F0 7307 JNB @44
      ARG1.OFF = ARG1.OFF + 2;
      ; STATEMENT # 257
      08F2 83061A0002 ADD ARG1,2H
      08F7 EB05 JMP @10
      @44:
      ELSE
258 3 ARG1.OFF = ARG1.OFF + 1;
      ; STATEMENT # 258
      08F9 83061A0001 ADD ARG1,1H
259 3 END;
      ; STATEMENT # 259
      @10:
      08FE E905FF JMP @98
      @99:
260 2 END;
      ; STATEMENT # 260
      0901 5D POP BP
      0902 C3 RET
      KBEXAMMEM ENDP
261 1 KB$EXAM$REG:
      ; STATEMENT # 261
      /* IMPLEMENTS THE EXAMINE REGISTER COMMAND. PROMPTS FOR A VALID
      REGISTER KEY AND DISPLAYS THE VALUE OF THAT REGISTER WHICH IS
      OPTIONALLY OPENED FOR INPUT. COMMA INCREMENTS TO NEXT REGISTER

```

```

                UNLESS IT IS 'FL' WHICH TERMINATES AS DOES PERIOD. */
                KBEXAMREG      PROC NEAR
0903 55          PUSH      BP
0904 8BEC        MOV       BP,SP
                PROCEDURE;
262  2          DECLARE I BYTE, SAVE WORD;
263  2          CALL KB$BLANK$ADDR$FIELD(1);
                                ; STATEMENT # 263
0906 B001        MOV       AL,1H
0908 50          PUSH      AX          ; 1
0909 E8B2F9      CALL      KBBLANKADDRFIELD
264  2          CALL KB$GET$CHAR;
                                ; STATEMENT # 264
090C E88CFA      CALL      KBGETCHAR
265  2          IF CHAR>ODH THEN GOTO ERROR; /* INVALID REG KEY */
                                ; STATEMENT # 265
090F 803E5A000D  CMP       CHAR,ODH
0914 7603        JBE       $+5H
0916 E9A3F8      JMP       ERROR
267  2          I = CHAR;
                                ; STATEMENT # 267
0919 A05A00        MOV       AL,CHAR
091C A26400        MOV       I,AL
268  2          DO WHILE TRUE;
                                ; STATEMENT # 268
                @100:
269  3          DISP(0),DISP(1) = 0; /* DISPLAY REG NAME */
                                ; STATEMENT # 269
091F B000          MOV       AL,0H
0921 A25B00        MOV       DISP,AL
0924 A25C00        MOV       DISP+1H,AL
270  3          DISP(2) = KB$REG(I*2);
                                ; STATEMENT # 270
0927 A06400        MOV       AL,I
092A B102          MOV       CL,2H
092C F6E1          MUL       CL
092E 89C3          MOV       BX,AX
0930 2E8A4F4B      MOV       CL,CS:KBREG[BX]
0934 880E5D00      MOV       DISP+2H,CL
271  3          DISP(3) = KB$REG(I*2+1);
                                ; STATEMENT # 271
0938 2E8A4F4C      MOV       CL,CS:KBREG[BX+1H]
093C 880E5E00      MOV       DISP+3H,CL
272  3          CALL KB$DISPLAY(@DISP,ADDR$FIELD,0);
                                ; STATEMENT # 272
0940 8D065B00      LEA      AX,DISP
0944 1E           PUSH      DS          ; 1
0945 50           PUSH      AX          ; 2
0946 B001          MOV       AL,1H
0948 50           PUSH      AX          ; 3
0949 B000          MOV       AL,0H
094B 50           PUSH      AX          ; 4
094C E802F9      CALL      KBDISPLAY
273  3          CALL KB$OUT$WORD(REG$SAV(I),DATA$FIELD,1,NOBLANK); /* VALUE */
                                ; STATEMENT # 273
094F 8A1E6400      MOV       BL,I
0953 B700          MOV       BH,0H

```

```

0955 D1E3          SHL     BX,1
0957 FF772E       PUSH    REGSAV[BX]; 1
095A B000         MOV     AL,0H
095C 50          PUSH    AX          ; 2
095D B101         MOV     CL,1H
095F 51          PUSH    CX          ; 3
0960 50          PUSH    AX          ; 4
0961 E8B1F9       CALL    KBOUTWORD
274 3            CALL    KB$GET$CHAR;
                                ; STATEMENT # 274
0964 E834FA       CALL    KBGETCHAR
275 3            IF CHAR<>KBCOM AND CHAR<>KBPER THEN
                                ; STATEMENT # 275
0967 803E5A0011   CMP     CHAR,11H
096C B0FF         MOV     AL,OFFH
096E 7501         JNZ    $+3H
0970 40          INC     AX
0971 50          PUSH    AX          ; 1
0972 803E5A0010   CMP     CHAR,10H
0977 B0FF         MOV     AL,OFFH
0979 7501         JNZ    $+3H
097B 40          INC     AX
097C 59          POP     CX          ; 1
097D 22C1         AND    AL,CL
097F D0D8         RCR    AL,1
0981 733A         JNB    @47
276 3            DO;
277 4            SAVE = KB$GET$EXPR(DATA$FIELD,1,NOBLANK); /* UPDATE */
                                ; STATEMENT # 277
0983 B000         MOV     AL,0H
0985 50          PUSH    AX          ; 1
0986 B101         MOV     CL,1H
0988 51          PUSH    CX          ; 2
0989 50          PUSH    AX          ; 3
098A E828FA       CALL    KBGETEXPR
098D A35000       MOV     SAVE,AX
278 4            IF CHAR<>KBCOM AND CHAR<>KBPER THEN GOTO ERROR;
                                ; STATEMENT # 278
0990 803E5A0011   CMP     CHAR,11H
0995 B0FF         MOV     AL,OFFH
0997 7501         JNZ    $+3H
0999 40          INC     AX
099A 50          PUSH    AX          ; 1
099B 803E5A0010   CMP     CHAR,10H
09A0 B0FF         MOV     AL,OFFH
09A2 7501         JNZ    $+3H
09A4 40          INC     AX
09A5 59          POP     CX          ; 1
09A6 22C1         AND    AL,CL
09A8 D0D8         RCR    AL,1
09AA 7303         JNB    $+5H
09AC E90DF8       JMP     ERROR
280 4            REG$SAV(I) = SAVE;
                                ; STATEMENT # 280
09AF 8A1E6400     MOV     BL,I
09B3 B700         MOV     BH,0H
09B5 D1E3          SHL     BX,1

```

```

09B7 A15000      MOV     AX,SAVE
09BA 89472E      MOV     REGSAV[BX],AX
281  4          END;
                @47:
282  3          IF CHAR=KBPER OR I=13 THEN RETURN;          /* DONE? */
                ; STATEMENT # 282
09BD 803E5A0010  CMP     CHAR,10H
09C2 B0FF        MOV     AL,OFFH
09C4 7401        JZ     $+3H
09C6 40          INC     AX
09C7 50          PUSH    AX          ; 1
09C8 803E64000D  CMP     I,0DH
09CD B0FF        MOV     AL,OFFH
09CF 7401        JZ     $+3H
09D1 40          INC     AX
09D2 59          POP     CX          ; 1
09D3 0AC1        OR     AL,CL
09D5 D0D8        RCR     AL,1
09D7 7302        JNB    @49
                ; STATEMENT # 283
09D9 5D          POP     BP
09DA C3          RET
                @49:
284  3          I = I + 1;
                ; STATEMENT # 284
09DB 8006640001  ADD     I,1H
285  3          END;
                ; STATEMENT # 285
09E0 E93CFF        JMP     @100
                @101:
286  2          END;
                ; STATEMENT # 286
09E3 5D          POP     BP
09E4 C3          RET
                KBEXAMREG      ENDP
287  1          KB$MOVE:
                ; STATEMENT # 287
                /* IMPLEMENTS THE MOVE COMMAND. PROMPTS FOR 3 ARGUMENTS AND MOVES
                THE BLOCK OF MEMORY SPECIFIED BY ARG1-ARG2 TO ARG3. IF THERE IS
                A DIFFERENCE WHEN READ BACK, THEN ERROR. */
                KBMOVE      PROC NEAR
09E5 55          PUSH    BP
09E6 8BEC        MOV     BP,SP
                PROCEDURE;
288  2          CALL KB$BLANK$ADDR$FIELD(3);          /* FIRST ARGUMENT */
                ; STATEMENT # 288
09E8 B003        MOV     AL,3H
09EA 50          PUSH    AX          ; 1
09EB E8D0F8        CALL    KBBLANKADDRFIELD
289  2          CALL KB$GET$CHAR;
                ; STATEMENT # 289
09EE E8AAF9        CALL    KBGETCHAR
290  2          CALL KB$GET$ADDR(@ARG1,CS,3);
                ; STATEMENT # 290
09F1 8D061A00    LEA    AX,ARG1
09F5 1E          PUSH    DS          ; 1

```

```

09F6 50          PUSH    AX      ; 2
09F7 FF363E00   PUSH    REGSAV+10H; 3
09FB B003       MOV     AL,3H
09FD 50          PUSH    AX      ; 4
09FE E800FB     CALL    KBGETADDR
291  2          IF CHAR<>KBCOM THEN GOTO ERROR;
                                ; STATEMENT # 291
0A01 803E5A0011 CMP     CHAR,11H
0A06 7403       JZ      $+5H
0A08 E9B1F7     JMP     ERROR
293  2          CALL    KB$BLANK$ADDR$FIELD(2); /* SECOND ARGUMENT */
                                ; STATEMENT # 293
0A0B B002       MOV     AL,2H
0A0D 50          PUSH    AX      ; 1
0A0E E8ADF8     CALL    KBBLANKADDRFIELD
294  2          CALL    KB$GET$CHAR;
                                ; STATEMENT # 294
0A11 E887F9     CALL    KBGETCHAR
295  2          END$OFF = KB$GET$EXPR(ADDR$FIELD,2,BLANK);
                                ; STATEMENT # 295
0A14 B001       MOV     AL,1H
0A16 50          PUSH    AX      ; 1
0A17 B102       MOV     CL,2H
0A19 51          PUSH    CX      ; 2
0A1A 50          PUSH    AX      ; 3
0A1B E897F9     CALL    KBGETEXPR
0A1E A31800     MOV     ENDOFF,AX
296  2          IF END$OFF<ARG1.OFF THEN GOTO ERROR;
                                ; STATEMENT # 296
0A21 A11800     MOV     AX,ENDOFF
0A24 3B061A00   CMP     AX,ARG1
0A28 7303       JNB    $+5H
0A2A E98FF7     JMP     ERROR
298  2          IF CHAR<>KBCOM THEN GOTO ERROR;
                                ; STATEMENT # 298
0A2D 803E5A0011 CMP     CHAR,11H
0A32 7403       JZ      $+5H
0A34 E985F7     JMP     ERROR
300  2          CALL    KB$BLANK$ADDR$FIELD(1); /* THIRD ARGUMENT */
                                ; STATEMENT # 300
0A37 B001       MOV     AL,1H
0A39 50          PUSH    AX      ; 1
0A3A E881F8     CALL    KBBLANKADDRFIELD
301  2          CALL    KB$GET$CHAR;
                                ; STATEMENT # 301
0A3D E85BF9     CALL    KBGETCHAR
302  2          CALL    KB$GET$ADDR(@ARG3,ARG1.SEG,1);
                                ; STATEMENT # 302
0A40 8D061E00   LEA    AX,ARG3
0A44 1E          PUSH    DS      ; 1
0A45 50          PUSH    AX      ; 2
0A46 FF361C00   PUSH    ARG1+2H ; 3
0A4A B001       MOV     AL,1H
0A4C 50          PUSH    AX      ; 4
0A4D E8B1FA     CALL    KBGETADDR
303  2          IF CHAR<>KBPER THEN GOTO ERROR;
                                ; STATEMENT # 303

```

```

0A50 803E5A0010    CMP    CHAR,10H
0A55 7403          JZ     $+5H
0A57 E962F7        JMP    ERROR
305  2            LOOP:
                                ; STATEMENT # 305
                                LOOP:
                                MEMORY$ARG3 = MEMORY$ARG1;
0A5A C41E1A00      LES    BX,MEMORYARG1PTR
0A5E 268A07        MOV    AL,ES:MEMORYARG1[BX]
0A61 C41E1E00      LES    BX,MEMORYARG3PTR
0A65 268807        MOV    ES:MEMORYARG3[BX],AL
306  2            IF MEMORY$ARG3<>MEMORY$ARG1 THEN GOTO ERROR;
                                ; STATEMENT # 306
0A68 C41E1E00      LES    BX,MEMORYARG3PTR
0A6C 268A07        MOV    AL,ES:MEMORYARG3[BX]
0A6F C41E1A00      LES    BX,MEMORYARG1PTR
0A73 263A07        CMP    AL,ES:MEMORYARG1[BX]
0A76 7403          JZ     $+5H
0A78 E941F7        JMP    ERROR
308  2            IF ARG1.OFF = END$OFF THEN RETURN;
                                ; STATEMENT # 308
0A7B A11A00        MOV    AX,ARG1
0A7E 3B061800      CMP    AX,ENDOFF
0A82 7502          JNZ   @55
                                ; STATEMENT # 309
0A84 5D            POP    BP
0A85 C3            RET
                                @55:
310  2            ARG1.OFF = ARG1.OFF + 1;
                                ; STATEMENT # 310
0A86 83061A0001    ADD    ARG1,1H
311  2            ARG3.OFF = ARG3.OFF + 1;
                                ; STATEMENT # 311
0A8B 83061E0001    ADD    ARG3,1H
312  2            GOTO LOOP;
                                ; STATEMENT # 312
0A90 EBC8          JMP    LOOP
313  2            END;
                                KMOVE    ENDP
314  1            KB$INPUT:
                                ; STATEMENT # 314
                                /* PROMPTS FOR A PORT WORD IN THE ADDRESS FIELD. WHEN A COMMA
                                IS ENTERED THE BYTE OR WORD IS DISPLAYED IN THE DATA FIELD.
                                THIS MAY BE REPEATED FOR MULTIPLE READING OF THE PORT. PERIOD
                                TERMINATES THE COMMAND. */
                                KBINPUT    PROC NEAR
0A92 55            PUSH   BP
0A93 8BEC          MOV    BP,SP
315  2            PROCEDURE;
316  2            DECLARE PORT WORD;
                                CALL KB$BLANK$ADDR$FIELD(1);
                                /* PROMPT FOR PORT */
                                ; STATEMENT # 316
0A95 B001          MOV    AL,1H
0A97 50            PUSH   AX
0A98 E823F8        CALL  KBLANKADDRFIELD
317  2            CALL KB$GET$CHAR;

```

```

; STATEMENT # 317
318 2 0A9B E8FDF8 CALL KBGETCHAR
      PORT = KB$GET$EXPR(ADDR$FIELD,1,BLANK); /* GET PORT NUMBER */
; STATEMENT # 318
0AAE B001 MOV AL,1H
0AA0 50 PUSH AX ; 1
0AA1 50 PUSH AX ; 2
0AA2 50 PUSH AX ; 3
0AA3 E80FF9 CALL KBGETEXPR
0AA6 A35200 MOV PORT,AX
319 2 CALL KB$OUT$WORD(PORT,ADDR$FIELD,0,BLANK); /* REMOVE PROMPT */
; STATEMENT # 319
0AA9 FF365200 PUSH PORT ; 1
0AAD B001 MOV AL,1H
0AAF 50 PUSH AX ; 2
0AB0 B100 MOV CL,0H
0AB2 51 PUSH CX ; 3
0AB3 50 PUSH AX ; 4
0AB4 E85EF8 CALL KBOUTWORD
320 2 LOOP:
; STATEMENT # 320
      LOOP:
0AB7 803E5A0011 CMP CHAR,11H
0ABC 7403 JZ $+5H
0ABE E9FBF6 JMP ERROR
      IF CHAR<>KBCOM THEN GOTO ERROR;
322 2      IF WORD$MODE THEN
; STATEMENT # 322
0AC1 A06000 MOV AL,WORDMODE
0AC4 D0D8 RCR AL,1
0AC6 7310 JNB @57
323 2 CALL KB$OUT$WORD(INWORD(PORT),DATA$FIELD,0,NOBLANK);
; STATEMENT # 323
0AC8 8B165200 MOV DX,PORT
0ACC ED INW DX
0ACD 50 PUSH AX ; 1
0ACE B000 MOV AL,0H
0AD0 50 PUSH AX ; 2
0AD1 50 PUSH AX ; 3
0AD2 50 PUSH AX ; 4
0AD3 E83FF8 CALL KBOUTWORD
0AD6 EBOC JMP @58
      @57:
      ELSE
324 2 CALL KB$OUT$BYTE(INPUT(PORT),0);
; STATEMENT # 324
0AD8 8B165200 MOV DX,PORT
0ADC EC IN DX
0ADD 50 PUSH AX ; 1
0ADE B000 MOV AL,0H
0AE0 50 PUSH AX ; 2
0AE1 E8F1F7 CALL KBOUTBYTE
      @58:
325 2 CALL KB$GET$CHAR;
; STATEMENT # 325
0AE4 E8B4F8 CALL KBGETCHAR
326 2 IF CHAR=KBPER THEN RETURN;

```

```

; STATEMENT # 326
OAE7 803E5A0010    CMP    CHAR,10H
OAEC 75C9          JNZ    LOOP
; STATEMENT # 327
OAE8 5D           POP    BP
OAEF C3           RET
328 2             GOTO LOOP;
329 2             END;
                KBINPUT    ENDP
330 1             KB$OUTPUT:
                ; STATEMENT # 330
                /* PROMPTS FOR A PORT WORD IN THE ADDRESS FIELD AND A BYTE OR
                WORD DATUM IN THE DATA FIELD. THIS DATUM IS OUTPUT A SINGLE TIME
                TO THE SPECIFIED PORT. */
                KBOUTPUT    PROC NEAR
OAF0 55           PUSH   BP
OAF1 8BEC         MOV    BP,SP
                PROCEDURE;
331 2             DECLARE (DATUM,PORT) WORD;
332 2             CALL KB$BLANK$ADDR$FIELD(1); /* PROMPT FOR PORT */
                ; STATEMENT # 332
OAF3 B001         MOV    AL,1H
OAF5 50           PUSH   AX ; 1
OAF6 E8C5F7       CALL   KBBLANKADDRFIELD
333 2             CALL KB$GET$CHAR;
                ; STATEMENT # 333
OAF9 E89FF8       CALL   KBGETCHAR
334 2             PORT = KB$GET$EXPR(ADDR$FIELD,1,BLANK);
                ; STATEMENT # 334
OAFc B001         MOV    AL,1H
OAFE 50           PUSH   AX ; 1
OAFF 50           PUSH   AX ; 2
OB00 50           PUSH   AX ; 3
OB01 E8B1F8       CALL   KBGETEXPR
OB04 A35600       MOV    PORT,AX
335 2             IF CHAR<>KBCOM THEN GOTO ERROR;
                ; STATEMENT # 335
OB07 803E5A0011    CMP    CHAR,11H
OB0C 7403         JZ     $+5H
OB0E E9ABF6       JMP    ERROR
337 2             CALL KB$OUT$WORD(PORT,ADDR$FIELD,0,BLANK); /* REMOVE PROMPT */
                ; STATEMENT # 337
OB11 FF365600       PUSH   PORT ; 1
OB15 B001         MOV    AL,1H
OB17 50           PUSH   AX ; 2
OB18 B100         MOV    CL,0H
OB1A 51           PUSH   CX ; 3
OB1B 50           PUSH   AX ; 4
OB1C E8F6F7       CALL   KBOUTWORD
338 2             CALL KB$BLANK$DATA$FIELD(1); /* PROMPT FOR DATUM */
                ; STATEMENT # 338
OB1F B001         MOV    AL,1H
OB21 50           PUSH   AX ; 1
OB22 E882F7       CALL   KBBLANKDATAFIELD
339 2             CALL KB$GET$CHAR;
                ; STATEMENT # 339

```



```

340 2  OB25 E873F8      CALL  KBGETCHAR
      LOOP:
                                     ; STATEMENT # 340
      OB28 A06000      MOV   AL,WORDMODE
      OB2B D0D8        RCR   AL,1
      OB2D 7308        JNB   @61
      IF WORD$MODE THEN
341 2      DATUM = KB$GET$EXPR(DATA$FIELD,1,NOBLANK); /* GET DATUM WORD */
                                     ; STATEMENT # 341
      OB2F B000        MOV   AL,0H
      OB31 50          PUSH  AX      ; 1
      OB32 B101        MOV   CL,1H
      OB34 51          PUSH  CX      ; 2
      OB35 EB08        JMP   @18
      @61:
      ELSE
342 2      DATUM = KB$GET$EXPR(DATA$BYTE,1,NOBLANK); /* GET DATUM BYTE */
                                     ; STATEMENT # 342
      OB37 B0FF        MOV   AL,OFFH
      OB39 50          PUSH  AX      ; 1
      OB3A B001        MOV   AL,1H
      OB3C 50          PUSH  AX      ; 2
      OB3D B000        MOV   AL,0H
      @18:
      OB3F 50          PUSH  AX      ; 3
      OB40 E872F8      CALL  KBGETEXPR
      OB43 A35400      MOV   DATUM,AX
343 2      IF CHAR=KBCOL THEN GOTO ERROR;
                                     ; STATEMENT # 343
      OB46 803E5A0014  CMP   CHAR,14H
      OB4B 7503        JNZ   $+5H
      OB4D E96CF6        JMP   ERROR
345 2      IF WORD$MODE THEN
                                     ; STATEMENT # 345
      OB50 A06000      MOV   AL,WORDMODE
      OB53 D0D8        RCR   AL,1
      OB55 730A        JNB   @64
346 2      OUTWORD(PORT) = DATUM;
                                     ; STATEMENT # 346
      OB57 8B165600    MOV   DX,PORT
      OB5B A15400      MOV   AX,DATUM
      OB5E EF          OUTW  DX
      OB5F EB08        JMP   @65
      @64:
      ELSE
347 2      OUTPUT(PORT) = LOW(DATUM);
                                     ; STATEMENT # 347
      OB61 A15400      MOV   AX,DATUM
      OB64 8B165600    MOV   DX,PORT
      OB68 EE          OUT   DX
      @65:
348 2      IF CHAR=KBCOM THEN
                                     /* MULTIPLE OUTPUTS */
                                     ; STATEMENT # 348
      OB69 803E5A0011  CMP   CHAR,11H
      OB6E 7510        JNZ   @66
349 2      DO;

```

```

350 3          CALL KB$BLANK$DATA$FIELD(1);
                                ; STATEMENT # 350
      0B70 B001          MOV     AL,1H
      0B72 50           PUSH    AX          ; 1
      0B73 E831F7       CALL    KBBLANKDATAFIELD
351 3          CALL KB$GET$CHAR;
                                ; STATEMENT # 351
      0B76 E822F8       CALL    KBGETCHAR
352 3          IF CHAR<>KBPER THEN GOTO LOOP;
                                ; STATEMENT # 352
      0B79 803E5A0010   CMP     CHAR,10H
      0B7E 75A8         JNZ     LOOP
                                ; STATEMENT # 353
354 3          END;
      @66:
355 2          END;
                                ; STATEMENT # 355
      0B80 5D           POP     BP
      0B81 C3           RET
      KBOUTPUT      ENDP

/*****
*   COMMAND DISPATCH MAIN PROGRAM LOOP
*****/

356 1          DISABLE;
                                ; STATEMENT # 356
      009C FA           CLI
      009D 2E8E169800   MOV     SS,CS:@@STACK$FRAME
      00A2 BC5000       MOV     SP,@@STACK$OFFSET
      00A5 8BEC         MOV     BP,SP
      00A7 2E8E1E9A00   MOV     DS,CS:@@DATA$FRAME
      00AC FB           STI
      00AD FA           CLI
357 1          OUTPUT(KB$STAT$PORT) = KB$INIT$MODE; /* INIT 8279 */
                                ; STATEMENT # 357
      00AE BAEAFF       MOV     DX,OFFEAH
      00B1 B000         MOV     AL,0H
      00B3 EE           OUT     DX
358 1          OUTPUT(KB$STAT$PORT) = KB$INIT$SCAN;
                                ; STATEMENT # 358
      00B4 B039         MOV     AL,39H
      00B6 EE           OUT     DX
359 1          CALL KB$DISPLAY(@KB$SIGNON,ADDR$FIELD,0); /* SIGN ON MESSAGE */
                                ; STATEMENT # 359
      00B7 2E8D061F00   LEA    AX,CS:KBSIGNON
      00BC 0E           PUSH    CS          ; 1
      00BD 50           PUSH    AX          ; 2
      00BE B001         MOV     AL,1H
      00C0 50           PUSH    AX          ; 3
      00C1 B000         MOV     AL,0H
      00C3 50           PUSH    AX          ; 4
      00C4 E88A01       CALL    KBDISPLAY
360 1          CALL KB$DISPLAY(@KB$VERSION,DATA$FIELD,0); /* VERSION NUMBER */
                                ; STATEMENT # 360
      00C7 2E8D062300   LEA    AX,CS:KBVERSION

```

```

00CC 0E          PUSH   CS          ; 1
00CD 50          PUSH   AX          ; 2
00CE B000        MOV    AL,OH
00D0 50          PUSH   AX          ; 3
00D1 50          PUSH   AX          ; 4
00D2 E87C01      CALL  KBDISPLAY

      /* INITIALIZE USER'S REGISTERS */
361  1          CS,SS,DS,ES,FL,IP = 0;
                                ; STATEMENT # 361
00D5 B80000      MOV    AX,OH
00D8 A33E00      MOV    REGSAV+10H,AX
00DB A34200      MOV    REGSAV+14H,AX
00DE A34000      MOV    REGSAV+12H,AX
00E1 A34400      MOV    REGSAV+16H,AX
00E4 A34800      MOV    REGSAV+1AH,AX
00E7 A34600      MOV    REGSAV+18H,AX
362  1          SP = USER$INIT$SP;
                                ; STATEMENT # 362
00EA C7063600001  MOV    REGSAV+8H,100H
363  1          CALL INIT$INT$VECTOR(@INT$VECTOR(1),.INTERRUPT1$ENTRY);
                                ; STATEMENT # 363
00F0 8D060400    LEA   AX,INTVECTOR+4H
00F4 1E          PUSH  DS          ; 1
00F5 50          PUSH  AX          ; 2
00F6 B87D06      MOV    AX,OFFSET(INTERRUPT1ENTRY)
00F9 50          PUSH  AX          ; 3
00FA E80C06      CALL  INITINTVECTOR
364  1          CALL INIT$INT$VECTOR(@INT$VECTOR(2),.INTERRUPT3$ENTRY);
                                ; STATEMENT # 364
00FD 8D060800    LEA   AX,INTVECTOR+8H
0101 1E          PUSH  DS          ; 1
0102 50          PUSH  AX          ; 2
0103 B8EC06      MOV    AX,OFFSET(INTERRUPT3ENTRY)
0106 50          PUSH  AX          ; 3
0107 E8FF05      CALL  INITINTVECTOR
365  1          CALL INIT$INT$VECTOR(@INT$VECTOR(3),.INTERRUPT3$ENTRY);
                                ; STATEMENT # 365
010A 8D060C00    LEA   AX,INTVECTOR+0CH
010E 1E          PUSH  DS          ; 1
010F 50          PUSH  AX          ; 2
0110 B8EC06      MOV    AX,OFFSET(INTERRUPT3ENTRY)
0113 50          PUSH  AX          ; 3
0114 E8F205      CALL  INITINTVECTOR
366  1          BRK1$FLAG = FALSE;
                                ; STATEMENT # 366
0117 C606580000    MOV    BRK1FLAG,OH
367  1          MONITOR$STACKBASE = STACKBASE; /* SAVE MONITOR STACK VALUES */
                                ; STATEMENT # 367
011C 8CD0          MOV    AX,SS
011E A31600      MOV    MONITORSTACKBASE,AX
368  1          MONITOR$STACKPTR = STACKPTR;
                                ; STATEMENT # 368
0121 89E0          MOV    AX,SP
0123 A31400      MOV    MONITORSTACKPTR,AX
369  1          GOTO AFTER$error;

```



```

0168 E8BF05      CALL    KBGO
016B EB3C        JMP     AFTERCOMMAND
381  2          CALL KB$SINGLE$STEP;
                                ; STATEMENT # 381
                                @73:
016D E84906      CALL    KBSINGLESTEP
0170 EB37        JMP     AFTERCOMMAND
382  2          CALL KB$INPUT;
383  2          CALL KB$OUTPUT;
384  2          CALL KB$MOVE;
                                ; STATEMENT # 384
                                @76:
0172 E87008      CALL    KBMOVE
0175 EB32        JMP     AFTERCOMMAND
385  2          DO; WORD$MODE = TRUE; CALL KB$EXAM$MEM; END;
                                @77:
                                ; STATEMENT # 386
0177 C6066000FF  MOV     WORDMODE,OFFH
                                ; STATEMENT # 387
                                @19:
017C E86106      CALL    KBEXAMMEM
                                ; STATEMENT # 388
017F EB28        JMP     AFTERCOMMAND
389  2          DO; WORD$MODE = TRUE; CALL KB$INPUT; END;
                                @78:
                                ; STATEMENT # 390
0181 C6066000FF  MOV     WORDMODE,OFFH
                                ; STATEMENT # 391
                                @21:
0186 E80909      CALL    KBINPUT
                                ; STATEMENT # 392
0189 EB1E        JMP     AFTERCOMMAND
393  2          DO; WORD$MODE = TRUE; CALL KB$OUTPUT; END;
                                @79:
                                ; STATEMENT # 394
018B C6066000FF  MOV     WORDMODE,OFFH
                                ; STATEMENT # 395
                                @25:
0190 E85D09      CALL    KBOUTPUT
                                ; STATEMENT # 396
0193 EB14        JMP     AFTERCOMMAND
397  2          END;
                                ; STATEMENT # 397
                                @102:
0195 7C01        DW     @19
0197 6301        DW     @71
0199 6801        DW     @72
019B 6D01        DW     @73
019D 8601        DW     @21
019F 9001        DW     @25
01A1 7201        DW     @76
01A3 7701        DW     @77
01A5 8101        DW     @78
01A7 8B01        DW     @79
398  1          AFTER$COMMAND:
                                ; STATEMENT # 398

```

```

                                AFTERCOMMAND:
01A9 BC5000      MOV      SP,@@STACK$OFFSET
01AC 8BEC       MOV      BP,SP
01AE 2E8E1E9A00 MOV      DS,CS:@DATA$FRAME
01B3 B000       MOV      AL,0H
01B5 50        PUSH     AX          ; 1
01B6 E8EE00     CALL    KBBLANKDATAFIELD
                                CALL KB$BLANK$DATA$FIELD(0);
399  1          GOTO    NEXT$COMMAND;
                                ; STATEMENT # 399
01B9 E96CFF     JMP      NEXTCOMMAND

400  1          ERROR:
                                ; STATEMENT # 400
                                /* THIS ROUTINE HANDLES ALL ERRORS DETECTED BY THE MONITOR AND WILL
                                OUTPUT THE ERROR MESSAGE TO THE DISPLAY AND THEN JUMP TO
                                'AFTER$ERROR' TO GET ANOTHER COMMAND. */
                                ERROR:
01BC BC5000      MOV      SP,@@STACK$OFFSET
01BF 8BEC       MOV      BP,SP
01C1 2E8E1E9A00 MOV      DS,CS:@DATA$FRAME
01C6 2E8D062B00 LEA     AX,CS:KBERRMSG
01CB 0E        PUSH     CS          ; 1
01CC 50        PUSH     AX          ; 2
01CD B001       MOV      AL,1H
01CF 50        PUSH     AX          ; 3
01D0 B000       MOV      AL,0H
01D2 50        PUSH     AX          ; 4
01D3 E87B00     CALL    KBDISPLAY
                                CALL KB$DISPLAY(@KB$ERR$MSG,ADDR$FIELD,0);
401  1          CALL    KB$BLANK$DATA$FIELD(0);
                                ; STATEMENT # 401
01D6 B000       MOV      AL,0H
01D8 50        PUSH     AX          ; 1
01D9 E8CB00     CALL    KBBLANKDATAFIELD
402  1          GOTO    AFTER$ERROR;
                                ; STATEMENT # 402
01DC E959FF     JMP      AFTERERROR

403  1          AFTER$INTERRUPT:
                                ; STATEMENT # 403
                                /* THIS ROUTINE CHECKS FOR THE LAST COMMAND WHEN THE MONITOR IS
                                REENTERED VIA THE INTERRUPT VECTOR. */
                                AFTERINTERRUPT:
01DF BC5000      MOV      SP,@@STACK$OFFSET
01E2 8BEC       MOV      BP,SP
01E4 2E8E1E9A00 MOV      DS,CS:@DATA$FRAME
01E9 A05800     MOV      AL,BRK1$FLAG
01EC D0D8       RCR      AL,1
                                @27:
01EE 73B9       JNB     AFTERCOMMAND
                                IF BRK1$FLAG THEN
404  1          DO;
405  2          MEMORY$BRK1 = BRK1$SAVE;
                                ; STATEMENT # 405

```

```

01F0 A05900      MOV     AL, BRK1SAVE
01F3 C41E2200    LES     BX, MEMORYBRK1PTR
01F7 268807      MOV     ES:MEMORYBRK1[BX], AL
406  2          BRK1$FLAG = FALSE;
                                ; STATEMENT # 406
01FA C606580000  MOV     BRK1FLAG, 0H
407  2          IF ((IP-1) AND 000FH)=(BRK1.OFF AND 000FH) AND
                                ; STATEMENT # 407
01FF A14600      MOV     AX, REGSAV+18H
0202 83E801      SUB     AX, 1H
0205 50          PUSH    AX          ; 1
0206 250F00      AND     AX, 0FH
0209 8B0E2200    MOV     CX, BRK1
020D 51          PUSH    CX          ; 2
020E 81E10F00    AND     CX, 0FH
0212 3BC1        CMP     AX, CX
0214 B0FF        MOV     AL, 0FFH
0216 7401        JZ     $+3H
0218 40          INC     AX
0219 5A          POP     DX          ; 2
021A 8756FE      XCHG   DX, [BP]-2H; 1
021D B104        MOV     CL, 4H
021F D3EA        SHR     DX, CL
0221 03163E00    ADD     DX, REGSAV+10H
0225 5B          POP     BX          ; 1
0226 D3EB        SHR     BX, CL
0228 031E2400    ADD     BX, BRK1+2H
022C 50          PUSH    AX          ; 1
022D 3BD3        CMP     DX, BX
022F B0FF        MOV     AL, 0FFH
0231 7401        JZ     $+3H
0233 40          INC     AX
0234 59          POP     CX          ; 1
0235 22C1        AND     AL, CL
0237 D0D8        RCR     AL, 1
0239 73B3        JNB    @27
                                (SHR(IP-1,4)+CS)=(SHR(BRK1.OFF,4)+BRK1.SEG) THEN
408  2          DO;
409  3          IP = IP - 1;
                                ; STATEMENT # 409
023B 832E460001  SUB     REGSAV+18H, 1H
410  3          CALL  KB$DISPLAY(@KB$BRK1, DATA$FIELD, 0);
                                ; STATEMENT # 410
0240 2E8D063300  LEA    AX, CS:KBBRK1
0245 0E          PUSH    CS          ; 1
0246 50          PUSH    AX          ; 2
0247 B000        MOV     AL, 0H
0249 50          PUSH    AX          ; 3
024A 50          PUSH    AX          ; 4
024B E80300      CALL   KBDISPLAY
411  3          GOTO  NEXT$COMMAND;
                                ; STATEMENT # 411
024E E9D7FE      JMP     NEXTCOMMAND
412  3          END;
413  2          END;
414  1          GOTO  AFTER$COMMAND;

```

415    1            END MONITOR;    /\* END OF MODULE \*/  
         EOF



## CROSS-REFERENCE LISTING

```

-----
DEFN  ADDR  SIZE  NAME, ATTRIBUTES, AND REFERENCES
-----
      6          ADDRFIELD          LITERALLY
          16  32  108  113  119  205  229  272  295
          318  319  334  337  359  370  400
398  01A9H      AFTERCOMMAND      LABEL
          172  414
371  0138H      AFTERERROR        LABEL
          369  402
403  01DFH      AFTERINTERRUPT     LABEL
          180
106  0000H      4  ARG          STRUCTURE BASED(PTR)
          107  108  112  113
      9  001AH      4  ARG1        STRUCTURE AT
          225  229  257  258  290  296  302  308  310
      9  001EH      4  ARG3        STRUCTURE AT
          302  311
34   0006H      1  B          BYTE PARAMETER AUTOMATIC
          35   37   38
      6          BLANK          LITERALLY
          46  108  113  119  229  295  318  319  334
          337
62   0004H      1  BLANKING   BYTE PARAMETER AUTOMATIC
          63   76   87   96
41   0004H      1  BLANKING   BYTE PARAMETER AUTOMATIC
          42   46
13   FHFFF6H    2  BLOCK8089  WORD AT INITIAL ABSOLUTE
13   FHFFF8H    4  BLOCK8089PTR  POINTER AT INITIAL ABSOLUTE
11   FHFFF0H    1  BOOT1      BYTE ARRAY(1) AT INITIAL ABSOLUTE
11   FHFFF1H    2  BOOT2      WORD ARRAY(1) AT INITIAL ABSOLUTE
11   FHFFF3H    2  BOOT3      WORD ARRAY(1) AT INITIAL ABSOLUTE
12   0000H      4  BOOT4      WORD ARRAY(2) DATA
10          BP          LITERALLY
          150

```





				363 364 365
182	0006H	4	INTVECTORPTR	POINTER PARAMETER AUTOMATIC 183 184 185
			INWORD	BUILTIN 323
10			IP	LITERALLY 119 120 215 361 407 409
30	02BEH	23	KBBLANKADDRFIELD	PROCEDURE STACK=0010H 126 191 223 263 288 293 300 316 332 372
26	02A7H	23	KBBLANKDATAFIELD	PROCEDURE STACK=0010H 127 192 206 338 350 373 398 401
7	0037H	4	KBBLANKS	BYTE ARRAY(4) DATA 28 32
7	0033H	4	KBBRK1	BYTE ARRAY(4) DATA 410
7	001BH	4	KBCMNDPMT	BYTE ARRAY(4) DATA 370
8			KBCOL	LITERALLY 97 109 114 343
8			KBCOM	LITERALLY 97 124 163 189 214 226 236 240 248 275 278 291 298 320 335 348
7			KBDATAPORT	LITERALLY 23 60
14	0251H	86	KBDISPLAY	PROCEDURE STACK=000AH 28 32 39 54 69 205 272 359 360 370 400 410
7	002BH	4	KBERRMSG	BYTE ARRAY(4) DATA 400
221	07E0H	291	KBEXAMMEM	PROCEDURE STACK=0030H 378 387
261	0903H	226	KBEXAMREG	PROCEDURE STACK=0024H 379
7	002FH	4	KBEXEC	BYTE ARRAY(4) DATA 205
105	0501H	79	KBGETADDR	PROCEDURE STACK=002CH 128 194 225 290 302
56	039BH	26	KBGETCHAR	PROCEDURE STACK=0002H



212	07B9H	39	KBSINGLESTEP	PROCEDURE STACK=0034H 381
7			KBSTATPORT	LITERALLY 17 18 57 59 357 358
118	0550H	101	KBUPDATEIP	PROCEDURE STACK=0030H 162 188 213
7	0023H	4	KBVERSION	BYTE ARRAY(4) DATA 360
5	0061H	1	LASTCOMMAND	BYTE 160 374
7	003BH	16	LED	BYTE ARRAY(16) DATA 37 38 44
305	0A5AH		LOOP	LABEL 312
340	0B28H		LOOP	LABEL 353
320	0AB7H		LOOP	LABEL 328
			LOW	BUILTIN 75 86 95 250 251 347
9	0000H	1	MEMORYARG1	BYTE BASED(MEMORYARG1PTR) 232 250 251 305 306
9	001AH	4	MEMORYARG1PTR	POINTER 9 231 232 242 243 250 251 305 306
9	0000H	1	MEMORYARG3	BYTE BASED(MEMORYARG3PTR) 305 306
9	001EH	4	MEMORYARG3PTR	POINTER 9 305 306
9	0000H	1	MEMORYBRK1	BYTE BASED(MEMORYBRK1PTR) 197 198 199 405
9	0022H	4	MEMORYBRK1PTR	POINTER 9 197 198 199 405
9	0000H	1	MEMORYCSIP	BYTE BASED(MEMORYCSIPPTR) 122
9	0026H	4	MEMORYCSIPPTR	POINTER 9 122
9	0000H	2	MEMORYUSERSTACK	WORD BASED(MEMORYUSERSTACKPTR) 132 135 147 150

9	002AH	4	MEMORYUSERSTACKPTR	POINTER 9 132 135 147 150
9	0000H	2	MEMORYWORDARG1	WORD BASED(MEMORYARG1PTR) 231 242 243
1	009CH	437	MONITOR	PROCEDURE STACK=0050H
3	0016H	2	MONITORSTACKBASE	WORD 157 178 367
3	0014H	2	MONITORSTACKPTR	WORD 156 177 368
370	0128H		NEXTCOMMAND	LABEL 399 411
6			NOBLANK	LITERALLY 231 239 247 273 277 323 341 342
9	0000H	2	OFF	WORD MEMBER(USERSTACK) 133 136 139 144 146 149 151 154 175
9	0000H	2	OFF	WORD MEMBER(CSIP) 120 165 207 216
9	0000H	2	OFF	WORD MEMBER(BRK1) 407
9	0000H	2	OFF	WORD MEMBER(ARG3) 311
9	0000H	2	OFF	WORD MEMBER(ARG1) 229 257 258 296 308 310
183	0000H	2	OFF	WORD MEMBER(VECTOR) 185
106	0000H	2	OFF	WORD MEMBER(ARG) 108 112 113
63	0063H	1	OPER	BYTE 64 91 100
			OUTPUT	BUILTIN 17 18 23 59 347 357 358
			OUTWORD	BUILTIN 346
331	0056H	2	PORT	WORD 334 337 346 347
315	0052H	2	PORT	WORD 318 319 323 324
105	0004H	1	PROMPTS	BYTE PARAMETER AUTOMATIC





				121	166	194	208	217		
9	0002H	2	SEG	WORD MEMBER(BRK1)						
				407						
9	0002H	2	SEG	WORD MEMBER(ARG3)						
9	0002H	2	SEG	WORD MEMBER(ARG1)						
				302						
183	0002H	2	SEG	WORD MEMBER(VECTOR)						
				184						
106	0002H	2	SEG	WORD MEMBER(ARG)						
				107 112						
			SHL	BUILTIN						
				84						
			SHR	BUILTIN						
				37 44 407						
10			SP	LITERALLY						
				144						
10			SS	LITERALLY						
				143 361						
6			SSCOMMAND	LITERALLY						
				160						
			STACKBASE	BUILTIN						
				155 157 176 178 367						
			STACKPTR	BUILTIN						
				154 156 175 177 368						
11			STARTADDR	LITERALLY						
				11 12						
6			STEPTRAP	LITERALLY						
				159 167 209 218						
15	0062H	1	T	BYTE						
				20 22 23						
6			TRUE	LITERALLY						
				66 201 228 268 386 390 394						
6			USERINITSP	LITERALLY						
				362						
9	002AH	4	USERSTACK	STRUCTURE AT						
				133 136 138 139 143 144 146 149 151						
				154 155 175 176						
183	0000H	4	VECTOR	STRUCTURE BASED(INTVECTORPTR)						

				184	185														
222	004EH	2	W	WORD															
				239	242	243	247	250	251										
63	004CH	2	W	WORD															
				65	92	93	95	96	98										
41	000AH	2	W	WORD	PARAMETER	AUTOMATIC													
				42	44														
5	0060H	1	WORDMODE	BYTE															
				230	237	256	322	340	345	376	386	390							
				394															

MODULE INFORMATION:

CODE AREA SIZE        = 0B82H    2946D  
 CONSTANT AREA SIZE = 0000H     0D  
 VARIABLE AREA SIZE = 0065H    101D  
 MAXIMUM STACK SIZE = 0050H     80D  
 865 LINES READ  
 0 PROGRAM ERROR(S)

END OF PL/M-86 COMPILATION



# SDK-86 SERIAL MONITOR PL/M-86 SOURCE LISTING

ISIS-II PL/M-86 V1.1 COMPILATION OF MODULE MONITOR  
 OBJECT MODULE PLACED IN :F1:SERIAL.OBJ  
 COMPILER INVOKED BY: PLM86 :F1:SERIAL.PLM LARGE OPTIMIZE(2) PAGESWIDTH(95)

```
$TITLE('SDK86 SERIAL MONITOR')
$NOINTVECTOR
```

```
/* *****
*****
```

```
      SDK-86 MONITOR, V1.2
      06 AUGUST 1979
```

```
      (C) 1978 INTEL CORPORATION. ALL RIGHTS RESERVED. NO PART
      OF THIS PROGRAM OR PUBLICATION MAY BE REPRODUCED, TRANSMITTED,
      TRANSCRIBED, STORED IN A RETRIEVAL SYSTEM, OR TRANSLATED INTO ANY
      LANGUAGE, IN ANY FORM OR BY ANY MEANS, ELECTRONIC, MECHANICAL,
      MAGNETIC, OPTICAL, CHEMICAL, MANUAL OR OTHERWISE, WITHOUT THE PRIOR
      WRITTEN PERMISSION OF INTEL CORPORATION, 3065 BOWERS AVENUE, SANTA
      CLARA, CALIFORNIA, 95051.
```

```
*****
*****
```

```
ABSTRACT
=====
```

```
THIS PROGRAM IS THE ROM BASED SERIAL MONITOR FOR THE SDK-86. IT
PROVIDES THE USER WITH A MODERATE LEVEL OF CAPABILITY TO
EXAMINE/MODIFY MEMORY AND REGISTERS, CONTROL PROGRAM EXECUTION,
AND LOAD/SAVE PROGRAMS.
```

```
ENVIRONMENT
=====
```

```
THE SDK SERIAL MONITOR COMMUNICATES WITH THE USER VIA AN INTERACTIVE
TERMINAL (TTY,CRT) ATTACHED TO THE SERIAL PORT.
```

```
PROGRAM ORGANIZATION
=====
```

```
THE PROGRAM IS DIVIDED INTO 1 DATA AND 2 CODE MODULES:
  1. DATA DECLARATION MODULE.      GLOBAL DATA DECLARATIONS.
  2. COMMON ROUTINES.                LOWER LEVEL PROCEDURES
  3. COMMAND MODULE.                 INDIVIDUAL COMMANDS AND OUTER BLOCK
```

```
CALLING GRAPH
=====
```

```
>>COMMAND DISPATCH MODULE (OUTER BLOCK)
      INDIVIDUAL COMMAND PROCEDURES
      COMMON ROUTINES
```

```
GLOBAL DATA STRUCTURES
=====
```

```
THE MONITOR MAINTAINS THE USER'S MACHINE STATE (REGISTERS) IN A
WORD ARRAY. THE REGISTERS ARE SAVED FROM THE USER'S STACK
AS PUSHED BY PLM86 INTERRUPT PROCEDURE.
POINTERS TO THE SDK-86 2**20 ADDRESS SPACE ARE IMPLEMENTED WITH
```

POINTER STRUCTURES ALLOCATED AS 2 WORD STRUCTURES.

\*/

1 MONITOR:DO; /\* BEGINNING OF MODULE \*/

/\* \*\*\*\*\*  
 \*\*\*\*\*

GLOBAL DATA DECLARATIONS MODULE  
 =====

ABSTRACT

=====

THIS MODULE CONTAINS ALL THE GLOBAL DATA DECLARATIONS AND LITERALS (EQUATES).

MODULE ORGANIZATION

=====

THE MODULE IS DIVIDED INTO 5 SECTIONS:

- |                              |                                     |
|------------------------------|-------------------------------------|
| 1. UTILITY SECTION           | GLOBAL FLAGS, VARIABLES, EQUATES    |
| 2. I/O SECTION               | I/O PORTS, MASKS, AND SPECIAL CHARS |
| 3. MEMORY ARGUMENTS SECTIONS | STRUCTURES FOR POINTERS             |
| 4. REGISTER SECTION          | USER REGISTER SAVE AREA             |
| 5. BOOT AND 8089 SECTION.    | BOOTSTRAP AND 8089 DESCRIPTOR       |

\*/

/\* \*\*\*\*\*  
 \* UTILITY SECTION \*  
 \*\*\*\*\*/

2 1 DECLARE INT\$VECTOR(5) POINTER; /\* INTERRUPT VECTORS \*/

3 1 DECLARE MONITOR\$STACKPTR WORD,  
 MONITOR\$STACKBASE WORD;

4 1 DECLARE COPYRIGHT(\*) BYTE DATA ('(C) 1978 INTEL CORP');

5 1 DECLARE BRK1\$FLAG BYTE, /\* TRUE IF BREAK SET \*/  
 BRK1\$SAVE BYTE, /\* INST BREAK SAVE \*/  
 CHAR BYTE, /\* ONE CHAR LOOK AHEAD \*/  
 CHECK\$SUM BYTE, /\* PAPER TAPE CHECKSUM \*/  
 I BYTE, /\* INDEX \*/  
 END\$OFF WORD, /\* END OFFSET ADDRESS \*/  
 WORD\$MODE BYTE, /\* WORD MODE FLAG \*/  
 LAST\$COMMAND BYTE; /\* LAST COMMAND SAVE \*/

6 1 DECLARE TRUE LITERALLY 'OFFH',  
 FALSE LITERALLY '000H',  
 BREAK\$INST LITERALLY 'OCCH', /\* BREAKPOINT INST \*/  
 STEP\$TRAP LITERALLY '0100H', /\* SS TRAP FLAG MASK \*/  
 USER\$INIT\$SP LITERALLY '100H', /\* USER STACK INITIAL \*/  
 GO\$COMMAND LITERALLY '2', /\* GO COMMAND CODE \*/  
 SS\$COMMAND LITERALLY '3', /\* SINGLE STEP CODE \*/  
 STANDARD\$LEN LITERALLY '16', /\* PAPER TAPE DATA REC LEN \*/  
 MAX\$DELAY LITERALLY '10000'; /\* DELAY FOR PAPER TAPE \*/

7 1 DECLARE

```

        KB$SIGNON(*)      BYTE DATA (5BH,86H,00H,00H,7DH,7FH,00H,00H),
                          /* " 2 1.        6 8 " */
        SIO$BREAK$MSG(*)  BYTE DATA ('BR ',0),
        SIO$SIGNON(*)     BYTE DATA (0DH,0AH,'SDK-86 MONITOR, V1.2',0),
        ASCII(*)         BYTE DATA ('0123456789ABCDEF'),
        SIO$CMND(*)       BYTE DATA ('SXGNMDIORW');

/*****
*   I/O DECLARATIONS SECTION
*****/

8 1  DECLARE
        SIO$STAT$PORT    LITERALLY 'OFFF2H', /* 8251 USART */
        SIO$DATA$PORT    LITERALLY 'OFFFOH', /* STATUS INPUT PORT */
        SIO$8251$RESET   LITERALLY '065H', /* DATA INPUT PORT */
        SIO$8251$MODE    LITERALLY 'OCFH', /* RESET COMMAND */
        SIO$8251$CMND    LITERALLY '025H', /* ASYNC MODE */
        SIO$8251$DTR$ON  LITERALLY '027H', /* DTR OFF */
        SIO$DSRDY        LITERALLY '80H', /* SAME AS CMND BUT DTR ON */
        SIO$RXRDY        LITERALLY '02H', /* DATA SET READY */
        SIO$TXRDY        LITERALLY '01H', /* RECEIVE DATA READY */
                          /* XMIT BUFFER EMPTY */

9 1  DECLARE
        KB$STAT$PORT     LITERALLY 'OFFFEAH', /* STATUS/COMMAND PORT */
        KB$DATA$PORT     LITERALLY 'OFFFE8H', /* DATA PORT */
        KB$INIT$MODE     LITERALLY '00H', /* 8 8-BIT, LEFT ENTRY,
        KB$INIT$SCAN     LITERALLY '39H'; /* ENCODE, 2 KEY LOCKOUT */
                          /* 10MS SCAN RATE */

10 1 DECLARE
        ASCR             LITERALLY '0DH', /* CARRIAGE RETURN */
        ASLF             LITERALLY '0AH', /* LINE FEED */
        ASBL             LITERALLY '20H', /* BLANK OR SPACE */

/*****
*   MEMORY ARGUMENT SECTION
*****/

11 1 DECLARE
        MEMORY$ARG1$PTR  POINTER, /* ARGUMENT 1 */
        ARG1 STRUCTURE (OFF WORD, SEG WORD)
        AT (@MEMORY$ARG1$PTR),
        MEMORY$ARG1 BASED MEMORY$ARG1$PTR BYTE,
        MEMORY$WORD$ARG1 BASED MEMORY$ARG1$PTR WORD,

        MEMORY$ARG3$PTR  POINTER, /* ARGUMENT 3 */
        ARG3 STRUCTURE (OFF WORD, SEG WORD)
        AT (@MEMORY$ARG3$PTR),
        MEMORY$ARG3 BASED MEMORY$ARG3$PTR BYTE,

        MEMORY$BRK1$PTR  POINTER, /* BREAKPOINT 1 */
        BRK1 STRUCTURE (OFF WORD, SEG WORD)
        AT (@MEMORY$BRK1$PTR),
        MEMORY$BRK1 BASED MEMORY$BRK1$PTR BYTE,

        MEMORY$CSIP$PTR  POINTER, /* CS & IP WORD */
        CSIP STRUCTURE (OFF WORD, SEG WORD)
        AT (@MEMORY$CSIP$PTR),
        MEMORY$CSIP BASED MEMORY$CSIP$PTR BYTE,

```

```

MEMORY$USERSTACK$PTR POINTER,
USERSTACK STRUCTURE (OFF WORD, SEG WORD)
  AT (@MEMORY$USERSTACK$PTR),
MEMORY$USERSTACK BASED MEMORY$USERSTACK$PTR WORD;

```

```

/*****
* REGISTER SECTION *
*****/

```

```

12 1 DECLARE
REG(*) BYTE DATA /* REGISTER NAMES */
('AXBXCXDXSPBPSIDICSDSSSESIPFL'),
REG$INDEX WORD,
REG$SAV(14) WORD, /* USER'S SAVED REGS */
REG$ORD(*) BYTE DATA
(7,6,1,3,2,0,9,11,12,8,13),
SP LITERALLY 'REG$SAV( 4)',
BP LITERALLY 'REG$SAV( 5)',
CS LITERALLY 'REG$SAV( 8)',
DS LITERALLY 'REG$SAV( 9)',
SS LITERALLY 'REG$SAV(10)',
ES LITERALLY 'REG$SAV(11)',
IP LITERALLY 'REG$SAV(12)',
FL LITERALLY 'REG$SAV(13)';

```

```

/*****
* BOOTSTRAP JUMP AND 8089 VECTOR *
*****/

```

```

/* THIS BOOT CONSISTS OF A LONG JUMP TO THE BEGINNING OF THE MONITOR
AT FFO0+XXXX WHERE XXXX IS THE STARTING ADDRESS OFFSET (IP) AND
MUST BE DETERMINED AFTER EACH COMPILE. */

```

```

13 1 DECLARE
START$ADDR LITERALLY '00A8H', /* STARTING ADDRESS */
BOOT1(*) BYTE AT (OFFF0H) DATA (0EAH), /* LONG JUMP OPCODE */
BOOT2(*) WORD AT (OFFF1H) DATA (START$ADDR),
BOOT3(*) WORD AT (OFFF3H) DATA (OFF00H); /* SEGMENT ADDRESS! */

```

```

/* THIS TWO-WORD DATA IS A JUMP TO THE STARTING ADDRESS AND IS LOCATED
AT THE FIRST LOCATION OF ROM (NO OTHER DATA OR CONSTANT DECLARATIONS
MAY PRECEDE IT). THE JUMP IS ACTUALLY TO (START-ADDR)-4 SINCE THE
INSTRUCTION IS A RELATIVE JUMP OF LENGTH 3. */

```

```

14 1 DECLARE
BOOT4(*) WORD DATA (0E990H,START$ADDR-4); /* NOP,JMP START-ADDR */

```

```

/* THIS BLOCK OF ROM AT FFFF6-FFFFA IS INITIALIZED FOR THE 8089
DEVICE AND POINTS TO A BLOCK OF RAM AT 0100H. */

```

```

15 1 DECLARE
BLOCK$8089 WORD AT (OFFF6H) DATA (00001H),
BLOCK$8089$PTR POINTER AT (OFFF8H) DATA (00100H);

```

```

/*****
* FILL DECLARATIONS SECTION *
*****/

```

```

/* THESE DECLARATIONS DEFINE FILL CHARACTERS FOR ALL UNUSED
LOCATIONS IN THE ROM ADDRESS SPACE. ANY MODIFICATION TO THE CODE
THAT CHANGES THE USED LOCATIONS IN THE ROM REQUIRES
MODIFICATION OF THIS SECTION. */

```

```

16 1 DECLARE

```

```

F          LITERALLY 'OFFH',
FILL1(*)  BYTE AT (OFFFDBH) DATA (F,F,F,F,F),
FILL2(*)  BYTE AT (OFFFE0H) DATA (F,F,F,F,F,F,F,F,F,F,F,F,F,F,F),
FILL3(*)  BYTE AT (OFFFF5H) DATA (F),
FILL4(*)  BYTE AT (OFFFFCH) DATA (F,F,F,F);

```

```

/* *****
*****

```

#### COMMON PROCEDURES

```

=====

```

#### ABSTRACT

```

=====

```

THIS MODULE CONTAINS THOSE LOWER LEVEL PROCEDURES CALLED BY HIGHER LEVEL ROUTINES.

#### MODULE ORGANIZATION

```

=====

```

THIS MODULE IS DIVIDED INTO 4 SECTIONS AS FOLLOWS:

1. BASIC I/O SECTION
  - SIO\$CHAR\$RDY            INPUT CHARACTER READY
  - SIO\$CHECK\$CONTROL\$CHAR    CHECK FOR CONTROL CHARACTER
  - SIO\$OUT\$CHAR            OUTPUT CHARACTER
  - SIO\$GET\$CHAR            INPUT A CHARACTER
  - SIO\$OUT\$BYTE            OUTPUT A BYTE IN HEX
  - SIO\$OUT\$WORD            OUTPUT A WORD IN HEX
  - SIO\$OUT\$BLANK           OUTPUT A SINGLE BLANK
  - SIO\$OUT\$STRING          OUTPUT A STRING
  - SIO\$OUT\$HEADER          OUTPUT A PAPER TAPE HEADER
2. UTILITY ROUTINES SECTION
  - SIO\$VALID\$HEX           TEST FOR VALID HEX CHAR
  - SIO\$HEX                 CONVERT TO HEX FROM ASCII
  - SIO\$VALID\$REG\$FIRST     TEST FOR VALID REGISTER FIRST CHAR
  - SIO\$VALID\$REG           TEST FOR VALID REGISTER NAME
  - SIO\$CRLF                OUTPUTS A CR AND LF
  - SIO\$TEST\$WORD\$MODE     TEST FOR A 'W' IN COMMAND
  - SIO\$SCAN\$BLANK          SCANS FOR OPTIONAL BLANK
3. ARGUMENT EXPRESSION EVALUATION SECTION
  - SIO\$GET\$WORD            GET AN WORD EXPRESSION
  - SIO\$GET\$ADDR            GET AN ADDRESS EXPRESSION
  - SIO\$UPDATE\$IP           OPTIONAL UPDATE OF CS:IP
4. PAPER TAPE READ SECTION
  - SIO\$READ\$CHAR           READ CHAR FROM TTY READER
  - SIO\$READ\$BYTE           READ A BYTE
  - SIO\$READ\$WORD           READ A WORD
5. INTERRUPT AND RESTORE/EXECUTE ROUTINES
  - SAVE\$REGISTERS          SAVES USER REGISTERS
  - RESTORE\$EXECUTE         RESTORE MACHINE STATE AND EXEC
  - INTERRUPT1\$ENTRY        INTERRUPT ROUTINE FOR SINGLE STEP

```

        INTERRUPT3$ENTRY      INTERRUPT ROUTINE FOR GO
        INIT$INT$VECTOR      INITIALIZES INTERRUPT VECTORS
    */

    /******
     *   BASIC I/O SECTION   *
     ******/

17  1  SIO$CHAR$RDY:
    /* TESTS FOR INPUT CHARACTER PENDING BY READING THE STATUS PORT
    AND MASKING WITH SIO$RXRDY(READ DATA READY). RETURNS TRUE IF
    NOT EMPTY(CHAR PENDING) AND FALSE IF NO CHAR PENDING */
18  2  PROCEDURE BYTE;
20  2  IF (INPUT(SIO$STAT$PORT) AND SIO$RXRDY)=0 THEN RETURN FALSE;
21  2  RETURN TRUE;
    END;

22  1  SIO$CHECK$CONTROL$CHAR:
    /* THIS ROUTINE CHECKS IF A CONTROL CHARACTER HAS BEEN INPUT TO
    THE SERIAL PORT. AFTER A CONTROL-S IT WAITS FOR A CONTROL-Q BEFORE
    RETURNING TO THE CALLER. A CONTROL-C CAUSES A JUMP TO THE ERROR
    ROUTINE. */
    PROCEDURE;
23  2  CHAR = INPUT(SIO$DATA$PORT) AND 07FH;
24  2  IF CHAR=13H THEN /* CONTROL-S ? */
25  2  DO WHILE CHAR<>11H; /* CONTROL-Q */
26  3  IF SIO$CHAR$RDY THEN
27  3  DO;
28  4  CHAR = INPUT(SIO$DATA$PORT) AND 07FH;
29  4  IF CHAR=03H THEN GOTO ERROR;
31  4  END;
32  3  END;
33  2  ELSE IF CHAR = 03H THEN GOTO ERROR;
    END SIO$CHECK$CONTROL$CHAR;

36  1  SIO$OUT$CHAR:
    /* THIS ROUTINE OUTPUTS THE INPUT PARAMETER TO THE USART OUTPUT
    PORT WHEN USART IS READY FOR OUTPUT (XMIT BUFFER EMPTY). */
    PROCEDURE(C);
37  2  DECLARE C BYTE;
38  2  IF SIO$CHAR$RDY THEN CALL SIO$CHECK$CONTROL$CHAR;
40  2  DO WHILE (INPUT(SIO$STAT$PORT) AND SIO$TXRDY)=0;END;
42  2  OUTPUT(SIO$DATA$PORT) = C;
43  2  END;

44  1  SIO$GET$CHAR:
    /* THIS ROUTINE INPUTS A CHARACTER FROM THE INPUT PORT AND RETURNS
    WITH IT IN THE GLOBAL 'CHAR'. THE CHARACTER IS ECHOED TO THE
    OUTPUT PORT IF PRINTABLE. */
    PROCEDURE;
45  2  DO WHILE (INPUT(SIO$STAT$PORT) AND SIO$RXRDY)=0;END;
47  2  CHAR = INPUT(SIO$DATA$PORT) AND 07FH;
48  2  IF CHAR>=ASBL THEN CALL SIO$OUT$CHAR(CHAR);
50  2  END;

51  1  SIO$OUT$BYTE:
    /* THIS ROUTINE OUTPUTS THE SINGLE INPUT PARAMETER TO THE USART

```



```

                IN ASCII HEXADECIMAL FORMAT. */
PROCEDURE(B);
52  2      DECLARE B BYTE;
53  2      CALL SIO$OUT$CHAR(ASCII(SHR(B,4) AND OFH));
54  2      CALL SIO$OUT$CHAR(ASCII(B AND OFH));
55  2      CHECK$SUM = CHECK$SUM - B;
56  2      END;

57  1      SIO$OUT$WORD:
          /* THIS ROUTINE OUTPUTS THE INPUT PARAMETER AS 4 ASCII HEXADECIMAL
          CHARACTERS TO THE USART OUTPUT PORT. */
          PROCEDURE(W);
58  2          DECLARE W WORD;
59  2          CALL SIO$OUT$BYTE(HIGH(W));
60  2          CALL SIO$OUT$BYTE(LOW(W));
61  2          END;

62  1      SIO$OUT$BLANK:
          /* THIS ROUTINE OUTPUTS ONE BLANK. */
          PROCEDURE;
63  2          CALL SIO$OUT$CHAR(ASBL);
64  2          END;

65  1      SIO$OUT$STRING:
          /* OUTPUTS A STRING POINTED TO BY THE FIRST PARM. */
          PROCEDURE(PTR);
66  2          DECLARE PTR POINTER, STR BASED PTR (1) BYTE;
67  2          I = 0;
68  2          DO WHILE STR(I)<>0;
69  3              CALL SIO$OUT$CHAR(STR(I));
70  3              I = I + 1;
71  3          END;
72  2          END;

73  1      SIO$OUT$HEADER:
          /* THIS ROUTINE OUTPUTS THE PAPER TAPE HEADER CONSISTING OF ':'
          FOLLOWED BY THE RECORD LENGTH, LOAD ADDRESS, AND THE RECORD TYPE.
          IT INITIALIZES THE CHECKSUM TO ZERO. */
          PROCEDURE(LENGTH,LOAD$ADDR,REC$TYPE);
74  2          DECLARE (LENGTH,REC$TYPE) BYTE, LOAD$ADDR WORD;
75  2          CALL SIO$OUT$CHAR(':');
76  2          CHECK$SUM = 0;
77  2          CALL SIO$OUT$BYTE(LENGTH);
78  2          CALL SIO$OUT$WORD(LOAD$ADDR);
79  2          CALL SIO$OUT$BYTE(REC$TYPE);
80  2          END;

81  1      SIO$8251$SETTLING$DELAY:
          /* THIS DELAY ROUTINE ALLOWS THE USART SUFFICIENT TIME
          TO SETTLE AFTER WRITE OPERATIONS. */
          PROCEDURE;
82  2          I = SHR(OFFH,OFFH);
83  2          END;

```

```

/*****
*   UTILITY ROUTINES SECTION   *

```

```
*****/
84 1 SIO$VALID$HEX:
    /* THIS ROUTINE TESTS IF THE INPUT PARM IS A VALID ASCII HEX DIGIT
    AND RETURNS TRUE AS THE VALUE OF THE PROCEDURE IF SO AND FALSE
    IF NOT. */
    PROCEDURE (H) BYTE;
85 2     DECLARE H BYTE;
86 2     DO I=0 TO LAST(ASCII);
87 3     IF H=ASCII(I) THEN RETURN TRUE;
89 3     END;
90 2     RETURN FALSE;
91 2     END;

92 1 SIO$HEX:
    /* THIS ROUTINE CONVERTS THE INPUT PARM FROM ASCII TO ITS BINARY
    EQUIVALENT AND RETURNS IT AS THE VALUE OF THE PROCEDURE. NO CHECK
    IS MADE FOR INPUT VALIDITY. */
    PROCEDURE (C) WORD;
93 2     DECLARE C BYTE;
94 2     IF C<='9' THEN RETURN DOUBLE(C-30H);
96 2     ELSE RETURN DOUBLE(C-37H);
97 2     END;

98 1 SIO$VALID$REG$FIRST:
    /* THIS ROUTINE CHECKS IF 'CHAR' IS A VALID FIRST LETTER OF A REGISTER
    NAME AND RETURNS TRUE AS THE VALUE OF THE PROCEDURE IF SO. */
    PROCEDURE BYTE;
99 2     DO I=0 TO 26 BY 2;
100 3     IF CHAR=REG(I) THEN RETURN TRUE;
102 3     END;
103 2     RETURN FALSE;
104 2     END;

105 1 SIO$VALID$REG:
    /* THIS ROUTINE CHECKS IF THE TWO INPUT PARMS TAKEN TOGETHER FORM
    A VALID REGISTER NAME. IT SEARCHES THE REGISTER TABLE AND IF A
    MATCH IS FOUND, THE GLOBAL 'REG$INDEX' IS SET TO THE INDEX OF THE
    VALID REGISTER AND THE PROCEDURE RETURNS TRUE. IF NO MATCH THE
    PROCEDURE RETURNS FALSE AND REG$INDEX IS UNDEFINED. */
    PROCEDURE (C1,C2) BYTE;
106 2     DECLARE (C1,C2) BYTE;
107 2     DO REG$INDEX=0 TO 13;
108 3     IF C1=REG(REG$INDEX*2) AND C2=REG(REG$INDEX*2+1) THEN
109 3         RETURN TRUE;
110 3     END;
111 2     RETURN FALSE;
112 2     END;

113 1 SIO$CRLF:
    /* THIS ROUTINE OUTPUTS A CR AND LF TO THE OUTPUT PORT. */
    PROCEDURE;
114 2     CALL SIO$OUT$CHAR(ASCR);
115 2     CALL SIO$OUT$CHAR(ASLF);
116 2     END;

117 1 SIO$TEST$WORD$MODE:
```

```

/* THIS PROCEDURE TESTS FOR A 'W' FOLLOWING THE COMMAND AND IF SO
SETS THE FLAG 'WORD$MODE' TO TRUE OR FALSE OTHERWISE. SCANS OFF
OPTIONAL BLANK FOLLOWING COMMAND. */
PROCEDURE;
118 2   WORD$MODE = FALSE;
119 2   CALL SIO$GET$CHAR;
120 2   IF CHAR='W' THEN
121 2     DO;
122 3     WORD$MODE = TRUE;
123 3     CALL SIO$GET$CHAR;
124 3     END;
125 2   IF CHAR=ASBL THEN
126 2     CALL SIO$GET$CHAR;
127 2   END;

128 1   SIO$SCAN$BLANK:
/* THIS ROUTINE IS CALLED AFTER A COMMAND LETTER TO SCAN OFF THE
OPTIONAL BLANK. */
PROCEDURE;
129 2   CALL SIO$GET$CHAR;
130 2   IF CHAR=ASBL THEN
131 2     CALL SIO$GET$CHAR;
132 2   END;

/* *****
* ARGUMENT EXPRESSION EVALUATOR SECTION *
***** */

133 1   SIO$GET$WORD:
/* THIS ROUTINE READS CHARS FROM THE INPUT PORT AND EVALUATES
AN EXPRESSION CONSISTING OF '+-' AND OPERANDS OF HEX NUMBERS
AND REGISTER NAMES. */
PROCEDURE WORD;
134 2   DECLARE (SAVE,W) WORD, (OPER,T) BYTE;
135 2   OPER = '+';
136 2   W = 0;
137 2   DO WHILE TRUE;
138 3     T = CHAR;
139 3     SAVE = 0;
140 3     IF SIO$VALID$REG$FIRST THEN
141 3       DO;
142 4       CALL SIO$GET$CHAR;
143 4       IF SIO$VALID$REG(T,CHAR) THEN
144 4         DO;
145 5         SAVE = REG$SAV(REG$INDEX);
146 5         CALL SIO$GET$CHAR;
147 5         GOTO EVAL;
148 5         END;
149 4       ELSE
150 4         SAVE = SIO$HEX(T);
151 3     END;
152 3     IF NOT(SIO$VALID$HEX(T)) THEN GOTO ERROR;
153 3     DO WHILE SIO$VALID$HEX(CHAR);
154 4     SAVE = SHL(SAVE,4) + SIO$HEX(CHAR);
155 4     CALL SIO$GET$CHAR;
156 4     END;

```

```

157 3      EVAL:      IF OPER='+' THEN
158 3          W = W + SAVE;
          ELSE
159 3          W = W - SAVE;
160 3          IF CHAR=ASCR OR CHAR=':' OR CHAR=',' THEN
161 3              RETURN W;
162 3          IF CHAR='+' OR CHAR='-' THEN
163 3              OPER = CHAR;
          ELSE
164 3              GOTO ERROR;
165 3          CALL SIO$GET$CHAR;
166 3      END;
167 2      END;

168 1      SIO$GET$ADDR:
          /* THIS ROUTINE ACCEPTS A VALID ADDRESS EXPRESSION CONSISTING
          OF AN OPTIONAL <SEG>: AND AN DISPLACEMENT. */
          PROCEDURE(PTR,DEFAULT$BASE);
169 2          DECLARE PTR POINTER, DEFAULT$BASE WORD,
          ARG BASED PTR STRUCTURE (OFF WORD, SEG WORD);
170 2          ARG.SEG = DEFAULT$BASE;
171 2          ARG.OFF = SIO$GET$WORD;
172 2          IF CHAR=':' THEN
173 2              DO;
174 3              CALL SIO$GET$CHAR;
175 3              ARG.SEG = ARG.OFF;
176 3              ARG.OFF = SIO$GET$WORD;
177 3              IF CHAR=':' THEN GOTO ERROR;
179 3              END;
180 2          END;

181 1      SIO$UPDATE$IP:
          /* THIS PROCEDURE IS CALLED BY SINGLE STEP AND GO TO OUTPUT THE CURRENT
          IP AND INSTRUCTION BYTE AND OPEN THE IP FOR INPUT. */
          PROCEDURE;
182 2          CALL SIO$OUT$BLANK;
183 2          CALL SIO$OUT$WORD(IP);
184 2          CSIP.SEG = CS;
185 2          CSIP.OFF = IP;
186 2          CALL SIO$OUT$CHAR('-');
187 2          CALL SIO$OUT$BLANK;
188 2          CALL SIO$OUT$BYTE(MEMORY$CSIP);
189 2          CALL SIO$OUT$BLANK;
190 2          CALL SIO$GET$CHAR;
191 2          IF CHAR<>',' AND CHAR<>ASCR THEN CALL SIO$GET$ADDR(@CSIP,CS);
193 2          END;

          /******
          * PAPER TAPE READ SECTION *
          *****/

194 1      SIO$READ$CHAR:
          /* THIS PROCEDURE READS A BYTE FROM THE PAPER TAPE READER OF THE TTY
          BY ACTIVATING DTR, SAMPLING DSR FOR THE START BIT, DEACTIVATING
          DTR WHEN THE START BIT APPEARS, AND READING THE DATUM FROM THE
          USART. TO PROVIDE A HOLD-OFF CAPABILITY FOR THE LOAD COMMAND

```

```

ONLY (NOT INTENDED FOR TTY PAPER TAPE) CONTROL-S WILL CAUSE THIS
ROUTINE TO WAIT FOR A CORRESPONDING CONTROL-Q TO BE READ BEFORE
CONTINUING. */
PROCEDURE BYTE;
  DECLARE DELAY WORD;
195 2
196 2    LOOP:
      OUTPUT(SIO$STAT$PORT) = SIO$8251$DTR$ON;          /* DTR ON */
      DELAY = 0;
      DO WHILE (INPUT(SIO$STAT$PORT) AND SIO$DSRDY)=0; /*WAIT STARTBIT*/
197 2
198 2
199 3        DELAY = DELAY + 1;
200 3        IF DELAY>=MAX$DELAY THEN
201 3            DO;
202 4            OUTPUT(SIO$STAT$PORT) = SIO$8251$CMND;    /* DTR OFF */
203 4            GOTO ERROR;
204 4            END;
205 3        END;
206 2        OUTPUT(SIO$STAT$PORT) = SIO$8251$CMND;        /* DTR OFF */
207 2        DO WHILE (INPUT(SIO$STAT$PORT) AND SIO$RXRDY)=0;END; /* WAIT LOOP */
209 2        CALL SIO$CHECK$CONTROL$CHAR;
210 2        IF CHAR = 11H THEN GOTO LOOP; /* GET ANOTHER IF CTL-Q */
212 2        RETURN CHAR;
213 2    END;

214 1    SIO$READ$BYTE:
      /* THIS ROUTINE READS A BYTE FROM THE PAPER TAPE READER. */
      PROCEDURE BYTE;
      DECLARE T BYTE;
      T = LOW(SIO$HEX(SIO$READ$CHAR));
215 2
216 2      T = SHL(T,4) + LOW(SIO$HEX(SIO$READ$CHAR));
217 2
218 2      CHECK$SUM = CHECK$SUM + T;
219 2      RETURN T;
220 2    END;

221 1    SIO$READ$WORD:
      /* THIS ROUTINE READS A WORD FROM THE PAPER TAPE READER AND RETURNS IT
      AS THE VALUE OF THE PROCEDURE. */
      PROCEDURE WORD;
      DECLARE T BYTE;
      T = SIO$READ$BYTE;
222 2
223 2      RETURN SHL(DOUBLE(T),8) + DOUBLE(SIO$READ$BYTE);
224 2
225 2    END;

      /******
      *   INTERRUPT AND RESTORE/EXECUTE SECTION   *
      /******

226 1    SAVE$REGISTERS:
      /* THIS ROUTINE IS USED TO SAVE THE STACKED USER'S REGISTERS IN THE
      MONITOR'S SAVE AREA. */
      PROCEDURE;
      BP = MEMORY$USERSTACK;
227 2
228 2      USERSTACK.OFF = USERSTACK.OFF + 4;
229 2      DO I=0 TO 10; /* POP REGISTERS OFF OF STACK */
230 3          REG$SAV(REG$ORD(I)) = MEMORY$USERSTACK;
231 3          USERSTACK.OFF = USERSTACK.OFF + 2;
232 3      END;

```

```

233 2      SS = USERSTACK.SEG;
234 2      SP = USERSTACK.OFF;
235 2      END;

236 1      RESTORE$EXECUTE:
          /* THIS PROCEDURE RESTORES THE STATE OF THE USER MACHINE AND
          PASSES CONTROL BACK TO THE USER PROGRAM. IT CONTAINS A
          MACHINE LANGUAGE SUBROUTINE TO PERFORM THE POPPING OF THE
          USER REGISTERS AND TO EXECUTE AN 'IRET' TO TRANSFER CONTROL
          TO THE USER'S PROGRAM. */
          PROCEDURE;
237 2      DECLARE RESTORE$EXECUTE$CODE(*) BYTE DATA
          (08BH,0E3H,          /* MOV BP,SP          */
           08BH,046H,002H,     /* MOV AX,/BP/.PARM2 */
           08BH,05EH,004H,     /* MOV BX,/BP/.PARM1 */
           08EH,0D0H,          /* MOV SS,AX          */
           08BH,0E3H,          /* MOV SP,BX          */
           05DH,               /* POP BP             */
           05FH,               /* POP DI             */
           05EH,               /* POP SI             */
           05BH,               /* POP BX             */
           05AH,               /* POP DX             */
           059H,               /* POP CX             */
           058H,               /* POP AX             */
           01FH,               /* POP DS             */
           007H,               /* POP ES             */
           0CFH),              /* IRET              */
          RESTORE$EXECUTE$CODE$PTR WORD DATA (.RESTORE$EXECUTE$CODE);

238 2      USERSTACK.SEG = SS;
239 2      USERSTACK.OFF = SP;
240 2      DO I=0 TO 10;          /* PUSH USER'S REGISTERS ONTO HIS STACK */
241 3          USERSTACK.OFF = USERSTACK.OFF - 2;
242 3          MEMORY$USERSTACK = REG$SAV(REG$ORD(10-I));
243 3      END;
244 2      USERSTACK.OFF = USERSTACK.OFF - 2;
245 2      MEMORY$USERSTACK = BP;
246 2      CALL RESTORE$EXECUTE$CODE$PTR(USERSTACK.OFF,USERSTACK.SEG);
247 2      END;

248 1      INTERRUPT1$ENTRY:
          /* THIS PROCEDURE IS CALLED WHEN THE CPU IS INTERRUPTED BY EXECUTING
          AN INSTRUCTION WITH THE TRAP BIT SET (SINGLE STEP). */
          PROCEDURE INTERRUPT 1;
249 2      USERSTACK.OFF = STACKPTR;          /* CHANGE TO MONITOR'S STACK */
250 2      USERSTACK.SEG = STACKBASE;
251 2      STACKPTR = MONITOR$STACKPTR;
252 2      STACKBASE = MONITOR$STACKBASE;
253 2      CALL SAVE$REGISTERS;
254 2      FL = FL AND (NOT STEP$TRAP);        /* CLEAR STEP FLAG */
255 2      IF LAST$COMMAND<>SS$COMMAND THEN /* CONTINUE IF NOT SS */
256 2          CALL RESTORE$EXECUTE;
257 2      CALL SIO$CRLF;
258 2      CALL SIO$UPDATE$IP;
259 2      IF CHAR=', ' THEN
260 2          DO;

```

```

261 3          IP = CSIP.OFF;
262 3          CS = CSIP.SEG;
263 3          FL = FL OR STEP$TRAP;          /* SET STEP FLAG */
264 3          CALL RESTORE$EXECUTE;
265 3          END;
266 2          IF CHAR<>ASCR THEN GOTO ERROR;
268 2          GOTO NEXT$COMMAND;
269 2          END;

270 1  INTERRUPT3$ENTRY:
      /* THIS PROCEDURE IS CALLED WHEN THE CPU EXECUTES A 'INT 3' INSTRUCTION.
      THE MONITOR INSERTS THIS (OCCH) FOR A BREAKPOINT. ALSO AN EXTERNAL
      INTERRUPT OR A USER SOFTWARE INTERRUPT MAY CAUSE THIS PROCEDURE TO BE
      CALLED. */
      PROCEDURE INTERRUPT 3;
271 2          USERSTACK.OFF = STACKPTR;
272 2          USERSTACK.SEG = STACKBASE;
273 2          STACKPTR = MONITOR$STACKPTR;
274 2          STACKBASE = MONITOR$STACKBASE;
275 2          CALL SAVE$REGISTERS;
276 2          CALL SIO$CRLF;
277 2          GOTO AFTER$INTERRUPT;
278 2          END;

279 1  INIT$INT$VECTOR:
      /* THIS ROUTINE INITIALIZES AN INTERRUPT VECTOR AS FOLLOWS: THE OFFSET
      FROM THE ADDRESS OF 'INT$ROUTINE' CORRECTED BY THE APPROPRIATE
      NUMBER OF BYTES FOR THE INTERRUPT PLM PROLOGUE. THE SEGMENT FROM THE
      CURRENT CS REGISTER IS DETERMINED BY A MACHINE LANGUAGE CODED
      SUBROUTINE. */
      PROCEDURE(INT$VECTOR$PTR,INT$ROUTINE$OFFSET);
280 2          DECLARE INT$VECTOR$PTR POINTER, INT$ROUTINE$OFFSET WORD,
      VECTOR BASED INT$VECTOR$PTR STRUCTURE (OFF WORD, SEG WORD),
      CORRECTION LITERALLY '19H', /* OFFSET FOR PROLOGUE */
      INIT$INT$VECTOR$CODE(*) BYTE DATA
      (055H,          /* PUSH BP          */
      08BH,0ECH,      /* MOV BP,SP          */
      08CH,0C8H,      /* MOV AX,CS          */
      0C4H,05EH,004H, /* LES BX,/BP/.PARAM */
      026H,089H,007H, /* MOV ES:W/BX/,AX   */
      05DH,          /* POP BP             */
      0C2H,004H,000H), /* RET 4              */
      INIT$INT$VECTOR$CODE$PTR WORD DATA (.INIT$INT$VECTOR$CODE);

281 2          CALL INIT$INT$VECTOR$CODE$PTR(@VECTOR.SEG); /* SEGMENT PORTION */
282 2          VECTOR.OFF = INT$ROUTINE$OFFSET - CORRECTION; /* OFFSET PORTION */
283 2          END;

```

```

/* *****
*****

```

COMMAND MODULE  
=====

ABSTRACT  
=====

THIS MODULE CONTAINS ALL THE COMMANDS IMPLEMENTED AS INDIVIDUAL PROCEDURES

AND CALLED FROM THE OUTER BLOCK OF THE COMMAND DISPATCH LOOP.

MODULE ORGANIZATION

=====

THIS MODULE CONTAINS THE FOLLOWING SECTIONS:

1. COMMANDS SECTION
 

SIO\$GO	GO
SIO\$SINGLE\$STEP	SINGLE STEP
SIO\$EXAM\$MEM	SUBSTITUTE MEMORY
SIO\$EXAM\$REG	EXAMINE REGISTER
SIO\$MOVE	MOVE
SIO\$DISPLAY	DISPLAY BYTES
SIO\$INPUT	INPUT PORT
SIO\$OUTPUT	OUTPUT PORT
SIO\$WRITE	WRITE DATA RECORDS
SIO\$READ	READ DATA RECORDS
2. COMMAND DISPATCH (OUTER BLOCK, MAIN PROGRAM LOOP)
 

NEXT\$COMMAND	DISPATCH
ERROR	ERROR ROUTINE

\*/

```

/*****
*   COMMAND SECTION   *
*****/

```

```

284  1  SIO$GO:
      /* IMPLEMENTS THE 'GO' COMMAND. THE USER MAY SPECIFY A NEW
      IP:PC AND AN OPTIONAL BREAKPOINT. */
      PROCEDURE;
285  2  CALL SIO$UPDATE$IP;
286  2  IF CHAR=', ' THEN          /* BREAKPOINT */
287  2  DO;
288  3  CALL SIO$GET$CHAR;
289  3  CALL SIO$GET$ADDR(@BRK1,CSIP.SEG);
290  3  IF CHAR<>ASCR THEN GOTO ERROR;
292  3  BRK1$SAVE = MEMORY$BRK1;
293  3  MEMORY$BRK1 = BREAK$INST;
294  3  IF MEMORY$BRK1<>BREAK$INST THEN GOTO ERROR;
296  3  BRK1$FLAG = TRUE;
297  3  END;
      ELSE          /* NO BREAKPOINT */
298  2  IF CHAR<>ASCR THEN GOTO ERROR;
      CALL SIO$CRLF;
301  2  IP = CSIP.OFF;
302  2  CS = CSIP.SEG;
303  2  FL = FL AND (NOT STEP$TRAP);    /* CLEAR IF SET */
304  2  CALL RESTORE$EXECUTE;
305  2  END;

306  1  SIO$SINGLE$STEP:
      /* IMPLEMENTS THE SINGLE STEP COMMAND. DISPLAYS IP AND THE
      CURRENT INSTRUCTION BYTE. OPENS CS:IP FOR INPUT. DEPRESSING
      COMMA CAUSES THE MONITOR TO SINGLE STEP THE INSTRUCTION, AND
      PERIOD TERMINATES THE COMMAND. */
      PROCEDURE;

```



```

307 2          CALL SIO$UPDATE$IP;
308 2          IF CHAR<>',' THEN GOTO ERROR;
310 2          IP = CSIP.OFF;
311 2          CS = CSIP.SEG;
312 2          FL = FL OR STEP$TRAP;
313 2          CALL RESTORE$EXECUTE;
314 2          END;

315 1          SIO$EXAM$MEM:
                /* IMPLEMENTS THE EXAMINE MEMORY COMMAND. */
                PROCEDURE;
316 2          DECLARE W WORD;
317 2          CALL SIO$TEST$WORD$MODE;
318 2          CALL SIO$GET$ADDR(@ARG1,CS);
319 2          IF CHAR<>',' THEN GOTO ERROR;
321 2          DO WHILE TRUE;
322 3              CALL SIO$OUT$BLANK;
323 3              IF WORD$MODE THEN
324 3                  CALL SIO$OUT$WORD(MEMORY$WORD$ARG1);
                ELSE
325 3                  CALL SIO$OUT$BYTE(MEMORY$ARG1);
326 3                  CALL SIO$OUT$CHAR('-');
327 3                  CALL SIO$OUT$BLANK;
328 3                  CALL SIO$GET$CHAR;
329 3                  IF CHAR=ASCR THEN RETURN;
331 3                  IF CHAR<>',' THEN
332 3                      DO;
333 4                          W = SIO$GET$WORD;
334 4                          IF (CHAR <> ',' ) AND (CHAR <> ASCR) THEN GOTO ERROR;
336 4                          IF WORD$MODE THEN
337 4                              DO;
338 5                                  MEMORY$WORD$ARG1 = W;
339 5                                  IF MEMORY$WORD$ARG1<>W THEN GOTO ERROR;
341 5                                  END;
                ELSE
342 4                  DO;
343 5                      MEMORY$ARG1 = LOW(W);
344 5                      IF MEMORY$ARG1<>LOW(W) THEN GOTO ERROR;
346 5                      END;
347 4                  END;
348 3                  IF CHAR=ASCR THEN RETURN;
350 3                  IF WORD$MODE THEN
351 3                      ARG1.OFF = ARG1.OFF + 2;
                ELSE
352 3                      ARG1.OFF = ARG1.OFF + 1;
353 3                  CALL SIO$CRLF;
354 3                  CALL SIO$OUT$WORD(ARG1.OFF);
355 3                  END;
356 2          END;

357 1          SIO$EXAM$REG:
                /* IMPLEMENTS THE EXAMINE REGISTER COMMAND. SCANS FOR A VALID
                REGISTER NAME AND DISPLAYS THE VALUE OF THAT REGISTER WHICH IS
                OPTIONALLY OPENED FOR INPUT. COMMA INCREMENTS TO NEXT REGISTER
                UNLESS IT IS 'FL' WHICH TERMINATES AS DOES CR. */
                PROCEDURE;
358 2          DECLARE (T,I) BYTE, SAVE WORD;

```

```

359 2      CALL SIO$SCAN$BLANK;
360 2      IF CHAR=ASCR THEN
361 2          DO;
362 3          CALL SIO$CRLF;
363 3          DO I=0 TO 13;
364 4              CALL SIO$OUT$BLANK;
365 4              CALL SIO$OUT$CHAR(REG(I*2));
366 4              CALL SIO$OUT$CHAR(REG(I*2+1));
367 4              CALL SIO$OUT$CHAR('=');
368 4              CALL SIO$OUT$WORD(REG$SAV(I));
369 4              IF I=6 THEN CALL SIO$CRLF;
371 4          END;
372 3          RETURN;
373 3          END;
374 2      IF NOT(SIO$VALID$REG$FIRST) THEN GOTO ERROR;
376 2      T = CHAR;
377 2      CALL SIO$GET$CHAR;
378 2      IF NOT(SIO$VALID$REG(T,CHAR)) THEN GOTO ERROR;
380 2      I = REG$INDEX;
381 2      DO WHILE TRUE;
382 3          CALL SIO$OUT$CHAR('=');
383 3          CALL SIO$OUT$WORD(REG$SAV(I));
384 3          CALL SIO$OUT$CHAR('-');
385 3          CALL SIO$OUT$BLANK;
386 3          CALL SIO$GET$CHAR;
387 3          IF CHAR<>',' AND CHAR<>ASCR THEN
388 3              DO;
389 4              SAVE = SIO$GET$WORD;
390 4              IF (CHAR <> ',' ) AND (CHAR <> ASCR) THEN GOTO ERROR;
392 4              REG$SAV(I) = SAVE;
393 4              END;
394 3          IF CHAR=ASCR OR I=13 THEN RETURN;
396 3          I = I + 1;
397 3          CALL SIO$CRLF;
398 3          CALL SIO$OUT$CHAR(REG(I*2));
399 3          CALL SIO$OUT$CHAR(REG(I*2+1));
400 3          END;
401 2      END;

402 1      SIO$MOVE:
          /* IMPLEMENTS THE MOVE COMMAND. ACCEPTS 3 ARGUMENTS AND MOVES THE
          BLOCK OF MEMORY SPECIFIED BY ARG1-ARG2 TO ARG3. ARG2<ARG1 OR THERE
          IS A DIFFERENCE WHEN THE BYTE IS READ BACK, THEN ERROR. */
          PROCEDURE;
403 2          CALL SIO$SCAN$BLANK;
404 2          CALL SIO$GET$ADDR(@ARG1,CS);          /* FIRST ARGUMENT */
405 2          IF CHAR<>',' THEN GOTO ERROR;
407 2          CALL SIO$GET$CHAR;
408 2          END$OFF = SIO$GET$WORD;          /* SECOND ARGUMENT */
409 2          IF END$OFF<ARG1.OFF THEN GOTO ERROR;
411 2          IF CHAR<>',' THEN GOTO ERROR;
413 2          CALL SIO$GET$CHAR;
414 2          CALL SIO$GET$ADDR(@ARG3,CS);          /* THIRD ARGUMENT */
415 2          IF CHAR<>ASCR THEN GOTO ERROR;
417 2          CALL SIO$CRLF;
418 2      LOOP:
          MEMORY$ARG3 = MEMORY$ARG1;

```

```
419 2          IF MEMORY$ARG3<>MEMORY$ARG1 THEN GOTO ERROR;
421 2          IF ARG1.OFF = END$OFF THEN RETURN;
423 2          ARG1.OFF = ARG1.OFF + 1;
424 2          ARG3.OFF = ARG3.OFF + 1;
425 2          GOTO LOOP;
426 2          END;

427 1          SIO$DISPLAY:
          /* IMPLEMENTS THE DISPLAY BYTE COMMAND. IF CALLED WITH 1 PARM THEN
          OUTPUTS A SINGLE BYTE. IF CALLED WITH 2 PARMS THEN OUTPUTS THE RANGE
          BETWEEN THE TWO ADDRESSES. IF OFFSET<BEGIN THEN OUTPUTS ONLY A SINGLE
          BYTE. */
          PROCEDURE;
428 2          DECLARE T BYTE;
429 2          CALL SIO$TEST$WORD$MODE;
430 2          CALL SIO$GET$ADDR(@ARG1,CS);
431 2          IF CHAR=ASCR THEN
432 2          END$OFF = ARG1.OFF;
          ELSE
433 2          DO;
434 3          IF CHAR<>',' THEN GOTO ERROR;
436 3          CALL SIO$GET$CHAR;
437 3          END$OFF = SIO$GET$WORD;
438 3          IF END$OFF < ARG1.OFF THEN GOTO ERROR;
440 3          IF CHAR<>ASCR THEN GOTO ERROR;
442 3          END;
443 2          NEWLINE:
          CALL SIO$CRLF;
          CALL SIO$OUT$WORD(ARG1.OFF);
444 2          LOOP: CALL SIO$OUT$BLANK;
445 2          IF WORD$MODE THEN
446 2          DO;
447 2          CALL SIO$OUT$WORD(MEMORY$WORD$ARG1);
448 3          IF ARG1.OFF = END$OFF THEN RETURN;
449 3          ARG1.OFF = ARG1.OFF + 1;
451 3          END;
          ELSE
453 2          CALL SIO$OUT$BYTE(MEMORY$ARG1);
454 2          IF ARG1.OFF>=END$OFF THEN RETURN;
456 2          ARG1.OFF = ARG1.OFF + 1;
457 2          T = ARG1.OFF AND 000FH;
458 2          IF T=0 OR (WORD$MODE AND T=1) THEN GOTO NEWLINE;
460 2          GOTO LOOP;
461 2          END;

462 1          SIO$INPUT:
          /* THIS ROUTINE IMPLEMENTS THE 'INPUT' COMMAND. USER SPECIFIES
          A PORT AND THE DATUM OF THE PORT IS DISPLAYED. */
          PROCEDURE;
463 2          DECLARE PORT WORD;
464 2          CALL SIO$TEST$WORD$MODE;
465 2          PORT = SIO$GET$WORD;
466 2          LOOP:
          IF CHAR<>',' THEN GOTO ERROR;
468 2          CALL SIO$CRLF;
469 2          IF WORD$MODE THEN
470 2          CALL SIO$OUT$WORD(INWORD(PORT));
```

```

ELSE
471 2     CALL SIO$OUT$BYTE(INPUT(PORT));
472 2     CALL SIO$GET$CHAR;
473 2     IF CHAR=ASCR THEN RETURN;
475 2     GOTO LOOP;
476 2     END;

477 1     SIO$OUTPUT:
        /* THIS ROUTINE IMPLEMENTS THE 'OUTPUT' COMMAND. THE USER SUPPLIED
        DATUM IS OUTPUT TO THE SPECIFIED PORT. */
        PROCEDURE;
478 2     DECLARE (DATUM,PORT) WORD;
479 2     CALL SIO$TEST$WORD$MODE;
480 2     PORT = SIO$GET$WORD;
481 2     IF CHAR<>',' THEN GOTO ERROR;
483 2     CALL SIO$GET$CHAR;
484 2     LOOP:
        DATUM = SIO$GET$WORD;
485 2     IF CHAR=':' THEN GOTO ERROR;
487 2     IF WORD$MODE THEN
488 2         OUTWORD(PORT) = DATUM;
        ELSE
489 2         OUTPUT(PORT) = LOW(DATUM);
490 2         IF CHAR=',' THEN
491 2             DO;
492 3             CALL SIO$CRLF;
493 3             CALL SIO$OUT$CHAR('-');
494 3             CALL SIO$OUT$BLANK;
495 3             CALL SIO$GET$CHAR;
496 3             IF CHAR <> ASCR THEN GOTO LOOP;
498 3             END;
499 2         END;

500 1     SIO$WRITE:
        /* IMPLEMENTS THE PAPER TAPE WRITE COMMAND. OUTPUTS LEADING NULLS,
        EXTENDED ADDRESS RECORD (8086 ONLY), START ADDRESS RECORDS
        (8086 ONLY), DATA RECORDS, EOF RECORD, AND TRAILING NULLS. */
        PROCEDURE;
501 2     DECLARE (START$REC,MODE$8086) BYTE, (LEN,INDEX) WORD;
502 2     CALL SIO$GET$CHAR;
503 2     MODE$8086 = TRUE;
504 2     IF CHAR='X' THEN /* TEST FOR 8080 MODE */
505 2         DO;
506 3         MODE$8086 = FALSE;
507 3         CALL SIO$GET$CHAR;
508 3         END;
509 2     IF CHAR=ASBL THEN CALL SIO$GET$CHAR;
511 2     CALL SIO$GET$ADDR(@ARG1,CS);
512 2     IF CHAR<>',' THEN GOTO ERROR;
514 2     CALL SIO$GET$CHAR;
515 2     END$OFF = SIO$GET$WORD;
516 2     IF END$OFF<ARG1.OFF THEN GOTO ERROR;
518 2     IF CHAR<>ASCR THEN
519 2         DO;
520 3         START$REC = TRUE;
521 3         CALL SIO$GET$CHAR;
522 3         CALL SIO$GET$ADDR(@ARG3,CS);

```

```

523 3      END;
      ELSE
524 2      DO;
525 3      START$REC = FALSE;
526 3      ARG3.OFF = 0;
527 3      END;
528 2      IF CHAR<>ASCR THEN GOTO ERROR;
530 2      CALL SIO$CRLF;

531 2      DO I=1 TO 60;          /* LEADING NULLS */
532 3      CALL SIO$OUT$CHAR(0);
533 3      END;
534 2      CALL SIO$CRLF;

535 2      IF MODE$8086 THEN
536 2      DO;
537 3      IF START$REC THEN
538 3      DO;
539 4      CALL SIO$OUT$HEADER(04,0,03); /* START ADDRESS RECORD */
540 4      CALL SIO$OUT$WORD(ARG3.SEG);
541 4      CALL SIO$OUT$WORD(ARG3.OFF);
542 4      CALL SIO$OUT$BYTE(CHECK$SUM);
543 4      CALL SIO$CRLF;
544 4      ARG3.OFF = 0;
545 4      END;
546 3      CALL SIO$OUT$HEADER(02,0,02); /* EXTENDED ADDRESS RECORD */
547 3      CALL SIO$OUT$WORD(ARG1.SEG);
548 3      CALL SIO$OUT$BYTE(CHECK$SUM);
549 3      CALL SIO$CRLF;
550 3      END;

551 2      LEN = STANDARD$LEN;          /* DATA RECORD */
552 2      LOOP: INDEX = END$OFF - ARG1.OFF;
553 2      IF INDEX<STANDARD$LEN THEN LEN = INDEX + 1;
555 2      CALL SIO$OUT$HEADER(LEN,ARG1.OFF,00);
556 2      DO I=1 TO LEN;
557 3      CALL SIO$OUT$BYTE(MEMORY$ARG1);
558 3      ARG1.OFF = ARG1.OFF + 1;
559 3      END;
560 2      CALL SIO$OUT$BYTE(CHECK$SUM);
561 2      CALL SIO$CRLF;
562 2      IF END$OFF<>ARG1.OFF-1 THEN GOTO LOOP;

564 2      CALL SIO$OUT$HEADER(00,ARG3.OFF,01); /* EOF RECORD */
565 2      CALL SIO$OUT$BYTE(CHECK$SUM);
566 2      CALL SIO$CRLF;

567 2      DO I=1 TO 60;          /* TRAILING NULLS */
568 3      CALL SIO$OUT$CHAR(0);
569 3      END;
570 2      END;

571 1      SIO$READ:
      /* IMPLEMENTS THE READ PAPER TAPE COMMAND. */
      PROCEDURE;
572 2      DECLARE BIAS WORD, (REC$TYPE,LEN,I,T) BYTE, OFFSET WORD;
573 2      BIAS = 0;          /* DEFAULT BIAS */

```

```

574 2      ARG1.SEG = 0;          /* DEFAULT CS FOR 8080 FORMAT FILE */
575 2      CALL SIO$SCAN$BLANK;
576 2      IF CHAR<>ASCR THEN BIAS = SIO$GET$WORD;
578 2      IF CHAR<>ASCR THEN GOTO ERROR;
580 2      CALL SIO$CRLF;
581 2      LOOP:
583 2          DO WHILE SIO$READ$CHAR<>' ':END;
584 2          CHECK$SUM = 0;
585 2          LEN = SIO$READ$BYTE;
586 2          OFFSET = SIO$READ$WORD;
587 2          ARG1.OFF = OFFSET + BIAS;
588 2          REC$TYPE = SIO$READ$BYTE;
589 2          IF REC$TYPE=03 THEN      /* START ADDR TYPE */
590 3              DO;
591 3                  CS = SIO$READ$WORD;
592 3                  IP = SIO$READ$WORD;
593 2          IF REC$TYPE=02 THEN      /* EXTENDED ADDR TYPE */
594 2              ARG1.SEG = SIO$READ$WORD;
595 2          IF REC$TYPE = 01 THEN      /* EOF */
596 2              IF OFFSET <> 0 THEN IP = OFFSET;
598 2          IF REC$TYPE=00 THEN      /* DATA TYPE */
599 2              DO I=1 TO LEN;
600 3                  T,MEMORY$ARG1 = SIO$READ$BYTE;
601 3                  IF MEMORY$ARG1<>T THEN GOTO ERROR;
603 3                  ARG1.OFF = ARG1.OFF + 1;
604 3              END;
605 2          T = SIO$READ$BYTE;      /* FETCH CHECKSUM */
606 2          IF CHECK$SUM<>0 THEN GOTO ERROR;
608 2          IF REC$TYPE<>01 AND LEN<>0 THEN GOTO LOOP;
610 2          CALL SIO$OUT$CHAR(0); /* DELAY FOR LAST CR, LF SENT */
611 2          CALL SIO$OUT$CHAR(0); /* BY INTELLEC */
612 2      END;

/*****
*   COMMAND DISPATCH MAIN PROGRAM LOOP   *
*****/

613 1      DISABLE;
614 1      OUTPUT(KB$STAT$PORT) = KB$INIT$MODE;
615 1      OUTPUT(KB$STAT$PORT) = KB$INIT$SCAN;
616 1      OUTPUT(KB$STAT$PORT) = 90H; /* OUTPUT '8086' SIGNON BACKWARDS */
617 1      DO I=0 TO 7;
618 2          OUTPUT(KB$DATA$PORT) = KB$SIGNON(I);
619 2      END;

/* THIS STRANGE SEQUENCE OF CODE IS USED TO GUARANTEE CORRECT USART
INITIALIZATION AFTER EITHER: 1) HARDWARE RESET (EXPECTING MODE)
2) SOFTWARE RESTART (EXPECTING COMMAND). */

620 1      OUTPUT(SIO$STAT$PORT) = SIO$8251$RESET;
621 1      CALL SIO$8251$SETTLING$DELAY;
622 1      OUTPUT(SIO$STAT$PORT) = 25H;
623 1      CALL SIO$8251$SETTLING$DELAY;
624 1      OUTPUT(SIO$STAT$PORT) = SIO$8251$RESET;
625 1      CALL SIO$8251$SETTLING$DELAY;

```

```
626 1      OUTPUT(SIO$STAT$PORT) = SIO$8251$MODE;
627 1      CALL SIO$8251$SETTLING$DELAY;
628 1      OUTPUT(SIO$STAT$PORT) = SIO$8251$CMND;
629 1      CALL SIO$8251$SETTLING$DELAY;
630 1      CALL SIO$OUT$STRING(@SIO$SIGNON);

        /* INITIALIZE USER'S REGISTERS */
631 1      CS,SS,DS,ES,FL,IP = 0;
632 1      SP = USER$INIT$SP;

        /* INITIALIZE INTERRUPT VECTORS */
633 1      CALL INIT$INT$VECTOR(@INT$VECTOR(1),.INTERRUPT1$ENTRY);
634 1      CALL INIT$INT$VECTOR(@INT$VECTOR(2),.INTERRUPT3$ENTRY);
635 1      CALL INIT$INT$VECTOR(@INT$VECTOR(3),.INTERRUPT3$ENTRY);

636 1      BRK1$FLAG = FALSE;
637 1      MONITOR$STACKPTR = STACKPTR;
638 1      MONITOR$STACKBASE = STACKBASE;

639 1      NEXT$COMMAND:
        /* THIS IS THE PERPETUAL COMMAND LOOP WHICH DISPATCHES TO EACH
        COMMAND WHICH IS A SEPARATED PROCEDURE. */

        CALL SIO$CRLF;
        CALL SIO$OUT$CHAR(0);
        CALL SIO$OUT$CHAR(' ');
        CALL SIO$GET$CHAR;
        DO I=0 TO LAST(SIO$CMND);
        644 2      IF CHAR=SIO$CMND(I) THEN GOTO DISPATCH;
        646 2      END;
        647 1      GOTO ERROR;
        DISPATCH:
        649 1      LAST$COMMAND = I;
        DO CASE I;
        650 2      CALL SIO$EXAM$MEM;
        651 2      CALL SIO$EXAM$REG;
        652 2      CALL SIO$GO;
        653 2      CALL SIO$SINGLE$STEP;
        654 2      CALL SIO$MOVE;
        655 2      CALL SIO$DISPLAY;
        656 2      CALL SIO$INPUT;
        657 2      CALL SIO$OUTPUT;
        658 2      CALL SIO$READ;
        659 2      CALL SIO$WRITE;
        660 2      END;
        661 1      GOTO NEXT$COMMAND;

662 1      ERROR:
        /* THIS ROUTINE HANDLES ALL ERRORS DETECTED BY THE MONITOR AND
        WILL OUTPUT THE ERROR PROMPT TO THE OUTPUT PORT.*/

        CALL SIO$OUT$CHAR('#');
        663 1      GOTO NEXT$COMMAND;

664 1      AFTER$INTERRUPT:
        /* THIS ROUTINE IS CALLED AFTER AN INTERRUPT TO DISPLAY THE CS:IP
        AND RESTORE THE BREAKPOINTED INSTRUCTION. */
```

```

        IF BRK1$FLAG THEN
665 1      DO;
666 2      MEMORY$BRK1 = BRK1$SAVE;
667 2      BRK1$FLAG = FALSE;
668 2      IF ((IP-1) AND 000FH)=(BRK1.OFF AND 000FH) AND
          (SHR(IP-1,4)+CS)=(SHR(BRK1.OFF,4)+BRK1.SEG) THEN
669 2      DO;
670 3      IP = IP - 1;
671 3      CALL SIO$OUT$STRING(@SIO$BREAK$MSG);
672 3      END;
673 2      END;
674 1      CALL SIO$OUT$CHAR('e');
675 1      CALL SIO$OUT$WORD(CS);
676 1      CALL SIO$OUT$CHAR(':');
677 1      CALL SIO$OUT$WORD(IP);
678 1      GOTO NEXT$COMMAND;

679 1      END MONITOR;      /* END OF MODULE */
      EOF
```

## MODULE INFORMATION:

```

CODE AREA SIZE      = 0FDBH    4059D
CONSTANT AREA SIZE = 0000H    0D
VARIABLE AREA SIZE = 0078H    120D
MAXIMUM STACK SIZE = 0042H    66D
1211 LINES READ
0 PROGRAM ERROR(S)
```

END OF PL/M-86 COMPILATION





POINTERS TO THE SDK-86 2\*\*20 ADDRESS SPACE ARE IMPLEMENTED WITH  
 POINTER STRUCTURES ALLOCATED AS 2 WORD STRUCTURES.

```

*/
1      MONITOR:DO;                                /* BEGINNING OF MODULE */

/* *****
*****

GLOBAL DATA DECLARATIONS MODULE
=====

ABSTRACT
=====
THIS MODULE CONTAINS ALL THE GLOBAL DATA DECLARATIONS AND
LITERALS (EQUATES).

MODULE ORGAINIZATION
=====
THE MODULE IS DIVIDED INTO 5 SECTIONS:
1. UTILITY SECTION          GLOBAL FLAGS,VARIABLES,EQUATES
2. I/O SECTION             I/O PORTS,MASKS,AND SPECIAL CHARS
3. MEMORY ARGUMENTS SECTIONS STRUCTURES FOR POINTERS
4. REGISTER SECTION        USER REGISTER SAVE AREA
5. BOOT AND 8089 SECTION    BOOTSTRAP AND 8089 DESCRIPTOR

*/

/*****
*   UTILITY SECTION   *
*****/

2  1  DECLARE      INT$VECTOR(5)      POINTER;          /* INTERRUPT VECTORS */
3  1  DECLARE      MONITOR$STACKPTR   WORD,
MONITOR$STACKBASE WORD;
4  1  DECLARE      COPYRIGHT(*) BYTE DATA ('(C) 1978 INTEL CORP');
5  1  DECLARE      BRK1$FLAG          BYTE,              /* TRUE IF BREAK SET */
BRK1$SAVE          BYTE,              /* INST BREAK SAVE */
CHAR               BYTE,              /* ONE CHAR LOOK AHEAD */
CHECK$SUM          BYTE,              /* PAPER TAPE CHECKSUM */
I                  BYTE,              /* INDEX */
END$OFF            WORD,              /* END OFFSET ADDRESS */
WORD$MODE          BYTE,              /* WORD MODE FLAG */
LAST$COMMAND       BYTE;              /* LAST COMMAND SAVE */
6  1  DECLARE      TRUE                LITERALLY 'OFFH',
FALSE              LITERALLY '000H',
BREAK$INST         LITERALLY '0CCH',          /* BREAKPOINT INST */
STEP$TRAP          LITERALLY '0100H',        /* SS TRAP FLAG MASK */
USER$INIT$SP       LITERALLY '100H',         /* USER STACK INITIAL */
GO$COMMAND         LITERALLY '2',           /* GO COMMAND CODE */
SS$COMMAND         LITERALLY '3',           /* SINGLE STEP CODE */
STANDARD$LEN       LITERALLY '16',          /* PAPER TAPE DATA REC LEN */
MAX$DELAY          LITERALLY '10000';       /* DELAY FOR PAPER TAPE */

```

```

7 1 DECLARE
    KB$SIGNON(*) BYTE DATA (5BH,86H,00H,00H,7DH,7FH,00H,00H),
                                /* " 2 1. 6 8 " */
    SIO$BREAK$MSG(*) BYTE DATA ('BR ',0),
    SIO$SIGNON(*) BYTE DATA (0DH,0AH,'SDK-86 MONITOR, V1.2',0),
    ASCII(*) BYTE DATA ('0123456789ABCDEF'),
    SIO$CMND(*) BYTE DATA ('SXGNMDIORW');

    /*****
    * I/O DECLARATIONS SECTION *
    *****/

8 1 DECLARE
    SIO$STAT$PORT LITERALLY 'OFFF2H', /* 8251 USART */
    SIO$DATA$PORT LITERALLY 'OFFF0H', /* STATUS INPUT PORT */
    SIO$8251$RESET LITERALLY '065H', /* DATA INPUT PORT */
    SIO$8251$MODE LITERALLY '0CFH', /* RESET COMMAND */
    SIO$8251$CMND LITERALLY '025H', /* ASYNC MODE */
    SIO$8251$DTR$ON LITERALLY '027H', /* DTR OFF */
    SIO$DSRDY LITERALLY '80H', /* SAME AS CMND BUT DTR ON */
    SIO$RXRDY LITERALLY '02H', /* DATA SET READY */
    SIO$TXRDY LITERALLY '01H'; /* RECEIVE DATA READY */
                                /* XMIT BUFFER EMPTY */

9 1 DECLARE
    KB$STAT$PORT LITERALLY 'OFFFEAH', /* STATUS/CMD PORT */
    KB$DATA$PORT LITERALLY 'OFFE8H', /* DATA PORT */
    KB$INIT$MODE LITERALLY '00H', /* 8 8-BIT, LEFT ENTRY,
                                ENCODE, 2 KEY LOCKOUT */
    KB$INIT$SCAN LITERALLY '39H'; /* 10MS SCAN RATE */

10 1 DECLARE
    ASCR LITERALLY '0DH', /* CARRIAGE RETURN */
    ASLF LITERALLY '0AH', /* LINE FEED */
    ASBL LITERALLY '20H'; /* BLANK OR SPACE */

    /*****
    * MEMORY ARGUMENT SECTION *
    *****/

11 1 DECLARE
    MEMORY$ARG1$PTR POINTER, /* ARGUMENT 1 */
    ARG1 STRUCTURE (OFF WORD, SEG WORD)
    AT (@MEMORY$ARG1$PTR),
    MEMORY$ARG1 BASED MEMORY$ARG1$PTR BYTE,
    MEMORY$WORD$ARG1 BASED MEMORY$ARG1$PTR WORD,

    MEMORY$ARG3$PTR POINTER, /* ARGUMENT 3 */
    ARG3 STRUCTURE (OFF WORD, SEG WORD)
    AT (@MEMORY$ARG3$PTR),
    MEMORY$ARG3 BASED MEMORY$ARG3$PTR BYTE,

    MEMORY$BRK1$PTR POINTER, /* BREAKPOINT 1 */
    BRK1 STRUCTURE (OFF WORD, SEG WORD)
    AT (@MEMORY$BRK1$PTR),
    MEMORY$BRK1 BASED MEMORY$BRK1$PTR BYTE,

    MEMORY$CSIP$PTR POINTER, /* CS & IP WORD */
    CSIP STRUCTURE (OFF WORD, SEG WORD)
    AT (@MEMORY$CSIP$PTR),

```

```

MEMORY$CSIP BASED MEMORY$CSIP$PTR BYTE,

MEMORY$USERSTACK$PTR POINTER,
USERSTACK STRUCTURE (OFF WORD, SEG WORD)
  AT (@MEMORY$USERSTACK$PTR),
MEMORY$USERSTACK BASED MEMORY$USERSTACK$PTR WORD;

```

```

/*****
* REGISTER SECTION *
*****/

```

```

12 1 DECLARE
    REG(*)          BYTE DATA          /* REGISTER NAMES */
    ('AXBXCXDXSPBPSIDICSDSSSESIPFL'),
    REG$INDEX       WORD,
    REG$SAV(14)     WORD,              /* USER'S SAVED REGS */
    REG$ORD(*)      BYTE DATA
    (7,6,1,3,2,0,9,11,12,8,13),
    SP              LITERALLY 'REG$SAV( 4)',
    BP              LITERALLY 'REG$SAV( 5)',
    CS              LITERALLY 'REG$SAV( 8)',
    DS              LITERALLY 'REG$SAV( 9)',
    SS              LITERALLY 'REG$SAV(10)',
    ES              LITERALLY 'REG$SAV(11)',
    IP              LITERALLY 'REG$SAV(12)',
    FL              LITERALLY 'REG$SAV(13)';

/*****
* BOOTSTRAP JUMP AND 8089 VECTOR *
*****/

/* THIS BOOT CONSISTS OF A LONG JUMP TO THE BEGINNING OF THE MONITOR
AT FFO0+XXXX WHERE XXXX IS THE STARTING ADDRESS OFFSET (IP) AND
MUST BE DETERMINED AFTER EACH COMPILE. */
13 1 DECLARE
    START$ADDR     LITERALLY '00A8H',    /* STARTING ADDRESS */
    BOOT1(*)       BYTE AT (OFFF0H) DATA (0EAH), /* LONG JUMP OPCODE */
    BOOT2(*)       WORD AT (OFFF1H) DATA (START$ADDR),
    BOOT3(*)       WORD AT (OFFF3H) DATA (OFF00H); /* SEGMENT ADDRESS! */

/* THIS TWO-WORD DATA IS A JUMP TO THE STARTING ADDRESS AND IS LOCATED
AT THE FIRST LOCATION OF ROM (NO OTHER DATA OR CONSTANT DECLARATIONS
MAY PRECEDE IT). THE JUMP IS ACTUALLY TO (START-ADDR)-4 SINCE THE
INSTRUCTION IS A RELATIVE JUMP OF LENGTH 3. */
14 1 DECLARE
    BOOT4(*)       WORD DATA (0E990H,START$ADDR-4); /* NOP,JMP START-ADDR */

/* THIS BLOCK OF ROM AT FFFF6-FFFFA IS INITIALIZED FOR THE 8089
DEVICE AND POINTS TO A BLOCK OF RAM AT 0100H. */
15 1 DECLARE
    BLOCK$8089     WORD AT (OFFF6H) DATA (00001H),
    BLOCK$8089$PTR POINTER AT (OFFF8H) DATA (00100H);

/*****
* FILL DECLARATIONS SECTION *
*****/

```

```

/* THESE DECLARATIONS DEFINE FILL CHARACTERS FOR ALL UNUSED
LOCATIONS IN THE ROM ADDRESS SPACE. ANY MODIFICATION TO THE CODE
THAT CHANGES THE USED LOCATIONS IN THE ROM REQUIRES
MODIFICATION OF THIS SECTION. */

```

16 1 DECLARE

```

F          LITERALLY 'OFFH',
FILL1(*)  BYTE AT (OFFFDBH) DATA (F,F,F,F,F),
FILL2(*)  BYTE AT (OFFFE0H) DATA (F,F,F,F,F,F,F,F,F,F,F,F,F,F),
FILL3(*)  BYTE AT (OFFFF5H) DATA (F),
FILL4(*)  BYTE AT (OFFFFCH) DATA (F,F,F,F);

```

```

/* *****
*****

```

COMMON PROCEDURES  
=====

ABSTRACT  
=====

THIS MODULE CONTAINS THOSE LOWER LEVEL PROCEDURES CALLED BY HIGHER  
LEVEL ROUTINES.

MODULE ORGANIZATION  
=====

THIS MODULE IS DIVIDED INTO 4 SECTIONS AS FOLLOWS:

1. BASIC I/O SECTION
  - SIO\$CHAR\$RDY            INPUT CHARACTER READY
  - SIO\$CHECK\$CONTROL\$CHAR    CHECK FOR CONTROL CHARACTER
  - SIO\$OUT\$CHAR            OUTPUT CHARACTER
  - SIO\$GET\$CHAR            INPUT A CHARACTER
  - SIO\$OUT\$BYTE            OUTPUT A BYTE IN HEX
  - SIO\$OUT\$WORD            OUTPUT A WORD IN HEX
  - SIO\$OUT\$BLANK            OUTPUT A SINGLE BLANK
  - SIO\$OUT\$STRING            OUTPUT A STRING
  - SIO\$OUT\$HEADER            OUTPUT A PAPER TAPE HEADER
2. UTILITY ROUTINES SECTION
  - SIO\$VALID\$HEX            TEST FOR VALID HEX CHAR
  - SIO\$HEX                  CONVERT TO HEX FROM ASCII
  - SIO\$VALID\$REG\$FIRST      TEST FOR VALID REGISTER FIRST CHAR
  - SIO\$VALID\$REG            TEST FOR VALID REGISTER NAME
  - SIO\$CRLF                 OUTPUTS A CR AND LF
  - SIO\$TEST\$WORD\$MODE      TEST FOR A 'W' IN COMMAND
  - SIO\$SCAN\$BLANK            SCANS FOR OPTIONAL BLANK
3. ARGUMENT EXPRESSION EVALUATION SECTION
  - SIO\$GET\$WORD            GET AN WORD EXPRESSION
  - SIO\$GET\$ADDR            GET AN ADDRESS EXPRESSION
  - SIO\$UPDATE\$IP            OPTIONAL UPDATE OF CS:IP
4. PAPER TAPE READ SECTION
  - SIO\$READ\$CHAR            READ CHAR FROM TTY READER
  - SIO\$READ\$BYTE            READ A BYTE
  - SIO\$READ\$WORD            READ A WORD
5. INTERRUPT AND RESTORE/EXECUTE ROUTINES
  - SAVE\$REGISTERS            SAVES USER REGISTERS
  - RESTORE\$EXECUTE            RESTORE MACHINE STATE AND EXEC



```

25 2 02C1 7520 JNZ @2
      DO WHILE CHAR<>11H; /* CONTROL-Q */
                                ; STATEMENT # 25
      @121:
02C3 803E660011 CMP CHAR,11H
02C8 7423 JZ @5
26 3 IF SIO$CHAR$RDY THEN
                                ; STATEMENT # 26
02CA E8D3FF CALL SIOCHARRDY
02CD D0D8 RCR AL,1
02CF 73F2 JNB @121
27 3 DO;
28 4 CHAR = INPUT(SIO$DATA$PORT) AND 07FH;
                                ; STATEMENT # 28
02D1 BAF0FF MOV DX,OFFFOH
02D4 EC IN DX
02D5 247F AND AL,7FH
02D7 A26600 MOV CHAR,AL
29 4 IF CHAR=03H THEN GOTO ERROR;
                                ; STATEMENT # 29
02DA 3C03 CMP AL,3H
02DC 7503 JNZ $+5H
02DE E925FF JMP ERROR
31 4 END;
32 3 END;
                                ; STATEMENT # 32
02E1 EBEO JMP @121
      @2:
33 2 ELSE IF CHAR = 03H THEN GOTO ERROR;
                                ; STATEMENT # 33
02E3 803E660003 CMP CHAR,3H
02E8 7503 JNZ $+5H
02EA E919FF JMP ERROR
                                ; STATEMENT # 34
      @5:
      END SIO$CHECK$CONTROL$CHAR;
                                ; STATEMENT # 35
02ED 5D POP BP
02EE C3 RET
      SIOCHECKCONTROLCHAR ENDP
36 1 SIO$OUT$CHAR:
                                ; STATEMENT # 36
      /* THIS ROUTINE OUTPUTS THE INPUT PARAMETER TO THE USART OUTPUT
      PORT WHEN USART IS READY FOR OUTPUT (XMIT BUFFER EMPTY). */
      SIOOUTCHAR PROC NEAR
02EF 55 PUSH BP
02F0 8BEC MOV BP,SP
      PROCEDURE(C);
37 2 DECLARE C BYTE;
38 2 IF SIO$CHAR$RDY THEN CALL SIO$CHECK$CONTROL$CHAR;
                                ; STATEMENT # 38
02F2 E8ABFF CALL SIOCHARRDY
02F5 D0D8 RCR AL,1
02F7 7303 JNB @123
                                ; STATEMENT # 39
02F9 E8B7FF CALL SIOCHECKCONTROLCHAR

```

```

40  2          DO WHILE (INPUT(SIO$STAT$PORT) AND SIO$TXRDY)=0;END;
          ; STATEMENT # 40
          @123:
02FC  BAF2FF      MOV     DX,0FFF2H
02FF  EC          IN      DX
0300  A801      TEST    AL,1H
0302  74F8      JZ      @123
42  2          OUTPUT(SIO$DATA$PORT) = C;
          ; STATEMENT # 42
0304  BAF0FF      MOV     DX,OFFF0H
0307  8A4604     MOV     AL,[BP].C
030A  EE          OUT     DX
43  2          END;
          ; STATEMENT # 43
030B  5D          POP     BP
030C  C20200     RET     2H
          SIOOUTCHAR      ENDP

44  1          SIO$GET$CHAR:
          ; STATEMENT # 44
          /* THIS ROUTINE INPUTS A CHARACTER FROM THE INPUT PORT AND RETURNS
          WITH IT IN THE GLOBAL 'CHAR'. THE CHARACTER IS ECHOED TO THE
          OUTPUT PORT IF PRINTABLE. */
          SIOGETCHAR      PROC NEAR
030F  55          PUSH    BP
0310  8BEC      MOV     BP,SP
          PROCEDURE;
45  2          DO WHILE (INPUT(SIO$STAT$PORT) AND SIO$RXRDY)=0;END;
          ; STATEMENT # 45
          @125:
0312  BAF2FF      MOV     DX,0FFF2H
0315  EC          IN      DX
0316  A802      TEST    AL,2H
0318  74F8      JZ      @125
47  2          CHAR = INPUT(SIO$DATA$PORT) AND 07FH;
          ; STATEMENT # 47
031A  BAF0FF      MOV     DX,OFFF0H
031D  EC          IN      DX
031E  247F      AND     AL,7FH
0320  A26600     MOV     CHAR,AL
48  2          IF CHAR>=ASBL THEN CALL SIO$OUT$CHAR(CHAR);
          ; STATEMENT # 48
0323  3C20      CMP     AL,20H
0325  7207      JB      @8
          ; STATEMENT # 49
0327  FF366600   PUSH    CHAR ; 1
032B  E8C1FF      CALL   SIOOUTCHAR
          @8:
50  2          END;
          ; STATEMENT # 50
032E  5D          POP     BP
032F  C3          RET
          SIOGETCHAR      ENDP

51  1          SIO$OUT$BYTE:
          ; STATEMENT # 51
          /* THIS ROUTINE OUTPUTS THE SINGLE INPUT PARAMETER TO THE USART

```



```

                IN ASCII HEXADECEMAL FORMAT. */
                SIOOUTBYTE PROC NEAR
0330 55          PUSH BP
0331 8BEC        MOV BP,SP
                PROCEDURE(B);
52  2          DECLARE B BYTE;
53  2          CALL SIO$OUT$CHAR(ASCII(SHR(B,4) AND OFH));
                ; STATEMENT # 53
0333 8A5E04     MOV BL,[BP].B
0336 B104       MOV CL,4H
0338 D2EB       SHR BL,CL
033A 80E30F     AND BL,OFH
033D B700       MOV BH,0H
033F 2EFF773E   PUSH CS:ASCII[BX]
0343 E8A9FF     CALL SIOOUTCHAR
54  2          CALL SIO$OUT$CHAR(ASCII(B AND OFH));
                ; STATEMENT # 54
0346 8A5E04     MOV BL,[BP].B
0349 80E30F     AND BL,OFH
034C B700       MOV BH,0H
034E 2EFF773E   PUSH CS:ASCII[BX]
0352 E89AFF     CALL SIOOUTCHAR
55  2          CHECK$SUM = CHECK$SUM - B;
                ; STATEMENT # 55
0355 8A4604     MOV AL,[BP].B
0358 28066700   SUB CHECKSUM,AL
56  2          END;
                ; STATEMENT # 56
035C 5D         POP BP
035D C20200     RET 2H
                SIOOUTBYTE ENDP

57  1          SIO$OUT$WORD:
                ; STATEMENT # 57
                /* THIS ROUTINE OUTPUTS THE INPUT PARAMETER AS 4 ASCII HEXADECEMAL
                CHARACTERS TO THE USART OUTPUT PORT. */
                SIOOUTWORD PROC NEAR
0360 55          PUSH BP
0361 8BEC        MOV BP,SP
                PROCEDURE(W);
58  2          DECLARE W WORD;
59  2          CALL SIO$OUT$BYTE(HIGH(W));
                ; STATEMENT # 59
0363 8B4604     MOV AX,[BP].W
0366 88E0       MOV AL,AH
0368 50         PUSH AX ; 1
0369 E8C4FF     CALL SIOOUTBYTE
60  2          CALL SIO$OUT$BYTE(LOW(W));
                ; STATEMENT # 60
036C 8B4604     MOV AX,[BP].W
036F 50         PUSH AX ; 1
0370 E8BDFE     CALL SIOOUTBYTE
61  2          END;
                ; STATEMENT # 61
0373 5D         POP BP
0374 C20200     RET 2H
                SIOOUTWORD ENDP

```

```

62  1      SIO$OUT$BLANK:
                                ; STATEMENT # 62
      /* THIS ROUTINE OUTPUTS ONE BLANK. */
      SIOOUTBLANK PROC NEAR
0377 55          PUSH BP
0378 8BEC        MOV BP,SP
      PROCEDURE;
63  2      CALL SIO$OUT$CHAR(ASBL);
                                ; STATEMENT # 63
037A B020        MOV AL,20H
037C 50          PUSH AX ; 1
037D E86FFF      CALL SIOOUTCHAR
64  2      END;
                                ; STATEMENT # 64
0380 5D          POP BP
0381 C3          RET
      SIOOUTBLANK ENDP

65  1      SIO$OUT$STRING:
                                ; STATEMENT # 65
      /* OUTPUTS A STRING POINTED TO BY THE FIRST PARM. */
      SIOOUTSTRING PROC NEAR
0382 55          PUSH BP
0383 8BEC        MOV BP,SP
      PROCEDURE(PTR);
66  2      DECLARE PTR POINTER, STR BASED PTR (1) BYTE;
67  2      I = 0;
                                ; STATEMENT # 67
0385 C606680000 MOV I,0H
68  2      DO WHILE STR(I)<>0;
                                ; STATEMENT # 68
      @127:
038A A06800      MOV AL,I
038D B400        MOV AH,0H
038F 89C6        MOV SI,AX
0391 C45E04      LES BX,[BP].PTR
0394 26823800    CMP ES:[BX].STR[SI],0H
0398 7417        JZ @128
69  3      CALL SIO$OUT$CHAR(STR(I));
                                ; STATEMENT # 69
039A A06800      MOV AL,I
039D B400        MOV AH,0H
039F 89C6        MOV SI,AX
03A1 C45E04      LES BX,[BP].PTR
03A4 26FF30      PUSH ES:[BX].STR[SI]
03A7 E845FF      CALL SIOOUTCHAR
70  3      I = I + 1;
                                ; STATEMENT # 70
03AA 8006680001 ADD I,1H
71  3      END;
                                ; STATEMENT # 71
03AF EBD9        JMP @127
      @128:
72  2      END;
                                ; STATEMENT # 72
03B1 5D          POP BP

```

```

03B2 C20400          RET      4H
                SIOOUTSTRING  ENDP

73  1      SIO$OUT$HEADER:
                ; STATEMENT # 73
                /* THIS ROUTINE OUTPUTS THE PAPER TAPE HEADER CONSISTING OF ':'
                FOLLOWED BY THE RECORD LENGTH, LOAD ADDRESS, AND THE RECORD TYPE.
                IT INITIALIZES THE CHECKSUM TO ZERO. */
                SIOOUTHEADER  PROC NEAR
03B5  55            PUSH     BP
03B6  8BEC          MOV      BP,SP
                PROCEDURE(LENGTH,LOAD$ADDR,REC$TYPE);
74  2      DECLARE (LENGTH,REC$TYPE) BYTE, LOAD$ADDR WORD;
75  2      CALL SIO$OUT$CHAR(':');
                ; STATEMENT # 75
03B8  B03A          MOV      AL,3AH
03BA  50            PUSH     AX      ; 1
03BB  E831FF        CALL    SIOOUTCHAR
76  2      CHECK$SUM = 0;
                ; STATEMENT # 76
03BE  C606670000    MOV      CHECKSUM,0H
                CALL SIO$OUT$BYTE(LENGTH);
77  2      ; STATEMENT # 77
03C3  FF7608        PUSH     [BP].LENGTH; 1
03C6  E867FF        CALL    SIOOUTBYTE
78  2      CALL SIO$OUT$WORD(LOAD$ADDR);
                ; STATEMENT # 78
03C9  FF7606        PUSH     [BP].LOADADDR; 1
03CC  E891FF        CALL    SIOOUTWORD
79  2      CALL SIO$OUT$BYTE(REC$TYPE);
                ; STATEMENT # 79
03CF  FF7604        PUSH     [BP].RECTYPE; 1
03D2  E85BFF        CALL    SIOOUTBYTE
80  2      END;
                ; STATEMENT # 80
03D5  5D            POP      BP
03D6  C20600          RET      6H
                SIOOUTHEADER  ENDP

81  1      SIO$8251$SETTLING$DELAY:
                ; STATEMENT # 81
                /* THIS DELAY ROUTINE ALLOWS THE USART SUFFICIENT TIME
                TO SETTLE AFTER WRITE OPERATIONS. */
                SIO8251SETTLINGDELAY  PROC NEAR
03D9  55            PUSH     BP
03DA  8BEC          MOV      BP,SP
                PROCEDURE;
82  2      I = SHR(OFFH,OFFH);
                ; STATEMENT # 82
03DC  B0FF          MOV      AL,OFFH
03DE  B1FF          MOV      CL,OFFH
03E0  D2E8          SHR      AL,CL
03E2  A26800        MOV      I,AL
83  2      END;
                ; STATEMENT # 83
03E5  5D            POP      BP
03E6  C3            RET

```

SIO8251SETTLINGDELAY ENDP

/\*  
 \* UTILITY ROUTINES SECTION \*  
 \*/

```

84 1      SIO$VALID$HEX:
          ; STATEMENT # 84
          /* THIS ROUTINE TESTS IF THE INPUT PARM IS A VALID ASCII HEX DIGIT
          AND RETURNS TRUE AS THE VALUE OF THE PROCEDURE IF SO AND FALSE
          IF NOT. */
          SIOVALIDHEX      PROC NEAR
03E7 55          PUSH      BP
03E8 8BEC        MOV       BP,SP
          PROCEDURE (H) BYTE;
          DECLARE H BYTE;
85 2          DO I=0 TO LAST(ASCII);
86 2          ; STATEMENT # 86
          03EA C606680000    MOV       I,0H
          @129:
          03EF 803E68000F    CMP       I,0FH
          03F4 771A          JA        @130
          IF H=ASCII(I) THEN RETURN TRUE;
          ; STATEMENT # 87
          03F6 8A4604          MOV       AL,[BP].H
          03F9 8A1E6800          MOV       BL,I
          03FD B700          MOV       BH,0H
          03FF 2E3A473E          CMP       AL,CS:ASCII[BX]
          0403 7504          JNZ       @9
          ; STATEMENT # 88
          0405 B0FF          MOV       AL,OFFH
          0407 EB09          JMP       @3
          @9:
89 3          END;
          ; STATEMENT # 89
          0409 8006680001    ADD       I,1H
          040E 75DF          JNZ       @129
          @130:
          90 2          RETURN FALSE;
          ; STATEMENT # 90
          0410 B000          MOV       AL,0H
          @3:
          0412 5D          POP       BP
          0413 C20200          RET       2H
91 2          END;
          ; STATEMENT # 91
          SIOVALIDHEX      ENDP

92 1      SIO$HEX:
          ; STATEMENT # 92
          /* THIS ROUTINE CONVERTS THE INPUT PARM FROM ASCII TO ITS BINARY
          EQUIVALENT AND RETURNS IT AS THE VALUE OF THE PROCEDURE. NO CHECK
          IS MADE FOR INPUT VALIDITY. */
          SIOHEX          PROC NEAR
          0416 55          PUSH      BP
          0417 8BEC        MOV       BP,SP
  
```

```

          PROCEDURE(C) WORD;
93  2      DECLARE C BYTE;
94  2      IF C<='9' THEN RETURN DOUBLE(C-30H);
          ; STATEMENT # 94
          0419 807E0439      CMP      [BP].C,39H
          041D 7707          JA       @10
          ; STATEMENT # 95
          041F 8A4604      MOV      AL,[BP].C
          0422 2C30      SUB      AL,30H
          0424 EB05      JMP      @4
          @10:
96  2      ELSE RETURN DOUBLE(C-37H);
          ; STATEMENT # 96
          0426 8A4604      MOV      AL,[BP].C
          0429 2C37      SUB      AL,37H
          @4:
          042B B400      MOV      AH,0H
          042D 5D          POP      BP
          042E C20200      RET      2H
97  2      END;
          SIOHEX      ENDP
98  1      SIO$VALID$REG$FIRST:
          ; STATEMENT # 98
          /* THIS ROUTINE CHECKS IF 'CHAR' IS A VALID FIRST LETTER OF A REGISTER
          NAME AND RETURNS TRUE AS THE VALUE OF THE PROCEDURE IF SO. */
          SIOVALIDREGFIRST      PROC NEAR
          0431 55          PUSH     BP
          0432 8BEC      MOV      BP,SP
          PROCEDURE BYTE;
          DO I=0 TO 26 BY 2;
          ; STATEMENT # 99
          0434 C606680000      MOV      I,0H
          0439 EB07          JMP      @133
          @131:
          043B 8006680002      ADD      I,2H
          0440 721A          JB       @132
          @133:
          0442 803E68001A      CMP      I,1AH
          0447 7713          JA       @132
100 3      IF CHAR=REG(I) THEN RETURN TRUE;
          ; STATEMENT # 100
          0449 A06600      MOV      AL,CHAR
          044C 8A1E6800      MOV      BL,I
          0450 B700          MOV      BH,0H
          0452 2E3A4758      CMP      AL,CS:REG[BX]
          0456 75E3          JNZ     @131
          ; STATEMENT # 101
          0458 B0FF      MOV      AL,OFFH
          045A 5D          POP      BP
          045B C3          RET
102 3      END;
          ; STATEMENT # 102
          @132:
103 2      RETURN FALSE;
          ; STATEMENT # 103
          045C B000      MOV      AL,0H

```

```

045E 5D          POP      BP
045F C3          RET
104  2          END;
                                ; STATEMENT # 104
                                ENDP
                                SIOVALIDREGFIRST
105  1          SIO$VALID$REG:
                                ; STATEMENT # 105
                                /* THIS ROUTINE CHECKS IF THE TWO INPUT PARMS TAKEN TOGETHER FORM
                                A VALID REGISTER NAME. IT SEARCHES THE REGISTER TABLE AND IF A
                                MATCH IS FOUND, THE GLOBAL 'REG$INDEX' IS SET TO THE INDEX OF THE
                                VALID REGISTER AND THE PROCEDURE RETURNS TRUE. IF NO MATCH THE
                                PROCEDURE RETURNS FALSE AND REG$INDEX IS UNDEFINED. */
                                SIOVALIDREG PROC NEAR
0460 55          PUSH     BP
0461 8BEC        MOV      BP,SP
                                PROCEDURE (C1,C2) BYTE;
106  2          DECLARE (C1,C2) BYTE;
107  2          DO REG$INDEX=0 TO 13;
                                ; STATEMENT # 107
0463 C7062E000000 MOV     REGINDEX,0H
                                @134:
0469 833E2E000D  CMP     REGINDEX,0DH
046E 7731        JA      @135
108  3          IF C1=REG(REG$INDEX*2) AND C2=REG(REG$INDEX*2+1) THEN
                                ; STATEMENT # 108
0470 8B1E2E00    MOV     BX,REGINDEX
0474 D1E3        SHL     BX,1
0476 8A4606    MOV     AL,[BP].C1
0479 2E3A4758  CMP     AL,CS:REG[BX]
047D B0FF        MOV     AL,OFFH
047F 7401        JZ      $+3H
0481 40          INC     AX
0482 8A4E04    MOV     CL,[BP].C2
0485 50          PUSH   AX ; 1
0486 2E3A4F59  CMP     CL,CS:REG[BX+1H]
048A B0FF        MOV     AL,OFFH
048C 7401        JZ      $+3H
048E 40          INC     AX
048F 59          POP     CX ; 1
0490 22C1        AND     AL,CL
0492 D0D8        RCR     AL,1
0494 7304        JNB    @13
109  3          RETURN TRUE;
                                ; STATEMENT # 109
0496 B0FF        MOV     AL,OFFH
0498 EB09        JMP     @6
                                @13:
110  3          END;
                                ; STATEMENT # 110
049A 83062E0001  ADD     REGINDEX,1H
049F 73C8        JNB    @134
                                @135:
111  2          RETURN FALSE;
                                ; STATEMENT # 111
04A1 B000        MOV     AL,0H
                                @6:

```

```

04A3 5D          POP      BP
04A4 C20400      RET      4H
112  2          END;
                                ; STATEMENT # 112
                                SIOVALIDREG      ENDP

113  1          SIO$CRLF:
                                ; STATEMENT # 113
                                /* THIS ROUTINE OUTPUTS A CR AND LF TO THE OUTPUT PORT. */
                                SIOCRLF          PROC NEAR
04A7 55          PUSH     BP
04A8 8BEC        MOV      BP,SP
                                PROCEDURE;
114  2          CALL SIO$OUT$CHAR(ASCR);
                                ; STATEMENT # 114
04AA B00D        MOV      AL,ODH
04AC 50          PUSH     AX ; 1
04AD E83FFE      CALL    SIOOUTCHAR
115  2          CALL SIO$OUT$CHAR(ASLF);
                                ; STATEMENT # 115
04B0 B00A        MOV      AL,0AH
04B2 50          PUSH     AX ; 1
04B3 E839FE      CALL    SIOOUTCHAR
116  2          END;
                                ; STATEMENT # 116
04B6 5D          POP      BP
04B7 C3          RET
                                SIOCRLF          ENDP

117  1          SIO$TEST$WORD$MODE:
                                ; STATEMENT # 117
                                /* THIS PROCEDURE TESTS FOR A 'W' FOLLOWING THE COMMAND AND IF SO
                                SETS THE FLAG 'WORD$MODE' TO TRUE OR FALSE OTHERWISE. SCANS OFF
                                OPTIONAL BLANK FOLLOWING COMMAND. */
                                SIOTESTWORDMODE  PROC NEAR
04B8 55          PUSH     BP
04B9 8BEC        MOV      BP,SP
                                PROCEDURE;
118  2          WORD$MODE = FALSE;
                                ; STATEMENT # 118
04BB C606690000  MOV      WORDMODE,0H
119  2          CALL SIO$GET$CHAR;
                                ; STATEMENT # 119
04C0 E84CFE      CALL    SIOGETCHAR
120  2          IF CHAR='W' THEN
                                ; STATEMENT # 120
04C3 803E660057  CMP      CHAR,57H
04C8 7508        JNZ     @14
121  2          DO;
122  3          WORD$MODE = TRUE;
                                ; STATEMENT # 122
04CA C6066900FF    MOV      WORDMODE,OFFH
123  3          CALL SIO$GET$CHAR;
                                ; STATEMENT # 123
04CF E83DFE      CALL    SIOGETCHAR
124  3          END;
                                @14:

```

```

125 2          IF CHAR=ASBL THEN
                                ; STATEMENT # 125
04D2 803E660020      CMP      CHAR,20H
04D7 7503              JNZ      @15
126 2          CALL SIO$GET$CHAR;
                                ; STATEMENT # 126
04D9 E833FE          CALL      SIOGETCHAR
                                @15:
127 2          END;
                                ; STATEMENT # 127
04DC 5D              POP      BP
04DD C3              RET
                                SIOTESTWORDMODE      ENDP

128 1          SIO$SCAN$BLANK:
                                ; STATEMENT # 128
/* THIS ROUTINE IS CALLED AFTER A COMMAND LETTER TO SCAN OFF THE
   OPTIONAL BLANK. */
                                SIOSCANBLANK      PROC NEAR
04DE 55              PUSH     BP
04DF 8BEC            MOV      BP,SP
                                PROCEDURE;
129 2          CALL SIO$GET$CHAR;
                                ; STATEMENT # 129
04E1 E82BFE          CALL      SIOGETCHAR
130 2          IF CHAR=ASBL THEN
                                ; STATEMENT # 130
04E4 803E660020      CMP      CHAR,20H
04E9 7503              JNZ      @16
131 2          CALL SIO$GET$CHAR;
                                ; STATEMENT # 131
04EB E821FE          CALL      SIOGETCHAR
                                @16:
132 2          END;
                                ; STATEMENT # 132
04EE 5D              POP      BP
04EF C3              RET
                                SIOSCANBLANK      ENDP

/*****
 * ARGUMENT EXPRESSION EVALUATOR SECTION *
*****/

133 1          SIO$GET$WORD:
                                ; STATEMENT # 133
/* THIS ROUTINE READS CHARS FROM THE INPUT PORT AND EVALUATES
   AN EXPRESSION CONSISTING OF '+-' AND OPERANDS OF HEX NUMBERS
   AND REGISTER NAMES. */
                                SIOGETWORD      PROC NEAR
04F0 55              PUSH     BP
04F1 8BEC            MOV      BP,SP
                                PROCEDURE WORD;
134 2          DECLARE (SAVE,W) WORD, (OPER,T) BYTE;
135 2          OPER = '+';
                                ; STATEMENT # 135
04F3 C6066B002B      MOV      OPER,2BH

```



```

136 2          W = 0;
                                ; STATEMENT # 136
04F8 C7064E000000 MOV W,0H
137 2          DO WHILE TRUE;
                                ; STATEMENT # 137
          @136:
138 3          T = CHAR;
                                ; STATEMENT # 138
04FE A06600 MOV AL,CHAR
0501 A26C00 MOV T,AL
139 3          SAVE = 0;
                                ; STATEMENT # 139
0504 C7064C000000 MOV SAVE,0H
140 3          IF SIO$VALID$REG$FIRST THEN
                                ; STATEMENT # 140
050A E824FF CALL SIOVALIDREGFIRST
050D D0D8 RCR AL,1
050F 733B JNB @17
141 3          DO;
142 4          CALL SIO$GET$CHAR;
                                ; STATEMENT # 142
0511 E8FBFD CALL SIOGETCHAR
143 4          IF SIO$VALID$REG(T,CHAR) THEN
                                ; STATEMENT # 143
0514 FF366C00 PUSH T ; 1
0518 FF366600 PUSH CHAR ; 2
051C E841FF CALL SIOVALIDREG
051F D0D8 RCR AL,1
0521 731F JNB @18
144 4          DO;
145 5          SAVE = REG$SAV(REG$INDEX);
                                ; STATEMENT # 145
0523 8B1E2E00 MOV BX,REGINDEX
0527 D1E3 SHL BX,1
0529 8B4730 MOV AX,REGSAV[BX]
052C A34C00 MOV SAVE,AX
146 5          CALL SIO$GET$CHAR;
                                ; STATEMENT # 146
052F E8DDFD CALL SIOGETCHAR
147 5          GOTO EVAL;
                                ; STATEMENT # 147
          @7:
0532 803E6B002B CMP OPER,2BH
0537 7548 JNZ EVAL
0539 A14C00 MOV AX,SAVE
053C 01064E00 ADD W,AX
0540 EB46 JMP @22
148 5          END;
                                ; STATEMENT # 148
          @18:
          ELSE
149 4          SAVE = SIO$HEX(T);
                                ; STATEMENT # 149
0542 FF366C00 PUSH T ; 1
0546 E8CDFE CALL SIOHEX
0549 A34C00 MOV SAVE,AX
150 4          END;

```

```

@17:
151 3      IF NOT(SIO$VALID$HEX(T)) THEN GOTO ERROR;
                                           ; STATEMENT # 151
054C FF366C00      PUSH      T           ; 1
0550 E894FE        CALL      SIOVALIDHEX
0553 F6D0          NOT       AL
0555 D0D8          RCR       AL,1
0557 7303          JNB      $+5H
0559 E9AAFC        JMP       ERROR
153 3      DO WHILE SIO$VALID$HEX(CHAR);
                                           ; STATEMENT # 153
@138:
055C FF366600      PUSH      CHAR      ; 1
0560 E884FE        CALL      SIOVALIDHEX
0563 D0D8          RCR       AL,1
0565 73CB          JNB      @7
154 4      SAVE = SHL(SAVE,4) + SIO$HEX(CHAR);
                                           ; STATEMENT # 154
0567 A14C00        MOV       AX,SAVE
056A B104          MOV       CL,4H
056C D3E0          SHL      AX,CL
056E 50            PUSH     AX           ; 1
056F FF366600      PUSH     CHAR        ; 2
0573 E8A0FE        CALL     SIOHEX
0576 59            POP      CX           ; 1
0577 03C1          ADD      AX,CX
0579 A34C00        MOV      SAVE,AX
155 4      CALL SIO$GET$CHAR;
                                           ; STATEMENT # 155
057C E890FD        CALL     SIOGETCHAR
156 4      END;
                                           ; STATEMENT # 156
057F EBDB          JMP      @138
157 3      EVAL:   IF OPER='+' THEN
                                           ; STATEMENT # 157
                                           EVAL:
158 3      W = W + SAVE;
159 3      ELSE
159 3      W = W - SAVE;
                                           ; STATEMENT # 159
0581 A14C00        MOV      AX,SAVE
0584 29064E00      SUB      W,AX
@22:
160 3      IF CHAR=ASCR OR CHAR=':' OR CHAR=',' THEN
                                           ; STATEMENT # 160
0588 A06600        MOV      AL,CHAR
058B 3COD          CMP      AL,ODH
058D B0FF          MOV      AL,OFFH
058F 7401          JZ       $+3H
0591 40            INC      AX
0592 50            PUSH     AX           ; 1
0593 803E66003A    CMP      CHAR,3AH
0598 B0FF          MOV      AL,OFFH
059A 7401          JZ       $+3H
059C 40            INC      AX
059D 59            POP      CX           ; 1
059E 0AC1          OR       AL,CL

```

```

05A0 50          PUSH    AX          ; 1
05A1 803E66002C CMP     CHAR,2CH
05A6 B0FF        MOV     AL,OFFH
05A8 7401        JZ     $+3H
05AA 40          INC     AX
05AB 59          POP     CX          ; 1
05AC 0AC1        OR     AL,CL
05AE D0D8        RCR    AL,1
05B0 7305        JNB   @23
161 3          RETURN W;
                                ; STATEMENT # 161
05B2 A14E00      MOV     AX,W
05B5 5D          POP     BP
05B6 C3          RET
                                @23:
162 3          IF CHAR='+' OR CHAR='-' THEN
                                ; STATEMENT # 162
05B7 803E66002B CMP     CHAR,2BH
05BC B0FF        MOV     AL,OFFH
05BE 7401        JZ     $+3H
05C0 40          INC     AX
05C1 50          PUSH    AX          ; 1
05C2 803E66002D CMP     CHAR,2DH
05C7 B0FF        MOV     AL,OFFH
05C9 7401        JZ     $+3H
05CB 40          INC     AX
05CC 59          POP     CX          ; 1
05CD 0AC1        OR     AL,CL
05CF D0D8        RCR    AL,1
05D1 7203        JB     $+5H
05D3 E930FC      JMP     ERROR
163 3          OPER = CHAR;
                                ; STATEMENT # 163
05D6 A06600      MOV     AL,CHAR
05D9 A26B00      MOV     OPER,AL
                                ELSE
164 3          GOTO ERROR;
165 3          CALL SIO$GET$CHAR;
                                ; STATEMENT # 165
05DC E830FD      CALL   SIOGETCHAR
166 3          END;
                                ; STATEMENT # 166
05DF E91CFF      JMP     @136
                                @137:
167 2          END;
                                ; STATEMENT # 167
05E2 5D          POP     BP
05E3 C3          RET
                                SIOGETWORD ENDP
168 1          SIO$GET$ADDR:
                                ; STATEMENT # 168
                                /* THIS ROUTINE ACCEPTS A VALID ADDRESS EXPRESSION CONSISTING
                                OF AN OPTIONAL <SEG>: AND AN DISPLACEMENT. */
                                SIOGETADDR PROC NEAR
05E4 55          PUSH    BP
05E5 8BEC        MOV     BP,SP

```

```

PROCEDURE(PTR,DEFAULT$BASE);
169  2      DECLARE PTR POINTER, DEFAULT$BASE WORD,
        ARG BASED PTR STRUCTURE (OFF WORD, SEG WORD);
170  2      ARG.SEG = DEFAULT$BASE;
        ; STATEMENT # 170
05E7  8B4604      MOV     AX,[BP].DEFAULTBASE
05EA  C45E06      LES     BX,[BP].PTR
05ED  26894702     MOV     ES:ARG[BX+2H],AX
171  2      ARG.OFF = SIO$GET$WORD;
        ; STATEMENT # 171
05F1  E8FCFE      CALL    SIOGETWORD
05F4  C45E06      LES     BX,[BP].PTR
05F7  268907      MOV     ES:ARG[BX],AX
172  2      IF CHAR=':' THEN
        ; STATEMENT # 172
05FA  803E66003A   CMP     CHAR,3AH
05FF  7520          JNZ     @26
173  2      DO;
174  3      CALL SIO$GET$CHAR;
        ; STATEMENT # 174
0601  E80BFD      CALL    SIOGETCHAR
175  3      ARG.SEG = ARG.OFF;
        ; STATEMENT # 175
0604  C45E06      LES     BX,[BP].PTR
0607  268B07      MOV     AX,ES:ARG[BX]
060A  26894702     MOV     ES:ARG[BX+2H],AX
176  3      ARG.OFF = SIO$GET$WORD;
        ; STATEMENT # 176
060E  E8DFFE      CALL    SIOGETWORD
0611  C45E06      LES     BX,[BP].PTR
0614  268907      MOV     ES:ARG[BX],AX
177  3      IF CHAR=':' THEN GOTO ERROR;
        ; STATEMENT # 177
0617  803E66003A   CMP     CHAR,3AH
061C  7503          JNZ     $+5H
061E  E9E5FB      JMP     ERROR
        ; STATEMENT # 178
179  3      END;
        @26:
180  2      END;
        ; STATEMENT # 180
0621  5D          POP     BP
0622  C20600      RET     6H
        SIOGETADDR      ENDP

181  1      SIO$UPDATE$IP:
        ; STATEMENT # 181
        /* THIS PROCEDURE IS CALLED BY SINGLE STEP AND GO TO OUTPUT THE CURRENT
        IP AND INSTRUCTION BYTE AND OPEN THE IP FOR INPUT. */
        SIOUPDATEIP      PROC NEAR
0625  55          PUSH    BP
0626  8BEC      MOV     BP,SP
        PROCEDURE;
182  2      CALL SIO$OUT$BLANK;
        ; STATEMENT # 182
0628  E84CFD      CALL    SIOOUTBLANK
183  2      CALL SIO$OUT$WORD(IP);

```

```

; STATEMENT # 183
062B FF364800    PUSH    REGSAV+18H; 1
062F E82EFD     CALL    SIOOUTWORD
184  2          CSIP.SEG = CS;

; STATEMENT # 184
0632 A14000     MOV     AX,REGSAV+10H
0635 A32800     MOV     CSIP+2H,AX
185  2          CSIP.OFF = IP;

; STATEMENT # 185
0638 A14800     MOV     AX,REGSAV+18H
063B A32600     MOV     CSIP,AX
186  2          CALL SIO$OUT$CHAR('-');

; STATEMENT # 186
063E B02D       MOV     AL,2DH
0640 50        PUSH    AX ; 1
0641 E8ABFC     CALL    SIOOUTCHAR
187  2          CALL SIO$OUT$BLANK;

; STATEMENT # 187
0644 E830FD     CALL    SIOOUTBLANK
188  2          CALL SIO$OUT$BYTE(MEMORY$CSIP);

; STATEMENT # 188
0647 C41E2600    LES     BX,MEMORYCSIPPTR
064B 26FF37    PUSH   ES:MEMORYCSIP[BX]
064E E8DFFC     CALL    SIOOUTBYTE
189  2          CALL SIO$OUT$BLANK;

; STATEMENT # 189
0651 E823FD     CALL    SIOOUTBLANK
190  2          CALL SIO$GET$CHAR;

; STATEMENT # 190
0654 E8B8FC     CALL    SIOGETCHAR
191  2          IF CHAR<>',' AND CHAR<>ASCR THEN CALL SIO$GET$ADDR(@CSIP,CS);
; STATEMENT # 191
0657 803E66002C CMP    CHAR,2CH
065C B0FF       MOV     AL,OFFH
065E 7501     JNZ    $+3H
0660 40       INC    AX
0661 50       PUSH   AX ; 1
0662 803E66000D CMP    CHAR,ODH
0667 B0FF       MOV     AL,OFFH
0669 7501     JNZ    $+3H
066B 40       INC    AX
066C 59       POP    CX ; 1
066D 22C1     AND    AL,CL
066F D0D8     RCR    AL,1
0671 730D     JNB   @28

; STATEMENT # 192
0673 8D062600    LEA    AX,CSIP
0677 1E       PUSH   DS ; 1
0678 50       PUSH   AX ; 2
0679 FF364000    PUSH   REGSAV+10H; 3
067D E864FF     CALL    SIOGETADDR
; STATEMENT # 192
193  2          END;

; STATEMENT # 193
0680 5D       POP    BP
0681 C3       RET
SIOUPDATEIP    ENDP

```

```

/*****
* PAPER TAPE READ SECTION *
*****/

```

```

194 1      SIO$READ$CHAR:
                                ; STATEMENT # 194
      /* THIS PROCEDURE READS A BYTE FROM THE PAPER TAPE READER OF THE TTY
      BY ACTIVATING DTR, SAMPLING DSR FOR THE START BIT, DEACTIVATING
      DTR WHEN THE START BIT APPEARS, AND READING THE DATUM FROM THE
      USART. TO PROVIDE A HOLD-OFF CAPABILITY FOR THE LOAD COMMAND
      ONLY (NOT INTENDED FOR TTY PAPER TAPE) CONTROL-S WILL CAUSE THIS
      ROUTINE TO WAIT FOR A CORRESPONDING CONTROL-Q TO BE READ BEFORE
      CONTINUING. */
      SIOREADCHAR      PROC NEAR
0682 55          PUSH      BP
0683 8BEC        MOV       BP,SP
      PROCEDURE BYTE;
195 2      DECLARE DELAY WORD;
196 2      LOOP:
                                ; STATEMENT # 196
      LOOP:
      OUTPUT(SIO$STAT$PORT) = SIO$8251$DTR$ON;      /* DTR ON */
0685 BAF2FF      MOV       DX,OFFF2H
0688 B027        MOV       AL,27H
068A EE          OUT       DX
197 2      DELAY = 0;
                                ; STATEMENT # 197
068B C70650000000 MOV      DELAY,0H
198 2      DO WHILE (INPUT(SIO$STAT$PORT) AND SIO$DSRDY)=0; /*WAIT STARTBIT*/
                                ; STATEMENT # 198
      @140:
0691 BAF2FF      MOV       DX,OFFF2H
0694 EC          IN        DX
0695 A880        TEST      AL,80H
0697 7517        JNZ      @141
199 3      DELAY = DELAY + 1;
                                ; STATEMENT # 199
0699 A15000      MOV       AX,DELAY
069C 83C001      ADD       AX,1H
069F A35000      MOV       DELAY,AX
200 3      IF DELAY>=MAX$DELAY THEN
                                ; STATEMENT # 200
06A2 3D1027      CMP       AX,2710H
06A5 72EA        JB        @140
201 3      DO;
202 4      OUTPUT(SIO$STAT$PORT) = SIO$8251$CMND;      /* DTR OFF */
                                ; STATEMENT # 202
06A7 BAF2FF      MOV       DX,OFFF2H
06AA B025        MOV       AL,25H
06AC EE          OUT       DX
203 4      GOTO ERROR;
                                ; STATEMENT # 203
06AD E956FB      JMP       ERROR
204 4      END;
205 3      END;

```

```

; STATEMENT # 205
@141:
206 2      OUTPUT(SIO$STAT$PORT) = SIO$8251$CMND; /* DTR OFF */
; STATEMENT # 206
06B0 BAF2FF      MOV     DX,0FFF2H
06B3 B025        MOV     AL,25H
06B5 EE          OUT     DX
207 2      DO WHILE (INPUT(SIO$STAT$PORT) AND SIO$RXRDY)=0;END; /* WAIT LOOP */
; STATEMENT # 207
@142:
06B6 BAF2FF      MOV     DX,0FFF2H
06B9 EC          IN     DX
06BA A802        TEST    AL,2H
06BC 74F8        JZ     @142
209 2      CALL SIO$CHECK$CONTROL$CHAR;
; STATEMENT # 209
06BE E8F2FB      CALL    SIOCHECKCONTROLCHAR
210 2      IF CHAR = 11H THEN GOTO LOOP; /* GET ANOTHER IF CTL-Q */
; STATEMENT # 210
06C1 803E660011  CMP     CHAR,11H
06C6 74BD        JZ     LOOP
212 2      RETURN CHAR;
; STATEMENT # 212
06C8 A06600      MOV     AL,CHAR
06CB 5D          POP     BP
06CC C3          RET
213 2      END;
; STATEMENT # 213
SIORADCHAR      ENDP
214 1      SIO$READ$BYTE:
; STATEMENT # 214
/* THIS ROUTINE READS A BYTE FROM THE PAPER TAPE READER. */
SIORADBYTE      PROC NEAR
06CD 55          PUSH    BP
06CE 8BEC        MOV     BP,SP
PROCEDURE BYTE;
215 2      DECLARE T BYTE;
216 2      T = LOW(SIO$HEX(SIO$READ$CHAR));
; STATEMENT # 216
06D0 E8AFFF      CALL    SIORADCHAR
06D3 50          PUSH    AX ; 1
06D4 E83FFD      CALL    SIOHEX
06D7 A26D00      MOV     T,AL
217 2      T = SHL(T,4) + LOW(SIO$HEX(SIO$READ$CHAR));
; STATEMENT # 217
06DA A06D00      MOV     AL,T
06DD B104        MOV     CL,4H
06DF D2E0        SHL    AL,CL
06E1 50          PUSH    AX ; 1
06E2 E89DFF      CALL    SIORADCHAR
06E5 50          PUSH    AX ; 2
06E6 E82DFD      CALL    SIOHEX
06E9 59          POP     CX ; 1
06EA 02C1        ADD     AL,CL
06EC A26D00      MOV     T,AL
218 2      CHECK$SUM = CHECK$SUM + T;

```

```

                                ; STATEMENT # 218
219 2 06EF A06D00      MOV     AL,T
      06F2 00066700  ADD     CHECKSUM,AL
      RETURN T;

                                ; STATEMENT # 219
220 2 06F6 5D        POP     BP
      06F7 C3        RET
      END;

                                ; STATEMENT # 220
      SIOREADBYTE      ENDP

221 1 SIO$READ$WORD:
                                ; STATEMENT # 221
      /* THIS ROUTINE READS A WORD FROM THE PAPER TAPE READER AND RETURNS IT
      AS THE VALUE OF THE PROCEDURE. */
      SIOREADWORD      PROC NEAR
222 2 06F8 55        PUSH    BP
223 2 06F9 8BEC      MOV     BP,SP
      PROCEDURE WORD;
      DECLARE T BYTE;
      T = SIO$READ$BYTE;

                                ; STATEMENT # 223
224 2 06FB E8CFFF      CALL   SIOREADBYTE
      06FE A26E00      MOV     T,AL
      RETURN SHL(DOUBLE(T),8) + DOUBLE(SIO$READ$BYTE);
                                ; STATEMENT # 224
      0701 A06E00      MOV     AL,T
      0704 B400      MOV     AH,0H
      0706 B108      MOV     CL,8H
      0708 D3E0      SHL    AX,CL
      070A 50        PUSH    AX      ; 1
      070B E8BFFF      CALL   SIOREADBYTE
      070E B400      MOV     AH,0H
      0710 59        POP     CX      ; 1
      0711 03C1      ADD     AX,CX
      0713 5D        POP     BP
      0714 C3        RET
225 2 END;

                                ; STATEMENT # 225
      SIOREADWORD      ENDP

      /*****
      * INTERRUPT AND RESTORE/EXECUTE SECTION *
      *****/

226 1 SAVE$REGISTERS:
                                ; STATEMENT # 226
      /* THIS ROUTINE IS USED TO SAVE THE STACKED USER'S REGISTERS IN THE
      MONITOR'S SAVE AREA. */
      SAVEREGISTERS      PROC NEAR
227 2 0715 55        PUSH    BP
      0716 8BEC      MOV     BP,SP
      PROCEDURE;
      BP = MEMORY$USERSTACK;

                                ; STATEMENT # 227
      0718 C41E2A00      LES     BX,MEMORYUSERSTACKPTR

```



```

071C 268B07      MOV     AX,ES:MEMORYUSERSTACK[BX]
071F A33A00      MOV     REGSAV+0AH,AX
228  2          USERSTACK.OFF = USERSTACK.OFF + 4;
                          ; STATEMENT # 228
0722 83062A0004  ADD     USERSTACK,4H
229  2          DO I=0 TO 10; /* POP REGISTERS OFF OF STACK */
                          ; STATEMENT # 229
0727 C606680000  MOV     I,0H
          @144:
072C 803E68000A  CMP     I,0AH
0731 7725        JA     @145
230  3          REG$SAV(REG$ORD(I)) = MEMORY$USERSTACK;
                          ; STATEMENT # 230
0733 8A1E6800      MOV     BL,I
0737 B700          MOV     BH,0H
0739 2E8A9F7400    MOV     BL,CS:REGORD[BX]
073E B700          MOV     BH,0H
0740 D1E3          SHL     BX,1
0742 C4362A00      LES     SI,MEMORYUSERSTACKPTR
0746 268B04      MOV     AX,ES:MEMORYUSERSTACK[SI]
0749 894730      MOV     REGSAV[BX],AX
231  3          USERSTACK.OFF = USERSTACK.OFF + 2;
                          ; STATEMENT # 231
074C 83062A0002  ADD     USERSTACK,2H
232  3          END;
                          ; STATEMENT # 232
0751 8006680001  ADD     I,1H
0756 75D4        JNZ    @144
          @145:
233  2          SS = USERSTACK.SEG;
                          ; STATEMENT # 233
0758 A12C00      MOV     AX,USERSTACK+2H
075B A34400      MOV     REGSAV+14H,AX
234  2          SP = USERSTACK.OFF;
                          ; STATEMENT # 234
075E A12A00      MOV     AX,USERSTACK
0761 A33800      MOV     REGSAV+8H,AX
235  2          END;
                          ; STATEMENT # 235
0764 5D          POP     BP
0765 C3          RET
          SAVEREGISTERS      ENDP
236  1          RESTORE$EXECUTE:
                          ; STATEMENT # 236
          /* THIS PROCEDURE RESTORES THE STATE OF THE USER MACHINE AND
          PASSES CONTROL BACK TO THE USER PROGRAM. IT CONTAINS A
          MACHINE LANGUAGE SUBROUTINE TO PERFORM THE POPPING OF THE
          USER REGISTERS AND TO EXECUTE AN 'IRET' TO TRANSFER CONTROL
          TO THE USER'S PROGRAM. */
          RESTOREEXECUTE      PROC NEAR
0766 55          PUSH    BP
0767 8BEC      MOV     BP,SP
          PROCEDURE;
237  2          DECLARE RESTORE$EXECUTE$CODE(*) BYTE DATA
          (08BH,0ECH,          /* MOV BP,SP      */
          08BH,046H,002H,      /* MOV AX,/BP/.PARAM2 */

```

```

                                08BH,05EH,004H,      /* MOV BX,/BP/.PARAM1  */
                                08EH,0DOH,        /* MOV SS,AX           */
                                08BH,0E3H,        /* MOV SP,BX          */
                                05DH,            /* POP BP             */
                                05FH,            /* POP DI             */
                                05EH,            /* POP SI             */
                                05BH,            /* POP BX             */
                                05AH,            /* POP DX             */
                                059H,            /* POP CX             */
                                058H,            /* POP AX             */
                                01FH,            /* POP DS             */
                                007H,            /* POP ES             */
                                0CFH),          /* IRET               */
    RESTORE$EXECUTE$CODE$PTR WORD DATA (.RESTORE$EXECUTE$CODE);

238  2      USERSTACK.SEG = SS;
                                ; STATEMENT # 238
    0769  A14400      MOV      AX,REGSAV+14H
    076C  A32C00      MOV      USERSTACK+2H,AX
239  2      USERSTACK.OFF = SP;
                                ; STATEMENT # 239
    076F  A13800      MOV      AX,REGSAV+8H
    0772  A32A00      MOV      USERSTACK,AX
240  2      DO I=0 TO 10;      /* PUSH USER'S REGISTERS ONTO HIS STACK */
                                ; STATEMENT # 240
    0775  C606680000  MOV      I,0H
                                @146:
    077A  803E68000A  CMP      I,0AH
    077F  7727        JA      @147
241  3      USERSTACK.OFF = USERSTACK.OFF - 2;
                                ; STATEMENT # 241
    0781  832E2A0002  SUB      USERSTACK,2H
242  3      MEMORY$USERSTACK = REG$SAV(REG$ORD(10-I));
                                ; STATEMENT # 242
    0786  B30A        MOV      BL,0AH
    0788  2A1E6800    SUB      BL,I
    078C  B700        MOV      BH,0H
    078E  2E8A9F7400  MOV      BL,CS:REGORD[BX]
    0793  B700        MOV      BH,0H
    0795  D1E3        SHL      BX,1
    0797  8B4730      MOV      AX,REGSAV[BX]
    079A  C41E2A00    LES      BX,MEMORYUSERSTACKPTR
    079E  268907      MOV      ES:MEMORYUSERSTACK[BX],AX
243  3      END;
                                ; STATEMENT # 243
    07A1  8006680001  ADD      I,1H
    07A6  75D2        JNZ     @146
                                @147:
244  2      USERSTACK.OFF = USERSTACK.OFF - 2;
                                ; STATEMENT # 244
    07A8  832E2A0002  SUB      USERSTACK,2H
245  2      MEMORY$USERSTACK = BP;
                                ; STATEMENT # 245
    07AD  A13A00      MOV      AX,REGSAV+0AH
    07B0  C41E2A00    LES      BX,MEMORYUSERSTACKPTR
    07B4  268907      MOV      ES:MEMORYUSERSTACK[BX],AX
246  2      CALL RESTORE$EXECUTE$CODE$PTR(USERSTACK.OFF,USERSTACK.SEG);

```

```

; STATEMENT # 246
07B7 FF362A00    PUSH    USERSTACK; 1
07BB FF362C00    PUSH    USERSTACK+2H; 2
247 2 07BF 2EFF160400 CALL    CS:RESTOREEXECUTECODEPTR
      END;

; STATEMENT # 247
07C4 5D          POP     BP
07C5 C3          RET
      RESTOREEXECUTE    ENDP

248 1  INTERRUPT1$ENTRY:
      ; STATEMENT # 248
      /* THIS PROCEDURE IS CALLED WHEN THE CPU IS INTERRUPTED BY EXECUTING
      AN INSTRUCTION WITH THE TRAP BIT SET (SINGLE STEP). */
07C6 06          PUSH    ES
07C7 1E          PUSH    DS
07C8 2E8E1EA600 MOV     DS,CS:@@DATA$FRAME
07CD 50          PUSH    AX
07CE 51          PUSH    CX
07CF 52          PUSH    DX
07D0 53          PUSH    BX
07D1 56          PUSH    SI
07D2 57          PUSH    DI
07D3 E80900      CALL    INTERRUPT1ENTRY
07D6 5F          POP     DI
07D7 5E          POP     SI
07D8 5B          POP     BX
07D9 5A          POP     DX
07DA 59          POP     CX
07DB 58          POP     AX
07DC 1F          POP     DS
07DD 07          POP     ES
07DE CF          IRET
      INTERRUPT1ENTRY    PROC NEAR
07DF 55          PUSH    BP
07E0 8BEC        MOV     BP,SP
      PROCEDURE INTERRUPT 1;
249 2  USERSTACK.OFF = STACKPTR; /* CHANGE TO MONITOR'S STACK */
      ; STATEMENT # 249
07E2 89E0        MOV     AX,SP
07E4 A32A00        MOV     USERSTACK,AX
250 2  USERSTACK.SEG = STACKBASE;
      ; STATEMENT # 250
07E7 8CD0        MOV     AX,SS
07E9 A32C00        MOV     USERSTACK+2H,AX
251 2  STACKPTR = MONITOR$STACKPTR;
      ; STATEMENT # 251
07EC A11400        MOV     AX,MONITORSTACKPTR
07EF 89C4        MOV     SP,AX
252 2  STACKBASE = MONITOR$STACKBASE;
      ; STATEMENT # 252
07F1 A11600        MOV     AX,MONITORSTACKBASE
07F4 8ED0        MOV     SS,AX
253 2  CALL SAVE$REGISTERS;
      ; STATEMENT # 253
07F6 E81CFF        CALL    SAVEREGISTERS

```

```

254 2          FL = FL AND (NOT STEP$TRAP);          /* CLEAR STEP FLAG */
          ; STATEMENT # 254
07F9 81264A00FFFE AND REGSAV+1AH,0FEFFH
255 2          IF LAST$COMMAND<>SS$COMMAND THEN /* CONTINUE IF NOT SS */
          ; STATEMENT # 255
07FF 803E6A0003 CMP LASTCOMMAND,3H
0804 7403 JZ @31
256 2          CALL RESTORE$EXECUTE;
          ; STATEMENT # 256
0806 E85DFF CALL RESTOREEXECUTE
          @31:
257 2          CALL SIO$CRLF;
          ; STATEMENT # 257
0809 E89BFC CALL SIOCRLF
258 2          CALL SIO$UPDATE$IP;
          ; STATEMENT # 258
080C E816FE CALL SIOUPDATEIP
259 2          IF CHAR=', ' THEN
          ; STATEMENT # 259
080F 803E66002C CMP CHAR,2CH
0814 7515 JNZ @32
260 2          DO;
261 3          IP = CSIP.OFF;
          ; STATEMENT # 261
0816 A12600 MOV AX,CSIP
0819 A34800 MOV REGSAV+18H,AX
262 3          CS = CSIP.SEG;
          ; STATEMENT # 262
081C A12800 MOV AX,CSIP+2H
081F A34000 MOV REGSAV+10H,AX
263 3          FL = FL OR STEP$TRAP;          /* SET STEP FLAG */
          ; STATEMENT # 263
0822 810E4A000001 OR REGSAV+1AH,100H
264 3          CALL RESTORE$EXECUTE;
          ; STATEMENT # 264
0828 E83BFF CALL RESTOREEXECUTE
265 3          END;
          @32:
266 2          IF CHAR<>ASCR THEN GOTO ERROR;
          ; STATEMENT # 266
082B 803E66000D CMP CHAR,0DH
0830 7403 JZ $+5H
0832 E9D1F9 JMP ERROR
268 2          GOTO NEXT$COMMAND;
          ; STATEMENT # 268
0835 E937F9 JMP NEXTCOMMAND
269 2          END;
          INTERRUPT1ENTRY ENDP
270 1          INTERRUPT3$ENTRY:
          ; STATEMENT # 270
          /* THIS PROCEDURE IS CALLED WHEN THE CPU EXECUTES A 'INT 3' INSTRUCTION.
          THE MONITOR INSERTS THIS (OCCH) FOR A BREAKPOINT. ALSO AN EXTERNAL
          INTERRUPT OR A USER SOFTWARE INTERRUPT MAY CAUSE THIS PROCEDURE TO BE
          CALLED. */
0838 06 PUSH ES
0839 1E PUSH DS

```

```

083A 2E8E1EA600    MOV     DS,CS:@@DATA$FRAME
083F 50              PUSH    AX
0840 51              PUSH    CX
0841 52              PUSH    DX
0842 53              PUSH    BX
0843 56              PUSH    SI
0844 57              PUSH    DI
0845 E80900         CALL    INTERRUPT3ENTRY
0848 5F              POP     DI
0849 5E              POP     SI
084A 5B              POP     BX
084B 5A              POP     DX
084C 59              POP     CX
084D 58              POP     AX
084E 1F              POP     DS
084F 07              POP     ES
0850 CF              IRET

                INTERRUPT3ENTRY    PROC NEAR
0851 55              PUSH    BP
0852 8BEC           MOV     BP,SP
                PROCEDURE INTERRUPT 3;
271 2              USERSTACK.OFF = STACKPTR;
                                ; STATEMENT # 271
0854 89E0           MOV     AX,SP
0856 A32A00         MOV     USERSTACK,AX
272 2              USERSTACK.SEG = STACKBASE;
                                ; STATEMENT # 272
0859 8CD0           MOV     AX,SS
085B A32C00         MOV     USERSTACK+2H,AX
273 2              STACKPTR = MONITOR$STACKPTR;
                                ; STATEMENT # 273
085E A11400         MOV     AX,MONITORSTACKPTR
0861 89C4           MOV     SP,AX
274 2              STACKBASE = MONITOR$STACKBASE;
                                ; STATEMENT # 274
0863 A11600         MOV     AX,MONITORSTACKBASE
0866 8ED0           MOV     SS,AX
275 2              CALL SAVE$REGISTERS;
                                ; STATEMENT # 275
0868 E8AAFE         CALL    SAVEREGISTERS
276 2              CALL SIO$CRLF;
                                ; STATEMENT # 276
086B E839FC         CALL    SIOCRLF
277 2              GOTO AFTER$INTERRUPT;
                                ; STATEMENT # 277
086E E9A7F9         JMP     AFTERINTERRUPT
278 2              END;
                INTERRUPT3ENTRY    ENDP

279 1              INIT$INT$VECTOR:
                                ; STATEMENT # 279
/* THIS ROUTINE INITIALIZES AN INTERRUPT VECTOR AS FOLLOWS: THE OFFSET
FROM THE ADDRESS OF 'INT$ROUTINE' CORRECTED BY THE APPROPRIATE
NUMBER OF BYTES FOR THE INTERRUPT PLM PROLOGUE. THE SEGMENT FROM THE
CURRENT CS REGISTER IS DETERMINED BY A MACHINE LANGUAGE CODED
SUBROUTINE. */
                INITINTVECTOR    PROC NEAR

```

```

0871 55          PUSH   BP
0872 8BEC        MOV     BP,SP
280  2          PROCEDURE(INT$VECTOR$PTR,INT$ROUTINE$OFFSET);
                DECLARE INT$VECTOR$PTR POINTER, INT$ROUTINE$OFFSET WORD,
                VECTOR BASED INT$VECTOR$PTR STRUCTURE (OFF WORD, SEG WORD),
                CORRECTION LITERALLY '19H', /* OFFSET FOR PROLOGUE */
                INIT$INT$VECTOR$CODE(*) BYTE DATA
                (055H, /* PUSH BP */
                08BH,0ECH, /* MOV BP,SP */
                08CH,0C8H, /* MOV AX,CS */
                0C4H,05EH,004H, /* LES BX,/BP/,P.ARM1 */
                026H,089H,007H, /* MOV ES:W/BX/,AX */
                05DH, /* POP BP */
                0C2H,004H,000H), /* RET 4 */
                INIT$INT$VECTOR$CODE$PTR WORD DATA (.INIT$INT$VECTOR$CODE);
281  2          CALL INIT$INT$VECTOR$CODE$PTR(@VECTOR.SEG); /* SEGMENT PORTION */
                ; STATEMENT # 281
0874 C45E06      LES     BX,[BP].INTVECTORPTR
0877 268D4702    LEA    AX,ES:VECTOR[BX+2H]
087B 06          PUSH   ES ; 1
087C 50          PUSH   AX ; 2
087D 2EFF160600  CALL   CS:INITINTVECTORCODEPTR
282  2          VECTOR.OFF = INT$ROUTINE$OFFSET - CORRECTION; /* OFFSET PORTION */
                ; STATEMENT # 282
0882 8B4604      MOV     AX,[BP].INTROUTINEOFFSET
0885 83E819      SUB     AX,19H
0888 C45E06      LES     BX,[BP].INTVECTORPTR
088B 268907      MOV     ES:VECTOR[BX],AX
283  2          END;
                ; STATEMENT # 283
088E 5D          POP     BP
088F C20600      RET     6H
                INITINTVECTOR ENDP

```

/\* \*\*\*\*\*  
\*\*\*\*\*

COMMAND MODULE  
=====

ABSTRACT  
=====

THIS MODULE CONTAINS ALL THE COMMANDS IMPLEMENTED AS INDIVIDUAL PROCEDURES  
AND CALLED FROM THE OUTER BLOCK OF THE COMMAND DISPATCH LOOP.

MODULE ORGANIZATION  
=====

THIS MODULE CONTAINS THE FOLLOWING SECTIONS:

1. COMMANDS SECTION
  - SIO\$GO GO
  - SIO\$SINGLE\$STEP SINGLE STEP
  - SIO\$EXAM\$MEM SUBSTITUTE MEMORY
  - SIO\$EXAM\$REG EXAMINE REGISTER
  - SIO\$MOVE MOVE
  - SIO\$DISPLAY DISPLAY BYTES

```

SIO$INPUT      INPUT PORT
SIO$OUTPUT     OUTPUT PORT
SIO$WRITE      WRITE DATA RECORDS
SIO$READ       READ DATA RECORDS
2. COMMAND DISPATCH (OUTER BLOCK, MAIN PROGRAM LOOP)
NEXT$COMMAND   DISPATCH
ERROR          ERROR ROUTINE
    */

```

```

/*****
*   COMMAND SECTION
*****/

```

```

284  1      SIO$GO:
                                           ; STATEMENT # 284
        /* IMPLEMENTS THE 'GO' COMMAND. THE USER MAY SPECIFY A NEW
        IP:PC AND AN OPTIONAL BREAKPOINT. */
        SIOGO      PROC NEAR
0892  55          PUSH    BP
0893  8BEC        MOV     BP,SP
        PROCEDURE;
285  2          CALL SIO$UPDATE$IP;
                                           ; STATEMENT # 285
0895  E88DFD     CALL    SIOUPDATEIP
286  2          IF CHAR=',,' THEN
                                           /* BREAKPOINT */
                                           ; STATEMENT # 286
0898  803E66002C  CMP     CHAR,2CH
089D  753C       JNZ     @34
287  2          DO;
288  3          CALL SIO$GET$CHAR;
                                           ; STATEMENT # 288
089F  E86DFA     CALL    SIOGETCHAR
289  3          CALL SIO$GET$ADDR(@BRK1,CSIP,SEG);
                                           ; STATEMENT # 289
08A2  8D062200   LEA    AX,BRK1
08A6  1E         PUSH   DS      ; 1
08A7  50         PUSH   AX      ; 2
08A8  FF362800   PUSH   CSIP+2H ; 3
08AC  E835FD     CALL    SIOGETADDR
290  3          IF CHAR<>ASCR THEN GOTO ERROR;
                                           ; STATEMENT # 290
08AF  803E66000D  CMP     CHAR,ODH
08B4  7403       JZ     $+5H
08B6  E94DF9     JMP     ERROR
292  3          BRK1$SAVE = MEMORY$BRK1;
                                           ; STATEMENT # 292
08B9  C41E2200   LES    BX,MEMORYBRK1PTR
08BD  268A07     MOV    AL,ES:MEMORYBRK1[BX]
08C0  A26500     MOV    BRK1$SAVE,AL
293  3          MEMORY$BRK1 = BREAK$INST;
                                           ; STATEMENT # 293
08C3  26C607CC   MOV    ES:MEMORYBRK1[BX],OCCH
294  3          IF MEMORY$BRK1<>BREAK$INST THEN GOTO ERROR;
                                           ; STATEMENT # 294
08C7  C41E2200   LES    BX,MEMORYBRK1PTR
08CB  26803FCC     CMP    ES:MEMORYBRK1[BX],OCCH

```

```

08CF 7403          JZ      $+5H
08D1 E932F9       JMP      ERROR
296  3           BRK1$FLAG = TRUE;
                                ; STATEMENT # 296
08D4 C6066400FF  MOV      BRK1FLAG,OFFH
297  3           END;
                                ; STATEMENT # 297
08D9 EBOA        JMP      @37
                                ; STATEMENT # 297
                                @34:
298  2           ELSE
                                IF CHAR<>ASCR THEN GOTO ERROR;
                                ; STATEMENT # 298
                                /* NO BREAKPOINT */
08DB 803E66000D  CMP      CHAR,ODH
08E0 7403        JZ      $+5H
08E2 E921F9       JMP      ERROR
                                ; STATEMENT # 299
                                @37:
                                CALL SIO$CRLF;
                                ; STATEMENT # 300
08E5 E8BFFB      CALL     SIOCRLF
301  2           IP = CSIP.OFF;
                                ; STATEMENT # 301
08E8 A12600        MOV      AX,CSIP
08EB A34800        MOV      REGSAV+18H,AX
302  2           CS = CSIP.SEG;
                                ; STATEMENT # 302
08EE A12800        MOV      AX,CSIP+2H
08F1 A34000        MOV      REGSAV+10H,AX
303  2           FL = FL AND (NOT STEP$TRAP);
                                /* CLEAR IF SET */
                                ; STATEMENT # 303
08F4 81264A00FFF AND      REGSAV+1AH,0FEFFH
304  2           CALL RESTORE$EXECUTE;
                                ; STATEMENT # 304
08FA E869FE       CALL     RESTORE$EXECUTE
305  2           END;
                                ; STATEMENT # 305
08FD 5D          POP      BP
08FE C3          RET
                                SIOGO ENDP
306  1           SIO$SINGLE$STEP:
                                ; STATEMENT # 306
                                /* IMPLEMENTS THE SINGLE STEP COMMAND. DISPLAYS IP AND THE
                                CURRENT INSTRUCTION BYTE. OPENS CS:IP FOR INPUT. DEPRESSING
                                COMMA CAUSES THE MONITOR TO SINGLE STEP THE INSTRUCTION, AND
                                PERIOD TERMINATES THE COMMAND. */
                                SIOSINGLESTEP PROC NEAR
08FF 55          PUSH     BP
0900 8BEC        MOV      BP,SP
307  2           PROCEDURE;
                                CALL SIO$UPDATE$IP;
                                ; STATEMENT # 307
0902 E820FD      CALL     SIOUPDATEIP
308  2           IF CHAR<>',' THEN GOTO ERROR;
                                ; STATEMENT # 308
0905 803E66002C  CMP      CHAR,2CH
090A 7403        JZ      $+5H

```



```

090C E9F7F8      JMP      ERROR
          IP = CSIP.OFF;
                                ; STATEMENT # 310
090F A12600      MOV      AX,CSIP
0912 A34800      MOV      REGSAV+18H,AX
311  2          CS = CSIP.SEG;
                                ; STATEMENT # 311
0915 A12800      MOV      AX,CSIP+2H
0918 A34000      MOV      REGSAV+10H,AX
312  2          FL = FL OR STEP$TRAP;
                                ; STATEMENT # 312
091B 810E4A000001 OR      REGSAV+1AH,100H
313  2          CALL RESTORE$EXECUTE;
                                ; STATEMENT # 313
0921 E842FE      CALL      RESTOREEXECUTE
314  2          END;
                                ; STATEMENT # 314
0924 5D          POP      BP
0925 C3          RET
          SIOSINGLESTEP      ENDP
315  1          SIO$EXAM$MEM:
                                ; STATEMENT # 315
          /* IMPLEMENTS THE EXAMINE MEMORY COMMAND. */
          SIOEXAMMEM      PROC NEAR
0926 55          PUSH     BP
0927 8BEC      MOV      BP,SP
          PROCEDURE;
316  2          DECLARE W WORD;
317  2          CALL SIO$TEST$WORD$MODE;
                                ; STATEMENT # 317
0929 E88CFB      CALL      SIOTESTWORDMODE
318  2          CALL SIO$GET$ADDR(@ARG1,CS);
                                ; STATEMENT # 318
092C 8D061A00     LEA     AX,ARG1
0930 1E          PUSH     DS      ; 1
0931 50          PUSH     AX      ; 2
0932 FF364000     PUSH     REGSAV+10H; 3
0936 E8ABFC      CALL      SIOGETADDR
319  2          IF CHAR<>',' THEN GOTO ERROR;
                                ; STATEMENT # 319
0939 803E66002C  CMP      CHAR,2CH
093E 7403      JZ       $+5H
0940 E9C3F8      JMP      ERROR
321  2          DO WHILE TRUE;
                                ; STATEMENT # 321
          @148:
322  3          CALL SIO$OUT$BLANK;
                                ; STATEMENT # 322
0943 E831FA      CALL      SIOOUTBLANK
323  3          IF WORD$MODE THEN
                                ; STATEMENT # 323
0946 A06900      MOV      AL,WORDMODE
0949 D0D8      RCR      AL,1
094B 730C      JNB     @41
324  3          CALL SIO$OUT$WORD(MEMORY$WORD$ARG1);
                                ; STATEMENT # 324

```

```

094D C41E1A00      LES     BX, MEMORYARG1PTR
0951 26FF37        PUSH    ES:MEMORYWORDARG1[BX]
0954 E809FA        CALL   SIOOUTWORD
0957 EBOA           JMP     @42

      @41:
      ELSE
325  3             CALL   SIO$OUT$BYTE(MEMORY$ARG1);
                                ; STATEMENT # 325
0959 C41E1A00      LES     BX, MEMORYARG1PTR
095D 26FF37        PUSH    ES:MEMORYARG1[BX]
0960 E8CDF9        CALL   SIOOUTBYTE

      @42:
326  3             CALL   SIO$OUT$CHAR('-');
                                ; STATEMENT # 326
0963 B02D           MOV     AL, 2DH
0965 50            PUSH    AX
0966 E886F9        CALL   SIOOUTCHAR
327  3             CALL   SIO$OUT$BLANK;
                                ; STATEMENT # 327
0969 E80BFA        CALL   SIOOUTBLANK
328  3             CALL   SIO$GET$CHAR;
                                ; STATEMENT # 328
096C E8A0F9        CALL   SIOGETCHAR
329  3             IF CHAR=ASCR THEN RETURN;
                                ; STATEMENT # 329
096F 803E66000D    CMP     CHAR, ODH
0974 7502         JNZ     @43
                                ; STATEMENT # 330
0976 5D           POP     BP
0977 C3           RET

      @43:
331  3             IF CHAR<>',' THEN
                                ; STATEMENT # 331
0978 803E66002C    CMP     CHAR, 2CH
097D 745C         JZ      @44
332  3             DO;
333  4             W = SIO$GET$WORD;
                                ; STATEMENT # 333
097F E86EFB        CALL   SIOGETWORD
0982 A35200        MOV     W, AX
334  4             IF (CHAR <> ',') AND (CHAR <> ASCR) THEN GOTO ERROR;
                                ; STATEMENT # 334
0985 803E66002C    CMP     CHAR, 2CH
098A B0FF         MOV     AL, OFFH
098C 7501         JNZ     $+3H
098E 40           INC     AX
098F 50           PUSH    AX
0990 803E66000D    CMP     CHAR, ODH
0995 B0FF         MOV     AL, OFFH
0997 7501         JNZ     $+3H
0999 40           INC     AX
099A 59           POP     CX
099B 22C1         AND     AL, CL
099D D0D8         RCR     AL, 1
099F 7303         JNB     $+5H
09A1 E962F8        JMP     ERROR
336  4             IF WORD$MODE THEN

```

```

; STATEMENT # 336
09A4 A06900 MOV AL,WORDMODE
09A7 D0D8 RCR AL,1
09A9 7317 JNB @46
337 4 DO;
338 5 MEMORY$WORD$ARG1 = W;
; STATEMENT # 338
09AB A15200 MOV AX,W
09AE C41E1A00 LES BX,MEMORYARG1PTR
09B2 268907 MOV ES:MEMORYWORDARG1[BX],AX
339 5 IF MEMORY$WORD$ARG1<>W THEN GOTO ERROR;
; STATEMENT # 339
09B5 C41E1A00 LES BX,MEMORYARG1PTR
09B9 268B07 MOV AX,ES:MEMORYWORDARG1[BX]
09BC 3B065200 CMP AX,W
09C0 EB14 JMP @11
341 5 END;
; STATEMENT # 341
@46:
ELSE
342 4 DO;
343 5 MEMORY$ARG1 = LOW(W);
; STATEMENT # 343
09C2 A15200 MOV AX,W
09C5 C41E1A00 LES BX,MEMORYARG1PTR
09C9 268807 MOV ES:MEMORYARG1[BX],AL
344 5 IF MEMORY$ARG1<>LOW(W) THEN GOTO ERROR;
; STATEMENT # 344
09CC A15200 MOV AX,W
09CF C41E1A00 LES BX,MEMORYARG1PTR
09D3 263807 CMP ES:MEMORYARG1[BX],AL
@11:
09D6 7403 JZ $+5H
09D8 E92BF8 JMP ERROR
; STATEMENT # 345
346 5 END;
347 4 END;
@44:
348 3 IF CHAR=ASCR THEN RETURN;
; STATEMENT # 348
09DB 803E66000D CMP CHAR,ODH
09E0 7502 JNZ @50
; STATEMENT # 349
09E2 5D POP BP
09E3 C3 RET
350 3 @50:
IF WORD$MODE THEN
; STATEMENT # 350
09E4 A06900 MOV AL,WORDMODE
09E7 D0D8 RCR AL,1
09E9 7307 JNB @51
351 3 ARG1.OFF = ARG1.OFF + 2;
; STATEMENT # 351
09EB 83061A0002 ADD ARG1,2H
09F0 EB05 JMP @52
@51:
ELSE

```

```

352 3          ARG1.OFF = ARG1.OFF + 1;
          ; STATEMENT # 352
          09F2 83061A0001      ADD      ARG1,1H
          @52:
353 3          CALL SIO$CRLF;
          ; STATEMENT # 353
          09F7 E8ADFA          CALL      SIOCRLF
354 3          CALL SIO$OUT$WORD(ARG1.OFF);
          ; STATEMENT # 354
          09FA FF361A00      PUSH      ARG1      ; 1
          09FE E85FF9      CALL      SIOOUTWORD
355 3          END;
          ; STATEMENT # 355
          0A01 E93FFF      JMP      @148
          @149:
356 2          END;
          ; STATEMENT # 356
          0A04 5D          POP      BP
          0A05 C3          RET
          SIOEXAMMEM      ENDP

357 1          SIO$EXAM$REG:
          ; STATEMENT # 357
          /* IMPLEMENTS THE EXAMINE REGISTER COMMAND. SCANS FOR A VALID
          REGISTER NAME AND DISPLAYS THE VALUE OF THAT REGISTER WHICH IS
          OPTIONALLY OPENED FOR INPUT. COMMA INCREMENTS TO NEXT REGISTER
          UNLESS IT IS 'FL' WHICH TERMINATES AS DOES CR. */
          SIOEXAMREG      PROC NEAR
          0A06 55          PUSH      BP
          0A07 8BEC      MOV      BP,SP
          PROCEDURE;
358 2          DECLARE (T,I) BYTE, SAVE WORD;
359 2          CALL SIO$SCAN$BLANK;
          ; STATEMENT # 359
          0A09 E8D2FA          CALL      SIOSCANBLANK
360 2          IF CHAR=ASCR THEN
          ; STATEMENT # 360
          0A0C 803E66000D      CMP      CHAR,0DH
          0A11 7559          JNZ      @53
361 2          DO;
362 3          CALL SIO$CRLF;
          ; STATEMENT # 362
          0A13 E891FA          CALL      SIOCRLF
363 3          DO I=0 TO 13;
          ; STATEMENT # 363
          0A16 C606700000      MOV      I,0H
          @150:
          0A1B 803E70000D      CMP      I,0DH
          0A20 7748          JA      @151
364 4          CALL SIO$OUT$BLANK;
          ; STATEMENT # 364
          0A22 E852F9          CALL      SIOOUTBLANK
365 4          CALL SIO$OUT$CHAR(REG(I*2));
          ; STATEMENT # 365
          0A25 A07000          MOV      AL,I
          0A28 B102          MOV      CL,2H
          0A2A F6E1          MUL      CL

```

```

366 4 0A2C 89C3          MOV     BX,AX
      0A2E 2EFF7758     PUSH    CS:REG[BX]
      0A32 E8BAF8     CALL    SIOOUTCHAR
      CALL SIO$OUT$CHAR(REG(I*2+1));
      ; STATEMENT # 366

      0A35 A07000     MOV     AL,I
      0A38 B102     MOV     CL,2H
      0A3A F6E1     MUL     CL
      0A3C 89C3     MOV     BX,AX
      0A3E 2EFF7759     PUSH    CS:REG[BX+1H]
      0A42 E8AAF8     CALL    SIOOUTCHAR
367 4  CALL SIO$OUT$CHAR('=');
      ; STATEMENT # 367

      0A45 B03D     MOV     AL,3DH
      0A47 50     PUSH    AX ; 1
      0A48 E8A4F8     CALL    SIOOUTCHAR
368 4  CALL SIO$OUT$WORD(REG$SAV(I));
      ; STATEMENT # 368

      0A4B 8A1E7000     MOV     BL,I
      0A4F B700     MOV     BH,0H
      0A51 D1E3     SHL     BX,1
      0A53 FF7730     PUSH    REGSAV[BX]; 1
      0A56 E807F9     CALL    SIOOUTWORD
369 4  IF I=6 THEN CALL SIO$CRLF;
      ; STATEMENT # 369

      0A59 803E700006     CMP     I,6H
      0A5E 7503     JNZ     @54
      ; STATEMENT # 370

      0A60 E844FA     CALL    SIOCRLF
371 4  @54:
      END;
      ; STATEMENT # 371

      0A63 8006700001     ADD     I,1H
      0A68 75B1     JNZ     @150
372 3  @151:
      RETURN;
      ; STATEMENT # 372

      0A6A 5D     POP     BP
      0A6B C3     RET
373 3  END;
374 2  @53:
      IF NOT(SIO$VALID$REG$FIRST) THEN GOTO ERROR;
      ; STATEMENT # 374

      0A6C E8C2F9     CALL    SIOVALIDREGFIRST
      0A6F F6D0     NOT     AL
      0A71 D0D8     RCR     AL,1
      0A73 7303     JNB     $+5H
      0A75 E98EF7     JMP     ERROR
376 2  T = CHAR;
      ; STATEMENT # 376

      0A78 A06600     MOV     AL,CHAR
      0A7B A26F00     MOV     T,AL
377 2  CALL SIO$GET$CHAR;
      ; STATEMENT # 377

      0A7E E88EF8     CALL    SIOGETCHAR
378 2  IF NOT(SIO$VALID$REG(T,CHAR)) THEN GOTO ERROR;
      ; STATEMENT # 378

```

```

0A81 FF366F00      PUSH    T          ; 1
0A85 FF366600      PUSH    CHAR       ; 2
0A89 E8D4F9        CALL    SIOVALIDREG
0A8C F6D0           NOT     AL
0A8E D0D8           RCR    AL,1
0A90 7303          JNB    $+5H
0A92 E971F7        JMP    ERROR
380  2             I = REG$INDEX;
                                ; STATEMENT # 380
0A95 A12E00         MOV     AX,REGINDEX
0A98 A27000         MOV     I,AL
381  2             DO WHILE TRUE;
                                ; STATEMENT # 381
                                @152:
382  3             CALL SIO$OUT$CHAR('=');
                                ; STATEMENT # 382
0A9B B03D           MOV     AL,3DH
0A9D 50             PUSH   AX          ; 1
0A9E E84EF8        CALL   SIOOUTCHAR
383  3             CALL SIO$OUT$WORD(REG$SAV(I));
                                ; STATEMENT # 383
0AA1 8A1E7000      MOV     BL,I
0AA5 B700           MOV     BH,0H
0AA7 D1E3          SHL    BX,1
0AA9 FF7730         PUSH   REGSAV[BX]; 1
0AAC E8B1F8        CALL   SIOOUTWORD
384  3             CALL SIO$OUT$CHAR('-');
                                ; STATEMENT # 384
0AAF B02D           MOV     AL,2DH
0AB1 50             PUSH   AX          ; 1
0AB2 E83AF8        CALL   SIOOUTCHAR
385  3             CALL SIO$OUT$BLANK;
                                ; STATEMENT # 385
0AB5 E8BFF8        CALL   SIOOUTBLANK
386  3             CALL SIO$GET$CHAR;
                                ; STATEMENT # 386
0AB8 E854F8        CALL   SIOGETCHAR
387  3             IF CHAR<>',' AND CHAR<>ASCR THEN
                                ; STATEMENT # 387
0ABB 803E66002C    CMP     CHAR,2CH
0ACO B0FF          MOV     AL,OFFH
0AC2 7501          JNZ    $+3H
0AC4 40           INC     AX
0AC5 50           PUSH   AX          ; 1
0AC6 803E66000D    CMP     CHAR,0DH
0ACB B0FF          MOV     AL,OFFH
0ACD 7501          JNZ    $+3H
0ACF 40           INC     AX
0ADO 59           POP     CX          ; 1
0AD1 22C1          AND    AL,CL
0AD3 D0D8          RCR    AL,1
0AD5 7333          JNB    @57
388  3             DO;
389  4             SAVE = SIO$GET$WORD;
                                ; STATEMENT # 389
0AD7 E816FA        CALL   SIOGETWORD
0ADA A35400         MOV     SAVE,AX

```

```

390  4          IF (CHAR <> ',' ) AND (CHAR <> ASCR) THEN GOTO ERROR;
                                ; STATEMENT # 390
OADD  803E66002C      CMP      CHAR,2CH
OAE2  B0FF           MOV      AL,OFFH
OAE4  7501           JNZ      $+3H
OAE6  40             INC      AX
OAE7  50             PUSH     AX          ; 1
OAE8  803E66000D     CMP      CHAR,ODH
OAE9  B0FF           MOV      AL,OFFH
OAEF  7501           JNZ      $+3H
OAF1  40             INC      AX
OAF2  59             POP      CX          ; 1
OAF3  22C1           AND      AL,CL
OAF5  D0D8           RCR      AL,1
OAF7  7303           JNB      $+5H
OAF9  E90AF7         JMP      ERROR
392  4          REG$SAV(I) = SAVE;
                                ; STATEMENT # 392
OAF9  8A1E7000       MOV      BL,I
OB00  B700           MOV      BH,0H
OB02  D1E3           SHL      BX,1
OB04  A15400         MOV      AX,SAVE
OB07  894730         MOV      REGSAV[BX],AX
393  4          END;
                                @57:
394  3          IF CHAR=ASCR OR I=13 THEN RETURN;
                                ; STATEMENT # 394
OB0A  803E66000D     CMP      CHAR,ODH
OB0F  B0FF           MOV      AL,OFFH
OB11  7401           JZ       $+3H
OB13  40             INC      AX
OB14  50             PUSH     AX          ; 1
OB15  803E70000D     CMP      I,ODH
OB1A  B0FF           MOV      AL,OFFH
OB1C  7401           JZ       $+3H
OB1E  40             INC      AX
OB1F  59             POP      CX          ; 1
OB20  0AC1           OR       AL,CL
OB22  D0D8           RCR      AL,1
OB24  7302           JNB      @59
                                ; STATEMENT # 395
OB26  5D             POP      BP
OB27  C3             RET
                                @59:
396  3          I = I + 1;
                                ; STATEMENT # 396
OB28  8006700001     ADD      I,1H
397  3          CALL SIO$CRLF;
                                ; STATEMENT # 397
OB2D  E877F9         CALL     SIOCRLF
398  3          CALL SIO$OUT$CHAR(REG(I*2));
                                ; STATEMENT # 398
OB30  A07000         MOV      AL,I
OB33  B102           MOV      CL,2H
OB35  F6E1           MUL      CL
OB37  89C3           MOV      BX,AX
OB39  2EFF7758       PUSH     CS:REG[BX]

```

```

399 3  OB3D E8AFF7          CALL    SIOOUTCHAR
      CALL SIO$OUT$CHAR(REG(I*2+1));
      ; STATEMENT # 399
      OB40 A07000          MOV     AL,I
      OB43 B102            MOV     CL,2H
      OB45 F6E1            MUL     CL
      OB47 89C3            MOV     BX,AX
      OB49 2EFF7759        PUSH    CS:REG[BX+1H]
      OB4D E89FF7          CALL    SIOOUTCHAR
400 3  END;
      ; STATEMENT # 400
      OB50 E948FF          JMP     @152
      @153:
401 2  END;
      ; STATEMENT # 401
      OB53 5D              POP     BP
      OB54 C3              RET
      SIOEXAMREG          ENDP
402 1  SIO$MOVE:
      ; STATEMENT # 402
      /* IMPLEMENTS THE MOVE COMMAND. ACCEPTS 3 ARGUMENTS AND MOVES THE
      BLOCK OF MEMORY SPECIFIED BY ARG1-ARG2 TO ARG3. ARG2<ARG1 OR THERE
      IS A DIFFERENCE WHEN THE BYTE IS READ BACK, THEN ERROR. */
      SIOMOVE            PROC NEAR
      OB55 55              PUSH    BP
      OB56 8BEC            MOV     BP,SP
      PROCEDURE;
403 2  CALL SIO$SCAN$BLANK;
      ; STATEMENT # 403
      OB58 E883F9          CALL    SIOSCANBLANK
404 2  CALL SIO$GET$ADDR(@ARG1,CS);
      /* FIRST ARGUMENT */
      ; STATEMENT # 404
      OB5B 8D061A00        LEA    AX,ARG1
      OB5F 1E              PUSH    DS ; 1
      OB60 50              PUSH    AX ; 2
      OB61 FF364000        PUSH    REGSAV+10H; 3
      OB65 E87CFA          CALL    SIOGETADDR
405 2  IF CHAR<>',' THEN GOTO ERROR;
      ; STATEMENT # 405
      OB68 803E66002C      CMP     CHAR,2CH
      OB6D 7403            JZ     $+5H
      OB6F E994F6          JMP     ERROR
407 2  CALL SIO$GET$CHAR;
      ; STATEMENT # 407
      OB72 E89AF7          CALL    SIOGETCHAR
408 2  END$OFF = SIO$GET$WORD;
      /* SECOND ARGUMENT */
      ; STATEMENT # 408
      OB75 E878F9          CALL    SIOGETWORD
      OB78 A31800          MOV     ENDOFF,AX
409 2  IF END$OFF<ARG1.OFF THEN GOTO ERROR;
      ; STATEMENT # 409
      OB7B A11300          MOV     AX,ENDOFF
      OB7E 3B061A00        CMP     AX,ARG1
      OB82 7303            JNB    $+5H
      OB84 E97FF6          JMP     ERROR
411 2  IF CHAR<>',' THEN GOTO ERROR;

```



```

; STATEMENT # 411
OB87 803E66002C    CMP    CHAR,2CH
OB8C 7403          JZ     $+5H
OB8E E975F6        JMP     ERROR
413 2             CALL  SIO$GET$CHAR;
; STATEMENT # 413
OB91 E87BF7        CALL  SIOGETCHAR
414 2             CALL  SIO$GET$ADDR(@ARG3,CS); /* THIRD ARGUMENT */
; STATEMENT # 414
OB94 8D061E00     LEA   AX,ARG3
OB98 1E           PUSH  DS ; 1
OB99 50           PUSH  AX ; 2
OB9A FF364000     PUSH  REGSAV+10H; 3
OB9E E843FA        CALL  SIOGETADDR
415 2             IF CHAR<>ASCR THEN GOTO ERROR;
; STATEMENT # 415
OBA1 803E66000D   CMP    CHAR,ODH
OBA6 7403         JZ     $+5H
OBA8 E95BF6       JMP     ERROR
417 2             CALL  SIO$CRLF;
; STATEMENT # 417
OBAB E8F9F8       CALL  SIOCRLF
418 2             LOOP:
; STATEMENT # 418
LOOP:
MEMORY$ARG3 = MEMORY$ARG1;
OBAA C41E1A00     LES   BX,MEMORYARG1PTR
OBB2 268A07     MOV   AL,ES:MEMORYARG1[BX]
OBB5 C41E1E00     LES   BX,MEMORYARG3PTR
OBB9 268807     MOV   ES:MEMORYARG3[BX],AL
419 2             IF MEMORY$ARG3<>MEMORY$ARG1 THEN GOTO ERROR;
; STATEMENT # 419
OBBC C41E1E00     LES   BX,MEMORYARG3PTR
OBC0 268A07     MOV   AL,ES:MEMORYARG3[BX]
OBC3 C41E1A00     LES   BX,MEMORYARG1PTR
OBC7 263A07     CMP   AL,ES:MEMORYARG1[BX]
OBCA 7403         JZ     $+5H
OBCC E937F6       JMP     ERROR
421 2             IF ARG1.OFF = END$OFF THEN RETURN;
; STATEMENT # 421
OBCF A11A00       MOV   AX,ARG1
OBD2 3B061800    CMP   AX,ENDOFF
OBD6 7502        JNZ   @65
; STATEMENT # 422
OBD8 5D          POP   BP
OBD9 C3          RET
@65:
423 2             ARG1.OFF = ARG1.OFF + 1;
; STATEMENT # 423
OBDA 83061A0001   ADD   ARG1,1H
424 2             ARG3.OFF = ARG3.OFF + 1;
; STATEMENT # 424
OBDF 83061E0001   ADD   ARG3,1H
425 2             GOTO LOOP;
; STATEMENT # 425
OBE4 EBC8        JMP   LOOP
426 2             END;

```

SIOMOVE ENDP

```

427 1      SIO$DISPLAY:
                                ; STATEMENT # 427
      /* IMPLEMENTS THE DISPLAY BYTE COMMAND. IF CALLED WITH 1 PARM THEN
      OUTPUTS A SINGLE BYTE. IF CALLED WITH 2 PARMS THEN OUTPUTS THE RANGE
      BETWEEN THE TWO ADDRESSES. IF OFFSET<BEGIN THEN OUTPUTS ONLY A SINGLE
      BYTE. */
      SIODISPLAY      PROC NEAR
OBE6 55      PUSH      BP
OBE7 8BEC    MOV       BP,SP
      PROCEDURE;
428 2      DECLARE T BYTE;
429 2      CALL SIO$TEST$WORD$MODE;
                                ; STATEMENT # 429
OBE9 E8CCF8  CALL      SIOTESTWORDMODE
430 2      CALL SIO$GET$ADDR(@ARG1,CS);
                                ; STATEMENT # 430
OBE6 8D061A00 LEA     AX,ARG1
OBF0 1E      PUSH     DS      ; 1
OBF1 50      PUSH     AX      ; 2
OBF2 FF364000 PUSH    REGSAV+10H; 3
OBF6 E8EBF9  CALL     SIOGETADDR
431 2      IF CHAR=ASCR THEN
                                ; STATEMENT # 431
OBF9 803E66000D CMP     CHAR,ODH
OBF6 7508    JNZ     @66
432 2      END$OFF = ARG1.OFF;
                                ; STATEMENT # 432
OC00 A11A00   MOV     AX,ARG1
OC03 A31800   MOV     ENDOFF,AX
OC06 EB29     JMP     NEWLINE
      @66:
      ELSE
433 2      DO;
434 3      IF CHAR<>' ,' THEN GOTO ERROR;
                                ; STATEMENT # 434
OC08 803E66002C CMP     CHAR,2CH
OC0D 7403     JZ      $+5H
OC0F E9F4F5   JMP     ERROR
436 3      CALL SIO$GET$CHAR;
                                ; STATEMENT # 436
OC12 E8FAF6   CALL     SIOGETCHAR
437 3      END$OFF = SIO$GET$WORD;
                                ; STATEMENT # 437
OC15 E8D8F8   CALL     SIOGETWORD
OC18 A31800   MOV     ENDOFF,AX
438 3      IF END$OFF < ARG1.OFF THEN GOTO ERROR;
                                ; STATEMENT # 438
OC1B A11800   MOV     AX,ENDOFF
OC1E 3B061A00 CMP     AX,ARG1
OC22 7303     JNB     $+5H
OC24 E9DFF5   JMP     ERROR
440 3      IF CHAR<>ASCR THEN GOTO ERROR;
                                ; STATEMENT # 440
OC27 803E66000D CMP     CHAR,ODH
OC2C 7403     JZ      $+5H

```

```

442 3 0C2E E9D5F5 JMP ERROR
443 2 END;
NEWLINE: ; STATEMENT # 443
NEWLINE:
CALL SIO$CRLF;
444 2 0C31 E873F8 CALL SIOCRLF
CALL SIO$OUT$WORD(ARG1.OFF); ; STATEMENT # 444
0C34 FF361A00 PUSH ARG1 ; 1
0C38 E825F7 CALL SIOOUTWORD
445 2 LOOP: CALL SIO$OUT$BLANK; ; STATEMENT # 445
LOOP:
0C3B E839F7 CALL SIOOUTBLANK
446 2 IF WORD$MODE THEN ; STATEMENT # 446
0C3E A06900 MOV AL,WORDMODE
0C41 D0D8 RCR AL,1
0C43 731C JNB @71
447 2 DO;
448 3 CALL SIO$OUT$WORD(MEMORY$WORD$ARG1); ; STATEMENT # 448
0C45 C41E1A00 LES BX,MEMORYARG1PTR
0C49 26FF37 PUSH ES:MEMORYWORDARG1[BX]
0C4C E811F7 CALL SIOOUTWORD
449 3 IF ARG1.OFF = END$OFF THEN RETURN; ; STATEMENT # 449
0C4F A11A00 MOV AX,ARG1
0C52 3B061800 CMP AX,ENDOFF
0C56 7502 JNZ @72 ; STATEMENT # 450
0C58 5D POP BP
0C59 C3 RET
@72:
451 3 ARG1.OFF = ARG1.OFF + 1; ; STATEMENT # 451
0C5A 83061A0001 ADD ARG1,1H
452 3 END; ; STATEMENT # 452
0C5F EBOA JMP @73 ; STATEMENT # 452
@71:
453 2 ELSE
CALL SIO$OUT$BYTE(MEMORY$ARG1); ; STATEMENT # 453
0C61 C41E1A00 LES BX,MEMORYARG1PTR
0C65 26FF37 PUSH ES:MEMORYARG1[BX]
0C68 E8C5F6 CALL SIOOUTBYTE
@73:
454 2 IF ARG1.OFF>=END$OFF THEN RETURN; ; STATEMENT # 454
0C6B A11A00 MOV AX,ARG1
0C6E 3B061800 CMP AX,ENDOFF
0C72 7202 JB @74 ; STATEMENT # 455
0C74 5D POP BP
0C75 C3 RET

```

```

@74:
456 2      ARG1.OFF = ARG1.OFF + 1;
; STATEMENT # 456
OC76 83061A0001      ADD      ARG1,1H
457 2      T = ARG1.OFF AND 000FH;
; STATEMENT # 457
OC7B A11A00          MOV      AX,ARG1
OC7E 250F00          AND      AX,0FH
OC81 A27100          MOV      T,AL
458 2      IF T=0 OR (WORD$MODE AND T=1) THEN GOTO NEWLINE;
; STATEMENT # 458
OC84 823E710000     CMP      T,0H
OC89 B0FF            MOV      AL,0FFH
OC8B 7401            JZ       $+3H
OC8D 40              INC      AX
OC8E 50              PUSH     AX      ; 1
OC8F 803E710001     CMP      T,1H
OC94 B0FF            MOV      AL,0FFH
OC96 7401            JZ       $+3H
OC98 40              INC      AX
OC99 22066900       AND      AL,WORDMODE
OC9D 59              POP      CX      ; 1
OC9E 0AC1            OR       AL,CL
OCA0 D0D8            RCR      AL,1
OCA2 728D            JB       NEWLINE
460 2      GOTO LOOP;
; STATEMENT # 460
OCA4 EB95            JMP      LOOP
461 2      END;
SIODISPLAY      ENDP
462 1      SIO$INPUT:
; STATEMENT # 462
/* THIS ROUTINE IMPLEMENTS THE 'INPUT' COMMAND. USER SPECIFIES
A PORT AND THE DATUM OF THE PORT IS DISPLAYED. */
SIOINPUT      PROC NEAR
OCA6 55              PUSH     BP
OCA7 8BEC            MOV      BP,SP
PROCEDURE;
463 2      DECLARE PORT WORD;
464 2      CALL SIO$TEST$WORD$MODE;
; STATEMENT # 464
OCA9 E80CF8          CALL     SIOTESTWORDMODE
465 2      PORT = SIO$GET$WORD;
; STATEMENT # 465
OCAC E841F8          CALL     SIOGETWORD
OCAF A35600          MOV      PORT,AX
466 2      LOOP:
; STATEMENT # 466
LOOP:
OCB2 803E66002C     CMP      CHAR,2CH
OCB7 7403            JZ       $+5H
OCB9 E94AF5          JMP      ERROR
IF CHAR<>',' THEN GOTO ERROR;
468 2      CALL SIO$CRLF;
; STATEMENT # 468
OCBC E8E8F7          CALL     SIOCRLF

```

```

469 2          IF WORD$MODE THEN
                                ; STATEMENT # 469
      OCBF A06900          MOV     AL,WORDMODE
      OCC2 D0D8           RCR     AL,1
      OCC4 730B           JNB     @77
470 2          CALL SIO$OUT$WORD(INWORD(PORT));
                                ; STATEMENT # 470
      OCC6 8B165600       MOV     DX,PORT
      OCCA ED             INW     DX
      OCCB 50             PUSH    AX ; 1
      OCCC E891F6         CALL   SIOOUTWORD
      OCCF EB09           JMP     @78
                                @77:
471 2          ELSE
      CALL SIO$OUT$BYTE(INPUT(PORT));
                                ; STATEMENT # 471
      OCD1 8B165600       MOV     DX,PORT
      OCD5 EC             IN      DX
      OCD6 50             PUSH    AX ; 1
      OCD7 E856F6         CALL   SIOOUTBYTE
                                @78:
472 2          CALL SIO$GET$CHAR;
                                ; STATEMENT # 472
      OCDA E832F6         CALL   SIOGETCHAR
473 2          IF CHAR=ASCR THEN RETURN;
                                ; STATEMENT # 473
      OCDD 803E6600D      CMP     CHAR,ODH
      OCE2 75CE           JNZ     LOOP
                                ; STATEMENT # 474
      OCE4 5D             POP     BP
      OCE5 C3             RET
475 2          GOTO LOOP;
476 2          END;
                                SIOINPUT      ENDP
477 1          SIO$OUTPUT:
                                ; STATEMENT # 477
      /* THIS ROUTINE IMPLEMENTS THE 'OUTPUT' COMMAND. THE USER SUPPLIED
      DATUM IS OUTPUT TO THE SPECIFIED PORT. */
      SIOOUTPUT          PROC NEAR
      OCE6 55             PUSH    BP
      OCE7 8BEC           MOV     BP,SP
      PROCEDURE;
478 2          DECLARE (DATUM,PORT) WORD;
479 2          CALL SIO$TEST$WORD$MODE;
                                ; STATEMENT # 479
      OCE9 E8CCF7         CALL   SIOTESTWORDMODE
480 2          PORT = SIO$GET$WORD;
                                ; STATEMENT # 480
      OCEC E801F8         CALL   SIOGETWORD
      OCEF A35A00         MOV     PORT,AX
481 2          IF CHAR<>',' THEN GOTO ERROR;
                                ; STATEMENT # 481
      OCF2 803E66002C     CMP     CHAR,2CH
      OCF7 7403           JZ      $+5H
      OCF9 E90AF5         JMP     ERROR
483 2          CALL SIO$GET$CHAR;

```

```

; STATEMENT # 483
484 2   OCFC E810F6      CALL   SIOGETCHAR
      LOOP:
; STATEMENT # 484
      LOOP:
      DATUM = SIO$GET$WORD;
      OCFF E8EEF7      CALL   SIOGETWORD
      OD02 A35800      MOV    DATUM,AX
485 2   IF CHAR=':' THEN GOTO ERROR;
; STATEMENT # 485
      OD05 803E66003A  CMP    CHAR,3AH
      OD0A 7503        JNZ    $+5H
      OD0C E9F7F4      JMP    ERROR
487 2   IF WORD$MODE THEN
; STATEMENT # 487
      OD0F A06900      MOV    AL,WORDMODE
      OD12 D0D8        RCR    AL,1
      OD14 730A        JNB   @82
488 2   OUTWORD(PORT) = DATUM;
; STATEMENT # 488
      OD16 8B165A00    MOV    DX,PORT
      OD1A A15800      MOV    AX,DATUM
      OD1D EF          OUTW  DX
      OD1E EB08        JMP    @83
      @82:
      ELSE
489 2   OUTPUT(PORT) = LOW(DATUM);
; STATEMENT # 489
      OD20 A15800      MOV    AX,DATUM
      OD23 8B165A00    MOV    DX,PORT
      OD27 EE          OUT   DX
      @83:
490 2   IF CHAR=', ' THEN
; STATEMENT # 490
      OD28 803E66002C  CMP    CHAR,2CH
      OD2D 7516        JNZ    @84
491 2   DO;
492 3   CALL SIO$CRLF;
; STATEMENT # 492
      OD2F E875F7      CALL   SIOCRLF
493 3   CALL SIO$OUT$CHAR('-');
; STATEMENT # 493
      OD32 B02D        MOV    AL,2DH
      OD34 50          PUSH  AX ; 1
      OD35 E8B7F5      CALL   SIOOUTCHAR
494 3   CALL SIO$OUT$BLANK;
; STATEMENT # 494
      OD38 E83CF6      CALL   SIOOUTBLANK
495 3   CALL SIO$GET$CHAR;
; STATEMENT # 495
      OD3B E8D1F5      CALL   SIOGETCHAR
496 3   IF CHAR <> ASCR THEN GOTO LOOP;
; STATEMENT # 496
      OD3E 803E66000D  CMP    CHAR,ODH
      OD43 75BA        JNZ    LOOP
; STATEMENT # 497
498 3   END;

```

```

@84:
499 2      END;                                ; STATEMENT # 499
      OD45 5D      POP      BP
      OD46 C3      RET
      SIOOUTPUT      ENDP

500 1      SIO$WRITE:                          ; STATEMENT # 500
      /* IMPLEMENTS THE PAPER TAPE WRITE COMMAND. OUTPUTS LEADING NULLS,
      EXTENDED ADDRESS RECORD (8086 ONLY), START ADDRESS RECORDS
      (8086 ONLY), DATA RECORDS, EOF RECORD, AND TRAILING NULLS. */
      SIOWRITE      PROC NEAR
      OD47 55      PUSH     BP
      OD48 8BEC    MOV      BP,SP
      PROCEDURE;
      DECLARE (START$REC,MODE$8086) BYTE, (LEN,INDEX) WORD;
      CALL SIO$GET$CHAR;
      ; STATEMENT # 502
      OD4A E8C2F5    CALL     SIOGETCHAR
      MODE$8086 = TRUE;
      ; STATEMENT # 503
      OD4D C6067300FF  MOV     MODE8086,0FFH
      IF CHAR='X' THEN /* TEST FOR 8080 MODE */
      ; STATEMENT # 504
      OD52 803E660058  CMP     CHAR,58H
      OD57 7508      JNZ     @86
      DO;
      MODE$8086 = FALSE;
      ; STATEMENT # 506
      OD59 C606730000  MOV     MODE8086,0H
      CALL SIO$GET$CHAR;
      ; STATEMENT # 507
      OD5E E8AEF5      CALL     SIOGETCHAR
      END;
      @86:
      IF CHAR=ASBL THEN CALL SIO$GET$CHAR;
      ; STATEMENT # 509
      OD61 803E660020  CMP     CHAR,20H
      OD66 7503      JNZ     @87
      ; STATEMENT # 510
      OD68 E8A4F5      CALL     SIOGETCHAR
      @87:
      CALL SIO$GET$ADDR(@ARG1,CS);
      ; STATEMENT # 511
      OD6B 8D061A00    LEA     AX,ARG1
      OD6F 1E          PUSH    DS ; 1
      OD70 50          PUSH    AX ; 2
      OD71 FF364000    PUSH    REGSAV+10H; 3
      OD75 E86CF8      CALL     SIOGETADDR
      IF CHAR<>' ' THEN GOTO ERROR;
      ; STATEMENT # 512
      OD78 803E66002C  CMP     CHAR,2CH
      OD7D 7403      JZ      $+5H
      OD7F E984F4      JMP     ERROR
      CALL SIO$GET$CHAR;
      ; STATEMENT # 514

```

```

515 2   OD82 E88AF5      CALL   SIOGETCHAR
      END$OFF = SIO$GET$WORD;
      ; STATEMENT # 515
      OD85 E868F7      CALL   SIOGETWORD
      OD88 A31800      MOV    ENDOFF,AX
516 2   IF END$OFF<ARG1.OFF THEN GOTO ERROR;
      ; STATEMENT # 516
      OD8B A11800      MOV    AX,ENDOFF
      OD8E 3B061A00    CMP    AX,ARG1
      OD92 7303        JNB   $+5H
      OD94 E96FF4      JMP   ERROR
518 2   IF CHAR<>ASCR THEN
      ; STATEMENT # 518
      OD97 803E66000D  CMP    CHAR,ODH
      OD9C 7417        JZ    @90
519 2   DO;
520 3   START$REC = TRUE;
      ; STATEMENT # 520
      OD9E C6067200FF  MOV    STARTREC,OFFH
521 3   CALL SIO$GET$CHAR;
      ; STATEMENT # 521
      ODA3 E869F5      CALL   SIOGETCHAR
522 3   CALL SIO$GET$ADDR(@ARG3,CS);
      ; STATEMENT # 522
      ODA6 8D061E00    LEA   AX,ARG3
      ODAA 1E          PUSH  DS ; 1
      ODAB 50          PUSH  AX ; 2
      ODAC FF364000    PUSH  REGSAV+10H; 3
      ODB0 E831F8      CALL   SIOGETADDR
523 3   END;
      ; STATEMENT # 523
      ODB3 EBOB        JMP   @91
      @90:
524 2   ELSE
525 3   DO;
      START$REC = FALSE;
      ; STATEMENT # 525
      ODB5 C606720000  MOV    STARTREC,0H
526 3   ARG3.OFF = 0;
      ; STATEMENT # 526
      ODBA C7061E000000  MOV    ARG3,0H
527 3   END;
      @91:
528 2   IF CHAR<>ASCR THEN GOTO ERROR;
      ; STATEMENT # 528
      ODC0 803E66000D  CMP    CHAR,ODH
      ODC5 7403        JZ    $+5H
      ODC7 E93CF4      JMP   ERROR
530 2   CALL SIO$CRLF;
      ; STATEMENT # 530
      ODCA E8DAF6      CALL   SIOCRLF
531 2   DO I=1 TO 60;
      /* LEADING NULLS */
      ; STATEMENT # 531
      ODCD C606680001  MOV    I,1H
      @154:
      ODD2 803E68003C  CMP    I,3CH

```



```

532 3   ODD7 770D          JA      @155
          CALL SIO$OUT$CHAR(0);
          ; STATEMENT # 532
          ODD9 B000          MOV     AL,0H
          ODDB 50           PUSH   AX      ; 1
          ODDC E810F5        CALL   SIOOUTCHAR
533 3   END;
          ; STATEMENT # 533
          ODDF 8006680001    ADD     I,1H
          ODE4 75EC          JNZ    @154
          @155:
534 2   CALL SIO$CRLF;
          ; STATEMENT # 534
          ODE6 E8BEF6        CALL   SIOCRLF
          IF MODE$8086 THEN
          ; STATEMENT # 535
          ODE9 A07300        MOV     AL,MODE8086
          ODEC D0D8          RCR    AL,1
          ODEE 734E          JNB   @93
536 2   DO;
537 3   IF START$REC THEN
          ; STATEMENT # 537
          ODF0 A07200        MOV     AL,STARTREC
          ODF3 D0D8          RCR    AL,1
          ODF5 732B          JNB   @94
538 3   DO;
539 4   CALL SIO$OUT$HEADER(04,0,03); /* START ADDRESS RECORD */
          ; STATEMENT # 539
          ODF7 B004          MOV     AL,4H
          ODF9 50           PUSH   AX      ; 1
          ODFA B80000        MOV     AX,0H
          ODFD 50           PUSH   AX      ; 2
          ODFE B003          MOV     AL,3H
          OE00 50           PUSH   AX      ; 3
          OE01 E8B1F5        CALL   SIOOUTHEADER
540 4   CALL SIO$OUT$WORD(ARG3.SEG);
          ; STATEMENT # 540
          OE04 FF362000      PUSH   ARG3+2H ; 1
          OE08 E855F5        CALL   SIOOUTWORD
541 4   CALL SIO$OUT$WORD(ARG3.OFF);
          ; STATEMENT # 541
          OE0B FF361E00      PUSH   ARG3    ; 1
          OE0F E84EF5        CALL   SIOOUTWORD
542 4   CALL SIO$OUT$BYTE(CHECK$SUM);
          ; STATEMENT # 542
          OE12 FF366700      PUSH   CHECKSUM; 1
          OE16 E817F5        CALL   SIOOUTBYTE
543 4   CALL SIO$CRLF;
          ; STATEMENT # 543
          OE19 E88BF6        CALL   SIOCRLF
          ARG3.OFF = 0;
          ; STATEMENT # 544
          OE1C C7061E000000  MOV     ARG3,0H
          END;
          @94:
546 3   CALL SIO$OUT$HEADER(02,0,02); /* EXTENDED ADDRESS RECORD */

```

```

                                ; STATEMENT # 546
0E22 B002          MOV     AL,2H
0E24 50           PUSH    AX          ; 1
0E25 B90000       MOV     CX,0H
0E28 51           PUSH    CX          ; 2
0E29 50           PUSH    AX          ; 3
0E2A E888F5       CALL   SIOOUTHEADER
547 3             CALL   SIO$OUT$WORD(ARG1.SEG);
                                ; STATEMENT # 547
0E2D FF361C00     PUSH    ARG1+2H ; 1
0E31 E82CF5       CALL   SIOOUTWORD
548 3             CALL   SIO$OUT$BYTE(CHECK$SUM);
                                ; STATEMENT # 548
0E34 FF366700     PUSH    CHECKSUM; 1
0E38 E8F5F4       CALL   SIOOUTBYTE
549 3             CALL   SIO$CRLF;
                                ; STATEMENT # 549
0E3B E869F6       CALL   SIOCRLF
550 3             END;
                    @93:
551 2             LEN = STANDARD$LEN;          /* DATA RECORD */
                                ; STATEMENT # 551
0E3E C7065C001000 MOV    LEN,10H
552 2             LOOP: INDEX = END$OFF - ARG1.OFF;
                                ; STATEMENT # 552
                    LOOP:
0E44 A11800       MOV     AX,ENDOFF
0E47 2B061A00     SUB     AX,ARG1
0E4B A35E00       MOV     INDEX,AX
553 2             IF INDEX<STANDARD$LEN THEN LEN = INDEX + 1;
                                ; STATEMENT # 553
0E4E 83F810       CMP     AX,10H
0E51 7309         JNB    @95
                                ; STATEMENT # 554
0E53 A15E00       MOV     AX,INDEX
0E56 83C001       ADD     AX,1H
0E59 A35C00       MOV     LEN,AX
                    @95:
555 2             CALL   SIO$OUT$HEADER(LEN,ARG1.OFF,00);
                                ; STATEMENT # 555
0E5C FF365C00     PUSH    LEN          ; 1
0E60 FF361A00     PUSH    ARG1        ; 2
0E64 B000         MOV     AL,0H
0E66 50           PUSH    AX          ; 3
0E67 E84BF5       CALL   SIOOUTHEADER
556 2             DO I=1 TO LEN;
                                ; STATEMENT # 556
0E6A C606680001   MOV     I,1H
                    @156:
0E6F A06800       MOV     AL,I
0E72 B400         MOV     AH,0H
0E74 3B065C00     CMP     AX,LEN
0E78 7716         JA     @157
557 3             CALL   SIO$OUT$BYTE(MEMORY$ARG1);
                                ; STATEMENT # 557
0E7A C41E1A00     LES     BX,MEMORYARG1PTR

```



```

                                ; STATEMENT # 570
OED6 5D                POP     BP
OED7 C3                RET
                                SIOWRITE      ENDP

571 1      SIO$READ:
                                ; STATEMENT # 571
                                /* IMPLEMENTS THE READ PAPER TAPE COMMAND. */
                                SIOREAD      PROC NEAR
OED8 55                PUSH    BP
OED9 8BEC              MOV     BP,SP
                                PROCEDURE;
572 2      DECLARE BIAS WORD, (REC$TYPE,LEN,I,T) BYTE, OFFSET WORD;
573 2      BIAS = 0;
                                /* DEFAULT BIAS */
                                ; STATEMENT # 573
OEDB C70660000000     MOV     BIAS,0H
574 2      ARG1.SEG = 0;
                                /* DEFAULT CS FOR 8080 FORMAT FILE */
                                ; STATEMENT # 574
OEE1 C7061C000000     MOV     ARG1+2H,0H
575 2      CALL SIO$SCAN$BLANK;
                                ; STATEMENT # 575
OEE7 E8F4F5           CALL    SIOSCANBLANK
576 2      IF CHAR<>ASCR THEN BIAS = SIO$GET$WORD;
                                ; STATEMENT # 576
OEEA 803E66000D      CMP     CHAR,0DH
OEEF 7406             JZ      @97
                                ; STATEMENT # 577
OEF1 E8FCF5           CALL    SIOGETWORD
OEF4 A36000           MOV     BIAS,AX
                                @97:
578 2      IF CHAR<>ASCR THEN GOTO ERROR;
                                ; STATEMENT # 578
OEF7 803E66000D      CMP     CHAR,0DH
OEF8 7403             JZ      $+5H
OEFE E905F3           JMP     ERROR
580 2      CALL SIO$CRLF;
                                ; STATEMENT # 580
OF01 E8A3F5           CALL    SIOCRLF
581 2      LOOP:
                                ; STATEMENT # 581
                                LOOP:
OF04 E87BF7           CALL    SIOREADCHAR
OF07 3C3A             CMP     AL,3AH
OF09 75F9             JNZ    LOOP
                                DO WHILE SIO$READ$CHAR<>' ':;END;
583 2      CHECK$SUM = 0;
                                ; STATEMENT # 583
OF0B C606670000     MOV     CHECKSUM,0H
584 2      LEN = SIO$READ$BYTE;
                                ; STATEMENT # 584
OF10 E8BAF7           CALL    SIOREADBYTE
OF13 A27500           MOV     LEN,AL
585 2      OFFSET = SIO$READ$WORD;
                                ; STATEMENT # 585
OF16 E8DFF7           CALL    SIOREADWORD
OF19 A36200           MOV     OFFSET,AX
586 2      ARG1.OFF = OFFSET + BIAS;

```

```

; STATEMENT # 586
OF1C A16200      MOV     AX,OFFSET
OF1F 03066000   ADD     AX,BIAS
587  2  OF23  A31A00      MOV     ARG1,AX
      REC$TYPE = SIO$READ$BYTE;
; STATEMENT # 587
OF26 E8A4F7      CALL    SIOREADBYTE
588  2  OF29  A27400      MOV     RECTYPE,AL
      IF REC$TYPE=03 THEN /* START ADDR TYPE */
; STATEMENT # 588
OF2C 803E740003  CMP     RECTYPE,3H
589  2  OF31  750C        JNZ    999
590  3          DO;
      CS = SIO$READ$WORD;
; STATEMENT # 590
OF33 E8C2F7      CALL    SIOREADWORD
591  3  OF36  A34000      MOV     REGSAV+10H,AX
      IP = SIO$READ$WORD;
; STATEMENT # 591
OF39 E8BCF7      CALL    SIOREADWORD
592  3  OF3C  A34800      MOV     REGSAV+18H,AX
      END;
      @99:
593  2          IF REC$TYPE=02 THEN /* EXTENDED ADDR TYPE */
; STATEMENT # 593
OF3F 803E740002  CMP     RECTYPE,2H
594  2  OF44  7506        JNZ    @100
      ARG1.SEG = SIO$READ$WORD;
; STATEMENT # 594
OF46 E8AFF7      CALL    SIOREADWORD
595  2  OF49  A31C00      MOV     ARG1+2H,AX
      @100:
      IF REC$TYPE = 01 THEN /* EOF */
; STATEMENT # 595
OF4C 803E740001  CMP     RECTYPE,1H
596  2  OF51  750D        JNZ    @101
      IF OFFSET <> 0 THEN IP = OFFSET;
; STATEMENT # 596
OF53 833E620000  CMP     OFFSET,0H
598  2  OF58  7406        JZ     @101
; STATEMENT # 597
OF5A A16200      MOV     AX,OFFSET
598  2  OF5D  A34800      MOV     REGSAV+18H,AX
      @101:
      IF REC$TYPE=00 THEN /* DATA TYPE */
; STATEMENT # 598
OF60 823E740000  CMP     RECTYPE,0H
599  2  OF65  7537        JNZ    @103
      DO I=1 TO LEN;
; STATEMENT # 599
OF67 C606760001  MOV     I,1H
      @162:
OF6C A07600      MOV     AL,I
599  2  OF6F  3A067500  CMP     AL,LEN
      OF73  7729        JA     @103
600  3          T,MEMORY$ARG1 = SIO$READ$BYTE;
; STATEMENT # 600

```

```

        OF75 E855F7      CALL    SIOREADBYTE
        OF78 A27700      MOV     T,AL
        OF7B C41E1A00    LES     BX,MEMORYARG1PTR
        OF7F 268807      MOV     ES:MEMORYARG1[BX],AL
601    3                IF MEMORY$ARG1<>T THEN GOTO ERROR;
                                ; STATEMENT # 601
        OF82 C41E1A00    LES     BX,MEMORYARG1PTR
        OF86 268A07      MOV     AL,ES:MEMORYARG1[BX]
        OF89 3A067700    CMP     AL,T
        OF8D 7403        JZ      $+5H
        OF8F E974F2      JMP     ERROR
603    3                ARG1.OFF = ARG1.OFF + 1;
                                ; STATEMENT # 603
        OF92 83061A0001  ADD     ARG1,1H
604    3                END;
                                ; STATEMENT # 604
        OF97 8006760001  ADD     I,1H
        OF9C 75CE        JNZ    @162
        @103:
605    2                T = SIO$READ$BYTE; /* FETCH CHECKSUM */
                                ; STATEMENT # 605
        OF9E E82CF7      CALL    SIOREADBYTE
        OFA1 A27700      MOV     T,AL
606    2                IF CHECK$SUM<>0 THEN GOTO ERROR;
                                ; STATEMENT # 606
        OFA4 823E670000  CMP     CHECKSUM,0H
        OFA9 7403        JZ      $+5H
        OFAB E958F2      JMP     ERROR
608    2                IF REC$TYPE<>01 AND LEN<>0 THEN GOTO LOOP;
                                ; STATEMENT # 608
        OFAE 803E740001  CMP     RECTYPE,1H
        OFB3 B0FF        MOV     AL,OFFH
        OFB5 7501        JNZ    $+3H
        OFB7 40          INC     AX
        OFB8 50          PUSH    AX ; 1
        OFB9 823E750000  CMP     LEN,0H
        OFBE B0FF        MOV     AL,OFFH
        OFC0 7501        JNZ    $+3H
        OFC2 40          INC     AX
        OFC3 59          POP     CX ; 1
        OFC4 22C1        AND     AL,CL
        OFC6 D0D8        RCR     AL,1
        OFC8 7303        JNB    $+5H
        OFCA E937FF      JMP     LOOP
610    2                CALL SIO$OUT$CHAR(0); /* DELAY FOR LAST CR, LF SENT */
                                ; STATEMENT # 610
        OFCD B000        MOV     AL,0H
        OFCF 50          PUSH    AX ; 1
        OFD0 E81CF3      CALL    SIOOUTCHAR
611    2                CALL SIO$OUT$CHAR(0); /* BY INTELLEC */
                                ; STATEMENT # 611
        OFD3 B000        MOV     AL,0H
        OFD5 50          PUSH    AX ; 1
        OFD6 E816F3      CALL    SIOOUTCHAR
612    2                END;
                                ; STATEMENT # 612
        OFD9 5D          POP     BP

```

OFDA C3 RET  
 SIORREAD ENDP

/\*  
 \* COMMAND DISPATCH MAIN PROGRAM LOOP \*  
 \*/

```

613 1          DISABLE;
                                ; STATEMENT # 613
00A8 FA          CLI
00A9 2E8E16A400  MOV     SS,CS:@@STACK$FRAME
00AE BC4200      MOV     SP,@@STACK$OFFSET
00B1 8BEC        MOV     BP,SP
00B3 2E8E1EA600  MOV     DS,CS:@@DATA$FRAME
00B8 FB          STI
00B9 FA          CLI
614 1          OUTPUT(KB$STAT$PORT) = KB$INIT$MODE;
                                ; STATEMENT # 614
00BA BAEAFF      MOV     DX,OFFEAFH
00BD B000        MOV     AL,0H
00BF EE          OUT     DX
615 1          OUTPUT(KB$STAT$PORT) = KB$INIT$SCAN;
                                ; STATEMENT # 615
00C0 B039        MOV     AL,39H
00C2 EE          OUT     DX
616 1          OUTPUT(KB$STAT$PORT) = 90H; /* OUTPUT '8086' SIGNON BACKWARDS */
                                ; STATEMENT # 616
00C3 B090        MOV     AL,90H
00C5 EE          OUT     DX
617 1          DO I=0 TO 7;
                                ; STATEMENT # 617
00C6 C606680000  MOV     I,0H
                                @164:
00CB 803E680007  CMP     I,7H
00D0 7715        JA      @165
618 2          OUTPUT(KB$DATA$PORT) = KB$SIGNON(I);
                                ; STATEMENT # 618
00D2 8A1E6800    MOV     BL,I
00D6 B700        MOV     BH,0H
00D8 2E8A471B    MOV     AL,CS:KBSIGNON[BX]
00DC BAE8FF      MOV     DX,OFFE8H
00DF EE          OUT     DX
619 2          END;
                                ; STATEMENT # 619
00E0 8006680001  ADD     I,1H
00E5 75E4        JNZ    @164
                                @165:
/* THIS STRANGE SEQUENCE OF CODE IS USED TO GUARANTEE CORRECT USART
INITIALIZATION AFTER EITHER: 1) HARDWARE RESET (EXPECTING MODE)
2) SOFTWARE RESTART (EXPECTING COMMAND). */
620 1          OUTPUT(SIO$STAT$PORT) = SIO$8251$RESET;
                                ; STATEMENT # 620
00E7 BAF2FF      MOV     DX,OFFF2H
00EA B065        MOV     AL,65H
    
```

```

621 1 00EC EE          OUT      DX
          CALL SIO$8251$SETTLING$DELAY;
          ; STATEMENT # 621
622 1 00ED E8E902     CALL      SIO8251SETTLINGDELAY
          OUTPUT(SIO$STAT$PORT) = 25H;
          ; STATEMENT # 622
          00F0 BAF2FF     MOV      DX,OFFF2H
          00F3 B025     MOV      AL,25H
          00F5 EE          OUT      DX
623 1          CALL SIO$8251$SETTLING$DELAY;
          ; STATEMENT # 623
624 1 00F6 E8E002     CALL      SIO8251SETTLINGDELAY
          OUTPUT(SIO$STAT$PORT) = SIO$8251$RESET;
          ; STATEMENT # 624
          00F9 BAF2FF     MOV      DX,OFFF2H
          00FC B065     MOV      AL,65H
          00FE EE          OUT      DX
625 1          CALL SIO$8251$SETTLING$DELAY;
          ; STATEMENT # 625
626 1 00FF E8D702     CALL      SIO8251SETTLINGDELAY
          OUTPUT(SIO$STAT$PORT) = SIO$8251$MODE;
          ; STATEMENT # 626
          0102 BAF2FF     MOV      DX,OFFF2H
          0105 B0CF     MOV      AL,OCFH
          0107 EE          OUT      DX
627 1          CALL SIO$8251$SETTLING$DELAY;
          ; STATEMENT # 627
628 1 0108 E8CE02     CALL      SIO8251SETTLINGDELAY
          OUTPUT(SIO$STAT$PORT) = SIO$8251$CMND;
          ; STATEMENT # 628
          010B BAF2FF     MOV      DX,OFFF2H
          010E B025     MOV      AL,25H
          0110 EE          OUT      DX
629 1          CALL SIO$8251$SETTLING$DELAY;
          ; STATEMENT # 629
630 1 0111 E8C502     CALL      SIO8251SETTLINGDELAY
          CALL SIO$OUT$STRING(@SIO$SIGNON);
          ; STATEMENT # 630
          0114 2E8D062700 LEA     AX,CS:SIO$SIGNON
          0119 0E          PUSH    CS          ; 1
          011A 50          PUSH    AX          ; 2
          011B E86402     CALL      SIOOUTSTRING
          /* INITIALIZE USER'S REGISTERS */
631 1          CS,SS,DS,ES,FL,IP = 0;
          ; STATEMENT # 631
          011E B80000     MOV     AX,0H
          0121 A34000     MOV     REGSAV+10H,AX
          0124 A34400     MOV     REGSAV+14H,AX
          0127 A34200     MOV     REGSAV+12H,AX
          012A A34600     MOV     REGSAV+16H,AX
          012D A34A00     MOV     REGSAV+1AH,AX
          0130 A34800     MOV     REGSAV+18H,AX
632 1          SP = USER$INIT$SP;
          ; STATEMENT # 632
          /* INITIALIZE INTERRUPT VECTORS */

```



```

633 1 0133 C70638000001 MOV REGSAV+8H,100H
      CALL INIT$INT$VECTOR(@INT$VECTOR(1),.INTERRUPT1$ENTRY);
      ; STATEMENT # 633
      0139 8D060400 LEA AX,INTVECTOR+4H
      013D 1E PUSH DS ; 1
      013E 50 PUSH AX ; 2
      013F B8DF07 MOV AX,OFFSET(INTERRUPT1$ENTRY)
      0142 50 PUSH AX ; 3
      0143 E82B07 CALL INITINTVECTOR
634 1 CALL INIT$INT$VECTOR(@INT$VECTOR(2),.INTERRUPT3$ENTRY);
      ; STATEMENT # 634
      0146 8D060800 LEA AX,INTVECTOR+8H
      014A 1E PUSH DS ; 1
      014B 50 PUSH AX ; 2
      014C B85108 MOV AX,OFFSET(INTERRUPT3$ENTRY)
      014F 50 PUSH AX ; 3
      0150 E81E07 CALL INITINTVECTOR
635 1 CALL INIT$INT$VECTOR(@INT$VECTOR(3),.INTERRUPT3$ENTRY);
      ; STATEMENT # 635
      0153 8D060C00 LEA AX,INTVECTOR+0CH
      0157 1E PUSH DS ; 1
      0158 50 PUSH AX ; 2
      0159 B85108 MOV AX,OFFSET(INTERRUPT3$ENTRY)
      015C 50 PUSH AX ; 3
      015D E81107 CALL INITINTVECTOR
636 1 BRK1$FLAG = FALSE;
      ; STATEMENT # 636
637 1 0160 C606640000 MOV BRK1$FLAG,0H
      MONITOR$STACKPTR = STACKPTR;
      ; STATEMENT # 637
      0165 89E0 MOV AX,SP
      0167 A31400 MOV MONITOR$STACKPTR,AX
638 1 MONITOR$STACKBASE = STACKBASE;
      ; STATEMENT # 638
      016A 8CD0 MOV AX,SS
      016C A31600 MOV MONITOR$STACKBASE,AX
639 1 NEXT$COMMAND:
      ; STATEMENT # 639
      /* THIS IS THE PERPETUAL COMMAND LOOP WHICH DISPATCHES TO EACH
      COMMAND WHICH IS A SEPARATED PROCEDURE. */
      NEXTCOMMAND:
      016F BC4200 MOV SP,@STACK$OFFSET
      0172 8BEC MOV BP,SP
      0174 2E8E1EA600 MOV DS,CS:@DATA$FRAME
      CALL SIO$CRLF;
      0179 E82B03 CALL SIOCRLF
      CALL SIO$OUT$CHAR(0);
      ; STATEMENT # 640
      017C B000 MOV AL,0H
      017E 50 PUSH AX ; 1
      017F E86D01 CALL SIOOUTCHAR
641 1 CALL SIO$OUT$CHAR(' ');
      ; STATEMENT # 641
      0182 B02E MOV AL,2EH

```

```

        0184 50          PUSH  AX      ; 1
        0185 E86701     CALL   SIOOUTCHAR
642  1          CALL SIO$GET$CHAR;
                                ; STATEMENT # 642
        0188 E88401     CALL   SIOGETCHAR
643  1          DO I=0 TO LAST(SIO$CMND);
                                ; STATEMENT # 643
        018B C606680000 MOV    I,0H
                                @166:
        0190 803E680009 CMP    I,9H
        0195 776F       JA     ERROR
644  2          IF CHAR=SIO$CMND(I) THEN GOTO DISPATCH;
                                ; STATEMENT # 644
        0197 A06600     MOV    AL,CHAR
        019A 8A1E6800   MOV    BL,I
        019E B700       MOV    BH,0H
        01A0 2E3A474E   CMP    AL,CS:SIOCMND[BX]
        01A4 7409       JZ     DISPATCH
646  2          END;
                                ; STATEMENT # 646
        01A6 8006680001 ADD    I,1H
        01AB 75E3       JNZ   @166
647  1          GOTO ERROR;
                                ; STATEMENT # 647
        01AD EB57       JMP    ERROR
648  1          DISPATCH:
                                ; STATEMENT # 648
                                DISPATCH:
                                LAST$COMMAND = I;
        01AF A06800     MOV    AL,I
        01B2 A26A00     MOV    LASTCOMMAND,AL
649  1          DO CASE I;
                                ; STATEMENT # 649
        01B5 B400       MOV    AH,0H
        01B7 89C3       MOV    BX,AX
        01B9 D1E3       SLL   BX,1
        01BB 2EFA7F201  JMP    CS:@168[BX]
650  2          CALL SIO$EXAM$MEM;
                                ; STATEMENT # 650
                                @109:
        01C0 E86307     CALL   SIOEXAMMEM
        01C3 EBAA       JMP    NEXTCOMMAND
651  2          CALL SIO$EXAM$REG;
                                ; STATEMENT # 651
                                @110:
        01C5 E83E08     CALL   SIOEXAMREG
        01C8 EBA5       JMP    NEXTCOMMAND
652  2          CALL SIO$GO;
                                ; STATEMENT # 652
                                @111:
        01CA E8C506     CALL   SIOGO
        01CD EBA0       JMP    NEXTCOMMAND
653  2          CALL SIO$SINGLE$STEP;
                                ; STATEMENT # 653
                                @112:
        01CF E82D07     CALL   SIOSINGLESTEP
        01D2 EB9B       JMP    NEXTCOMMAND

```

```

654 2          CALL SIO$MOVE;
                                ; STATEMENT # 654
                                @113:
01D4 E87E09          CALL SIO$MOVE
01D7 EB96            JMP NEXTCOMMAND
655 2          CALL SIO$DISPLAY;
                                ; STATEMENT # 655
                                @114:
01D9 E80A0A          CALL SIO$DISPLAY
01DC EB91            JMP NEXTCOMMAND
656 2          CALL SIO$INPUT;
                                ; STATEMENT # 656
                                @115:
01DE E8C50A          CALL SIO$INPUT
01E1 EB8C            JMP NEXTCOMMAND
657 2          CALL SIO$OUTPUT;
                                ; STATEMENT # 657
                                @116:
01E3 E8000B          CALL SIO$OUTPUT
01E6 EB87            JMP NEXTCOMMAND
658 2          CALL SIO$READ;
                                ; STATEMENT # 658
                                @117:
01E8 E8ED0C          CALL SIO$READ
                                @12:
01EB EB82            JMP NEXTCOMMAND
659 2          CALL SIO$WRITE;
                                ; STATEMENT # 659
                                @118:
01ED E8570B          CALL SIO$WRITE
01F0 EBF9            JMP @12
660 2          END;
                                ; STATEMENT # 660
                                @168:
01F2 C001            DW @109
01F4 C501            DW @110
01F6 CA01            DW @111
01F8 CF01            DW @112
01FA D401            DW @113
01FC D901            DW @114
01FE DE01            DW @115
0200 E301            DW @116
0202 E801            DW @117
0204 ED01            DW @118
661 1          GOTO NEXT$COMMAND;
662 1          ERROR:
                                ; STATEMENT # 662
/* THIS ROUTINE HANDLES ALL ERRORS DETECTED BY THE MONITOR AND
WILL OUTPUT THE ERROR PROMPT TO THE OUTPUT PORT.*/

ERROR:
0206 BC4200          MOV SP,@@STACK$OFFSET
0209 8BEC            MOV BP,SP
020B 2E8E1EA600       MOV DS,CS:@@DATA$FRAME
0210 B023            MOV AL,23H
0212 50              PUSH AX ; 1
    
```

```

0213 E8D900      CALL    SIOOUTCHAR
663  1          CALL SIO$OUT$CHAR('#');
          GOTO NEXT$COMMAND;
          ; STATEMENT # 663
0216 EBD3       JMP     @12
664  1          AFTER$INTERRUPT:
          ; STATEMENT # 664
          /* THIS ROUTINE IS CALLED AFTER AN INTERRUPT TO DISPLAY THE CS:IP
          AND RESTORE THE BREAKPOINTED INSTRUCTION. */

          AFTERINTERRUPT:
0218 BC4200     MOV     SP,@@STACK$OFFSET
021B 8BEC      MOV     BP,SP
021D 2E8E1EA600 MOV     DS,CS:@@DATA$FRAME
0222 A06400     MOV     AL,BRK1FLAG
0225 D0D8      RCR     AL,1
0227 735A     JNB     @119
665  1          IF BRK1$FLAG THEN
666  2          DO;
          MEMORY$BRK1 = BRK1$SAVE;
          ; STATEMENT # 666
0229 A06500     MOV     AL,BRK1SAVE
022C C41E2200   LES     BX,MEMORYBRK1PTR
0230 268807     MOV     ES:MEMORYBRK1[BX],AL
667  2          BRK1$FLAG = FALSE;
          ; STATEMENT # 667
668  2          0233 C606640000 MOV     BRK1FLAG,0H
          IF ((IP-1) AND 000FH)=(BRK1.OFF AND 000FH) AND
          ; STATEMENT # 668
0238 A14800     MOV     AX,REGSAV+18H
023B 83E801     SUB     AX,1H
023E 50        PUSH    AX ; 1
023F 250F00     AND     AX,0FH
0242 8B0E2200   MOV     CX,BRK1
0246 51        PUSH    CX ; 2
0247 81E10F00   AND     CX,0FH
024B 3BC1      CMP     AX,CX
024D B0FF      MOV     AL,0FFH
024F 7401     JZ     $+3H
0251 40        INC     AX
0252 5A        POP     DX ; 2
0253 8756FE     XCHG   DX,[BP]-2H; 1
0256 B104      MOV     CL,4H
0258 D3EA      SHR     DX,CL
025A 03164000   ADD     DX,REGSAV+10H
025E 5B        POP     BX ; 1
025F D3EB      SHR     BX,CL
0261 031E2400   ADD     BX,BRK1+2H
0265 50        PUSH    AX ; 1
0266 3BD3      CMP     DX,BX
0268 B0FF      MOV     AL,0FFH
026A 7401     JZ     $+3H
026C 40        INC     AX
026D 59        POP     CX ; 1
026E 22C1     AND     AL,CL
0270 D0D8      RCR     AL,1

```

```

0272 730F          JNB      @119
                   (SHR(IP-1,4)+CS)=(SHR(BRK1.OFF,4)+BRK1.SEG) THEN
669  2            DO;
670  3            IP = IP - 1;
                   ; STATEMENT # 670
0274 832E480001   SUB      REGSAV+18H,1H
671  3            CALL SIO$OUT$STRING(@SIO$BREAK$MESSG);
                   ; STATEMENT # 671
0279 2E8D062300   LEA      AX,CS:SIOBREAKMSG
027E 0E           PUSH     CS      ; 1
027F 50           PUSH     AX      ; 2
0280 E8FF00       CALL     SIOOUTSTRING
672  3            END;
673  2            END;
                   @119:
674  1            CALL SIO$OUT$CHAR('@');
                   ; STATEMENT # 674
0283 B040         MOV      AL,40H
0285 50           PUSH     AX      ; 1
0286 E86600       CALL     SIOOUTCHAR
675  1            CALL SIO$OUT$WORD(CS);
                   ; STATEMENT # 675
0289 FF364000     PUSH     REGSAV+10H; 1
028D E8D000       CALL     SIOOUTWORD
676  1            CALL SIO$OUT$CHAR(':');
                   ; STATEMENT # 676
0290 B03A         MOV      AL,3AH
0292 50           PUSH     AX      ; 1
0293 E85900       CALL     SIOOUTCHAR
677  1            CALL SIO$OUT$WORD(IP);
                   ; STATEMENT # 677
0296 FF36#800     PUSH     REGSAV+18H; 1
029A E8C300       CALL     SIOOUTWORD
678  1            GOTO NEXT$COMMAND;
                   ; STATEMENT # 678
029D E9CFFE       JMP      NEXTCOMMAND
679  1            END MONITOR;      /* END OF MODULE */
EOF

```

## CROSS-REFERENCE LISTING

DEFN	ADDR	SIZE	NAME, ATTRIBUTES, AND REFERENCES
664	0218H		AFTERINTERRUPT LABEL 277
169	0000H	4	ARG STRUCTURE BASED(PTR) 170 171 175 176
11	001AH	4	ARG1 STRUCTURE AT 318 351 352 354 404 409 421 423 430 432 438 444 449 451 454 456 457 511 516 547 552 555 558 562 574 586 594 603
11	001EH	4	ARG3 STRUCTURE AT 414 424 522 526 540 541 544 564
10			ASBL LITERALLY 48 63 125 130 509
7	003EH	16	ASCII BYTE ARRAY(16) DATA 53 54 86 87
10			ASCR LITERALLY 114 160 191 266 290 298 329 334 348 360 387 390 394 415 431 440 473 496 518 528 576 578
10			ASLF LITERALLY 115
51	0004H	1	B BYTE PARAMETER AUTOMATIC 52 53 54 55
572	0060H	2	BIAS WORD 573 577 586
15	FHFFF6H	2	BLOCK8089 WORD AT INITIAL ABSOLUTE
15	FHFFF8H	4	BLOCK8089PTR POINTER AT INITIAL ABSOLUTE
13	FHFFF0H	1	BOOT1 BYTE ARRAY(1) AT INITIAL ABSOLUTE
13	FHFFF1H	2	BOOT2 WORD ARRAY(1) AT INITIAL ABSOLUTE
13	FHFFF3H	2	BOOT3 WORD ARRAY(1) AT INITIAL ABSOLUTE
14	0000H	4	BOOT4 WORD ARRAY(2) DATA
12			BP LITERALLY 245

6		BREAKINST	LITERALLY 293 294
11	0022H	4 BRK1	STRUCTURE AT 289 668
5	0064H	1 BRK1FLAG	BYTE 296 636 664 667
5	0065H	1 BRK1SAVE	BYTE 292 666
92	0004H	1 C	BYTE PARAMETER AUTOMATIC 93 94 95 96
36	0004H	1 C	BYTE PARAMETER AUTOMATIC 37 42
105	0006H	1 C1	BYTE PARAMETER AUTOMATIC 106 108
105	0004H	1 C2	BYTE PARAMETER AUTOMATIC 106 108
5	0066H	1 CHAR	BYTE 23 24 25 28 29 33 47 48 49 100 120 125 130 138 143 153 154 160 162 163 172 177 191 210 212 259 266 286 290 298 308 319 329 331 334 348 360 376 378 387 390 394 405 411 415 431 434 440 466 473 481 485 490 496 504 509 512 518 528 576 578 644
5	0067H	1 CHECKSUM	BYTE 55 76 218 542 548 560 565 583 606
4	0008H	19 COPYRIGHT	BYTE ARRAY(19) DATA
280		CORRECTION	LITERALLY 282
12		CS	LITERALLY 184 192 318 404 414 430 511 522 668 675
11	0026H	4 CSIP	STRUCTURE AT 184 185 192 261 262 289 301 302 310 311
478	0058H	2 DATUM	WORD 484 488 489
168	0004H	2 DEFAULTBASE	WORD PARAMETER AUTOMATIC 169 170
195	0050H	2 DELAY	WORD 197 199 200







			86	643					
5	006AH	1	LASTCOMMAND	BYTE					
				255	648				
501	005CH	2	LEN	WORD					
				551	554	555	556		
572	0075H	1	LEN	BYTE					
				584	599	608			
73	0008H	1	LENGTH	BYTE	PARAMETER	AUTOMATIC			
				74	77				
73	0006H	2	LOADADDR	WORD	PARAMETER	AUTOMATIC			
				74	78				
418	0BAEH		LOOP	LABEL					
				425					
552	0E44H		LOOP	LABEL					
				563					
196	0685H		LOOP	LABEL					
				211					
466	0CB2H		LOOP	LABEL					
				475					
445	0C3BH		LOOP	LABEL					
				460					
484	0CFFH		LOOP	LABEL					
				497					
581	0F04H		LOOP	LABEL					
				609					
			LOW	BUILTIN					
				60	216	217	343	344	489
6			MAXDELAY	LITERALLY					
				200					
11	0000H	1	MEMORYARG1	BYTE	BASED(MEMORYARG1PTR)				
				325	343	344	418	419	453
									557
									600
									601
11	001AH	4	MEMORYARG1PTR	POINTER					
				11	324	325	338	339	343
				448	453	557	600	601	344
									418
									419
11	0000H	1	MEMORYARG3	BYTE	BASED(MEMORYARG3PTR)				
				418	419				
11	001EH	4	MEMORYARG3PTR	POINTER					
				11	418	419			

11	0000H	1	MEMORYBRK1	BYTE BASED(MEMORYBRK1PTR) 292 293 294 666
11	0022H	4	MEMORYBRK1PTR	POINTER 11 292 293 294 666
11	0000H	1	MEMORYCSIP	BYTE BASED(MEMORYCSIPPTR) 188
11	0026H	4	MEMORYCSIPPTR	POINTER 11 188
11	0000H	2	MEMORYUSERSTACK	WORD BASED(MEMORYUSERSTACKPTR) 227 230 242 245
11	002AH	4	MEMORYUSERSTACKPTR	POINTER 11 227 230 242 245
11	0000H	2	MEMORYWORDARG1	WORD BASED(MEMORYARG1PTR) 324 338 339 448
501	0073H	1	MODE8086	BYTE 503 506 535
1	00A8H	504	MONITOR	PROCEDURE STACK=0042H
3	0016H	2	MONITORSTACKBASE	WORD 252 274 638
3	0014H	2	MONITORSTACKPTR	WORD 251 273 637
443	0C31H		NEWLINE	LABEL 459
639	016FH		NEXTCOMMAND	LABEL 268 661 663 678
11	0000H	2	OFF	WORD MEMBER(CSIP) 185 261 301 310
11	0000H	2	OFF	WORD MEMBER(USERSTACK) 228 231 234 239 241 244 246 249 271
11	0000H	2	OFF	WORD MEMBER(BRK1) 668
11	0000H	2	OFF	WORD MEMBER(ARG3) 424 526 541 544 564
11	0000H	2	OFF	WORD MEMBER(ARG1) 351 352 354 409 421 423 432 438 444 449 451 454 456 457 516 552 555 558 562 586 603
169	0000H	2	OFF	WORD MEMBER(ARG) 171 175 176

280	0000H	2	OFF	WORD MEMBER(VECTOR) 282
572	0062H	2	OFFSET	WORD 585 586 596 597
134	006BH	1	OPER	BYTE 135 157 163
			OUTPUT	BUILTIN 42 196 202 206 489 614 615 616 618 620 622 624 626 628
			OUTWORD	BUILTIN 488
478	005AH	2	PORT	WORD 480 488 489
463	0056H	2	PORT	WORD 465 470 471
168	0006H	4	PTR	POINTER PARAMETER AUTOMATIC 169 170 171 175 176
65	0004H	4	PTR	POINTER PARAMETER AUTOMATIC 66 68 69
572	0074H	1	RECTYPE	BYTE 587 588 593 595 598 608
73	0004H	1	RECTYPE	BYTE PARAMETER AUTOMATIC 74 79
12	0058H	28	REG	BYTE ARRAY(28) DATA 100 108 365 366 398 399
12	002EH	2	REGINDEX	WORD 107 108 145 380
12	0074H	11	REGORD	BYTE ARRAY(11) DATA 230 242
12	0030H	28	REGSAV	WORD ARRAY(14) 145 183 184 185 192 227 230 233 234 238 239 242 245 254 261 262 263 301 302 303 310 311 312 318 368 383 392 404 414 430 511 522 590 591 597 631 632 668 670 675 677
236	0766H	96	RESTOREEXECUTE	PROCEDURE STACK=0008H 256 264 304 313
237	007FH	22	RESTOREEXECUTECODE	BYTE ARRAY(22) DATA 237
237	0004H	2	RESTOREEXECUTECODEPTR	WORD DATA

				246
358	0054H	2	SAVE	WORD 389 392
134	004CH	2	SAVE	WORD 139 145 149 154 158 159
226	0715H	81	SAVEREGISTERS	PROCEDURE STACK=0002H 253 275
11	0002H	2	SEG	WORD MEMBER(USERSTACK) 233 238 246 250 272
11	0002H	2	SEG	WORD MEMBER(CSIP) 184 262 289 302 311
11	0002H	2	SEG	WORD MEMBER(BRK1) 668
11	0002H	2	SEG	WORD MEMBER(ARG3) 540
280	0002H	2	SEG	WORD MEMBER(VECTOR) 281
11	0002H	2	SEG	WORD MEMBER(ARG1) 547 574 594
169	0002H	2	SEG	WORD MEMBER(ARG) 170 175
			SHL	BUILTIN 154 217 224
			SHR	BUILTIN 53 82 668
8			SI08251CMND	LITERALLY 202 206 628
8			SI08251DTRON	LITERALLY 196
8			SI08251MODE	LITERALLY 626
8			SI08251RESET	LITERALLY 620 624
81	03D9H	14	SI08251SETTLINGDELAY	PROCEDURE STACK=0002H 621 623 625 627 629
7	0023H	4	SI0BREAKMSG	BYTE ARRAY(4) DATA 671
17	02A0H	19	SI0CHARRDY	PROCEDURE BYTE STACK=0002H





84	03E7H	47	SIOVALIDHEX	PROCEDURE BYTE STACK=0004H 151 153
105	0460H	71	SIOVALIDREG	PROCEDURE BYTE STACK=0008H 143 378
98	0431H	47	SIOVALIDREGFIRST	PROCEDURE BYTE STACK=0002H 140 374
500	0D47H	401	SIOWRITE	PROCEDURE STACK=0026H 659
12			SP	LITERALLY 239
12			SS	LITERALLY 238 631
6			SSCOMMAND	LITERALLY 255
			STACKBASE	BUILTIN 250 252 272 274 638
			STACKPTR	BUILTIN 249 251 271 273 637
6			STANDARDLEN	LITERALLY 551 553
13			STARTADDR	LITERALLY 13 14
501	0072H	1	STARTREC	BYTE 520 525 537
6			STEPTRAP	LITERALLY 254 263 303 312
66	0000H	1	STR	BYTE BASED(PTR) ARRAY(1) 68 69
572	0077H	1	T	BYTE 600 601 605
428	0071H	1	T	BYTE 457 458
358	006FH	1	T	BYTE 376 378
222	006EH	1	T	BYTE 223 224
215	006DH	1	T	BYTE 216 217 218 219



134	006CH	1	T	BYTE	138	143	149	151											
6			TRUE	LITERALLY	20	88	101	109	122	137	296	321	381						
6			USERINITSP	LITERALLY	632														
11	002AH	4	USERSTACK	STRUCTURE AT	228	231	233	234	238	239	241	244	246						
280	0000H	4	VECTOR	STRUCTURE BASED(INTVECTORPTR)	281	282													
316	0052H	2	W	WORD	333	338	339	343	344										
134	004EH	2	W	WORD	136	158	159	161											
57	0004H	2	W	WORD PARAMETER AUTOMATIC	58	59	60												
5	0069H	1	WORDMODE	BYTE	118	122	323	336	350	446	458	469	487						

MODULE INFORMATION:

```

CODE AREA SIZE      = 0FDBH  4059D
CONSTANT AREA SIZE = 0000H   0D
VARIABLE AREA SIZE = 0078H  120D
MAXIMUM STACK SIZE = 0042H   66D
1211 LINES READ
0 PROGRAM ERROR(S)
    
```

END OF PL/M-86 COMPILATION







INTEL CORPORATION, 3065 Bowers Avenue, Santa Clara, CA 95051 (408) 987-8080

Printed in U.S.A.

102671993