


# OPERATING AND SERVICE MANUAL

## PART NO. 02100-60053 POWER SUPPLY



HEWLETT  PACKARD

## OPERATING AND SERVICE MANUAL

**PART NO. 02100-60053**

**POWER SUPPLY**

**(FOR 2100 COMPUTERS AND 2155A I/O EXTENDER)**

### POWER SUPPLY DATE CODES COVERED

This manual applies directly to power supplies with date codes 1126, 1140, 1141, 1146, 1148, 1149, 1150, 1215, 1220, 1229, 1240, 1243, 1249, 1250, and 1314. Documentation pertaining to power supplies with higher date codes will be covered in manual updating supplements.

| Section  | Page |
|--|------|
| <b>I GENERAL INFORMATION</b>   |      |
| 1-1. Introduction . . . . .  | 1-1  |
| 1-3. General Description . . . . .   | 1-1  |
| 1-8. Specifications . . . . .  | 1-1  |
| 1-10. Identification . . . . .   | 1-1  |
| 1-11. Power Supply Date Code . . . . .   | 1-1  |
| 1-13. Assembly Part Numbers . . . . .  | 1-1  |
| 1-16. Printed-Circuit Card Revision Codes . . . . .                            | 1-2  |
| 1-18. Maintenance Tools, Parts, Materials, and Equipment . . . . .             | 1-3  |
| 1-19. Tools . . . . .  | 1-3  |
| 1-21. Parts and Materials . . . . .  | 1-3  |
| 1-24. Servicing Equipment . . . . .  | 1-3  |
| 1-26. Card Extender . . . . .  | 1-3  |
| 1-27. Operating and Service Manual . . . . .                                   | 1-3  |
| 1-28. Test Equipment . . . . .   | 1-3  |
| 1-29. Power Supply Configurations . . . . .                                    | 1-3  |
| 1-33. Field Office Assistance . . . . .  | 1-3  |
| <b>II INSTALLATION</b>   |      |
| 2-1. Introduction . . . . .  | 2-1  |
| 2-3. Inspection of Shipment . . . . .  | 2-1  |
| 2-8. Claims . . . . .  | 2-1  |
| 2-10. Packaging for Reshipment . . . . .                                       | 2-1  |
| 2-11. Reshipment Using Original Packaging . . . . .                            | 2-1  |
| 2-13. Reshipment Using New Packaging . . . . .                                 | 2-1  |
| 2-15. Installation . . . . .   | 2-1  |
| <b>III THEORY OF OPERATION</b>   |      |
| 3-1. Introduction . . . . .  | 3-1  |
| 3-4. Block Diagram Description . . . . .                                       | 3-1  |
| 3-6. Line Filter and Power Switch . . . . .                                    | 3-1  |
| 3-8. Preregulator . . . . .  | 3-1  |
| 3-10. Preregulator Control . . . . .   | 3-1  |
| 3-12. Inverter . . . . .   | 3-1  |
| 3-14. Inverter Drivers . . . . .   | 3-1  |
| 3-16. Rectifiers . . . . .   | 3-1  |
| 3-18. 20-Volt Regulators . . . . .   | 3-1  |
| 3-20. Current Limit . . . . .  | 3-2  |
| 3-22. Protection and Control . . . . .   | 3-2  |
| 3-25. Functional Description . . . . .   | 3-2  |
| 3-36. Detailed Description . . . . .   | 3-4  |
| 3-38. Input Circuits . . . . .   | 3-4  |
| 3-42. Preregulator Circuit . . . . .   | 3-7  |
| 3-44. First Output Filter Circuit . . . . .                                    | 3-7  |
| 3-46. 115-Volt AC Operation . . . . .  | 3-7  |
| 3-50. 230-Volt AC Operation . . . . .  | 3-7  |
| 3-52. Second Output Filter Circuit . . . . .                                   | 3-7  |
| 3-54. 160V Crowbar Circuit . . . . .   | 3-8  |
| 3-58. Preregulator Control Circuit for Card A1, Part No. 02100-60046 . . . . . | 3-8  |
| 3-60. Control Input . . . . .  | 3-8  |
| 3-63. Error Amplifier Circuit . . . . .  | 3-9  |
| 3-66. Preregulator Control Circuit for Card A1, Part No. 02100-60108 . . . . . | 3-10 |
| 3-68. Control Input . . . . .  | 3-10 |
| 3-73. Error Amplifier Circuit . . . . .  | 3-11 |

# CONTENTS (Continued)

| Section |   | Page |
|---------|---|------|
| 3-76.   | Internal Voltage Regulators for Card A1, Part No. 02100-60046 . . . . . | 3-11 |
| 3-78.   | Internal Voltage Regulators for Card A1, Part No. 02100-60108 . . . . . | 3-11 |
| 3-82.   | Inverter Circuits . . . . .   | 3-12 |
| 3-84.   | Inverter Driver Circuit . . . . .                                       | 3-12 |
| 3-87.   | Rectifier Assemblies . . . . .  | 3-12 |
| 3-90.   | +20 Volt Regulator . . . . .  | 3-12 |
| 3-96.   | -20 Volt Regulator . . . . .  | 3-15 |
| 3-101.  | Output Crowbar Circuit . . . . .  | 3-15 |
| 3-103.  | Current Limit Card A4, Part No. 02100-60061 . . . . .                   | 3-15 |
| 3-106.  | Load Current Output . . . . .   | 3-15 |
| 3-108.  | Overcurrent . . . . .   | 3-15 |
| 3-109.  | Test Points . . . . .   | 3-16 |
| 3-110.  | Current Limit Card A4, Part No. 02100-60110 . . . . .                   | 3-16 |
| 3-114.  | Overcurrent . . . . .   | 3-16 |
| 3-115.  | Test Points . . . . .   | 3-16 |
| 3-116.  | Protection and Control Card A3, Part No. 02100-60047 . . . . .          | 3-16 |
| 3-118.  | Monitor Circuits . . . . .  | 3-16 |
| 3-119.  | Basic Sections of Protection and Control Card . . . . .                 | 3-16 |
| 3-120.  | Positive Overvoltage Comparator and Latch . . . . .                     | 3-17 |
| 3-124.  | Negative Overvoltage Comparator . . . . .                               | 3-17 |
| 3-126.  | Undervoltage Comparator . . . . .                                       | 3-17 |
| 3-128.  | Shutdown Output Signal Generator . . . . .                              | 3-17 |
| 3-131.  | Internal Voltage Reference . . . . .                                    | 3-18 |
| 3-133.  | Power Up Output Circuit . . . . .                                       | 3-18 |
| 3-135.  | Protection and Control Card A3, Part No. 02100-60109 . . . . .          | 3-18 |
| 3-137.  | Monitor Circuits . . . . .  | 3-18 |
| 3-138.  | Basic Sections of Protection and Control Card . . . . .                 | 3-18 |
| 3-139.  | Positive Overvoltage Comparator and Latch . . . . .                     | 3-18 |
| 3-143.  | Negative Overvoltage Comparator . . . . .                               | 3-19 |
| 3-145.  | Undervoltage Comparator . . . . .                                       | 3-19 |
| 3-149.  | Shutdown Output Signal Generator . . . . .                              | 3-19 |
| 3-152.  | Internal Voltage Reference . . . . .                                    | 3-20 |
| 3-154.  | Power Up Output Circuit . . . . .                                       | 3-20 |
| <br>    |   |      |
| IV      | TROUBLESHOOTING   |      |
| 4-1.    | Introduction . . . . .  | 4-1  |
| 4-3.    | Test Data . . . . .   | 4-1  |
| 4-5.    | Troubleshooting Data . . . . .  | 4-1  |
| 4-7.    | Information in Other Manuals . . . . .                                  | 4-1  |
| 4-9.    | Basic Checkout . . . . .  | 4-1  |
| 4-10.   | General . . . . .   | 4-1  |
| 4-12.   | Required Test Equipment . . . . .                                       | 4-1  |
| 4-14.   | Test Procedure . . . . .  | 4-1  |
| 4-17.   | Detailed Checkout . . . . .   | 4-2  |
| 4-19.   | Required Test Equipment . . . . .                                       | 4-2  |
| 4-21.   | Test Procedure . . . . .  | 4-2  |
| <br>    |   |      |
| V       | MAINTENANCE   |      |
| 5-1.    | Introduction . . . . .  | 5-1  |
| 5-7.    | Safety Precautions . . . . .  | 5-1  |
| 5-8.    | High Voltage Points . . . . .   | 5-1  |
| 5-10.   | Test Equipment Ground . . . . .   | 5-1  |

# CONTENTS (Continued)

| Section  | Page |
|--|------|
| 5-12. Preventive Maintenance . . . . .   | 5-1  |
| 5-13.    General . . . . .   | 5-1  |
| 5-15.    Equipment Required . . . . .  | 5-1  |
| 5-17.    Procedure . . . . .   | 5-2  |
| 5-19.      Air Filter . . . . .  | 5-2  |
| 5-20.      Cables . . . . .  | 5-2  |
| 5-21.      Dust . . . . .  | 5-2  |
| 5-22.      Circuit Cards . . . . .   | 5-2  |
| 5-23.      Fans . . . . .  | 5-2  |
| 5-24.      Voltage Checks . . . . .  | 5-2  |
| 5-25.    Preventive Maintenance Summary . . . . .  | 5-2  |
| 5-27. Adjustments to Installed Power Supply . . . . .  | 5-2  |
| 5-29.    Preregulator Adjustment . . . . .   | 5-4  |
| 5-31.      Equipment . . . . .   | 5-4  |
| 5-32.      Procedure . . . . .   | 5-4  |
| 5-33.    Memory Supply (+20 Volts and -20 Volts) Adjustment . . . . .                              | 5-4  |
| 5-35.      Equipment . . . . .   | 5-4  |
| 5-36.      Procedure . . . . .   | 5-4  |
| 5-37.    Overvoltage Reference Adjustment . . . . .  | 5-4  |
| 5-39.      Equipment . . . . .   | 5-5  |
| 5-40.      Procedure . . . . .   | 5-5  |
| 5-41.    Power Fail Adjustment . . . . .   | 5-4  |
| 5-43.      Equipment . . . . .   | 5-4  |
| 5-44.      Procedure . . . . .   | 5-6  |
| 5-45.    Bench Test and Adjustments . . . . .  | 5-6  |
| 5-47.      Equipment . . . . .   | 5-6  |
| 5-49.    Preliminary Procedures . . . . .  | 5-7  |
| 5-51.    Control Voltage and Transformer Test . . . . .  | 5-7  |
| 5-53.    Inverter Driver Test . . . . .  | 5-8  |
| 5-55.    Preregulator and Inverter Test . . . . .  | 5-9  |
| 5-57.    PWU and IPU Signal Test and Adjustments<br>(for A3 Card, Part No. 02100-60047) . . . . .  | 5-10 |
| 5-59.    PWU and IPU Signal Tests and Adjustments<br>(for A3 Card, Part No. 02100-60109) . . . . . | 5-10 |
| 5-61.    Pvoltage and Overtemperature Detection Test . . . . .                                     | 5-11 |
| 5-63.    Overcurrent Test . . . . .  | 5-11 |
| 5-65.    Part Removal and Replacement Procedures . . . . .   | 5-13 |
| 5-67.      Card Removal and Replacement . . . . .  | 5-13 |
| 5-71.      Replacement of Semiconductor Devices . . . . .  | 5-13 |
| 5-74.      Integrated Circuit Replacement . . . . .  | 5-13 |
| 5-76.      Replacement of Wire Lugs . . . . .  | 5-13 |
| <br>VI    REPLACEABLE PARTS  |      |
| 6-1.    Introduction . . . . .   | 6-1  |
| 6-6.    Ordering Information . . . . .   | 6-1  |
| <br>VII   DIAGRAMS   |      |
| 7-1.    Introduction . . . . .   | 7-1  |
| 7-3.    Integrated Circuit Diagrams . . . . .  | 7-1  |
| 7-5.    Wiring Information . . . . .   | 7-1  |
| 7-8.    Replaceable Parts Lists . . . . .  | 7-1  |
| 7-13.   Parts Location and Schematic Diagrams . . . . .  | 7-1  |

# ILLUSTRATIONS

| Figure | Title   | Page |
|--------|---|------|
| 1-1    | Power Supply, Part No. 02100-60053  | 1-1  |
| 2-1.   | Power Supply, Installation  | 2-3  |
| 3-1.   | Power Supply, Block Diagram   | 3-3  |
| 3-2.   | Power Supply, Functional Diagram  | 3-5  |
| 3-3.   | Preregulator Circuit, Simplified Schematic Diagram  | 3-8  |
| 3-4.   | Preregulator Control Waveforms  | 3-9  |
| 3-5.   | Preregulator Waveforms (Unloaded Output)  | 3-9  |
| 3-6.   | Preregulator Waveforms (Loaded Output)  | 3-10 |
| 3-7.   | Inverter Driver Circuit, Timing Diagram   | 3-13 |
| 3-8.   | Inverter Driver Waveforms   | 3-13 |
| 3-9.   | Inverter Input and Output Waveforms   | 3-13 |
| 3-10.  | +20 Volt Regulator Waveforms  | 3-14 |
| 3-11.  | +20 Volt Regulator Output, Simplified Schematic Diagram   | 3-14 |
| 5-1.   | Power Supply Adjustments  | 5-3  |
| 5-2.   | Power Line Connection Test Cable (Fabricated)   | 5-7  |
| 5-3.   | Inverter Driver Test Waveforms  | 5-8  |
| 5-4.   | Integrated Waveform   | 5-10 |
| 5-5.   | Power Supply Load Test Fixture  | 5-12 |
| 5-6.   | Basic Checkout Troubleshooting Flowchart, Date Codes Prior to 1240                                      | 5-15 |
| 5-7.   | Control Voltage and Transformer Test Troubleshooting Flowchart,<br>Date Codes Prior to 1240             | 5-17 |
| 5-8.   | Inverter Driver Test Troubleshooting Flowchart, Date Codes Prior to 1240                                | 5-19 |
| 5-9.   | Preregulator and Inverter Test Troubleshooting Flowchart,<br>Date Codes Prior to 1240                   | 5-21 |
| 5-10.  | PWU and IPU Test Troubleshooting Flowchart, Date Codes Prior to 1240                                    | 5-23 |
| 5-11.  | Overvoltage and Overtemperature Detection Test Troubleshooting Flowchart,<br>Date Codes Prior to 1240   | 5-25 |
| 5-12.  | Overcurrent Test Troubleshooting Flowchart, Date Codes Prior to 1240                                    | 5-27 |
| 5-13.  | +20 and -20 Volt Output Test Troubleshooting Flowchart,<br>Date Codes Prior to 1240                     | 5-29 |
| 5-14.  | Basic Checkout Troubleshooting Flowchart, Date Codes 1240 and Higher                                    | 5-31 |
| 5-15.  | Control Voltage and Transformer Test Troubleshooting Flowchart,<br>Date Codes 1240 and Higher           | 5-33 |
| 5-16.  | Inverter Driver Test Troubleshooting Flowchart, Date Codes 1240 and Higher                              | 5-35 |
| 5-17.  | Preregulator and Inverter Test Troubleshooting Flowchart,<br>Date Codes 1240 and Higher                 | 5-37 |
| 5-18.  | PWU and IPU Test Troubleshooting Flowchart, Date Codes 1240 and Higher                                  | 5-39 |
| 5-19.  | Overvoltage and Overtemperature Detection Test Troubleshooting Flowchart,<br>Date Codes 1240 and Higher | 5-41 |
| 5-20.  | Overcurrent Test Troubleshooting Flowchart, Date Codes 1240 and Higher                                  | 5-43 |
| 5-21.  | +20 and -20 Volt Output Test Troubleshooting Flowchart,<br>Date Codes 1240 and Higher                   | 5-45 |
| 6-1.   | Power Supply Assembly, Exploded View  | 6-7  |
| 6-2.   | Rear Fan Panel Assembly, Exploded View  | 6-9  |
| 6-3.   | Inverter Assembly (02100-60095), Exploded View  | 6-11 |
| 6-4.   | Inverter Assembly (02100-60114), Exploded View  | 6-13 |
| 6-5.   | +160 Volt Output Board, Exploded View   | 6-15 |
| 6-6.   | Preregulator Assembly, Exploded View  | 6-17 |
| 6-7.   | Output Crowbar Assembly, Exploded View  | 6-19 |
| 6-8.   | ±20 Volt Regulator Assembly, Exploded View  | 6-21 |
| 6-9.   | +4.85 Volt Rectifier Assembly, Exploded View  | 6-23 |
| 6-10.  | Rectifier Assembly, Exploded View   | 6-25 |

## ILLUSTRATIONS (Continued)

| Figure | Title   | Page |
|--------|---|------|
| 7-1.   | Integrated Circuit Diagrams and Characteristics . . . . .   | 7-2  |
| 7-2.   | Power Supply, Wiring Diagram . . . . .  | 7-7  |
| 7-3.   | Power Supply (Preregulator Control) Parts Location and Schematic Diagrams,<br>Date Codes Prior to 1240 (Sheet 1 of 4) . . . . .     | 7-17 |
| 7-3.   | Power Supply (Inverter Driver) Parts Location and Schematic Diagrams,<br>Date Codes Prior to 1240 (Sheet 2 of 4) . . . . .          | 7-19 |
| 7-3.   | Power Supply (Protection and Control) Parts Location and Schematic Diagrams,<br>Date Codes Prior to 1240 (Sheet 3 of 4) . . . . .   | 7-21 |
| 7-3.   | Power Supply (Current Limit) Parts Location and Schematic Diagrams,<br>Date Codes Prior to 1240 (Sheet 4 of 4) . . . . .            | 7-23 |
| 7-4.   | Power Supply (Preregulator Control) Parts Location and Schematic Diagrams,<br>Date Codes 1240 and Higher (Sheet 1 of 4) . . . . .   | 7-27 |
| 7-4.   | Power Supply (Inverter Driver) Parts Location and Schematic Diagrams,<br>Date Codes 1240 and Higher (Sheet 2 of 4) . . . . .        | 7-29 |
| 7-4.   | Power Supply (Protection and Control) Parts Location and Schematic Diagrams,<br>Date Codes 1240 and Higher (Sheet 3 of 4) . . . . . | 7-33 |
| 7-4.   | Power Supply (Current Limit) Parts Location and Schematic Diagrams,<br>Date Codes 1240 and Higher (Sheet 4 of 4) . . . . .          | 7-37 |

## TABLES


| Table | Title   | Page |
|-------|---|------|
| 1-1.  | Power Supply Specifications . . . . .                                     | 1-2  |
| 1-2.  | Recommended Test Equipment and Servicing Devices . . . . .                | 1-4  |
| 1-3.  | Power Supply Configuration . . . . .                                      | 1-5  |
| 3-1.  | Applicable Schematic Diagrams . . . . .                                   | 3-7  |
| 5-1.  | DC Supply Voltages . . . . .  | 5-2  |
| 5-2.  | Output of +20 Volt and -20 Volt Regulators . . . . .                      | 5-5  |
| 5-3.  | Control Voltages . . . . .  | 5-8  |
| 5-4.  | Control Transformer Voltages . . . . .                                    | 5-8  |
| 5-5.  | Output Voltages with Reduced Input . . . . .                              | 5-9  |
| 5-6.  | Output Voltages . . . . .   | 5-10 |
| 5-7.  | Voltage Ranges for Overvoltage (Crowbar Trigger) Condition . . . . .      | 5-11 |
| 5-8.  | Current Limit Card Test Point Voltages . . . . .                          | 5-12 |
| 5-9.  | Loaded Output Voltages . . . . .  | 5-13 |
| 6-1.  | Power Supply Assembly, Replaceable Parts . . . . .                        | 6-1  |
| 6-2.  | Rear Fan Panel Assembly, Replaceable Parts . . . . .                      | 6-8  |
| 6-3.  | Inverter Assembly (02100-60095), Replaceable Parts . . . . .              | 6-10 |
| 6-4.  | Inverter Assembly (02100-60114), Replaceable Parts . . . . .              | 6-12 |
| 6-5.  | +160 Volt Output Board, Replaceable Parts . . . . .                       | 6-14 |
| 6-6.  | Preregulator Assembly, Replaceable Parts . . . . .                        | 6-16 |
| 6-7.  | Output Crowbar Assembly, Replaceable Parts . . . . .                      | 6-19 |
| 6-8.  | ±20 Volt Regulator Assembly, Replaceable Parts . . . . .                  | 6-20 |
| 6-9.  | +4.85 Volt Rectifier Assembly, Replaceable Parts . . . . .                | 6-23 |
| 6-10. | Rectifier Assembly, Replaceable Parts . . . . .                           | 6-24 |
| 6-11. | Numerical Listing of Electrical Parts . . . . .                           | 6-26 |
| 6-12. | Numerical Listing of Mechanical Parts . . . . .                           | 6-30 |
| 6-13. | Reference Designations and Abbreviations . . . . .                        | 6-33 |
| 6-14. | Code List of Manufacturers . . . . .                                      | 6-34 |
| 7-1.  | Point-to-Point Wiring List . . . . .                                      | 7-3  |
| 7-2.  | Power Supply, Replaceable Parts . . . . .                                 | 7-9  |
| 7-3.  | Preregulator Control Card A2 (02100-60108), Replaceable Parts . . . . .   | 7-25 |
| 7-4.  | Protection and Control Card A3 (02100-60109), Replaceable Parts . . . . . | 7-31 |
| 7-5.  | Current Limit Card A4 (02100-60110), Replaceable Parts . . . . .          | 7-35 |

**1-1. INTRODUCTION.**

1-2. This operating and service manual provides general information, installation instructions, theory of operation, troubleshooting, maintenance instructions, replaceable parts information, and diagrams for the Hewlett-Packard Power Supply, part no. 02100-60053 (figure 1-1). The power supply is designed for use in the HP 2100 Computer and the HP 2155A I/O Extender and is installed in these units during manufacture.

**1-3. GENERAL DESCRIPTION.**

1-4. The power supply is a modular assembly that can easily be removed from the computer (or extender) for replacement. The method of mounting the power supply in the computer is identical to that in the extender, since the cabinet structure is identical. The computer uses all seven of the dc operating voltages provided by the power supply, and the extender uses all except the +20 and -20 volt (core memory) outputs. All references to the computer in this section, as associated with the power supply, are also applicable to the extender unless otherwise specified.



2133/53-13

Figure 1-1. Power Supply, Part No. 02100-60053

1-5. The power supply can operate from either a 115- or optional 230-volt ac power source, by selecting the proper connections at the computer input circuit terminal board. The power supply is controlled by the POWER switch on the front panel of the computer. Power control circuits in the power supply provide power failure detection signals to the computer.

1-6. The power supply assembly is located at the rear of the computer cabinet. Access to the assembly is gained by removing the top and bottom panels of the cabinet. The power supply input line is routed through plenum chamber assembly A26 in the computer. The power supply output voltages are also connected to test points mounted on the back panel of the plenum chamber.

1-7. The power supply assembly, comprised of 12 sub-assemblies, furnishes the seven regulated dc voltages required by the computer and any I/O interface cards installed in the card cage. All optional units external to the computer cabinet furnish their own ac and dc voltages derived from a separate connection to the primary ac power line.

**1-8. SPECIFICATIONS.**

1-9. See table 1-1 for specifications of the power supply.

**1-10. IDENTIFICATION.****1-11. POWER SUPPLY DATE CODE.**

1-12. The power supply date code is marked on the power supply date code label at the rear of the power supply assembly. The date code, consisting of four digits, identifies the electrical configuration of the power supply assembly and is used to indicate design changes. If the date code marked on the label does not agree with the power supply date code on the title page of this manual, refer to the manual change information contained in a supplement accompanying this manual.

**1-13. ASSEMBLY PART NUMBERS.**

1-14. Four of the electronic assemblies in the power supply are plug-in circuit cards. Card parts location diagrams are shown in figures 7-3 or 7-4, sheets 1 through 4. In each illustration, the location of the card part number is shown, in addition to the identifying numbers and letters of the card pins and the location of all parts by reference designation. Part numbers for parts on these cards are found in tables 7-2 through 7-5 as appropriate.



Table 1-1. Power Supply Specifications

|  |  |
|--|--|
| <b>POWER REQUIREMENTS</b>                              |  |
| <b>LINE VOLTAGE:</b>                                   | 115V ac ± 10%, single phase, 12A, or<br>230V ac ± 10%, single phase, 6A                |
| <b>LINE FREQUENCY:</b>                                 | 47.5 to 66 Hz (see paragraph 1-31)   |
| <b>POWER CONSUMPTION:</b>                              | 1400 volt-amperes, maximum   |
| <b>POWER CABLE (CONNECTED TO COMPUTER OR EXTENDER)</b> |  |
| <b>LENGTH:</b>   | 10 feet (304, 8 centimeters)   |
| <b>CONNECTOR:</b>                                      | NEMA Type 5-15P (for 115V ac operation), or<br>NEMA Type 6-15P (for 230V ac operation) |
| <b>DC SUPPLY VOLTAGES AND CURRENTS</b>                 |  |
|  | +30V, 0.1A   |
|  | +12V, 5A for 2155A Extender; +12V, 3A for 2100 Computer                                |
|  | +4.85V, 50A  |
|  | -2V, 23A   |
|  | -12V, 5A for 2155A Extender; +12V, 3A for 2100 Computer                                |
|  | +20V, 6A   |
|  | -20V, 0.5A } For 2100 Computer only  |
| <b>ENVIRONMENTAL LIMITS</b>                            |  |
| <b>AMBIENT TEMPERATURE RANGE:</b>                      |  |
| <b>Operating:</b>                                      | 0° to 55°C (32° to 131°F)  |
| <b>Non-operating:</b>                                  | -40° to 75°C (-40° to 167°F)   |
| <b>RELATIVE HUMIDITY:</b>                              | 50 to 95% at 25° to 40°C (77° to 104°F) without condensation                           |
| <b>ALTITUDE:</b>                                       |  |
| <b>Operating:</b>                                      | 15,000 feet (4572 meters)  |
| <b>Non-operating:</b>                                  | 25,000 feet (7620 meters)  |
| <b>VENTILATION</b>                                     |  |
| <b>AIR FLOW:</b>                                       | 200 cubic feet (5,6634 cubic meters) per minute  |
| <b>HEAT DISSIPATION:</b>                               | 2300 BTUs (579,6 kilocalories) per hour, maximum                                       |
| <b>WEIGHT AND DIMENSIONS</b>                           |  |
| <b>WEIGHT:</b>   | 36 pounds (16,344 kilograms)   |
| <b>HEIGHT:</b>   | 10 inches (254 millimeters)  |
| <b>WIDTH:</b>  | 7.75 inches (196,85 millimeters)   |
| <b>DEPTH:</b>  | 12 inches (304,8 millimeters)  |

1-15. Assemblies other than circuit cards usually are not marked with their part number. Part numbers for these assemblies are found in section VI, where all electronic assemblies are identified by their location in the power supply.

1-16. PRINTED-CIRCUIT CARD REVISION CODES.

1-17. Marked beneath the part number of each printed-circuit card is a revision code (see figure 7-3). The first character of the code is a letter which identifies the etched-

foil pattern on the card. The next four digits, referred to as a date code, identify the electrical characteristics of the card with components mounted. The date code is followed by a 1- or 2-digit number which identifies the Hewlett-Packard division which manufactured the assembly. The entire revision code is either stamped on the card with marking ink, or as part of the etched-foil pattern. If both a stamped and an etched code are used, the stamped revision code identifies the card with components mounted, and the etched revision code identifies the card without components.

**1-18. MAINTENANCE TOOLS, PARTS, MATERIALS, AND EQUIPMENT.****1-19. TOOLS.**

1-20. A standard electronics tool kit will provide the tools required for normal servicing of the power supply. The kit must include a soldering iron designed for removing and installing 14-pin integrated circuits, and a rubber bulb with suction tube for withdrawing molten solder. Also required is a torque wrench, capable of indicating 15 pound-inches, with 3/8-inch, 7/16-inch, 1/2-inch, 9/16-inch and 11/16-inch sockets. The torque wrench is used when replacing stud-type semiconductor devices in the power supply (over-torquing can damage the anodized washers and semiconductor devices).

**1-21. PARTS AND MATERIALS.**

1-22. Spare parts that may be required for the power supply are listed in section VI of this manual. Part numbers and ordering information are included.

1-23. Materials and chemicals normally used for electronics service work must be available to the serviceman. These must include heat-conductive silicone compound (Wakefield 120-2 Thermal Joint Compound, HP part no. 6040-0239, or equivalent. When ordering this compound, specify a 2-ounce jar.)

**1-24. SERVICING EQUIPMENT.**

1-25. Equipment required for servicing the power supply consists of a card extender, an operating and service manual, and test equipment.

1-26. **CARD EXTENDER.** A card extender, part no. 02100-60049, allows circuit cards in the power supply to be extended for troubleshooting. The card extender is part of the 12900A Maintenance Accessory Kit, available at extra cost, which contains special tools and maintenance aids to facilitate maintenance of the computer.

1-27. **OPERATING AND SERVICE MANUAL.** This manual provides hardware documentation (see paragraph 1-2) for the power supply.

1-28. **TEST EQUIPMENT.** Equipment recommended for maintenance, troubleshooting, and repair of the power supply is listed in table 1-2.

**1-29. POWER SUPPLY CONFIGURATIONS.**

1-30. Table 1-3 lists the date codes (see paragraph 1-12) of the power supplies covered by this manual, together with the revision code (see paragraph 1-17) of each printed-circuit card used in the power supply. The power supply date code and card revision codes reflect the configuration as originally manufactured and shipped from the factory. Notes explain changes made to assemblies other than the printed-circuit cards.

1-31. The power fail circuits in the power supply are line-frequency sensitive and must be adjusted to operate at the line frequency available. A label located at the rear of the computer or extender in which the power supply is installed specifies the line frequency for which the power fail circuits were adjusted before shipment from the factory. If the available line frequency is different from that marked on the label, or if a replacement power supply is installed, the power fail circuits will require readjustment (refer to paragraph 5-42).

1-32. Because of field modifications, repairs, board exchange, and other factors that may alter the shipped configurations, the configurations existing in the field may not always agree with the information presented in table 1-3.

**1-33. FIELD OFFICE ASSISTANCE.**

1-34. Should servicing assistance be required, contact the nearest Hewlett-Packard Sales and Service Office. These offices are listed at the back of this manual.

Table 1-2. Recommended Test Equipment and Servicing Devices

| INSTRUMENT  | CRITICAL SPECIFICATIONS  | RECOMMENDED HP MODEL  |
|---|--|---|
| Dual-trace oscilloscope   | Rise time: $\leq 10$ ns. Vertical deflection: 1 volt/division and 10 volts/division (including attenuator probe, if used). Horizontal sweep speed: 0.1 microsecond/division to 1 second/division.                            | HP 180A Oscilloscope with 10004A Probe and the following plug-in units.<br>HP 1801A Dual Channel Vertical Amplifier<br>HP 1821A Time Base and Delay Generator |
| Digital voltmeter   | At least 4 digit readout. Minimum input resistance: 10 megohms. Full-scale ranges: 9.999 and 99.99V dc.  | HP 3439A Digital Voltmeter with HP 3441A Range Selector.  |
| AC voltmeter  | Expanded-scale or digital-readout type, capable of reading ac voltage to $\pm 1\%$ . Voltage range must be at least 100-115 volts (for a 115-volt input power supply), or 200-230 volts (for a 230-volt input power supply). | HP 3445A AC/DC Range Unit. (Also performs functions of HP 3441A Range Selector listed above. Requires HP 3439A Digital Voltmeter.)                            |
| Multimeter  | Accuracy: $\pm 3\%$ of full scale. Full-scale ranges: 100 mV to 300V (dc and ac), 10 ohms center-scale to 10 megohms center-scale.   | HP 427A   |
| Power supply  | Capable of supplying 0 to 20 volts at 0.75 ampere.   | HP 6202B  |
| Logic probe   | Indication: logic true $> +1.4$ volts.   | HP 10525A   |
| Metered variable autotransformer  | Capable of reducing input line-voltage to 98 volts rms (196 volts for a 230-volt input power supply), and able to furnish the power required (up to 1400 volt-amperes, depending on the load).                               | None  |
| Centigrade thermometer  | General-purpose type, accurate to $\pm 1^\circ\text{C}$ .  | HP 0440-0004  |
| High-pressure air source  | 25-50 psi pressure   | None  |
| Vacuum cleaner  | Must have flexible hose with small nozzle, vacuum port for hose, and pressure port for hose.   | None  |
| IC test clip  | None   | None  |
| <p>NOTES:</p> <ol style="list-style-type: none"> <li>The logic probe is optional. Operating voltage for the probe can be obtained from terminals 4 and 5 of TB1 located beneath the power supply.</li> <li>Ambient-temperature and humidity specifications of test equipment must suit the power supply environment.</li> </ol> |  |   |

Table 1-3. Power Supply Configuration

| POWER SUPPLY<br>DATE CODE | CARD REVISION CODE |      |      |      |      | REMARKS  |
|---------------------------|--------------------|------|------|------|------|----------|
|                           | A1                 | A2   | A3   | A4   | A5   |          |
| 1126                      | 1133               | 1126 | 1132 | 1126 | 1125 |          |
| 1140                      | 1139               | 1126 | 1132 | 1126 | 1125 |          |
| 1141                      | 1140               | 1140 | 1132 | 1126 | 1139 |          |
| 1146                      | 1140               | 1140 | 1132 | 1126 | 1139 |          |
| 1148                      | 1140               | 1140 | 1132 | 1144 | 1139 | (Note 1) |
| 1149                      | 1140               | 1140 | 1147 | 1144 | 1139 |          |
| 1150                      | 1140               | 1140 | 1147 | 1144 | 1150 |          |
| 1215                      | 1148               | 1140 | 1215 | 1144 | 1150 |          |
| 1220                      | 1148               | 1140 | 1215 | 1144 | 1150 | (Note 2) |
| 1229                      | 1148               | 1140 | 1215 | 1144 | 1150 | (Note 3) |
| 1240                      | 1224               | 1140 | 1243 | 1224 | 1150 | (Note 4) |
| 1243                      | 1224               | 1140 | 1243 | 1224 | 1150 | (Note 5) |
| 1249                      | 1249               | 1249 | 1243 | 1224 | 1150 |          |
| 1250                      | 1249               | 1249 | 1250 | 1224 | 1150 |          |
| 1314                      | 1249               | 1249 | 1250 | 1224 | 1150 | (Note 6) |

**NOTES:**

1. Cards A1 through A5 did not change. Part number of A6Q1 and A6Q2 changed to 1884-0219.
2. Cards A1 through A5 did not change. Change made to power supply to bring up to UL, CSA, and IEC standards.
3. Cards A1 through A5 did not change. Change made to A11  $\pm 20$  volts Regulator.
4. Part no. of cards A1, A3, and A4 changed to 02100-60108, 02100-60109, and 02100-60110, respectively.
5. Date code 1243 is identical to date code 1240.
6. Cards A1 through A5 did not change. Assembly A7 changed mechanically.

## 2-1. INTRODUCTION.

2-2. This section presents installation instructions for replacement power supplies. Installation instructions include initial inspection and installation of the power supply. Also described are claims procedures and methods of repacking the power supply for reshipment.

## 2-3. INSPECTION OF SHIPMENT.

2-4. If external damage to the shipping container is evident, or if the container is water-stained, ask the carrier's agent to be present when the container is opened.

2-5. Unpack the container and examine the power supply for external damage. Look for such things as broken parts, dented corners, bent panels, and scratches. Also check the rigid foam-plastic cushioning material (if used) for signs of deformation which could indicate rough handling in transit.

2-6. If the above examination reveals damage to the power supply, follow the damage-claim procedure described in paragraph 2-8. Retain the shipping containers and packaging materials for examination in the settlement of claims, or for reshipment.

2-7. Upon completing the inspection for damage in transit, proceed with a physical inventory of the material received, as described in the following paragraphs.

## 2-8. CLAIMS.

2-9. If the power supply is incomplete or damaged when received and fails to meet specifications, notify the nearest Hewlett-Packard Sales and Service Office. (Sales and Service Offices are listed at the back of this manual.) If damage occurred in transit, notify the carrier also. Hewlett-Packard will arrange for replacement or repair without waiting for settlement of claims against the carrier.

## 2-10. PACKAGING FOR RESHIPMENT.

### 2-11. RESHIPMENT USING ORIGINAL PACKAGING.

2-12. The same containers and materials used in factory packing can be used for reshipment of the power supply. Alternatively, containers and packaging materials may be obtained from Hewlett-Packard Sales and Service Offices. If the power supply is being sent to the factory for servicing, attach a tag to the power supply specifying the return address, the type of service required, the model number of

the computer (or extender) and power supply date code. Mark the container "FRAGILE" to assure careful handling. In any correspondence, refer to the power supply by date code number (see paragraph 1-12 for a description of the date code number).

### 2-13. RESHIPMENT USING NEW PACKAGING.

2-14. The following instructions should be followed when packaging the power supply with commercially available materials:

- a. Wrap the power supply in heavy paper or sheet plastic. If shipping the power supply back to the factory, first attach a tag to the power supply with the return address and indicate the type of service required, the computer (or extender) model number, and power supply date code.
- b. Use a strong shipping container. A double-wall container of 350-pound test material is adequate.
- c. Use enough shock absorbing material (3- to 4-inch layer) on all sides of the power supply to provide a firm cushion and to prevent movement inside the container. Use particular care to protect the corners of the units.
- d. Seal the shipping container securely, and mark it "FRAGILE".
- e. In any correspondence with the factory, refer to the power supply by date code number.

## 2-15. INSTALLATION.


2-16. Installation instructions apply to installation of the power supply in the 2100 Computer or 2155A Extender. Environmental and power source requirements are described in documentation provided with the computer or extender.

2-17. Prior to installing the power supply, heed the following warning:

### WARNING

Be sure that the computer (or extender) ac power cable is disconnected from the ac power source before proceeding. Failure to heed this warning could result in injury or death.

- a. Place the computer (or extender) on its side with the side adjacent to the power supply assembly facing up (see figure 2-1).
  - b. Lift the back of the side frame slightly and carefully insert the power supply assembly from the rear of the computer (or extender).
  - c. Install the spacer (1) between the back of the side frame and the power supply assembly. Install the four screws (2).
  - d. Install the screw (3), lock washer (4), and flat washer (5) to secure the forward section of the power supply assembly.
  - e. Install the four screws (6), split washers (7), and flat washers (8) to secure the power supply assembly rear panel to the rear card cage support.
- Note: Prior to connecting the wires in the following steps, refer to the backplane wiring diagram in section III of the computer *Diagrams Manual*, (part no. 02100-90003 for 2100A or part no. 02100-90164 for 2100S), or the *2155A I/O Extender Manual*, part no. 02155-90002, as applicable.
- f. Connect the power supply wires to terminal board A26TB2 (9).
  - g. Connect the backplane wires and bus strips to terminal boards A25TB1 (10) and A25TB2 (11).
  - h. Install the plenum chamber bottom cover (12).
  - i. Install the top panel (13), the bottom panel (14), and the side panel (15).
  - j. Prior to operating the computer (or extender) perform the voltage checks described in paragraph 5-24, and the power fail adjustment described in paragraph 5-42.



2133/53-12

Figure 2-1. Power Supply, Installation

### 3-1. INTRODUCTION.

3-2. This section describes the operation of the circuits comprising the power supply. The description is divided into three levels. A general description at the block diagram level is presented first, followed by a functional description at the simplified schematic diagram level, then a detailed description of all circuits, emphasizing those that are unique.

3-3. The power supply section operates from a 115-volt (230-volt by changing the positions of jumpers on a terminal board), single-phase, 50- or 60-Hz power source which it converts to regulated dc supply voltages for the operation of the 2100 Computer (or 2155A Extender) in which it is installed. A POWER switch mounted on the front panel of the computer (or extender) controls turn-on and turn-off of the power supply. The power supply provides status signals used for power failure detection for protection of software stored in core memory. Hardware protection for the computer (or extender) is provided by power supply circuits that sense overvoltage, overcurrent, or overtemperature conditions. Protection for circuits in the power supply is provided by various overvoltage circuits, current limit circuits, and fuses.

### 3-4. BLOCK DIAGRAM DESCRIPTION.

3-5. Figure 3-1 is a block diagram of the power supply. The following paragraphs describe the function of each of the blocks shown in the figure.

#### 3-6. LINE FILTER AND POWER SWITCH.

3-7. The ac line voltage enters the 2100 Computer (or 2155A Extender) through a 12 ampere (6 ampere for 230-volt operation) fuse and an RFI filter located in the plenum chamber assembly. The POWER switch (S1) is located on the front panel of the computer (or extender). With the POWER switch in the ON position, the line voltage is applied to the preregulator circuits and to the preregulator control circuits. The control circuits require much less current than the preregulator and are separately fused for 2 amperes (1 ampere for 230-volt operation).

#### 3-8. PREREGULATOR.

3-9. The preregulator circuit is a full-wave bridge rectifier that converts the input line voltage to a regulated 160 volts dc which is used as the basis for all power supply outputs. The preregulator functions as a conventional controlled rectifier for a 230-volt ac input voltage and functions, in addition, as a voltage doubler for a 115-volt ac input voltage, resulting in the same value of dc output

voltage for either 115- or 230-volt ac input. The preregulator circuit is controlled by the preregulator control circuit.

#### 3-10. PREREGULATOR CONTROL.

3-11. The preregulator control circuit monitors the input line voltage to detect phase and amplitude values. This circuit also provides +5, -15, and +15 volts dc for use within the power supply circuits. The control circuit supplies trigger pulses that control the "on" time of the preregulator bridge circuit to maintain proper control of the 160-volt dc output.

#### 3-12. INVERTER.

3-13. The inverter circuits convert the 160-volt dc output of the preregulator circuit to a square-wave ac voltage which is transformer-coupled to the rectifier circuit. The transformer coupling provides isolation for stages following the inverters, as shown in figure 3-1. The operating frequency of the inverters is determined by the inverter driver circuit. The two inverter circuits are identical and operate 90 degrees out of phase with each other.

#### 3-14. INVERTER DRIVERS.

3-15. The inverter driver circuit generates a clock signal that is divided in frequency and time to develop phase 1 and phase 2 drive signals that are applied to the inverter circuits.

#### 3-16. RECTIFIERS.

3-17. The rectifier circuit rectifies the transformer-coupled outputs of the inverter circuits to provide (through output filters) the -2, +12, -12, +30 and +4.85 volts dc output voltages. A +30 and a -30 volt dc output is supplied as input to the +20 and -20 volt dc regulators. The -30 volt output is fed back to the preregulator control circuit to maintain output voltage regulation.

#### 3-18. 20-VOLT REGULATORS.

3-19. The 20-volt dc regulators consist of a +20 and a -20 volt regulator. The +20 volt regulator uses a switching circuit to process the +30 volt output of the rectifier circuit to provide a regulated +20 volts dc. The -20 volt regulator uses a series-shunt circuit to process the -30 volt output of the rectifier circuit to provide a regulated -20 volts dc. The -20 volt regulator is designed to track the +20 volt regulator output so the two outputs maintain equal voltages of opposite polarity.



### 3-20. CURRENT LIMIT.

3-21. The current limit circuit monitors the dc component of the voltage drop across the resistance of each output filter choke. *A change in current results in a like change in a load current signal which is sent to the load current gain compensation circuit in the preregulator control circuit.* An excessive increase in any output current results in an overcurrent signal that is sent to the protection and control circuit to develop the inhibit preregulator signal. This signal controls the preregulator output to protect the power supply.

### 3-22. PROTECTION AND CONTROL.

3-23. The protection and control circuits contain over-voltage sensing circuits to provide protection of computer (or extender) hardware and contain undervoltage sensing circuits to provide protection of computer software. The overvoltage comparator circuits monitor all dc voltage outputs in addition to monitoring the thermal switch (over-temperature sense) circuit. If the supply voltage or temperature exceeds a preset level, the protection and control circuits send an inhibit preregulator signal to the preregulator control circuits to turn off the preregulator, drive the crowbar circuit to shunt the 160-volt output and the +4.85, +20, -2, and -20 volt outputs to ground; and turn off the inverter drive signal.

3-24. The undervoltage comparator monitors the +4.85, +20, and -20 volts and the input line voltage. This comparator furnishes the Internal Power Up (IPU) signal to any auxiliary computer (or extender) and the Power Up (PWU) signal to the computer control logic. The IPU signal is connected to other computers (or extenders) in a multi-computer system to inform all computers whenever power of any one computer (or extender) goes down. If the IPU signal drops, the PWU signal also drops to a low logic state and causes the computer to start its shutdown procedure. After power turn-on, the PWU signal inhibits the computer operation until the power supply regulated outputs have maintained acceptable levels for approximately 0.5 second.

### 3-25. FUNCTIONAL DESCRIPTION.

3-26. As shown in the functional diagram (figure 3-2), the ac input line is connected through fuse F1, RFI filter FL1, and terminal board TB1 to the full-wave phase-controlled bridge rectifier preregulator. The preregulator contains two semiconductor controlled rectifiers (SCR's) and two diodes that rectify and control the voltage sent to the output. The SCR's are turned on by trigger pulses from the preregulator control circuit and turned off (commutated) when the ac input voltage passes through zero. This action sends a portion of the ac input voltage (during each cycle) through the filter circuit and provides the controlled 160-volt dc voltage. The tapped output of


choke-transformer T6 results in doubling the ripple frequency to allow smaller filter components. Capacitors A5C17 and A5C18 are connected into the filter circuit (by a jumper on terminal board TB1) as a voltage doubler when operating with 115 volt ac input. Thus, this circuit provides an output of 160 volts dc for either a 115- or 230-volt ac input.

3-27. The crowbar circuit across the 160-volt output is connected through protection and control card A3 to the feedback signals from the other dc outputs. When an over-voltage condition occurs in one of the outputs, the 160-volt crowbar conducts to short-circuit the 160-volt output (through a low resistance) and protect the load circuit. The crowbar circuit is also triggered directly whenever the 160-volt output exceeds 200 volts.

3-28. The ac input line is also connected from terminal board TB1 to cooling fans B1 and B2 in the computer (or extender), to cooling fans B1 and B2 in the power supply, and to transformer T5. The secondary winding of T5 supplies voltage to the +5, -15, and +15 volt dc regulators, which furnish operating voltages internal to the power supply. The secondary of T5 also supplies a sample of the phase and magnitude of the AC input voltage to the line synchronization circuit. This circuit supplies one of the inputs to the firing angle comparator through an integrator circuit which is controlled by a sinusoidal current source *which is in turn controlled by the load current feedback signal (I LOAD).* The other input to the firing angle comparator is from the error amplifier, which senses the -30 volt transformer winding flux that develops a feedback voltage (-30V No. 1). The output of the firing angle comparator controls a trigger pulse generator that furnishes pulses to the preregulator trigger transformer to turn on the SCR's in the phase-controlled preregulator. The SCR's are turned on one at a time (whichever one has a positive anode potential). In this manner, the preregulator is controlled to compensate for any variations in the ac input voltage, the load current, or the dc output voltage, and maintains a closely controlled 160 volts dc.

3-29. The 160-volt dc output is connected to the inverter bridge circuits through fuses A5F1 and A5F2. Each of the two bridge circuits consists of four transistor switches that are turned on and off by transformer-coupled pulses from the inverter driver circuit. This switching action develops ac square-wave pulses which are transformer-coupled to the rectifier circuits to supply the dc output voltages. As shown in figure 3-2, the inverter driver receives clock signals from a multivibrator that are supplied in two different phases (1 and 2) which are displaced from each other by 90 degrees. This results in the inverter bridges being operated 90 degrees out-of-phase with each other to supply ac square-wave output pulses that overlap as shown in figure 3-7. When the pulses are combined in the full-wave rectifiers, the low-ripple dc outputs are obtained by use of small output filter components.

Note: Information shown in italics on this page pertains only when A1 Preregulator Control Card, part no. 02100-60046, and A4 Current Limit Card, part no. 02100-60061, are installed in the power supply.



2133/53-1B

Figure 3-1. Power Supply, Block Diagram

3-30. The +30 and -30 volt rectified outputs are used to supply the +20 and -20 volt regulators. The additional regulation is required for the 20-volt supplies due to the load (core memory) which has large fluctuations in current demand and requires a high degree of voltage regulation. Since the proper operating voltage for the core memory varies with temperature, the 20-volt supplies are temperature compensated to always supply the optimum voltage. The two different types of 20-volt supplies are described in the following paragraphs.

3-31. The +20 volt supply is a switching-type voltage regulator, with the output voltage level determined by the duty cycle (ratio of "on" time to "off" time) of a switching transistor. The duty cycle is controlled by a feedback signal from the output voltage connected through a resistive divider to one input of an error (operational) amplifier. This input is also connected to the temperature sense resistor in the computer. The other input to the error amplifier is a +15 volt reference voltage. The error amplifier generates an error signal proportional to the difference between its two inputs. This error signal is applied to a comparator circuit. The other input to the comparator is a 20-kHz triangular waveform generated by an oscillator. The output of the comparator is a series of rectangular-shaped pulses, with the width determined by the amplitude of the error signal input. These rectangular-shaped pulses are connected through a driver stage to the switching transistor to control the duty cycle and regulate the +20 volt output.

3-32. The -20 volt supply is a combination series-shunt type voltage regulator, with the output voltage determined by the voltage drop across a transistor pair connected in series-shunt with the -30 volt rectified output. The output is filtered and fed-back to an error (operational) amplifier circuit to generate an error signal which controls the series and the shunt transistor and regulates the -20 volt output.

3-33. An additional -30 volt output from the rectifier circuit (labeled -30V No. 1 in figure 3-2) provides a feedback signal to the preregulator circuit to control the SCR phase angle (delay before turn-on during each cycle) and thus regulate the average dc output voltages. The feedback signal is developed by diodes A8CR11 through A8CR14 connected to the 30-volt taps of the inverter output transformers. The feedback signal is proportional to the magnetic flux density of the transformers and varies with variations in flux density. The feedback signal is compared to a +15 volt reference and supplied to one input of error (operational) amplifier A1U1 in the preregulator control circuit. The output of the error amplifier feeds one input to the firing angle comparator that controls the turn-on of the preregulator SCR's. The other input to the error amplifier is connected to the inhibit preregulator circuit on the protection and control card to control turn-off of the preregulator SCR's in the event of an overcurrent or overvoltage condition.

Note: Information shown in italics on this page pertains only when A1 Preregulator Control Card, part no. 02100-60046, and A4 Current Limit Card, part no. 02100-60061, are installed in the power supply.

3-34. *The load current signal from the current limit card is also connected to the preregulator control circuit to control the sinusoidal current source described in paragraph 3-28. This signal is developed by individual sense amplifiers on the current limit card that sense all the regulator outputs except for the -20 and +30 volt outputs.* The output of the sense amplifiers on the current limit card provide an overcurrent signal when any regulator current exceeds its overload value. The overcurrent signal is sent to the protection and control card to combine with circuits that sense overvoltage in each of the regulators and sense overtemperature in the power supply or computer (or extender). Any of the sense circuits can develop the inhibit preregulator signal that is sent to the error amplifier in the preregulator control circuit to turn off the preregulator. These circuits also drive the crowbar circuits to short-circuit the 160-volt preregulator output and the +20, -20, +4.85 and -2V outputs to prevent damage to the load circuits. In addition, these circuits control the inverter up signal to turn off the drive to the inverter circuit.

3-35. The undervoltage circuits on the protection and control card monitor the +4.85, +20 and -20 volt dc regulator outputs and the 16 volts ac from transformer T5 to determine when an undervoltage condition exists. These circuits supply the power failure detection status signals Power Up (PWU) and Internal Power Up (IPU). The IPU signal is sent to a connector on the computer (or extender) plenum chamber (A26) rear panel for connection to the IPU signal of the power supplies of other computers (or extenders) in a multi-computer system. The signal informs all computers whenever power of any one computer (or extender) decreases below a safe operating level. When the IPU signal drops, the PWU signals also go low to initialize the I/O control card circuitry and cause the computers to start an orderly shutdown procedure.


### 3-36. DETAILED DESCRIPTION.

3-37. This detailed description refers to the schematic diagrams shown in section VII and emphasizes the circuits that are unusual or peculiar to this power supply.

Note: Because power supplies manufactured starting with date code 1240 contain re-designed A1, A3, and A4 circuits, two sets of schematic diagrams are provided in section VII. Use table 3-1 to determine the applicable set of schematics.

3-38. INPUT CIRCUITS. (See Sheet 1 of either Figure 7-3 or 7-4.)

3-39. The 115-volt ac input from the computer (or extender) terminal board TB1 is connected to terminal board TB3 in the power supply and to the bridge rectifier in preregulator A6.



- NOTES:
1. RESISTANCE VALUES ARE IN OHMS AND CAPACITANCE VALUES ARE IN MICROFARADS UNLESS OTHERWISE SPECIFIED.
  2. JUMPERS ARE SHOWN CONNECTED (SOLID LINES) FOR 115-VOLT OPERATION FOR 230-VOLT OPERATION. THESE JUMPERS ARE REMOVED AND A JUMPER IS INSTALLED BETWEEN TERMINALS 8 AND 9 ONLY.
  3. CIRCUITS THAT ARE SHOWN SHADED ARE DELETED WHEN A1 PREREGULATOR CONTROL CARD, PART NO. 02100-60108 OR A4 CURRENT LIMIT CARD, PART NO. 02100-60110, ARE INSTALLED IN POWER SUPPLY.




Figure 3-2. Power Supply, Functional Diagram

Table 3-1. Applicable Schematic Diagrams

| ASSEMBLY | PART NO.    | SCHEM DIAG<br>FIG. NO. |
|----------|-------------|------------------------|
| A1       | 02100-60046 | Figure 7-3             |
| A1       | 02100-60108 | Figure 7-4             |
| A3       | 02100-60047 | Figure 7-3             |
| A3       | 02100-60109 | Figure 7-4             |
| A4       | 02100-60061 | Figure 7-3             |
| A4       | 02100-60110 | Figure 7-4             |

3-40. The ac input power is connected from terminal board TB3 to cooling fans B1 and B2 and to transformer T5. This transformer is a step-down transformer that furnishes 16 volts to the control circuits and furnishes 16 and 5.5 volts ac to rectifiers for the internal voltage regulators on preregulator control card A1.

3-41. The ac input power from terminal board TB3 is connected directly to the bridge rectifier in preregulator A6 as the main power input circuit.

3-42. PREREGULATOR CIRCUIT. (See Sheet 1 of either Figure 7-3 or 7-4.)

3-43. The full-wave phase-controlled preregulator bridge circuit is comprised of diodes A6CR1 and A6CR2 and SCR's A6Q1 and A6Q2. The SCR's are turned on by pulses from the preregulator control circuit trigger-pulse generator A6Q1 through preregulator trigger transformer A1T1. The "on" time of the SCR's during each cycle of the ac input voltage determines the value of the dc output voltage which is maintained at 160 volts. Operation of the preregulator control circuit is described in paragraph 3-58.

3-44. FIRST OUTPUT FILTER CIRCUIT. (See Sheet 1 of either Figure 7-3 or 7-4.)

3-45. The first output filter circuit contains choke-transformer T6, resistors A5R1 and A5R2, diodes A5CR1 and A5CR2, and capacitors A5C17 and A5C18. The primary and secondary windings of T6 are wound on the same core to provide high mutual inductance and are connected so as to aid the current flow around the loop formed by part of the bridge and the output filter. A jumper arrangement on computer (or extender) terminal board TB1 provides connections for 115-volt ac or 230-volt ac input. The jumper connections are described in paragraphs 3-46 and 3-51 to provide the same dc output voltage for either 115- or 230-volt ac input. Resistor A6R1 and capacitor A6C3 are connected across the bridge circuit to improve the "turn-on" characteristics of the SCR's. Resistor A6A1R1 is a current-limiting resistor and A6A1R2 is a noise-suppression resistor for SCR A6Q1. Resistors A5R1 and A5R2 are connected across capacitors A5C17 and A5C18 to provide a discharge path when power is turned off to prevent a hazard to maintenance personnel. Control of the SCR's to maintain a controlled 160-volt dc output is described in paragraphs 3-59 through 3-65.

3-46. 115-VOLT AC OPERATION. (See Sheet 1 of either Figure 7-3 or 7-4.)

3-47. For 115-volt operation, jumpers are connected between terminals 6 and 7, 7 and 8, and 9 and 10 of computer (or extender) terminal board TB1. This connects the "hot" side of the ac input to the bridge junction of SCR's A6Q1 and A6Q2 and the common side to the junction of diodes A6CR1 and A6CR2. The jumper connected between terminals 6 and 7 of TB1 connects capacitors A5C17 and A5C18 into the circuit as a voltage doubler as shown in the simplified schematic diagram in figure 3-3. During the positive half of the ac input voltage, (whenever SCR A6Q1 is fired) the current flows through SCR A6Q1, the secondary of transformer T6, capacitor A5C17, and the jumper (shown as a switch in figure 3-3) between terminals 6 and 7 of terminal board TB1 to the neutral side of the line. For the negative half-cycle, the current flows from neutral through the jumper between terminals 6 and 7 of terminal board TB1 to capacitor A5C18, the primary of T6, and SCR A6Q2 to the "hot" side of the ac line.

3-48. During the time that current is flowing through capacitor A5C17, the voltage across the secondary winding of T6 also appears across the primary winding due to mutual inductive coupling and this voltage back-biases diode A6CR2 and SCR A6Q2 so that no current can flow in the primary during the positive half-cycle. During the negative half-cycle A6Q2 conducts current through the primary to charge capacitor A5C18 and the voltage across the primary appears across the secondary and back-biases diode A6CR1 and SCR A6Q1.


3-49. Due to the jumper that connects the centertap between capacitors A5C17 and A5C18 to the line neutral, each of the capacitors is charged to an equal and opposite voltage in respect to line neutral. Thus, a forced voltage-doubling action occurs for the 115-volt circuit connection.

3-50. 230-VOLT AC OPERATION.

3-51. For 230-volt operation, all jumpers are removed except one which is connected between terminals 8 and 9 of computer or extender terminal board TB1. This jumper arrangement provides the same connections (as for 115-volt operation) to the bridge circuit but disconnects the connection between line neutral and capacitors A5C17 and A5C18 to change the voltage doubler circuit to a filter. During the positive half-cycle of the ac input voltage, (whenever SCR A6Q1 is fired) the current flows through SCR A6Q1, the secondary of transformer T6, capacitors A5C17 and A5C18, the primary of T6, and diode A6CR2 to neutral. During the negative half-cycle of the ac input voltage the current flows from neutral through diode A6CR1, the secondary of T6, capacitors A5C17 and A5C18, the primary of T6, and SCR A6Q2 to the "hot" side of the ac line.

3-52. SECOND OUTPUT FILTER CIRCUIT. (See Sheet 1 of either Figure 7-3 or 7-4.)

3-53. The second output filter is connected from a tap on choke-transformer T6 to inductor L9, resistor A5R5 and capacitors C19 and C20. This circuit operates to double the



2133/53-3

Figure 3-3. Preregulator Circuit, Simplified Schematic Diagram

ripple frequency and reduce the peak-to-peak voltage of the ripple for better filtering. The voltage developed at the tap on T6 represents the 120-Hz ripple of the bridge circuit output voltage. This ripple adds to the 120-Hz ripple of capacitors A5C17 and A5C18 in the phase relationship necessary to fill in the valley portions of the waveform and produce a 240-Hz ripple which is more easily filtered by inductor L9. Resistor A5R5 connected across L9 serves to damp the resonant frequency of the output filter.

3-54. 160V CROWBAR CIRCUIT. (See Sheet 1 of either Figure 7-3 or 7-4.)

3-55. A crowbar circuit on the 160V output board (A5) is connected across the 160-volt dc output, comprising SCR A5Q1, zener diodes A5CR3 and A5CR4, resistors A5R3, A5R4, A5R6, and A5R7, capacitor A5C1, diode A5CR5, and crowbar trigger transformer A5T1. The crowbar circuit acts to place a low resistance short-circuit across the 160-volt output to protect the load if any of the dc outputs exceeds a preset value. If the 160-volt output should exceed the 200-volt drop of zener diodes A5CR3 and A5CR4, SCR A5Q1 is turned on to short-circuit the 160-volt output and blow the 12 ampere fuse F1 in the computer (or extender). Resistor A5R7 limits the peak current through SCR A5Q1. (This resistor is of special design to withstand high current surges and should never be replaced with a substitute for the exact type.) If any of the dc output voltages exceed a preset value, a signal is sent from the crowbar driver to crowbar trigger transformer A5T1 to apply a positive pulse through diode A5CR5 to the gate of SCR A5Q1. This action turns on SCR A5Q1 to short-circuit the 160-volt output. In this case, fuse F1 is normally not blown due to inhibiting of the preregulator as described in paragraph 3-63.

3-56. When the crowbar (short-circuit) action occurs, a reverse voltage could develop across capacitor A5C17 or A5C18 if there is any imbalance in either voltage or capacitance between the two capacitors. To prevent this reverse voltage, diodes A5CR1 and A5CR2 are connected across A5C17 and A5C18.

3-57. Two different 160-volt outputs (No. 1 and No. 2) are supplied by the output filter to the inverter circuits through fuses A5F1 and A5F2. The operation of the inverter circuits is described in paragraph 3-83.

3-58. PREREGULATOR CONTROL CIRCUIT FOR CARD A1, PART NO. 02100-60046. (See Figure 7-3, Sheet 1.)

Note: If the power supply contains preregulator control card, part no. 02100-60108, refer to paragraph 3-66 for the description of circuit operation.

3-59. The preregulator control circuit is located on preregulator control card A1 in the power supply. This circuit controls the firing time of the SCR's in the preregulator (A6) to maintain a constant 160-volt output.

3-60. CONTROL INPUT. Transformer T5 supplies a 16-volt ac rms input to the preregulator control circuit which represents the magnitude and phase of the ac input line voltage. This voltage is routed through the protection and control card A3 to provide an interlock circuit. If the protection and control card A3 is not installed, the 16-volt ac input line is opened and consequently the preregulator

circuit is inoperative. When the 16-volt ac input is applied to the preregulator control circuit input, diodes A1CR12 and A1CR13 pass the full wave rectified signal (waveform A) shown in figure 3-4. This signal is applied to the line synchronization circuits at the base of transistor A1Q10 and to the sinusoidal current source at the emitter of transistor A1Q11. Transistor A1Q12 is biased by a signal that varies with the load current to control the gain (adjustable by resistor A1R11) of the current source A1Q11. The output of A1Q11 is integrated by capacitor A1C12 and applied to the gate of FET A1Q4A as the partial cosine wave-shaped voltage (waveform D) shown in figure 3-4. Transistor A1Q4A forms one-half of the firing angle comparator that determines the firing time of the preregulator SCR's. The charge on capacitor A1C12 rises as shown in waveform D in figure 3-4 during each half-cycle period of the ac input voltage. The line synchronization circuit supplies a pulse to the base of transistor A1Q6 at the zero voltage point in the rectified waveform to turn on A1Q6 and discharge A1C12 rapidly as shown by the trailing edge of the cosine waveform pulse. Resistor A1R28 in the collector circuit of A1Q6 limits the discharge current of capacitor A1C12. Transistor A1Q6 is saturated at the low point in the waveform, until the base voltage (see waveform C, figure 3-4) turns A1Q6 off and the voltage at the collector rises and the integration cycle repeats. The base level is established by dc restorer FET A1Q5 which operates on each half cycle of the input voltage to charge capacitor A1C3 to the voltage at the collector of transistor A1Q11 immediately before capacitor A1C12 is discharged. A pulse from the base of transistor A1Q8 (see waveform C, figure 3-4) turns FET A1Q5 on and off between each integration cycle before transistor A1Q6 is pulsed.





Figure 3-4. Preregulator Control Waveforms

3-61. The firing angle comparator circuit is a differential amplifier consisting of transistors A1Q4A and A1Q4B. The input to A1Q4A is the integrated waveform whose derivative (instantaneous slope) varies with the ac input line voltage as modified by the load-compensated sinusoidal current source transistors A1Q11 and A1Q12. The other input to the firing angle comparator is applied to A1Q4B from error (operational) amplifier A1U1. The error amplifier is controlled by the inhibit preregulator signal from protection and control card A3 and by the flux-sensing voltage from the output of the -30 volt dc rectifiers.

3-62. The integrated waveform voltage applied to the A1Q4A gate input of the comparator is compared with the amplified feedback voltage from error amplifier A1U1 applied to the gate of A1Q4B. When the voltage at the gate of A1Q4A reaches the level of the voltage at the gate of A1Q4B, the "crossover" voltage point is reached. At this point A1Q4A conducts, thus turning off transistors A1Q3 and A1Q2 in turn. When transistor A1Q2 turns off, gate drive is applied to transistor A1Q1 thus turning it on. Transistor A1Q1 is a blocking oscillator that operates regeneratively, to produce a series of pulses when a positive pulse appears at its base. Transistor A1Q2 is a trigger clamp that ensures the blocking oscillator is off when A1Q4A is not conducting. The pulses are generated by the blocking oscillator in 2-kHz pulse bursts, at a 60-Hz rate synchronized to the ac input frequency as shown in waveform B in figure 3-5. The time when each pulse burst is generated depends on the width of the pulse sent from A1Q4A which in turn depends upon the amplitude of the voltages applied to the gates of A1Q4A and A1Q4B. The pulses from the blocking oscillator are sent through preregulator trigger transformer A6A1T1 to SCR's A6Q1 and A6Q2 in the preregulator bridge circuits. The SCR that has a positive half-cycle of the ac input voltage applied to its anode will conduct as shown in waveform C in figure 3-5 to maintain a regulated 160-volt dc output (see waveform D, figure 3-5). Figure 3-6 shows the same waveforms for a loaded output. Although only one pulse from the blocking oscillator is necessary to turn on an SCR, a series (burst) is supplied to ensure that the SCR will turn on and remain on under all dynamic load conditions so that the bridge will not miss a cycle of operation in the ac rectification.




2133/53-5

Figure 3-5. Preregator Waveforms (Unloaded Output)

3-63. ERROR AMPLIFIER CIRCUIT. Error amplifier A1U1 supplies a control voltage to the A1Q4B side of the firing angle comparator. This control voltage establishes the crossover voltage point as described in paragraph 3-62. The non-inverting input at pin 5 of A1U1 is referenced to ground through resistor A1R15 and to the inhibit preregulator signal circuit on the protection and control card A3. The inhibit preregulator signal is generated by an excessive current, voltage, or temperature condition and causes error amplifier A1U1 to supply a positive control voltage to the gate of A1Q4B which turns on A1Q4B and in turn, turns on transistors A1Q3 and A1Q2. This action holds trigger





2133/53-6

Figure 3-6. Preregulator Waveforms (Loaded Output)

pulse generator transistor A1Q1 off and the SCR's are not fired so the preregulator is off.

3-64. The inverting input at pin 4 of error amplifier A1U1 is connected to the -30V No. 1 (flux-sensing feedback) signal from rectifier assembly A8. This signal is applied through a filter network to the inverting input at pin 4 of A1U1. When the dc output varies, the feedback signal varies accordingly to cause the amplifier A1U1 output to change as necessary to fire the preregulator SCR's at the proper time. For example, if the -30V No. 1 output increases (more negative) the feedback signal increases and the output of A1U1 becomes more positive. This output is applied to the gate of A1Q4B and causes A1Q4A to reach the crossover voltage point (described in paragraph 3-62) later in time. This results in the SCR's being fired later in time to pass a smaller portion of the ac input and bring the output back down to 160 volts dc.

3-65. The resistor-capacitor network connected from the output to the input of amplifier A1U1 is to decrease the gain of A1U1 at frequencies near the line frequency and filter resonant frequency to prevent oscillations and provide loop stability. The A1Q13 transistor circuit is used to prevent initial surges of current at power turn-on, which could damage components in the preregulator circuit. During normal operation, transistor A1Q13 is biased off by the resistor divider connected to -30V No. 1 which provides about -3 volts to the base of A1Q13. When power is initially turned on, the -30V No. 1 has not yet been developed to provide this -3 volt bias and transistor A1Q13 will be on to present a current path across amplifier A1U1. This prevents a sharp negative voltage increase at the output of amplifier A1U1 and provides gradual application of power. The variable resistor A1R36 connected to the input of amplifier A1U1 adjusts the value of the 160-volt dc output.

3-66. PREREGULATOR CONTROL CIRCUIT FOR CARD A1, PART NO. 02100-60108. (See Figure 7-4, Sheet 1.)

3-67. The preregulator control circuit is located on preregulator control card A1 in the power supply. This circuit controls the firing time of the SCR's in the preregulator (A6) to maintain a constant 160-volt output.

3-68. CONTROL INPUT. Transformer T5 supplies a 16-volt ac rms input to the preregulator control circuit which represents the magnitude and phase of the ac input line voltage. This voltage is routed through the protection and control card A3 to provide an interlock circuit. If the protection and control card A3 is not installed, the 16-volt ac input line is opened and consequently the preregulator circuit is inoperative. When the 16-volt ac input is applied to the preregulator control circuit input, diodes A1CR3 and A1CR4 pass the full wave rectified signal similar to waveform A shown in figure 3-4. This signal is applied through resistor A1R17 to the emitter of transistor A1Q6 to develop a sinusoidal current source at the collector of transistor A1Q6 which is proportional to the instantaneous value of the absolute value of the ac line voltage. The signal is also applied to the line synchronization circuit through resistor A1R10 to the base of transistor A1Q4. During normal operation, current from the collector of transistor A1Q6 is integrated by the charging of capacitor A1C2. This action produces a cosinusoidal waveform which is shifted 90 degrees in phase from the input line voltage (similar to waveform D, figure 3-4). Transistor A1Q12 is driven by transistor A1Q4 and discharges capacitor A1C2 to reset the integration every time the ac input line voltage (sine wave) passes through zero.

3-69. Transistor A1Q5 serves as a variable dc voltage source to set the voltage level to which capacitor A1C2 is reset when the ac input line voltage passes through zero. This voltage level is proportional to the magnitude of the ac input line voltage because of the connection of resistor A1R14 to the unregulated -22 volts dc.

3-70. The combined effects of the input line controlled current source transistor A1Q6, and the variable reset point provided by transistors A1Q5 and A1Q12 serve as a line voltage feed forward function. This function varies the conduction angle of the preregulator SCR's to correspond with variations in the input line voltage amplitude.

3-71. The firing angle comparator consists of transistors (switches) A1Q14 and A1Q13 connected in series. One input to the comparator is the cosinusoidal waveform developed across capacitor A1C2 as described in paragraph 3-68. The other input to the comparator is the output voltage of error amplifier A1U1. The error amplifier produces an output voltage proportional to the difference between the unloaded inverter output (-30V No. 1) and an interval reference voltage (derived from +15V and variable resistor A1R9).

3-72. The voltage developed across capacitor A1C2 is compared to the output voltage of error amplifier A1U1 as described in paragraph 3-71. When the voltage across capacitor A1C2 becomes more positive than the output voltage of error amplifier A1U1 by a specific amount (the amount equal to the sum of the base-emitter function voltages of transistors A1Q13 and A1Q14), a "crossover" voltage point is reached. At this point transistors A1Q13 and A1Q14 conduct and current flows from ground through resistor A1R28 and diode A1CR13 to the base of transistor A1Q18, turning it on. Transistor A1Q18 is a

blocking oscillator that operates as a trigger pulse generator to produce a series of pulses when turned on. Diode CR11 couples the oscillator circuit back to transistor A1Q12 to ensure that the oscillator is turned off prior to the beginning of each input line cycle. The pulses are generated by the blocking oscillator in 2 kHz pulse bursts, at a 120-Hz rate synchronized to the ac input frequency as shown in waveform B in figure 3-5. The pulses from the blocking oscillator are sent through preregulator trigger transformer A6A1T1 to SCR's A6Q1 and A6Q2 in the preregulator bridge circuits. The SCR that has a positive half-cycle of the ac input voltage applied to its anode will conduct as shown in waveform C in figure 3-5 to maintain a regulated 160-volt dc output as shown in waveform D in figure 3-5. Figure 3-6 shows the same waveforms for a loaded output. Although only one pulse from the blocking oscillator is necessary to turn on an SCR, a series of pulses (burst) is supplied to ensure that the SCR will turn on and remain on under all dynamic load conditions so that the bridge will not miss a cycle of operation in the ac rectification.

3-73. **ERROR AMPLIFIER CIRCUIT.** Error amplifier A1U1 supplies a control voltage to the base of A1Q13 of the firing angle comparator. This control voltage establishes the crossover voltage point described in paragraph 3-72. The non-inverting input at pin 5 of A1U1 is referenced to ground through resistor A1R39 and to the inhibit preregulator signal circuit on the protection and control card A3 through resistor A1R37 and diode A1CR20 (normally reverse-biased). The inhibit preregulator signal is generated by an excessive current, voltage, or temperature condition and causes error amplifier A1U1 to supply a positive control voltage to the base of transistor A1Q13 to turn it off. This action holds trigger pulse generator A1Q13 off and the SCR's are not fired so the preregulator is off.

3-74. The inverting input at pin 4 of error amplifier A1U1 is connected to a voltage divider which is connected between the -30V No. 1 (flux-sensing feedback) signal from rectifier assembly A8 and the +15V internal supply which serves as a voltage reference. The -30V No. 1 signal passes through low-pass filter A1L1-A1C10 to the voltage divider consisting of resistors A1R42, A1R8 and variable resistor A1R9. Variable resistor A1R9 sets the ratio of the voltage divider so that when the voltage at the connection between A1R8 and A1R42 is at zero volts, the proper preregulator output occurs.

3-75. The high-pass filter consisting of A1C9 and A1R41 operates in conjunction with capacitors A1C3 and A1C4 and resistors A1R26 and A1R40 to improve the dynamic response characteristics of the overall preregulator circuit. Diode A1CR7 acts to prevent the inverting input of A1U1. Diodes A1CR8, A1CR9, and A1CR10 couple the feedback loop of A1U1 to the emitter of transistor A1Q5. This connection prevents excessive voltage from charging capacitor A1C4 during turn-on or turn-off transient voltages to eliminate a source of possible delay before the preregulator comes into regulation.

3-76. **INTERNAL VOLTAGE REGULATORS FOR CARD A1, PART NO. 02100-60046.** (See Figure 7-3, Sheet 1.)

Note: If the power supply contains preregulator control card, part no. 02100-60108, refer to paragraph 3-78 for the description of circuit operation.

3-77. The power supply requires low-current regulated dc voltages of +5, +15, and -15 volts for operation of circuits inside the power supply. These voltages are supplied by voltage regulators A1U2, A1U3, and A1U4. Voltage regulator A1U2 is an integrated circuit consisting of a temperature compensated reference voltage amplifier, error amplifier, current limiter, and series pass transistor. This regulator is connected as a positive voltage regulator to supply +5 volts dc through control of external series pass transistor A1Q14. Operating voltages for A1U2 are +22 volts applied to pins 11 and 12 through diode rectifiers CR44 and CR45 from transformer T5 in addition to +15 volts applied to the non-inverting input at pin 5 from voltage regulator transistor A1Q15. The reference voltage from A1U2 at pin 6 (7.5 volts) is supplied to the inverting input of operational amplifier A1U3 (pin 4) which operates as a voltage regulator for the +15 volt output. The other input to A1U3 (pin 5) is connected to a resistive divider that supplies 7.5 volts when the regulated output is at +15 volts. When the output varies above or below +15 volts, the operational amplifier output changes to change the current through zener diode A1CR14 and the base voltage of transistor A1Q15 to regulate the output. Transistor A1Q17 is a current limiter that acts as a base-emitter shunt if the output current of A1Q15 becomes excessive. Resistor A1R52 and capacitor A1C23 are connected in the A1U3 circuit to ensure freedom from oscillations. Operational amplifier A1U4 operates essentially the same as A1U3 to supply a regulated -15 volt dc output.

3-78. **INTERNAL VOLTAGE REGULATORS FOR CARD A1, PART NO. 02100-60108.** (See Figure 7-4, Sheet 1.)

3-79. The power supply requires low-current regulated dc voltages of +5, +15, and -15 volts for operation of circuits inside the power supply. These voltages are supplied by voltage regulator circuits on the preregulator control card. The +15 volt supply serves as a master reference source for all circuit functions except protection and control card A3 functions. Transistor A1Q11 and associated circuits form a series-pass regulator for the 22 volts, dc from transformer T5. Diodes A1CR1 and A1CR2 from a temperature-compensated reference circuit. Transistors A1Q1 and A1Q2 form an error amplifier to drive series-pass transistor A1Q11. Transistor A1Q3 operates as a current-limit transistor, shunting current from transistor A1Q2 whenever the current through resistor A1R7 causes transistor A1Q3 to conduct.

3-80. The -15 volt regulator receives -22 volts dc from transformer T5 through diodes CR14 and CR15 during

operation with normal power input. During power shut-down, the input to the -15 volt regulator is supplied by the output of the -20 volt regulator through diode CR17. The input voltage developed across capacitor A1C14 is regulated by series-pass transistor A1Q7 which is driven by an error amplifier consisting of transistors A1Q16 and A1Q17. Resistors A1R35 and A1R37 form a voltage divider which produces a voltage at the base of transistor A1Q17 that is half-way between the +15V output voltage and the -15V output voltage. This voltage is compared to ground potential by transistor A1Q17 to hold the -15V output voltage equal and opposite to the +15V output voltage. Transistor A1Q15 serves as a current-limit transistor.

3-81. The +5 volt regulator receives +8 volts dc from transformer T5 through diodes CR42 and CR43. Resistor A1R21 passes about one-half of the load current and series-pass regulator transistor A1Q10 passes the other half. A voltage divider formed by resistors A1R22 and A1R25 just forward biases the base of error amplifier A1Q8 when the +5 and +15 volt outputs are in regulation. The base drive current is shunted from series-regulator transistor A1Q10 to maintain a +5 volt output voltage. Resistor A1R23 supplies base drive current to transistor A1Q10.

3-82. INVERTER CIRCUITS. (See Sheet 2 of either Figure 7-3 or 7-4.)

3-83. The 160-volt dc output of the preregulator is connected to the inverter bridge circuits on inverter assembly A7. One inverter bridge circuit consists of transistors A7Q3, A7Q4, A7Q5, and A7Q6 and the other consists of transistors A7Q7, A7Q8, A7Q9, and A7Q10. The inverter bridge circuits are turned on and off at a rate of 800 Hz by pulses from the inverter driver circuit coupled through transformers A7T1 and A7T2. The pulses drive the bridge circuits 90 degrees out of phase with each other to produce ac square wave outputs that are easily rectified and filtered.

3-84. INVERTER DRIVER CIRCUIT. (See Sheet 2 of either Figure 7-3 or 7-4.)

3-85. The inverter driver circuit consists of two sets of drivers, one for each inverter bridge. One set consists of transistors A2Q1 through A2Q4, the other set consists of A2Q5 through A2Q8. Each set has a pair of transistors whose bases are driven by signals that are 180 degrees out of phase (phase 1 and 2), and each pair is driven by signals that are 90 degrees out of phase (see figure 3-7). The drive signals are supplied by a multivibrator circuit consisting of transistors A2Q9 and A2Q11 that supply a 3.2 kHz clock signal to flip-flops U4A (A FF) and U4B (B FF). The FF outputs are processed by gates A2U1, A2U2, and A2U3 to supply the phase 1A, 2A, and 1B, 2B signals to the inverter drivers. The timing and phase relationships of these signals are shown in figure 3-7.

3-86. When the phase 1A signal is positive at the base of transistor A2Q2, transistor A2Q1 is turned off and current flows through A2Q3 and the primary winding of transformer A7T1, diode A2CR1, and transistor A2Q2 to ground. Transistor A2Q1 is held off until A2Q2 turns off, then the cycle reverses when A2Q4 is turned on by phase

1B to develop the square wave pulses in transformer A7T1 as shown in figure 3-8. The phase 2A and 2B inputs result in the same waveshape pulses in transformer A7T2 with the 90-degree output phase relationship corresponding to the inputs. These signals cause the inverter bridge circuits to turn on and off alternately to produce the same relative waveshapes and phase relationships in transformers T3 and T4 as in A7T1 and A7T2, respectively (see figure 3-9). Note the "step" in the leading and trailing edge of the transformer waveform shown in figure 3-7. This step is caused by the timing of the pulses applied to the bases of the transistors in the inverter driver circuit. The "step" results in a momentary idle time between turn-on and turn-off of individual transistors in each pair of transistors to prevent shorting the transistors across the 160-volt line.


3-87. RECTIFIER ASSEMBLIES. (See Sheet 2 of either Figure 7-3 or 7-4.)

3-88. Rectifier assembly A8 contains six banks of diode rectifiers that rectify all outputs of transformers T3 and T4 except the +4.85 volt output which is rectified by rectifier assembly A9. Each bank of four diodes in assembly A8 is comprised of two pairs of diodes, one pair being connected to each transformer. Since the transformer outputs are 90 degrees out of phase, the combined full-wave rectified outputs of the transformers overlap each other to form a basically pure dc output that requires very little filtering. The -2V, -12V, and +12V outputs are supplied through an LC filter to terminal boards TB1 and TB2 and the +30V and -30V outputs are supplied to the +20V and -20V regulators respectively. An additional -30V output (-30V No. 1) is taken from diodes A8CR11 through A8CR14 that sense the changes in flux density in transformers T3 and T4. This -30V No. 1 signal is a feedback signal used in regulation of the output by the preregulator control circuit as described in paragraph 3-64.

3-89. On the +4.85V rectifier assembly (A9), diode rectifiers CR35 through CR38 are protected against excessive peak inverse voltage by the parallel connection of zener diodes CR46 through CR49, and capacitors C27 through C30, respectively.

3-90. +20 VOLT REGULATOR. (See sheet 2 of either Figure 7-3 or 7-4.)


3-91. The +20 volt regulator is a switching-type voltage regulator with the output voltage level determined by the duty cycle of switching transistor A11Q14. The normal operating frequency is 20 kHz. The input to this regulator is supplied from the +30 volt output of rectifier assembly A8. The output voltage of the regulator is sensed by a control circuit which automatically adjusts the duty cycle of transistor A11Q14 to maintain a constant output voltage regardless of rapid variations in load current and input voltage. The +20 volt feedback voltage is applied to the inverting input of error (operational) amplifier A2U7 through the +20 voltage adjustment resistor A2R35, which is also connected to a temperature sense resistor located on the inhibit driver load card (A106) in the memory section



2133/53-7A


Figure 3-7. Inverter Driver Circuit, Timing Diagram

of the computer card cage. Since the proper operating voltage for the core memory varies with temperature, this temperature compensation is required to maintain the optimum operating voltage. (When the power supply is installed in a 2155A Extender, the temperature compensation is not required as the extender does not contain memory circuits. The temperature compensation resistor, in this case, is replaced by an 825-ohm load resistor connected across terminals 8 and 9 of power supply terminal board TB2.) The non-inverting input to error amplifier A2U7 is connected to a reference voltage of +15 volts (internal regulator) through a resistive divider comprised of resistors



2133/53-9


Figure 3-9. Inverter Input and Output Waveforms



2133/53-8

Figure 3-8. Inverter Driver Waveforms

A2R37 and A2R39. The output of error amplifier A2U7 varies with the +20 volt output as compensated by core memory temperature variations, and feeds the non-inverting input of comparator (operational amplifier) A2U9. The other input to A2U9 is from operational amplifier A2U8 which is operated as a 20 kHz oscillator that generates a triangular-shaped waveform. See figure 3-10. This same input (inverting) to A2U8 is connected to the +20 volt inhibit signal from current limit card A4 described in paragraph 3-103. The output of comparator A2U9 is a series of rectangular-shaped pulses (see figure 3-10) with the width of the pulses being determined by the amplitude of the



2133/53-10

Figure 3-10. +20 Volt Regulator Waveforms


output signal from error amplifier A2U8. These rectangular-shaped pulses are sent through transistor A2Q15 to drive the base of transistor A2Q16 which controls the duty cycle of switching transistor A11Q14.

3-92. The output stage of the +20 volt regulator is shown in simplified schematic form in figure 3-11. Transistor A2Q15 operates as a level shifter, converting the voltage pulse from the comparator (A2U9) to a current pulse at the base of transistor A2Q16. Transistor A2Q16 is the input stage of a current-limited fast-acting push-pull driver circuit consisting of transistors A2Q13, A2Q14, and A2Q16. Transistor A11Q14 is the main power switching transistor of the

regulator, and is driven on and off alternately by the driver stage which is controlled by the comparator output. The on and off action provides 30-volt pulses across diode A11CR41 to the input of choke A11L4 which stores energy and transfers current to capacitor A11C14 while A11Q14 is conducting. When A11Q14 is turned off, the voltage at the junction of A11L4 and the collector of A11Q14 drops rapidly until diode A11CR41 conducts again. While A11Q14 is in the "off" state, the energy stored in A11L4 is released to maintain a continuous (but slightly varying) dc current in the loop consisting of A11L4, A11CR41, and A11C14. Thus, the loop serves to convert the variable duty cycle pulse applied across diode A11CR41 into a dc voltage (with a small triangular dc component) at capacitor A11C14 which is proportional to the duty cycle of the comparator output.

3-93. Chokes A11L2 and A11L3 and capacitor C16 serve to further filter the output of capacitor A11C14 to supply a low impedance dc output voltage.

3-94. In the push-pull driver circuit consisting of transistors A2Q13, A2Q14, and A2Q16 and associated circuitry, transistor A2Q16 serves as a high speed driver to A11Q14. Inductor A2L3 stores energy to speed up the turn off of A2Q16 by supplying a 0.8-volt reverse drive to the base as soon as the emitter current begins to decrease. Under normal operation, the current through inductor A2L3 is low enough so that the current through A2CR7 will decay to zero before A2Q16 turns on again. Whenever



2133/53-11B

Figure 3-11. +20 Volt Regulator Output, Simplified Schematic Diagram

the current through A2L3 becomes excessive, A2CR7 will remain forward biased after A2Q15 tries to turn on A2Q16. This holds A2Q14 and A2Q16 off to reduce the duty cycle of A2Q16 and limit the average current.

3-95. Transistor A2Q13 acts as a base clamp on A11Q14, to momentarily clamp the A11Q14 base to the emitter whenever A2Q16 begins to turn off A11Q14. The collector voltage of A11Q14 is coupled through capacitor A2C12 and resistor A2R30 to the base of A2Q13. Thus, when the collector voltage of A11Q14 begins to drop, a regenerative action occurs to draw the stored charge out of the base of A2Q14 to speed up the turn off action. This reduces the switching power losses in A11Q14.

3-96. -20 VOLT REGULATOR. (See Sheet 2 of either Figure 7-3 or 7-4.)

3-97. The -20 volt regulator is a push-pull, combination series-shunt type regulator capable of supplying a positive output current (sourcing) of 100 milliamperes and a negative output current (sinking) of 600 milliamperes at -20 volts. It is regulated within 1 percent of the value of the +20 volt regulator but of opposite polar.

3-98. In the first stage of the -20 volt regulator, the inverting input of error (operational) amplifier A2U6 is connected to a resistive voltage divider that is connected on one side to the +20 volt output and on the other side to the -20 volt output. The other input (non-inverting) of A2U6 is connected to ground potential. Since the output of error amplifier A2U6 will be of opposite polarity to the inverting input, any change in the +20 or -20 volt outputs will cause an opposite change in the output of A2U6. This causes the -20 volt output to be maintained at equal value (and opposite polarity) to the +20 volt output.

3-99. Operational amplifier A2U5 acts as a level shifting amplifier. The output of error amplifier A2U6 is amplified by A2U5. The input circuit to A2U5 is also connected to ground potential through capacitor A2C5 and to -30 volts through choke A2L2. These circuits control the input and output voltage excursion range of A2U5 to correspond to the range of the preceding and succeeding circuits.

3-100. Transistor A2Q10 operates as a current limit circuit for series-pass transistor A11Q13 by sensing the voltage drop across filter choke A2L1. Capacitor A2C6 serves as the output filter for the -20 volt regulator.

3-101. OUTPUT CROWBAR CIRCUIT. (See Figure 7-3, Sheet 1.)

3-102. The output crowbar circuit is comprised of two SCR's, one of which is connected from the -2 volt to the +4.85 volt output and the other is connected from the -20 volt to the +20 volt output. Gate pulses that fire the SCR's are supplied by the crowbar trigger transformer (A5T1 secondary) on the 160 volt output board A5. The primary of transformer A5T1 is connected to the crowbar driver circuit on protection and control card A3, described in paragraph 3-129.

3-103. CURRENT LIMIT CARD A4, PART NO. 02100-60061. (See Figure 7-3, Sheet 4.)

Note: If the power supply contains current limit card part no. 02100-60110, refer to paragraph 3-110 for the description of circuit operation.

3-104. The current limit card contains individual current sense amplifiers (operational amplifiers) U1, U2, U5, U6, and U7 to sense the value of the output load current of the +20, +12, +4.85, -2, and -12 volt regulators respectively. This sensing is accomplished by connecting the inputs of the sense amplifiers across the output filter choke in each regulator output section. Whenever the output current varies, the sense amplifier output varies accordingly due to the voltage change of the dc component across the filter choke. The resistor-capacitor network at the input of each sense amplifier provides low-pass ac filtering and the resistor-capacitor network connected between output and inverting input determines the amplifier dc gain and ac response characteristics. Zener diode CR9 connected to U7 provide automatic control of the operating voltage supplied to these amplifiers. This control is necessary when large common mode voltage changes (such as during initial turn-on) occur at the input to the amplifier which would be outside its operating range. Thus, the operating voltage of the amplifier is allowed to "float" to adjust to these changes.

3-105. The outputs of the sense amplifiers are combined into one circuit arrangement to develop the load current output and are combined in another circuit arrangement to develop the overcurrent signal.

3-106. LOAD CURRENT OUTPUT. The load current output signal is a voltage developed by the output of the sense amplifiers fed through resistor networks and operational amplifiers U3 and U8. The output of the +4.85, +20, and +12 volt sense amplifiers is applied through resistors R21, R19, and R20, respectively, to the inverting input of amplifier U3. The signal developed is proportional to the weighted sum of the load currents. This signal is combined, through another resistor network, with the - and -12 volt sense amplifier outputs and applied to the inverting input of amplifier U8. The output of amplifier U8 is a control voltage that is proportional to the weighted sum of all the regulator load currents. (In effect, it is directly proportional to the preregulator output current which flows through choke L9 in the preregulator filter.) This control signal is sent to the load current compensation circuit in the preregulator control section.

3-107. The output of the +20 volt sense amplifier is connected through pin 16 of the current limit card to the +20 volt regulator circuit through pins 2 and B of inverter driver card A2. This signal inhibits comparator A2U9 in the 20 volt regulator if a sharp increase occurs in the load current.

3-108. OVERCURRENT. The overcurrent signal is developed by the output of the -2, -12, +4.85, and +12

volt sense amplifiers fed through diodes, resistor networks, and amplifiers U4 and U9. The outputs of the -2 and -12 volt sense amplifiers are "or-tied" through diodes CR12 and CR13 and a voltage divider to amplifier U9. The outputs of the +4.85 and +12 volt sense amplifiers are "or-tied" through CR2 and CR3 and a voltage divider to amplifier U4. Amplifiers U9 and U4 are normally in the "off" condition. When any regulator output current exceeds its overload value, the output of amplifier U9 or U4 turns on transistor Q1 to supply the overcurrent signal. This signal is supplied to the protection and control card to develop the inhibit preregulator signal described in paragraph 3-118.

3-109. TEST POINTS. Test points E1 through E5 are provided at the outputs of the +20, +12, +4.85, -2, and -12 volt sense amplifiers, respectively, to facilitate circuit testing.

3-110. CURRENT LIMIT CARD A4, PART NO. 02100-60110. (See Figure 7-4, Sheet 4.)

3-111. The current limit card contains individual current sense amplifiers (operational amplifiers) U1, U2, U4, U5, and U6 to sense the value of the output load current of the +20, +12, +4.85, -2, and -12 volt regulators respectively. This sensing is accomplished by connecting the inputs of the sense amplifiers across the output filter choke in each regulator output section. Whenever the output current varies, the sense amplifier output varies accordingly due to the voltage change of the dc component across the filter choke. The resistor-capacitor network at the input of each sense amplifier provides low-pass ac filtering and the resistor-capacitor network connected between output and inverting input determines the amplifier dc gain and ac response characteristics. Zener diode CR8 connected to amplifier U1 and U2 and zener diode CR5 connected to U6 provide automatic control of the operating voltage supplied to these amplifiers. This control is necessary when large common mode voltage changes (such as during initial turn-on) occur at the input to the amplifier which would be outside its operating range. Thus, the operating voltage of the amplifier is allowed to "float" to adjust to these changes.

3-112. The outputs of the sense amplifiers are combined into one circuit arrangement to develop the overcurrent signal.

3-113. The output of the +20 volt sense amplifier is connected through pin 16 of the current limit card to the +20 volt regulator circuit through pins 2 and B of inverter driver card A2. This signal inhibits comparator A2U9 in the 20 volt regulator if a sharp increase occurs in the load current.

3-114. OVERCURRENT. The overcurrent signal is developed by the output of the -2, -12, +4.85, and +12 volt sense amplifiers fed through diodes, resistor networks, and amplifiers U7 and U3. The outputs of the -2 and -12 volt sense amplifiers are "or-tied" through diodes CR11 and CR12 and a voltage divider to amplifier U7. The outputs of the +4.85 and +12 volt sense amplifiers are "or-tied"

through CR1 and CR2 and a voltage divider to amplifier U3. Amplifiers U7 and U3 are normally in the "off" condition. When any regulator output current exceeds its overload value, the output of amplifier U7 or U3 turns on transistor Q1 to supply the overcurrent signal. This signal is supplied to the protection and control card to develop the inhibit preregulator signal described in paragraph 3-118.

3-115. TEST POINTS. Test points E1 through E5 are provided at the outputs of the +20, +12, +4.85, -2, and -12 volt sense amplifiers, respectively, to facilitate circuit testing.

3-116. PROTECTION AND CONTROL CARD A3, PART NO. 02100-60047. (See Figure 7-3, Sheet 3.)

Note: If the power supply contains protection and control card, part no. 02100-60109, refer to paragraph 3-135 for the description of circuit operation.

3-117. The protection and control card performs functions that protect the power supply and computer (or extender) circuits (hardware). These circuits also protect data (software) stored in the computer memory and registers when failures occur in power supply or computer circuits or in the ac power source. This card also contains circuits that provide for an orderly start-up and shut-down during normal turn-on and turn-off of the ac power.

3-118. MONITOR CIRCUITS. Each of the regulated dc output voltages is continuously monitored to detect overvoltage, and the +20, -20, and +4.85 volt regulator outputs and the ac power line voltage are continuously monitored to detect undervoltage. Thermal switches on the power supply heat sinks and in the computer (or extender) are monitored to detect overtemperature conditions. The overcurrent signal is sent from the current limit card to the protection and control card whenever a regulator output exceeds its overload value. When an overvoltage or overtemperature condition occurs, the inhibit preregulator (INH PREG) signal and the "not" inverter up (INU) signal are developed. The inhibit preregulator signal results in turn off of the preregulator, and the "not" inverter up signal results in turn-off of the inverter drive signal. In addition, a crowbar driver signal is developed to crowbar (short-circuit) all output voltages to protect the computer (or extender) circuits. When an overcurrent condition occurs, only the inhibit preregulator signal is generated. When an undervoltage condition occurs, a power failure detection signal ("not" PWU) is developed, prior to the complete loss of voltage, to save the current status of the computer program and to allow automatic restart after power is restored to normal.

3-119. BASIC SECTIONS OF PROTECTION AND CONTROL CARD. Circuit description of the protection and control card is divided into six basic sections, as follows:

- a. Positive overvoltage comparator and latch.
- b. Negative overvoltage comparator.

- c. Undervoltage comparator.
- d. Shutdown output signal generator.
- e. Internal voltage reference.
- f. Power-up output circuit.

3-120. Positive Overvoltage Comparator and Latch. This section consists of transistors U1Q1 through U1Q5 and transistor Q2 and associated circuits. Transistors U1Q1, U1Q2, U1Q3, and U1Q5 serve as multiple non-inverting inputs to a differential comparator circuit. Transistor U1Q4 serves as the inverting input. Whenever the voltage at a non-inverting input exceeds the +4.85 volt reference source applied to the base of U1Q4, transistor Q2 drives an output voltage from a -15 volt normal state to a +15 volt overvoltage state value. The output is coupled back through diode CR11, resistor R26, and capacitor C14 to the non-inverting input at the base of transistor U1Q5 causing it to saturate and latch the comparator circuit whenever one of the non-inverting inputs detects an overvoltage. The latch condition can only be removed by turning off the power. The output of transistor Q2 enables transistor Q1 (crowbar driver), transistor U3Q4 ("not" inverter up) and sends the Inhibit Preregulator signal through diode CR7. Resistor R9 in the emitter circuit of transistor U1Q4 is a current source resistor for the differential comparator and capacitor C10 in the base circuit of transistor U1Q5 decouples the latching input from noise voltage spikes that may be radiated or conducted from the adjacent high-powered switching circuits.

3-121. The thermal sense input is coupled to the latch circuit (U1Q5) through diode CR9. For this reason, the power supply will remain off after an overtemperature has occurred and been corrected, unless the power switch is turned off and back on, or unless diode CR9 is removed. (Removal of CR9 allows automatic restart of the computer after the temperature has returned to normal.)

3-122. The overall comparator circuit switching action is aided by capacitor C11 in the collector circuit of U1Q3 and capacitor C26 in the base circuit of transistor Q2. These capacitors speed up the switching and ensure that once the switching action begins it will continue until latched regardless of input changes.

3-123. The input circuits to transistors U1Q1, U1Q2, and U1Q3 comprise voltage divider pairs of resistors and voltage spike filter capacitors.

3-124. Negative Overvoltage Comparator. The negative overvoltage comparator consists of transistors U2Q1 and U2Q2 and associated circuits. The voltage divider resistors at the input to transistor U2Q1 are connected to the -2, -12, and -20 volt regulator outputs. Each voltage divider develops a voltage that is normally positive but which passes below ground level when the associated regulator output voltage exceeds its overvoltage limit. When this occurs, the "or-tied" diode (CR13, CR16, or CR18) conducts to cut off U1Q1. This action allows the voltage developed across resistor R30 to be applied to a non-inverting input of the positive overvoltage comparator at the base of U1Q5 through diode CR12, initiating the same latching action described in paragraph 3-120.

3-125. Diode CR31 protects the base-emitter junction of transistor U2Q1 from excessive reverse bias voltage. Resistor R73 and capacitor C28 provide a feedback signal from crowbar driver transistor Q1 to the base of U2Q1 whenever the crowbar is triggered. This feedback signal ensures the latch condition of transistor Q2 whenever the crowbar is triggered, even if it is triggered by noise voltage spikes or a single failure in the protection circuit. Capacitors C16, C18, and C19 filter noise voltage spikes in the input circuit of transistor U2Q1. Diode CR14 is a temperature compensation diode and resistor R33 is a bias-developing resistor in the base circuit of transistor U2Q2. Diode CR30 clamps the voltage developed across source resistor R38 in the emitter circuits of U2Q1 and U2Q2.

3-126. Undervoltage Comparator. The undervoltage comparator is similar in operation to the negative overvoltage comparator described in paragraph 3-124.

3-127. The base circuit of transistor U2Q4 serves as the inverting input to the comparator. The base is biased high by resistor R44 whenever the +20, +4.85, or -20 volt regulator outputs are below their undervoltage level. Transistor U2Q3 serves as the non-inverting input of this comparator and is referenced to the emitter-base junction of transistor Q4 (reference source) which provides temperature compensation for diodes CR24, CR28, and CR29 which form the "or-tied" inputs to this comparator. Whenever the cathode of one of these diodes drops below a +4.5 volt reference level, transistor U2Q4 turns off. This develops a voltage across resistor R34 which turns on transistor U2Q5 through zener diode CR22. The base of emitter-follower transistor Q6 goes low as does the IPU signal. When the IPU signal goes low, a control signal is fed back to the base of transistor U2Q4 through the resistor-capacitor network R72, C25, and R71. This feedback signal ensures that the IPU signal will remain low for at least 1 millisecond and shifts the trip point of the comparator up higher so that the source of the undervoltage must increase slightly above the voltage at which it tripped IPU, before IPU will return high.

3-128. Shutdown Output Signal Generator. The shutdown output signal generator circuit (transistors U3Q4, Q1 and associated circuitry) is controlled by the output of the positive overvoltage comparator (collector of transistor Q2). The positive signal applied through diode CR3 turns on transistor U3Q4 to turn off the inverter driver circuit whenever an overvoltage is detected. This same positive signal is sent through diode CR7 as the inhibit preregulator signal to turn off the preregulator circuit. The inhibit preregulator signal may also be developed by an open thermal switch (A6S1, A9S2 or S3) through diode CR8 and zener diode CR4 or by an overcurrent signal from the current limit card fed through diode CR5.

3-129. The circuit of transistor Q1 functions as a crowbar driver blocking oscillator. This circuit drives crowbar trigger transformer A5T1 (see figure 7-3, sheet 1) on 160V output board A5. Transformer A5T1 provides feedback (to sustain oscillations) to pin 11 of A3, through resistor R11, capacitor C3, and diode CR1 to the base of Q1.



Normally, transistor Q1 is inhibited from oscillation by resistor R12 and capacitor C2 which act as a noise filter to prevent Q1 from being triggered by random high frequency noise pulses from adjacent circuits. When the output of the overvoltage comparator (Q2) exceeds +8 volts, CR2 conducts to turn on blocking oscillator transistor Q1. Capacitor C4 counteracts the delay factor which would be caused by resistor R7 and capacitor C2. Once the blocking oscillator fires, the crowbar latch condition enables it to continue firing. Resistor R73 and capacitor C28 feed back a signal from the oscillator to the base of U2Q1 (comparator) to ensure that the latch condition is set despite random transient pulses that might otherwise cause it to reset.

3-130. Each of the three secondary windings of crowbar trigger transformer A5T1 are connected to a separate SCR. One of the SCR's is located on 160V output board A5 (see figure 7-3, sheet 1) in series with 2-ohm resistor A5R7. When this SCR is fired by the crowbar driver (blocking oscillator) it shunts the 160-volt output and discharges the preregulator output capacitors. The other two SCR's are on output crowbar A10 and are connected between the +20 and -20 volt output and between the +4.85 and -2 volt output, respectively (see figure 7-3, sheet 1). When these SCR's are fired, the associated filter capacitors are discharged.

3-131. Internal Voltage Reference. (See figure 7-3, Sheet 3.) The internal voltage reference circuit on A3 consists of transistors Q3 and Q4 which provide a temperature-compensated reference voltage for all functions of the protection and control card A3.

3-132. Diode CR10 is a low-temperature coefficient zener diode biased for maximum temperature stability. Resistors R25, R4 (REF ADJ), and R1 form an adjustable voltage divider centered at +4.5 volts. Transistors Q3 and Q4 form a temperature-balanced buffer stage. Capacitor C21 is connected in the emitter circuit of transistor Q3 to filter high frequency noise voltages radiated by adjacent circuits and prevent oscillation at the emitter of transistor Q3.

3-133. Power Up Output Circuit. The power up output circuit is a one-half second monostable multivibrator comprised of transistors U3Q2, U3Q1, and Q5. When the IPU signal goes low, as described in paragraph 3-127, due to the action of transistor Q6 (or the same Q6 in another 2100 Computer or 2155A Extender interconnected by IPU) the PWU signal goes low immediately and remains low for one-half second after IPU has returned high. The low PWU signal starts the power failure routine to provide an orderly shutdown and save the contents of the computer registers and memory.

3-134. The PWU signal goes low whenever the IPU signal goes low. This happens whenever U2Q5 is turned on by either the undervoltage comparator (through CR22), the overvoltage comparator (through CR15) or by the thermal switches (through CR23).

3-135. PROTECTION AND CONTROL CARD A3, PART NO. 02100-60109. (See Figure 7-4, Sheet 3.)

3-136. The protection and control card performs functions that protect the power supply and computer (or extender) circuits (hardware). These circuits also protect data (software) stored in the computer memory and registers when failures occur in power supply or computer circuits or in the ac power source. This card also contains circuits that provide for an orderly start-up and shut-down during normal turn-on and turn-off of the ac power.

3-137. MONITOR CIRCUITS. Each of the regulated dc output voltages is continuously monitored to detect overvoltage, and the +20, -20, and +4.85 volt regulator outputs and the ac power line voltage are continuously monitored to detect undervoltage. Thermal switches on the power supply heat sinks and in the computer (or extender) are monitored to detect overtemperature conditions. The overcurrent signal is sent from the current limit card to the protection and control card whenever a regulator output exceeds its overload value. When an overvoltage or overtemperature condition occurs, the inhibit preregulator (INH PREG) signal and the "not" inverter up (INU) signal are developed. The inhibit preregulator signal results in turn off of the preregulator, and the "not" inverter up signal results in turn-off of the inverter drive signal. In addition, a crowbar driver signal is developed to crowbar (short-circuit) all output voltages to protect the computer (or extender) circuits. When an overcurrent condition occurs, only the inhibit preregulator signal is generated. When an undervoltage condition occurs, a power failure detection signal ("not" PWU) is developed, prior to the complete loss of voltage, to save the current status of the computer program and to allow automatic restart after power is restored to normal.

3-138. BASIC SECTIONS OF PROTECTION AND CONTROL CARD. Circuit description of the protection and control card is divided into six basic sections, as follows:

- a. Positive overvoltage comparator and latch.
- b. Negative overvoltage comparator.
- c. Undervoltage comparator.
- d. Shutdown output signal generator.
- e. Internal voltage reference.
- f. Power-up output circuit.

3-139. Positive Overvoltage Comparator and Latch. This section consists of transistors A3Q9 through A3Q12, A3Q17 and associated circuits. Transistors A3Q9 through A3Q12 serve as non-inverting inputs to a differential comparator circuit. Diode CR29 serves as the inverting input. Whenever the voltage at a non-inverting input exceeds the +4.85 volt reference source applied to the anode of diode CR29, the collector of transistor A3Q17 drives an output voltage from a -15 volt normal state to a +15 volt overvoltage state value. The output is coupled back through diode CR31, resistor R73, and capacitor C25 to the non-inverting input at the base of transistor A7Q12 causing it to

saturate and latch the comparator circuit whenever one of the non-inverting inputs detects an overvoltage. The latch condition can only be removed by turning off the power. The output of transistor A3Q17 enables transistor A3Q16 (crowbar driver), transistor A3Q8 ("not" inverter up) and sends the Inhibit Preregulator signal through diode CR32. Resistor R70 in the emitter circuits of transistors A3Q9 through A3Q12 is a current source resistor for the differential comparator.

3-140. The thermal sense input is coupled to the latch circuit (A3Q12) through diodes CR30 and CR24. For this reason, the power supply will remain off after an over-temperature has occurred and been corrected, unless the power switch is turned off and back on, or unless diode CR30 or CR24 is removed. (Removal of CR30 or CR24 allows automatic restart of the computer after the temperature has returned to normal.)

3-141. The overall comparator switching action is aided by capacitor C14 in the collector circuit of A3Q11 and capacitor C23 in the base circuit of transistor A3Q17. These capacitors speed up the switching and ensure that once the switching action begins it will continue until latched regardless of subsequent input changes.

3-142. The input circuits to transistors A3Q9, A3Q10, and A3Q11 comprise voltage divider pairs of resistors and voltage spike filter capacitors.

3-143. Negative Overvoltage Comparator. The negative overvoltage comparator consists of transistor A3Q7 and associated circuits. The voltage divider resistors at the input to transistor A3Q7 are connected to the -2, -12, and -20 volt regulator outputs. Each voltage divider develops a voltage that is normally positive but which passes below ground potential when the associated regulator output voltage exceeds its overvoltage limit. When this occurs, the "or-tied" diode (CR16, CR17, or CR18) conducts to cut off A3Q7. This action allows the current through resistor R42 to be applied to a non-inverting input of the positive overvoltage comparator at the base of transistor A3Q12 through diode CR21, initiating the same latching action described in paragraph 3-139.

3-144. Capacitor C20 and resistor R51 provide a feedback signal from crowbar driver transistor A3Q16 to the base of A3Q7 whenever the crowbar is triggered. This feedback signal ensures the latch condition of transistor A3Q17 whenever the crowbar is triggered, even if it is triggered by noise voltage spikes or a single failure in the protection circuit. Capacitors C9, C10, and C11 filter noise voltage spikes in the input circuit of transistor A3Q7.

3-145. Undervoltage Comparator. The base-emitter function of transistor A3Q2 serves as the undervoltage comparator. This function is reverse biased when both the +4.85 volt and the +20 volt regulator outputs are above their undervoltage levels. The emitter of transistor A3Q2 is connected to the +4.5 volt reference voltage and the base is connected, through diodes CR7 and CR12, to the "and-tied" diodes CR6 and CR8. Diode CR7 provides

temperature compensation for diodes CR6 and CR8 and diode CR12 provides temperature compensation for the base-emitter function of transistor A3Q2. Whenever the cathode voltage of diode CR6 or CR8 drops below the 4.5-volt reference level, current flow from resistors R17 and R18 (which had been holding A3Q2 in the "off" state) is shunted through the forward-biased diode (CR6 or CR8) allowing resistor R22 to sink current from the base of transistor A3Q2, thus turning it on.

3-146. When transistor A3Q2 turns on (due to a positive undervoltage) it causes transistor A3Q4 to turn on through resistor R21. This action turns off transistor A3Q3 and causes timing capacitor C3 to discharge. Turning off transistor A3Q3 allows transistor A3Q6 to turn off and the PWU signal, at the emitter of emitter-follower A3Q5, is drawn towards zero volts by resistors R8 and R10. Resistor R29 and capacitor C8 provide positive ac feedback to the base of transistor A3Q3 to ensure that the PWU signal does not pulsate during the period of time required to discharge capacitor C3. Capacitor C3 may also be discharged by the IPU line to another computer when the IPU lines are connected together in a multi-computer system.

3-147. Transistor A3Q1 and associated circuits serve to detect failure of the -20 volt regulator to track the +20 volt regulator and to detect power failure due to undervoltage or loss of ac line power. Resistors R4 and R16 form a voltage divider which allows transistor A3Q1 to turn on when the magnitude of the -20 volt regulator output changes in excess of 3.5 volts more than the +20 volt regulator output changes. When transistor A3Q1 turns on it sinks current from the base of transistor A3Q2. This action initiates the positive undervoltage sequence described in paragraph 3-146.

3-148. Another input to transistor A3Q1 is through diode CR2 from the negative side of capacitor C4. The current flow through resistors R1 and R2 (line adjust) charges capacitor C4 and it discharges through resistor R3, diodes CR4 and CR5 and transformer T5. The positive peak voltage from the negative side of capacitor C4 to common potential is proportional to the average value of the input line voltage. (This positive peak voltage is nearly independent of line frequency, waveform distortion, or capacitance variations of capacitor C4.) Whenever this peak voltage becomes greater than common potential, transistor Q1 is turned on initiating the positive undervoltage sequence described in paragraph 3-146. Diode CR1 controls the response time of capacitor C4 to ensure that the loss of more than one power line cycle will be detected. Resistor R13 and Diode CR3 provide additional bias current to capacitor C4 only when transistor A3Q2 is on. This acts to produce a margin of about 4 volts ac between the line voltage value at which the PWU signal goes down and the value at which the PWU signal goes up.

3-149. Shutdown Output Signal Generator. The shutdown output signal generator circuit (transistors A3Q8, A3Q16, and associated circuitry) is controlled by the output of the positive overvoltage comparator (collector of transistor A3Q17). The positive signal applied through

diode CR23 turns on transistor A3Q8 to turn off the inverter driver circuit whenever an overvoltage is detected. This same positive signal is sent through diode CR32 as the inhibit preregulator signal to turn off the preregulator circuit. The inhibit preregulator signal may also be developed by an open thermal switch (A6S1, A9S2, or S3) through diode CR26 or by an overcurrent signal from the current limit card fed through diode CR27.

3-150. The circuit of transistor A3Q16 functions as a crowbar driver blocking oscillator. This circuit gives crowbar trigger transformer A5T1 (see figure 7-4, sheet 1) on 160V output board A5. Transformer A5T1 provides feedback (to sustain oscillations) to pin 11 of A3, through resistor R71, capacitor C24, and diode CR25 to the base of A3Q16. Normally, transistor A3Q16 is inhibited from oscillation by resistor R62. When the output of the overvoltage comparator (A3Q17) exceeds +6.2 volts, transistor A3Q15 conducts to turn on blocking oscillator A3Q16. Once the blocking oscillator fires, the crowbar latch condition ensures that it will continue to fire. Capacitor C20 and resistor R51 feed back a signal from the oscillator to the base of transistor A3Q7 (comparator) to ensure that the latch condition is set despite random transient pulses that might otherwise cause it to reset.

3-151. Each of the three secondary windings of crowbar trigger transformer A5T1 are connected to a separate SCR. One of the SCR's is located on 160V output board A5 (see figure 7-4, sheet 1) in series with 2-ohm resistor A5R7. When this SCR is fired by the crowbar driver (blocking oscillator) it shunts the 160-volt output and discharges the preregulator output capacitors. The other two SCR's are on output crowbar A10 and are connected between the +20 and -20 volt output and between the +4.85 and -2 volt output, respectively (see figure 7-4, sheet 1). When these SCR's are fired, the associated filter capacitors are discharged.

3-152. Internal Voltage Reference. The internal voltage reference circuit consists of CR28 and associated components. Transistors A3Q13 and A3Q14 provide a temperature-compensated reference voltage for all functions of protection and control card A3.

3-153. Diode CR28 is a low-temperature coefficient zener diode biased for maximum temperature stability. Resistors R67, R66 (REF ADJ) and R68 form an adjustable voltage divider centered at  $+4.5 \pm 0.5$  volts. Transistors A3Q13 and A3Q14 form a temperature-balanced buffer stage. Capacitor C18 is connected in the emitter circuit of A3Q14 to filter high frequency noise voltages radiated by adjacent circuits and prevent oscillation at the emitter of transistor Q13.

3-154. Power Up Output Circuit. The power up output circuit is a one-half second monostable multivibrator comprised of transistors A3Q3, A3Q4, A3Q5, and A3Q6. When the IPU signal goes low, as described in paragraph 3-146 due to the action of transistor A3Q4 (or the same A3Q4 in another 2100 Computer or 2155A Extender interconnected by IPU) the PWU signal goes low immediately and remains low for one-half second after IPU has returned high. The low PWU signal starts the power failure routine to provide an orderly shutdown and save the contents of the computer registers and memory.

3-155. The PWU signal goes low whenever the IPU signal goes low. This happens whenever A3Q4 is turned on by either the undervoltage comparator (through resistor R21), or by the overvoltage comparator (through diode CR10) or by a thermal switch (through resistor R44 and diode CR20).

#### 4-1. INTRODUCTION.

4-2. Troubleshooting is based on checkout procedures presented in the form of a series of flowcharts. A basic checkout troubleshooting flowchart directs initial tests and makes reference to adjustment procedures in the text and to subordinate troubleshooting flowcharts, each related to a circuit area. There is a set of flowcharts for power supplies with date codes prior to 1240 and a set for power supplies with date codes of 1240 and higher. All flowcharts and adjustment procedures are in section V.

#### 4-3. TEST DATA.

4-4. Performing the basic checkout test procedure is the first step of power supply testing. Overall performance of the power supply is tested with the power supply installed in the computer (or extender). If proper indications are not obtained, references are made to more detailed tests and adjustments to isolate the trouble. If proper indications are obtained, the power supply is assumed to be ready for operation.

#### 4-5. TROUBLESHOOTING DATA.

4-6. The troubleshooting data in this section is used for checking the power supply circuits to isolate trouble symptoms, which are detected during power supply testing, to a replaceable assembly or part. Troubleshooting data included in this section consists of test procedures and troubleshooting diagrams. Information in other sections of this manual which will be required during troubleshooting includes the circuit descriptions and related diagrams presented in section VII and the replaceable parts information presented in section VI. Total familiarity with the content, purpose and use of the information presented in these sections is recommended before attempting to troubleshoot or repair the power supply.

#### 4-7. INFORMATION IN OTHER MANUALS.

4-8. Information in other manuals which may be required during troubleshooting includes that presented in the following:

- a. *Computer Installation and Maintenance Manual* (part no. 02100-90002 for 2100A or part no. 02100-90162 for 2100S).
- b. 2155A I/O Extender Manual (part no. 02155-90002).
- c. The applicable diagnostic test procedures contained in the *Manual of Diagnostics*.

#### 4-9. BASIC CHECKOUT.

##### 4-10. GENERAL.

4-11. The basic checkout test procedure is performed on a power supply installed in a computer (or extender). This test procedure should be conducted immediately after a power supply is installed, and as required thereafter as part of a regularly scheduled maintenance program, as the first step of troubleshooting, and after repairs or modifications are made to the power supply. The basic checkout should always be performed prior to attempting to perform the detailed checkout. Successful completion of all steps in the basic checkout procedure ensures that the power supply is operational.

##### 4-12. REQUIRED TEST EQUIPMENT.

4-13. The test equipment required for basic checkout procedure is listed as part of the tests in Section V that are conducted during basic checkout.

##### 4-14. TEST PROCEDURE.

4-15. The basic checkout procedure consists of a series of tests that check the operation of key circuit functions in the power supply. The purpose of these tests is to provide an expedient means of detecting obvious trouble symptoms. The results of each test, when compared to expected normal results, provides an indication as to whether or not the circuit under test is functioning normally. Instructions are included for analyzing trouble symptoms, and references are provided to troubleshooting data for the circuits most likely to be causing the trouble indication. Troubles encountered during the performance of the basic checkout must be corrected before detailed testing is attempted.

4-16. Instructions for performing the basic checkout procedure are contained in the following steps:

- a. At the front panel of the computer (or extender), turn the POWER switch to OFF.
- b. Remove the top and bottom panels of the computer (or extender) and the top and bottom covers of the power supply.

#### WARNING

*Dangerous ac line voltage is present in the computer (or extender) even though the POWER switch has been turned off at the computer (or extender) front panel. Pro-*

*protective panels and covers installed on the power supply and on the bottom of the card cage are designed to prevent personal contact with components that are wired directly to the hot side of the ac line. Use caution when servicing in these areas even though the protective panels and covers are in place. If it is necessary to remove a protective panel or cover during servicing, first turn off the computer (or extender) and disconnect the computer (or extender) ac power cable from the ac power source. If it is necessary to apply power to the computer (or extender) while a protective panel or cover is removed, use extreme caution to avoid contact with the exposed area. Refer to paragraph 5-7 for additional safety information before proceeding.*

- c. Inspect the electrical assemblies and parts comprising the power supply for visible indications of trouble, such as burned wiring, broken wiring connections, loose or improper cable connections, or plug-in cards installed in wrong slots or improperly seated in mating connectors. Also inspect for excess dirt accumulations or foreign matter that could restrict air flow and cause overheating. Take immediate action to correct any condition that may be the cause of trouble. Note those conditions that do not require immediate corrective action, but which should be serviced when regularly scheduled preventive maintenance is performed.
- d. At the front panel of the computer, check that the LOADER ENABLE switch-indicator is off. Check all maintenance switches for proper operating positions. Refer to section I of the computer *Installation and Maintenance Manual* (part no. 02100-90002, for 2100A or part no. 02100-90162 for 2100S).
- e. Turn the computer (or extender) POWER switch to ON. Check that fans at the rear of the power supply are operating. Check each fan for abnormal airflow and audible indications of defective motor bearings, fan blade obstructions, or other indications of abnormal operation.

#### CAUTION

Do not continue with this procedure unless all fans are operating normally. Loss of air flow from an inoperative or improperly operating fan may cause overheating which could result in serious damage to computer (or extender) components. Turn off power and do not attempt further operation until the trouble has been corrected.

- f. Perform the procedures described in the basic checkout flowchart, figure 5-6 for power supplies with date codes prior to 1240 or figure 5-14 for power supplies with date codes 1240 or higher.

#### 4-17. DETAILED CHECKOUT.

4-18. Detailed checkout is performed on a power supply that is removed from a computer (or extender) for servicing on a test bench. The detailed checkout is required when indicated during basic checkout or after repairs or modifications have been made to a power supply. Successful completion of all steps in the detailed checkout procedure ensures that all circuits in the power supply are operational.

#### 4-19. REQUIRED TEST EQUIPMENT.

4-20. The test equipment required for detailed checkout procedure is listed as part of the tests in Section V that are conducted during detailed checkout.

#### 4-21. TEST PROCEDURE.

4-22. The detailed checkout procedure consists of a series of bench tests and adjustments that check the operation of detailed circuitry in the power supply. Detailed checkout is conducted by performing that part of the basic checkout flowchart instructions which require bench tests and adjustments. The results of each test, when compared to expected normal results, provide an indication as to whether or not the circuit under test is functioning normally. If the circuit is not functioning normally, the flowchart instructions are followed to a separate troubleshooting flowchart for analyzing trouble symptoms, and references are provided to troubleshooting data for the circuits most likely to be causing the trouble indication.

4-23. Instructions for performing the detailed checkout procedure are contained in the following steps:

- a. Refer to point B in the basic checkout flowchart diagram, figure 5-6 or 5-14.
- b. Perform the bench tests and adjustments described in the flowchart (figure 5-6 or 5-14).
- c. If incorrect indications are obtained during any of the tests, refer to the appropriate troubleshooting flowchart as referenced in figure 5-6 or 5-14.
- d. After isolation and correction of a trouble, repeat the test that was being performed when the trouble was detected and continue the checkout.

**5-1. INTRODUCTION.**

5-2. This section describes preventive maintenance, adjustments, tests, and part-replacement procedures for the power supply. These procedures are supported by figures 5-1 through 5-5. Figures 5-6 through 5-21 provide troubleshooting information to support both section IV and section V. Figures 5-6 through 5-13 are for power supplies having date codes prior to 1240. Figures 5-14 through 5-21 are for power supplies having date codes of 1240 or higher.

5-3. Preventive maintenance is performed at scheduled intervals, and its purpose is to prevent or minimize equipment deterioration. Included in the preventive maintenance procedures are voltage tests which check power supply operation.

5-4. Adjustments and test procedures are performed when required and their purpose is to aid in trouble isolation and to ensure normal operation after a trouble has been isolated and corrected.

5-5. Adjustments are included for a power supply installed in a computer (or extender) and tests and adjustments are included for a power supply being serviced on a bench.

5-6. To determine the appearance and location of components and assemblies for the performance of maintenance, refer to the parts location diagrams presented in Section VII.

**5-7. SAFETY PRECAUTIONS.****WARNING**

*When the input power is connected, use caution when working inside the power supply. Many exposed conductors carry low dc voltages which are capable of supplying heavy currents if short-circuited, resulting in high heat and the possibility of painful burns. Use caution when manipulating metal tools or probes. A wrist watch, or a metal necklace, bracelet, or ring must not be worn. Avoid dropping tools, screws, or other metal objects onto conductors. Remove power and recover dropped objects at once; if forgotten, damage could result later. AC power-line voltage and 160 volts dc are exposed when certain covers are removed; these covers are described in the following paragraph. Exercise extreme caution when working in the power supply with these covers removed, and never work under*

*this condition unless another person is nearby and within sight. If feasible, unplug the ac power cable before performing any work inside the power supply and wait 3 minutes for filter capacitors to discharge after removing power. To prevent explosion resulting from internal heating, always be sure that a replacement filter capacitor is properly connected with respect to polarity. Danger of death or serious injury exists if the precautions above are not observed.*

**5-8. HIGH VOLTAGE POINTS.**

5-9. The highest ac voltage in the power supply is the ac line voltage. The highest dc voltage in the power supply is 160 volts. The ac line voltage is exposed at the input circuits of the power supply (terminal board TB3, transformer T5, and preregulator assembly A6). The 160 volts dc is exposed at several points within the power supply when the top or bottom power supply covers are removed.

**5-10. TEST EQUIPMENT GROUND.**

5-11. If the test equipment has a metal case, the negative test lead preferably should not be internally connected to the case. Instead, the case should be connected to a good earth ground through the test equipment power cord. This precaution prevents the danger of shock or possibility of a short when the negative lead is connected to a point not at ground potential.

**5-12. PREVENTIVE MAINTENANCE.****5-13. GENERAL.**

5-14. The following preventive maintenance procedures are performed at monthly or semimonthly intervals, the frequency depending upon the physical conditions prevailing at the particular site. Performance once per month is adequate for most sites. The monthly performance is applicable to power supplies which operate 24 hours per day, seven days per week. The interval may be reduced in accordance with the amount of time the power supply is turned off. The power supply is not removed from the computer (or extender) to perform preventive maintenance.

**5-15. EQUIPMENT REQUIRED.**

5-16. The following items are required to perform preventive maintenance:

- a. Source of compressed air for cleaning the filter, or a cleaned filter.
- b. A vacuum cleaner for removing dust from the power supply.
- c. One digital voltmeter of the type listed in table 1-2.
- d. One general purpose Centigrade thermometer, accurate to at least  $\pm 1$  degree, for measuring ambient temperature.
- e. One oscilloscope of the type listed in table 1-2.

**5-17. PROCEDURE.**

5-18. Before starting preventive maintenance, set up the thermometer for measuring ambient temperature. The thermometer must be near the computer (or extender), but away from cold drafts and heat radiating objects. Do not place the thermometer on or in the computer (or extender). Plug in the digital voltmeter and turn it on. Then proceed as described in the following paragraphs.

**Note:** If the power supply is in an extender, also connect the extender to a 2100 Computer as described in the extender manual.

5-19. **AIR FILTER.** Clean the air filter at the rear of the power supply using the following procedure:

- a. Remove the air filter from the power supply by pulling firmly on the filter frame. (The filter is held in place by metal banana plugs attached to each corner of the filter frame.)
- b. Remove the filter from the computer room and blow the dirt from the filter. Blow in the opposite direction from that in which air normally moves through the filter. Then reinstall the filter. If compressed air is not available at the computer site, install a spare filter which has been cleaned.

5-20. **CABLES.** With the computer (or extender) POWER switch off and the ac power cable disconnected, remove the top and bottom panels of the computer (or extender) and the top and bottom covers of the power supply and check the cables and connectors for cracks, burns, or wear. Also inspect the ac power cable, paying particular attention to the portions of the cable near the connector and the cable clamp. Repair if necessary.

5-21. **DUST.** If required, remove dust and other light debris from the power supply, using the vacuum cleaner. Loosen encrusted dust with a soft-bristled brush, and pay particular attention to heat dissipating areas.

5-22. **CIRCUIT CARDS.** With the bottom and top panels of the computer (or extender), and the bottom cover of the power supply removed, check all circuit cards for proper seating. Adjust where necessary.

5-23. **FANS.** Turn on the computer POWER switch and check for proper operation of the cooling fans. Ensure that no object interferes with the rotation of the fan blades.

5-24. **VOLTAGE CHECKS.** Before making voltage checks, the voltmeter must be allowed time to warm up as prescribed by the manufacturer of the instrument. Also, the computer must run, with any type of program, for at least 15 minutes before making the voltage measurements. If any voltage is not within specified limits, make the necessary adjustments as described in paragraph 5-27. Make the voltage checks as described below:

- a. Stop the computer program.
- b. Measure the seven dc voltages listed in table 5-1. These voltages are available at test jacks mounted on the rear panel of the computer.
- c. Set the oscilloscope for reading ac voltage, and check each of the seven voltages listed in table 5-1 for ripple and noise. For each voltage, the indicated ripple and noise should be less than that listed in table 5-1.

**5-25. PREVENTIVE MAINTENANCE SUMMARY.**

5-26. Preventive maintenance for the power supply consists of the following:


- a. Clean the air filters.
- b. Check cables for wear.
- c. Remove dust.
- d. Check circuit cards for proper seating.
- e. Check operation of the cooling fans.
- f. Check the dc operating voltages at the rear of the computer (or extender).

**5-27. ADJUSTMENTS TO INSTALLED POWER SUPPLY.**

5-28. There are four adjustments that can be made to the power supply when it is installed in the computer (or extender). Paragraphs 5-29 through 5-44 give the procedures for each adjustment in the power supply that can be performed in the field. Figure 5-1 shows the locations of these adjustments. Note that the power supply assumes the reference designation A25 when it is installed in a computer (or extender).

Table 5-1. DC Supply Voltages

| TEST JACK | READING         |       | RIPPLE AND NOISE VOLT. TOL. P-P |
|-----------|-----------------|-------|---------------------------------|
|           | MIN.            | MAX.  |                                 |
| +30       | +29.0           | +30.5 | < 20%                           |
| +20       | (See Table 5-2) |       | $\pm 0.5\%$                     |
| +12       | +12.0           | +12.5 | < 2%                            |
| +4.85     | +4.80           | +4.90 |                                 |
| -2        | -1.85           | -2.0  |                                 |
| -12       | -12.0           | -12.7 | $\pm 0.5\%$                     |
| -20       | (See Table 5-2) |       |                                 |



NOTES: FOR COMPLETE REFERENCE DESIGNATIONS WHEN POWER SUPPLY IS INSTALLED IN A COMPUTER OR EXTENDER, PREFIX ALL REFERENCE DESIGNATIONS WITH A25.

- APPLIES TO A3, PART NO. 02100-60047.
- ♣ APPLIES TO A3, PART NO. 02100-60109.
- ★ APPLIES TO A1, PART NO. 02100-60046 ONLY.
- ♣ APPLIES TO A1, PART NO. 02100-60046.
- ▲ APPLIES TO A1, PART NO. 02100-60108.

REF 2133/53-25

Figure 5-1. Power Supply Adjustments



## 5-29. PREREGULATOR ADJUSTMENT.

5-30. The +30, +12, +4.85, -2, and -12 volt supply outputs are controlled by preregulator adjustment resistor A25A1R36 on the preregulator control card (see figure 5-1).

Note: The preregulator is adjusted to bring the +4.85 volt supply within the tolerance listed in table 5-1. With the +4.85 volt supply operating within that tolerance, all other supplies should also be operating within their specified tolerances. If any one of the other supplies does not operate within its specified tolerance, the power supply is malfunctioning.

5-31. EQUIPMENT. Adjustment of the preregulator requires one digital voltmeter, of the type listed in table 1-2.

5-32. PROCEDURE. The procedure consists of adjusting the preregulator until the +30, +12, +4.85, -2, and -12 volt supply outputs remain within tolerance under load and no-load conditions. The procedure is as follows:

- a. Ensure that the POWER switch is set to OFF. Then remove the computer (or extender) top and bottom panels, card cage card retainer, and power supply bottom cover.
- b. Turn the POWER switch to ON.
- c. Connect the voltmeter to the +4.85V test jack on the rear panel. While observing the voltmeter, adjust the preregulator voltage adjustment resistor A25A1R36 until the +4.85 volt supply is within the limits specified in table 5-1.
- d. Connect the voltmeter, in turn, to the +30V, +12V, -2V, and -12V test jacks on the rear panel while observing the voltmeter and verify that each supply voltage is within the limits specified in table 5-1. If any voltage is not within the specified limits, the power supply is malfunctioning. If this is the case, refer to paragraph 4-9 for troubleshooting the power supply.

## 5-33. MEMORY SUPPLY (+20 VOLTS AND -20 VOLTS) ADJUSTMENT.

5-34. The +20 volt and -20 volt supply outputs are controlled by the 20-volt adjustment resistor A25A2R35 on the inverter driver card (see figure 5-1). The outputs of the +20 and -20 volt regulators are set in accordance with the ambient temperature at the time of adjustment. Table 5-2 lists the voltages required for various temperatures. If resistor A25A2R35 cannot be adjusted to give the proper voltmeter readings, refer to paragraph 4-9 for troubleshooting the power supply.

5-35. EQUIPMENT. Adjustment of the +20 and -20 volt regulators requires the following equipment:

- a. One digital voltmeter of the type listed in table 1-2.
- b. One centigrade thermometer (for measuring room temperature) accurate to at least  $\pm 1$  degree.

5-36. PROCEDURE. The procedure for adjusting the +20 volt and -20 volt supply outputs is as follows:

- a. Ensure that the POWER switch is set to OFF. Then remove the computer (or extender) bottom panel and the power supply bottom cover.
- b. Set up the thermometer for measuring ambient temperature. The thermometer must be near the computer (or extender) but away from cold drafts and heat radiating objects. Do not place the thermometer on or in the computer (or extender).
- c. Turn the POWER switch to ON and allow the temperature reading to stabilize. Connect the voltmeter to the +20V test jack on the rear panel. Observe the voltmeter, and adjust resistor A25A2R35 until the voltmeter reading is in the range specified in table 5-2 for the ambient temperature.
- d. Connect the voltmeter to the -20V test jack on the rear panel. The voltmeter reading should be within one percent of the final reading obtained in step "c."
- e. Turn the POWER switch to OFF, and replace the power supply bottom cover and computer (or extender) bottom panel.

## 5-37. OVERVOLTAGE REFERENCE ADJUSTMENT.

5-38. The computer (or extender) circuits are protected from an overvoltage by the crowbar circuits in the power supply. The reference voltage which controls the operation of the crowbar circuits is adjusted by the overvoltage reference adjustment resistor A25A3R4 (A3, part no. 02100-60047) or A25A3R66 (A3, part no. 02100-60109) on the protection and control card (see figure 5-1). The overvoltage adjustment should be performed when directed in the troubleshooting section of this manual. If resistor A25A3R4 (A3, part no. 02100-60047) or A25A3R66 (A3, part no. 02100-60109) cannot be adjusted to give the proper voltmeter reading, refer to paragraph 4-9 for troubleshooting the power supply.

5-39. EQUIPMENT. Adjustment of the overvoltage reference requires one digital voltmeter of the type listed in table 1-2.

5-40. PROCEDURE. The procedure for performing the overvoltage adjustment is as follows:

- a. Ensure that the POWER switch is set to OFF, then connect the voltmeter between terminals A25A3E3 (ground) and A25A3E1 (see figure 5-1).

Table 5-2. Output of +20 Volt and -20 Volt Regulators

| TEMPERATURE<br>(°C) | DC VOLTAGE RANGE |        |         | TEMPERATURE<br>(°C) | DC VOLTAGE RANGE |        |         |
|---------------------|------------------|--------|---------|---------------------|------------------|--------|---------|
|                     | MINIMUM          | CENTER | MAXIMUM |                     | MINIMUM          | CENTER | MAXIMUM |
| 0                   | 21.10            | 21.30  | 21.50   | 28                  | 19.64            | 19.84  | 20.04   |
| 1                   | 21.05            | 21.25  | 21.45   | 29                  | 19.59            | 19.79  | 19.99   |
| 2                   | 21.00            | 21.20  | 21.40   | 30                  | 19.54            | 19.74  | 19.94   |
| 3                   | 20.94            | 21.14  | 21.34   | 31                  | 19.49            | 19.69  | 19.89   |
| 4                   | 20.89            | 21.09  | 21.29   | 32                  | 19.44            | 19.64  | 19.84   |
| 5                   | 20.84            | 21.04  | 21.24   | 33                  | 19.38            | 19.58  | 19.78   |
| 6                   | 20.80            | 21.00  | 21.20   | 34                  | 19.33            | 19.53  | 19.73   |
| 7                   | 20.74            | 20.94  | 21.14   | 35                  | 19.28            | 19.48  | 19.68   |
| 8                   | 20.68            | 20.88  | 21.08   | 36                  | 19.23            | 19.43  | 19.63   |
| 9                   | 20.63            | 20.83  | 21.03   | 37                  | 19.18            | 19.38  | 19.58   |
| 10                  | 20.58            | 20.78  | 20.98   | 38                  | 19.12            | 19.32  | 19.52   |
| 11                  | 20.53            | 20.73  | 20.93   | 39                  | 19.07            | 19.27  | 19.47   |
| 12                  | 20.48            | 20.68  | 20.88   | 40                  | 19.02            | 19.22  | 19.42   |
| 13                  | 20.42            | 20.62  | 20.82   | 41                  | 18.97            | 19.17  | 19.37   |
| 14                  | 20.37            | 20.57  | 20.77   | 42                  | 18.92            | 19.12  | 19.32   |
| 15                  | 20.32            | 20.52  | 20.72   | 43                  | 18.86            | 19.06  | 19.26   |
| 16                  | 20.27            | 20.47  | 20.67   | 44                  | 18.81            | 19.01  | 19.21   |
| 17                  | 20.22            | 20.42  | 20.62   | 45                  | 18.76            | 18.96  | 19.16   |
| 18                  | 20.16            | 20.36  | 20.56   | 46                  | 18.71            | 18.91  | 19.11   |
| 19                  | 20.11            | 20.31  | 20.51   | 47                  | 18.66            | 18.86  | 19.06   |
| 20                  | 20.06            | 20.26  | 20.46   | 48                  | 18.60            | 18.80  | 19.00   |
| 21                  | 20.01            | 20.21  | 20.41   | 49                  | 18.55            | 18.75  | 18.95   |
| 22                  | 19.96            | 20.16  | 20.36   | 50                  | 18.50            | 18.70  | 18.90   |
| 23                  | 19.90            | 20.10  | 20.30   | 51                  | 18.45            | 18.65  | 18.85   |
| 24                  | 19.85            | 20.05  | 20.25   | 52                  | 18.40            | 18.60  | 18.80   |
| 25                  | 19.80            | 20.00  | 20.20   | 53                  | 18.34            | 18.54  | 18.74   |
| 26                  | 19.75            | 19.95  | 20.15   | 54                  | 18.29            | 18.49  | 18.69   |
| 27                  | 19.70            | 19.90  | 20.10   | 55                  | 18.24            | 18.44  | 18.64   |

NOTE: Voltages listed are negative for the -20 volt regulator.

- b. Turn the POWER switch to ON.
- c. While observing the voltmeter, adjust resistor A25A3R4 (A3, part no. 02100-60047) or A25A3R66 (A3, part no. 02100-60109) until the voltmeter reads +4.60 ±0.02 volts dc. If the proper reading cannot be obtained, refer to paragraph 4-9 for troubleshooting the power supply.

#### 5-41. POWER FAIL ADJUSTMENT.

5-42. The following procedure describes how to adjust for the threshold voltage (power line voltage) at which the power fail interrupt occurs. This voltage is 100 to 102 volts rms for 115-volt operation and 200 to 204 volts rms for 230-volt operation. Since the power fail detection circuits are line-frequency sensitive, this adjustment should be performed if the computer (or extender) is changed from 60-Hz operation to 50-Hz operation, or from 50-Hz operation to 60-Hz operation. This line-frequency sensitivity characteristic does not apply to power supplies that contain an A3 protection and control card with a card revision code of 1215 or higher.

5-43. EQUIPMENT. The power fail adjustment requires the following equipment:

- a. One ac digital voltmeter with at least a 3-digit display, or an expanded-scale ac voltmeter. The meter

must be capable of reading ac voltage to within ±1 percent of the true value.

- b. One variable autotransformer capable of supply sufficient power for the computer (or extender). The computer requires up to 1400 volt-amperes, depending on the optional features used. (To reduce the power requirement to a minimum, all circuit cards for optional features can be disconnected before making the adjustment.) Be sure to turn off power before disconnecting or installing cards. The autotransformer must be capable of reducing the power-line voltage to 90 volts rms if the computer (or extender) is connected for 115-volt operation, or to 180 volts rms if connected for 230-volt operation.

5-44. PROCEDURE. To perform the power fail adjustment proceed as follows:

#### CAUTION

The power fail interrupt causes a program jump to core storage location 4. If there is no power fail interrupt program in the computer, location 4 should contain a halt instruction. Otherwise a jump may occur from location 4 to a program which will destroy wanted data or cause undesired operation of I/O devices or controlled equipment.

- a. Turn on the voltmeter, and allow the prescribed warm-up time before using the instrument.

Note: When performing the power fail adjustment on a power supply installed in an extender, be sure that the extension cables are connected to the associated computer and that the computer is connected to the normal ac input.

- b. Ensure that the computer (and/or extender) POWER switch is set to OFF.
- c. Remove the computer top panel and set the automatic restart switch S1 on I/O control card A7 to the ARS ("not" automatic restart) position.
- d. Remove the computer (or extender) bottom panel and the power supply bottom cover.
- e. Connect the autotransformer between the computer (or extender) and the power line.
- f. Connect the voltmeter for measuring the output voltage of the autotransformer.
- g. Set the autotransformer to furnish 115 volts rms to the computer (or extender), 230 volts if the computer (or extender) is connected for 230-volt operation.
- h. Turn the computer (and/or extender) POWER switch to ON. Allow sufficient warm-up time before making the adjustment. A program can be run during this time if desired.
- i. Slowly decrease the output of the autotransformer until the indicator lamps at the operator panel on the computer just go out. For A3 card, part number 02100-60047, the voltmeter should read  $95 \pm 1$  volts rms (or  $190 \pm 2$  volts rms for 230-volt operation). For A3 card, part number 02100-60109, the voltmeter should read  $100 \pm 0.5$  volts rms (or  $200 \pm 1$  volts rms for 230-volt operation).
- j. Slowly increase the output of the autotransformer until the indicator lamps at the operator panel on the computer just go on. For A3 cards, part number 02100-60047, the voltmeter should read  $100 \pm 1$  volts rms (or  $200 \pm 2$  volts rms for 230-volt operation). For A3 card, part number 02100-60109, the voltmeter should read  $101 \pm 0.5$  volts rms (or  $202 \pm 1$  volts rms for 230 volt operation).

Note: There is up to one-second delay from the time that the upper threshold voltage is detected until the indicator lamps go on.

- k. If the lower threshold point is not within tolerance, adjust the power fail adjustment resistor A25A3R64 (A3, part no. 02100-60047) or A25A3R2 (A3, part no. 02100-60109). (See figure 5-1.) Turn the adjustment

clockwise to increase the threshold point, or counterclockwise to decrease the threshold point. After adjusting the resistor, repeat steps "i" and "j" and readjust the resistor, as necessary. If the difference between the upper and lower threshold points exceeds 8 volts (A3, part no. 02100-60047) or 2 volts (A3, part no. 02100-60109), refer to paragraph 4-9 for troubleshooting the power supply.

Note: If the power fail circuit is suspected of causing problems, observe the PWU output (A25TB2-5) with an oscilloscope while performing step "k". Verify that the PWU signal switches from the high state to the low state without oscillation or pulsing of any kind.

- l. If the threshold points are within tolerance, replace the power supply bottom cover and the computer (or extender) bottom panel.


#### 5-45. BENCH TESTS AND ADJUSTMENTS.

5-46. Bench tests and adjustments are performed on the power supply when removed from the computer (or extender). These tests and adjustments are required after repairs have been made to a power supply. To perform these tests and adjustments, the equipment listed in paragraph 5-48 and the preliminary procedures described in paragraph 5-50 are required.

#### 5-47. EQUIPMENT.

5-48. The following equipment is required for test and adjustment of the power supply:

- a. Oscilloscope of the type listed in table 1-2.
- b. Variable autotransformer of the type listed in table 1-2.
- c. Multimeter of the type listed in table 1-2.
- d. Digital voltmeter of the type listed in table 1-2.
- e. Power supply, HP 6202B (or equivalent).
- f. Power supply card extender, part no. 02100-60049, (part of 12900A Maintenance Accessory Kit).
- g. Power line connection test cable (to be fabricated as shown in figure 5-2).
- h. Power supply load test fixture (to be fabricated as shown in figure 5-5).
- i. An 825-ohm resistor, HP part no. 0757-0421 (connected to terminal board TB2 in place of the temperature compensation circuit of the computer).



2133/53-15

Figure 5-2. Power Line Connection Test Cable (Fabricated)

5-49. PRELIMINARY PROCEDURES.

5-50. Prior to performing tests and adjustments of the power supply, perform the following preliminary procedures.

- a. Fabricate the power line connection test cable as shown in figure 5-2.
- b. Connect the 825-ohm resistor, listed in paragraph 5-48, between terminals 7 and 9 of terminal board TB2 (see figure 5-1 for terminal identification). This resistor will already be connected if the power supply has been removed from a 2155A Extender.
- c. Connect a jumper between terminals 8 and 9 of terminal board TB2. This jumper takes the place of the thermal switch circuit.
- d. Remove the top and bottom covers of the power supply.

5-51. CONTROL VOLTAGE AND TRANSFORMER TEST.

5-52. The control voltage and T5 transformer test is performed to determine that the internal voltage regulator outputs remain stable when the ac line input is varied between its high and low limits. Perform the preliminary procedures in paragraph 5-50 and proceed as follows:

- a. Install card extender, part no. 02100-60049, into connector XA1 (see figure 5-1) and insert preregulator control card A1 into the card extender.

**CAUTION**

In the following step, the autotransformer should be set to 0 volts output before connection to the ac power source. If the ammeter indicates more than one ampere anytime during this test, reduce the autotransformer output to 0 volts and refer to the troubleshooting procedures in figure 5-7 or 5-15.

- b. Connect a metered variable autotransformer between plug no. 1 of the power line connection test cable and the ac source (see figure 5-2). Do not connect power line connection test cable plug no. 2 to the ac source.
- c. Slowly adjust the autotransformer at a rate of about 10 volts per second for an output of 95 volts. Using a digital voltmeter and an oscilloscope, measure the +15, -15, and +5 volts at the card pins (see figure 7-3, sheet 1) for the voltages listed in table 5-3. If the voltages are incorrect, refer to the troubleshooting procedures in figure 5-7 or 5-15.

Table 5-3. Control Voltages

| VDC | CARD PIN (XA1) | READING |       | RIPPLE VOLTAGE AND NOISE TOLERANCE (PEAK-TO-PEAK) |
|-----|----------------|---------|-------|---|
|     |                | MIN.    | MAX.  |   |
| +15 | 4,C            | +13.7   | +15.3 | 0.1V  |
| -15 | 9,K            | -13.7   | -15.3 | 0.1V  |
| +5  | 18,V           | + 4.7   | + 5.3 | 0.1V  |

- d. Increase the autotransformer output to 130 volts and repeat the measurements made in step "c". Each voltage should be within 0.1 volt of the value indicated in step "c". If any of the voltages are not within this value, refer to the troubleshooting procedures in figure 5-7 or 5-15.
- e. Reduce the autotransformer output to 115 volts and using the HP 427A meter, measure at the card pins (see figure 7-3, sheet 1) for the voltages listed in table 5-4. If the voltages are incorrect, refer to the troubleshooting procedures in figure 5-7 or 5-15.

5-53. INVERTER DRIVER TEST.

5-54. The inverter driver test is performed by observing the inverter driver output waveforms on an oscilloscope to ensure that the circuit is operating properly. Perform the preliminary procedures in paragraph 5-50, and proceed as follows:

**CAUTION**

In the following step, the autotransformer should be set to 0 volts output before connection to the ac power source. If the ammeter indicates more than one ampere anytime during this test, reduce the autotransformer output to 0 volts and refer to the troubleshooting procedures in figure 5-8 or 5-16.

- a. Connect a metered variable autotransformer between plug no. 1 of the power line connection test cable and the ac source (see figure 5-2). Do not connect power line connection test cable plug no. 2 to the ac source.
- b. Install card extender, part no. 02100-60049, into connector XA2 (see figure 5-1) and insert inverter driver card A2 into the card extender.

Table 5-4. Control Transformer Voltages


| CARD PIN (XA1) | READING |        |
|----------------|---------|--------|
|                | MIN.    | MAX.   |
| 1,A,8,J        | 0V      | 0V     |
| 2,B            | 16V ac  | 20V ac |
| 3,C            | 16V ac  | 20V ac |
| 5,E            | 22V dc  | 26V dc |
| 6,F            | 8V dc   | 10V dc |
| 22,Z           | 0V      | 0V     |

- c. While observing the ammeter to ensure that the current does not exceed one ampere, slowly adjust the autotransformer for an output of 115 volts.
- d. Set the oscilloscope controls as follows:
  - (1) DISPLAY control to A.
  - (2) VOLTS/DIV control to 10 (set to 1 if 10:1 voltage divider probe is used).
  - (3) Input coupling switch to DC.
  - (4) TIME/DIV control to 0.5 MSEC.
  - (5) Sweep selector to MAIN.
  - (6) SWEEP MODE switch to AUTO.
  - (7) EXT INT LINE switch to INT.
  - (8) SLOPE switch to +.

**CAUTION**

In the following step, be extremely careful not to short any of the pins to adjacent pins (with the probe) to avoid damage to parts on the card.

- e. Connect the ground clip of the channel A probe to the inverter driver card ground test point and connect the probe to the pins shown in figure 5-3, in turn, while observing the waveforms shown.



2133/53-16

Figure 5-3. Inverter Driver Test Waveforms

5-55. PREREGULATOR AND INVERTER TEST.

5-56. The following test is performed to ensure that the preregulator and control circuit and the inverter circuit is operating properly. Perform the preliminary procedures in paragraph 5-50, and proceed as follows:

- a. Place the power supply on its side to allow access to the top and bottom for test connections. Connect the HP 427A meter (set to 300-volt dc scale) across the +160 volt terminals A5E53 and A5E48 (negative) shown in figure 7-2.

**CAUTION**

In the following step, the autotransformer should be set to 0 volts output before connection to the ac power source. If the ammeter indicates more than 3 amperes anytime during this test, reduce the autotransformer output to 0 volts and refer to the troubleshooting procedures in figure 5-9 or 5-17.

- b. Connect the power line connection test cable plug no. 1 from the power supply to the ac source as shown in figure 5-2. Connect a metered variable autotransformer between plug no. 2 of the test cable and the ac source.
- c. While observing the ammeter, to ensure the current does not exceed 3 amperes, slowly adjust the autotransformer (at a rate of about 10 volts per second) for an output of 40 volts.
- d. Measure the reduced output voltages at terminal boards TB1 and TB2 (figure 5-1) for the values listed in table 5-5. If the measured voltages are incorrect, refer to the troubleshooting procedures in figure 5-9 or 5-17.

**WARNING**

*After the input voltage is increased in the following step, the capacitors on the 160V output board retain their charge for over one minute after power is removed. Be careful not to touch terminals or parts on the power supply until power has been off for at least 3 minutes.*

Table 5-5. Output Voltages with Reduced Input


| TEST POINT | NORMAL VOLTAGE | MEASURED VOLTAGE |       |
|------------|----------------|------------------|-------|
|            |                | MIN.             | MAX.  |
| TB1-4,5    | +4.85V dc      | + 3.0            | + 4.0 |
| TB1-2,3    | -2V dc         | - 1.0            | - 1.6 |
| TB2-3      | +12V dc        | + 7.0            | + 9.0 |
| TB2-2      | -12V dc        | - 7.0            | - 9.0 |
| TB2-4      | +30V dc        | +18.0            | +22.0 |

- e. Increase the output of the autotransformer to 102 volts. Verify that the HP 427A meter connected in step "a" indicates  $155 \pm 5$  volts. If indication is incorrect, refer to the troubleshooting procedures in figure 5-9 or 5-17.
- f. Reduce the autotransformer output to 0 volts and allow 3 minutes for capacitors to discharge.
- g. Install card extender, part no. 02100-60049, into connector XA3 (see figure 5-1) and insert protection and control card A3 into the card extender.
- h. Disconnect the HP 427A meter and connect it to terminal board TB1 terminal 4 (4.85V dc) and terminal 6 (ground).
- i. Increase the autotransformer output to 102 volts. The meter should indicate  $4.95 \pm 0.10$  volts dc.
- j. If the voltage measured in step "i" does not equal  $4.95 \pm 0.10$  volts, adjust the preregulator control card A1 voltage adjustment resistor R36 for the proper indication.
- k. Measure the output voltages at terminal boards TB1 and TB2 (figure 5-1) and at the pins of protection and control card A3 (figure 7-3, sheet 3) for the values listed in table 5-6. If the voltages measured at the card pins or the terminal boards are incorrect (or in disagreement) refer to the troubleshooting procedures in figure 5-9 or 5-17.
- l. Reduce the autotransformer output to 0 volts to allow 3 minutes for capacitors to discharge.
- m. Remove the card extender into connector XA1 and insert preregulator control card A1 into the card extender.
- n. Install the card extender into connector XA1 and insert preregulator control card A1 into the card extender.
- o. Increase the output of the autotransformer to 115 volts.
- p. Set the oscilloscope controls as follows:
  - (1) DISPLAY control to A.
  - (2) VOLTS/DIV control to 1 (set to 0.1 if 10:1 voltage divider probe is used).
  - (3) Input coupling switch to DC.
  - (4) TIME/DIV control to 2 MSEC.
  - (5) SWEEP MODE switch to AUTO.
  - (6) Sweep selector switch to MAIN.
  - (7) EXT INT LINE switch to INT.
  - (8) SLOPE switch to +.

Table 5-6. Output Voltages

| OUTPUT TERM. | CARD A3 PIN NO. | READING |       |
|--------------|-----------------|---------|-------|
|              |                 | MIN.    | MAX.  |
| TB1-4,5      | X,Y,21          | + 4.85  | + 5.0 |
| TB1-2,3      | M               | - 1.7   | - 2.1 |
| TB2-3        | 3,C             | +11.6   | +12.5 |
| TB2-2        | 7,H             | -11.6   | -12.5 |
| TB1-1        | 19,W            | +19.9   | +20.1 |
| TB2-1        | R,14            | -19.9   | -20.1 |
| TB2-4        | None            | +28.0   | +32.0 |

- q. Connect the channel A probe to the junction of capacitor A1C3 and resistor A1R27 (see figure 7-3, sheet 1). The waveform displayed on the oscilloscope should be an integrated waveform as shown in figure 5-4.
- r. If the integrated waveform voltage amplitude is incorrect, adjust stability adjustment resistor A1R11 (figure 5-1) for a stable  $-1.5 \pm 0.1$  volt amplitude of the semisinusoidal portion of the waveform.
- 5-57. PWU AND IPU SIGNAL TESTS AND ADJUSTMENTS (FOR A3 CARD, PART NO. 02100-60047).
- 5-58. Tests and adjustments of the Power Up (PWU) and Internal Power Up (IPU) circuits are performed to determine that these circuits are operating properly. Perform the preliminary procedures in paragraph 5-50, and proceed as follows:
- Connect the power line connection test cable plug no. 2 from the power supply to the ac source as shown in figure 5-2. Connect a metered autotransformer between plug no. 1 of the test cable and the ac source.
  - Adjust the autotransformer for an output of 115 volts.
- Note: If adjustments performed in the following steps do not result in correct indications, refer to the troubleshooting procedures in figure 5-10.
- Using an HP 427A meter, measure the voltage at terminal A3E2 (see figure 5-1). Adjust variable resistor A3R64, if necessary, for an indication of  $4.5 \pm 0.05$  volts dc. Connect an oscilloscope to this terminal and check to ensure that voltage spikes or ripple is less than  $\pm 0.05$  volts.
- d. Connect the HP 427A meter (set to the 10-volt dc range) to terminal 6 of A25TB2 (see figure 5-1) to monitor the IPU signal. The HP 427A meter should indicate  $4 \pm 1$  volts.
- e. Disconnect the HP 427A meter from terminal 6 and connect the meter to terminal 5 of A25TB2 (see figure 5-1) to monitor the PWU signal. The HP 427A meter should indicate  $4 \pm 1$  volts.
- f. Connect the oscilloscope to terminal 5 of A25TB2.
- g. Slowly reduce the output of the autotransformer to 97 volts while monitoring the HP 427A meter. The meter indication should drop to less than 0.5 volts at an autotransformer output of  $97.5 \pm 0.5$  volts. The oscilloscope display should step from  $4 \pm 1$  volts to less than 0.5 volt without oscillation or intermittent pulsing.
- h. If the indication in step "g" is incorrect, adjust variable resistor A3R64 (see figure 5-1) slightly and repeat steps "g" and "h" for the proper indication.
- i. Monitor the HP 427A meter while increasing the autotransformer output from 97 volts to 102 volts. Within 0.5 second after reaching the 102-volt level, the meter should increase sharply from 0 to  $4 \pm 1$  volts. The oscilloscope display should step from less than 0.5 volt to  $4 \pm 1$  volts without oscillation or intermittent pulsing.
- 5-59. PWU AND IPU SIGNAL TESTS AND ADJUSTMENTS (FOR A3 CARD, PART NO. 02100-60109).
- 5-60. Tests and adjustments of the Power Up (PWU) and Internal Power Up (IPU) circuits are performed to determine that these circuits are operating properly. Perform the preliminary procedures in paragraph 5-50, and proceed as follows:
- Connect the power line connection test cable plug no. 2 from the power supply to the ac source as shown in figure 5-2. Connect a metered autotransformer between plug no. 1 of the test cable and the ac source.
  - Adjust the autotransformer for an output of 100 volts.
- Note: If adjustments performed in the following steps do not result in correct indications, refer to the troubleshooting procedures in figure 5-18.
- Using an HP 427A meter, measure the voltage at output terminal TB1-4 or TB1-5 (+4.85 volt supply). Adjust variable resistor A3R2 in a clockwise direction until a reading of approximately 0 volts is obtained (indicating that the +4.85 volt supply has been shut down because of an under voltage condition). Then, slowly adjust variable resistor A3R2 in a counterclockwise direction just until the +4.85 volt supply is again operating.



2133/53-17

Figure 5-4. Integrated Waveform

- d. Connect the HP 427A meter (set to the 10-volt dc range) to terminal 6 of A25TB2 (see figure 5-1) to monitor the IPU signal. The HP 427A meter should indicate  $5.4 \pm 0.5$  volts.
- e. Disconnect the HP 427A meter from terminal 6 and connect the meter to terminal 5 of A25TB2 (see figure 5-1) to monitor the PWU signal. The HP 427A meter should indicate  $3.4 \pm 0.5$  volts.
- f. Connect the oscilloscope to terminal 5 of A25TB2.
- g. Slowly reduce the output of the autotransformer to 100 volts while monitoring the HP 427A meter. The meter indication should drop to less than 0.5 volt at an autotransformer output of  $101 \pm 0.5$  volts. the oscilloscope display should step from  $5.4 \pm 0.5$  volts to less than 0.5 volt without oscillation or intermittent pulsing.
- h. If the indication in step "g" is incorrect, adjust variable resistor A3R2 (see figure 5-1) slightly and repeat steps "g" and "h" for the proper indication.
- i. Monitor the HP 427A meter while increasing the autotransformer output from 100 volts to 101 volts. Within 0.5 second after reaching the 101-volt level, the meter should increase sharply from 0 to  $5.4 \pm 0.5$  volts. The oscilloscope display should step from less than 0.5 volt to  $5.4 \pm 0.5$  volts without oscillation or intermittent pulsing.

5-61. OVERVOLTAGE AND OVERTEMPERATURE DETECTION TEST.

5-62. The overvoltage and overtemperature detection test is conducted to determine if the detection circuits in the power supply are operating properly. Perform the preliminary procedure in paragraph 5-50 and proceed as follows:

- a. Install card extender, part no. 02100-60049, into connector XA3 (see figure 5-1) and insert protection and control card A3 into the card extender.
- b. Connect the power line connection test cable plug no. 1 from the power supply to the ac source as shown in figure 5-2. Connect a metered autotransformer between plug no. 2 of the test cable and the ac source.
- c. Adjust the autotransformer for an output of 115 volts.
- d. Using an HP 427A meter, measure the voltage at terminal A3E1. Adjust variable resistor A3R4, if necessary, for an indication of  $4.50 \pm 0.05$  volts dc.
- e. Using an oscilloscope, monitor the voltage at each output terminal to verify that any voltage spikes do not exceed the overvoltage values shown in table 5-7.
- f. Adjust the autotransformer for an output of 0 volts.

Table 5-7. Voltage Ranges for Overvoltage (Crowbar Trigger) Condition

| OUTPUT VOLTAGE | OUTPUT TERM. | OVERVOLTAGE (VDC) RANGE |
|----------------|--------------|-------------------------|
| - 2            | TB1-2,3      | - 2.8 to - 3.1          |
| + 4.85         | TB1-4,5      | + 5.3 to + 5.75         |
| -12            | TB2-2        | -14.0 to -15.5          |
| +12            | TB2-3        | +14.0 to +15.5          |
| -20            | TB2-1        | -23.5 to -27.0          |
| +20            | TB1-1        | +23.5 to +25.5          |

Note: If correct indications cannot be obtained in the following steps, refer to the troubleshooting procedures in figure 5-11 or 5-19.

- g. Connect a multimeter to the collector of transistor A3Q2 (see figure 7-3, sheet 3 for location of A3Q2) and verify an indication of - 15 volts dc.
- h. Using an external power supply (HP 6202B, or equivalent) apply an overvoltage (as listed in table 5-7) to each output terminal while monitoring the meter that was connected in step "g". To apply the overvoltage, start at 0 volts and increase the voltage slowly until the meter indicates that the collector of A3Q2 steps and latches to +15 volts dc. After each trial, return the voltage to 0 volts to reset the latch circuit.
- i. If the meter indicates that the collector voltage of A3Q2 steps from - 15 to +15 volts dc (and latches) at a lower or higher voltage than that listed in table 5-7, refer to troubleshooting flowchart, figure 5-11 or 5-19.
- j. To simulate an overtemperature condition, disconnect the jumper that was connected between terminals 8 and 9 of terminal board TB2 in step "c" of paragraph 5-50. Using an HP 427A meter, monitor the voltage at pins 10,L of card A3 while removing the jumper. The voltage should rise from 0 to 5.3 volts dc when the jumper is removed. The collector of transistor A3Q2 should step from - 15 to +15 volts before pins 10,L reach maximum voltage. Reconnect the jumper.

5-63. OVERCURRENT TEST.

5-64. The overcurrent test is performed to determine that the current limit sense amplifiers and associated circuits are operating properly under varying load conditions. Perform the preliminary procedures in paragraph 5-50 and proceed as follows:

**CAUTION**

In the following step, the autotransformer should be set to 0 volts output before connection to the ac power source. If the ammeter indicates more



than 13 amperes anytime during this test, reduce the autotransformer output to 0 volts and refer to the troubleshooting procedures in figure 5-12 or 5-20.


- a. Connect the power line connection test cable plug no. 1 from the power supply to the ac source as shown in figure 5-2. Connect a metered variable autotransformer between plug no. 2 of the test cable and the ac source. Adjust the autotransformer output to 115 volts.
- b. Verify that the output voltages are as listed in table 5-6.
- c. Connect the power supply load test fixture as shown in figure 5-5, with all switches set to MINIMUM.

**Note:** In the following step, the power supply may crowbar and turn off when the switch position is changed. If this occurs, set the switch to the position to be tested and reset the crowbar latch circuit by temporarily disconnecting power line connection test cable plug no. 1 from the ac source, then reconnect it.

- d. Using an HP 427A meter to measure dc voltage and an HP 180A oscilloscope to measure ac ripple voltage, measure at current limit card A4 test points (see figure 5-1) in the sequence shown in table 5-8 for the switch positions listed. After measuring for the OVERLOAD switch position at each test point, monitor the meter closely while switching back to the MINIMUM switch position. The voltage should return to the MINIMUM load value within 10 seconds.

Table 5-8. Current Limit Card Test Point Voltages

| TEST POINT    | SWITCH POSITION | MINIMUM READING (VDC) | MAXIMUM READING (VDC) | MAXIMUM RIPPLE VOLTAGE (P-P) |
|---------------|-----------------|-----------------------|-----------------------|------------------------------|
| A4E4 (-2V)    | MINIMUM         | - 0.5                 | - 2                   | 0.3                          |
|               | MAXIMUM         | - 5                   | - 8                   | 0.4                          |
|               | OVERLOAD        | - 8                   | -12                   |                              |
| A4E5 (-12V)   | MINIMUM         | + 2                   | + 3.5                 | 0.1                          |
|               | MAXIMUM         | - 5                   | - 7                   |                              |
|               | OVERLOAD        | -10                   | -13                   |                              |
| A4E2 (+12V)   | MINIMUM         | - 0.2                 | - 2                   | 0.1                          |
|               | MAXIMUM         | + 6                   | + 9                   | 3                            |
|               | OVERLOAD        | +10                   | +13                   |                              |
| A4E3 (+4.85V) | MINIMUM         | 0                     | + 2                   | 0.5                          |
|               | MAXIMUM         | + 6                   | + 9                   | 1                            |
|               | OVERLOAD        | + 9                   | +12                   |                              |
| A4E1 (+20V)   | MINIMUM         | - 0.5                 | - 1.5                 | 0.05                         |
|               | MAXIMUM         | + 5                   | + 7                   | 0.2                          |
|               | OVERLOAD        | +12                   | +18                   |                              |



PARTS LIST

| REFERENCE DESIGNATION    | MFR CODE | MFR PART NO. |
|--------------------------|----------|--------------|
| F1,F2,F3                 | 75915    | 314010       |
| F4                       | 75915    | 312001       |
| R3,R4                    | 44655    | 0560D        |
| R6                       | 44655    | 0366         |
| S1 THRU S6               | 71590    | JV9003       |
| FUSEHOLDER, XF1 THRU XF4 | 75915    | 342014       |

NOTE:

RESISTORS R1, R2 AND R5 MAY BE FABRICATED USING THE FOLLOWING ADJUSTABLE TAP RESISTORS:

| RESISTOR VALUE | MFR CODE | MFR PART NO. |
|----------------|----------|--------------|
| 1 OHM, 50 WATT | 44655    | 0560A        |
| 2 OHM, 50 WATT | 44655    | 0560B        |

R1 REQUIRES FOUR 1-OHM RESISTORS IN PARALLEL. R2 REQUIRES THREE 1-OHM AND ONE 2-OHM RESISTOR IN PARALLEL. R5 REQUIRES FOUR 1-OHM RESISTORS IN SERIES.

2133/53-14

Figure 5-5. Power Supply Load Test Fixture

- e. Connect the HP 427A meter and HP 180A oscilloscope to the output terminals (see figure 5-1) listed in table 5-9 and measure the voltages listed for the MAXIMUM and MINIMUM switch positions. If correct indications cannot be obtained refer to the troubleshooting procedures in figure 5-11 or 5-19.

### 5-65. PART REMOVAL AND REPLACEMENT PROCEDURES.

5-66. The following paragraphs describe the methods for removing and installing various parts in the power supply. Before performing any of the procedures, read the entire description of the procedure. Heed all **WARNING** and **CAUTION** notices.

### 5-67. CARD REMOVAL AND REPLACEMENT.

#### CAUTION

Failure to observe the following procedures may result in damage to components on circuit cards.

5-68. Before removing or installing cards in the power supply, turn off power and allow 3 minutes for filter capacitors to discharge.

5-69. To remove a card from the power supply, remove the bottom cover of the power supply, then withdraw the card by pulling it outward from the card connector.

5-70. When removing or installing cards in the power supply, use extreme care not to damage traces or protruding components on the card or on adjacent cards.

### 5-71. REPLACEMENT OF SEMICONDUCTOR DEVICES.

#### CAUTION

Failure to observe the following procedures may result in damage to components.

5-72. When replacing semiconductor devices, be sure not to omit or scratch the surface of the insulating washer which separates the device from the mounting surface, if such a washer is used. These washers are shown in the applicable parts location diagrams in section VII. Use thermal joint compound, Wakefield series 120 (HP part no. 6040-0239) or equivalent on both sides of these washers when installing a semiconductor device.

5-73. When replacing the stud-type semiconductor devices in the power supply, use a torque wrench to avoid damage to the devices and anodized washers. Torque the mounting nuts to 15 pound-inches on devices located on the following assemblies:

- a. A6 Preregulator assembly thyristors and diodes (3,8, figure 6-5).

Table 5-9. Loaded Output Voltages

| TERM.<br>AND<br>VOLTAGE | SWITCH POSITION |       | RIPPLE<br>VOLTAGE<br>(P-P) |
|-------------------------|-----------------|-------|----------------------------|
|                         | MIN.            | MAX.  |                            |
| TB2-4<br>(+30V)         | 35              | 28    | 3                          |
| TB1-1<br>(+20V)         | 20.1            | 20.0  | 0.1                        |
| TB2-3<br>(+12V)         | 12.5            | 11.6  | 0.2                        |
| TB1-5<br>(+4.85V)       | 5.0             | 4.75  | 0.1                        |
| TB1-3<br>(-2V)          | - 2.1           | - 1.7 | 0.05                       |
| TB2-2<br>(-12V)         | -12.5           | -11.6 | 0.2                        |
| TB2-1<br>(-20V)         | -20.1           | -20   | 0.1                        |

- b. A8 Rectifier assembly diodes (3,4,8, figure 6-9).
- c. A9 +4.85 Volt Rectifier assembly diodes (4, figure 6-8).
- d. A10 Output Crowbar assembly thyristors and diodes (4,9, figure 6-6).
- e. A11  $\pm 20$  volt Regulator assembly diodes (12, figure 6-7).


### 5-74. INTEGRATED CIRCUIT REPLACEMENT.


5-75. The following procedure is recommended for replacing an integrated circuit:

- a. Clip the integrated circuit pins close to the integrated circuit pack with a pair of diagonal cutters.
- b. Using a 30-watt soldering iron, unsolder and remove each pin from the circuit card.
- c. Using a rubber bulb with a suction tube, withdraw molten solder from each hole in the circuit card.
- d. Mount the new integrated circuit on the card and solder each pin.
- e. Clean the area of the replaced part with cleaning solvent and a clean brush.

### 5-76. REPLACEMENT OF WIRE LUGS.

5-77. Crimp-type lugs are used in the power supply section. If it becomes necessary to replace one of these, use a solder lug. (In field repair operations, soldering is more reliable than crimping.) If a solder lug of the required size is not available, the crimp-type lug may be reused by soldering to it. With either type of lug, do not permit solder to run onto the portion which will be under a screw. (Hold this portion of the lug uppermost when soldering.) Observe the usual precautions for obtaining a good solder connection.










Figure 5-6. Basic Checkout Troubleshooting Flowchart, Date Codes Prior to 1240










Figure 5-7. Control Voltage and Transformer Test Troubleshooting Flowchart, Date Codes Prior to 1240





2133/53-20

Figure 5-8. Inverter Driver Test Troubleshooting Flowchart, Date Codes Prior to 1240







Figure 5-9. Preregulator and Inverter Test Troubleshooting Flowchart, Date Codes Prior to 1240



2133/53-22

Figure 5-10. PWU and IPU Test Troubleshooting Flowchart, Date Codes Prior to 1240







Figure 5-11. Overvoltage and Overtemperature Detection Test Troubleshooting Flowchart, Date Codes Prior to 1240



2133/53-24

Figure 5-12. Overcurrent Test Troubleshooting Flowchart, Date Codes Prior to 1240











Figure 5-13. +20 and -20 Volt Output Test Troubleshooting Flowchart, Date Codes Prior to 1240








Figure 5-14. Basic Checkout Troubleshooting Flowchart, Date Codes 1240 and Higher



CONTROL VOLTAGE AND TRANSFORMER TEST INDICATIONS INCORRECT.








Figure 5-15. Control Voltage and Transformer Test Troubleshooting Flowchart, Date Codes 1240 and Higher



2133/53-29

Figure 5-16. Inverter Driver Test Troubleshooting Flowchart, Date Codes 1240 and Higher










Figure 5-17. Preregulator and Inverter Test Troubleshooting Flowchart, Date Codes 1240 and Higher




2133/53-31

Figure 5-18. PWU and IPU Test Troubleshooting Flowchart, Date Codes 1240 and Higher




2133/53-32

Figure 5-19. Overvoltage and Overtemperature Detection Test Troubleshooting Flowchart, Date Codes 1240 and Higher



2133/53-33

Figure 5-20. Overcurrent Test Troubleshooting Flowchart, Date Codes 1240 and Higher






Figure 5-21. +20 and -20 Volt Output Test Troubleshooting Flowchart, Date Codes 1240 and Higher

## 6-1. INTRODUCTION.

6-2. This section contains information for ordering replacement parts for the power supply. Tables 6-1 through 6-10 are the replaceable parts lists for the assemblies and parts called out in figure 6-1 through 6-10. Table 6-11 is a total quantity listing of all the electrical parts in the power supply and table 6-12 is a total quantity listing of all the mechanical parts. The parts in tables 6-11 and 6-12 are listed in numerical order by part number.

6-3. A separate replaceable parts table and separate parts locations diagrams are provided for plug-in cards. These are located in Section VII of this manual, preceding the appropriate schematic diagram.

6-4. The parts tables in Section VII and tables 6-1 through 6-12 list the following information for each part:

- a. Hewlett-Packard part number.
- b. Description of the part. (Refer to table 6-13 for an explanation of abbreviations and reference designations used in the DESCRIPTION column.)
- c. A five-digit code that corresponds to the manufacturer of the part. (Refer to table 6-14 for a listing of the manufacturers that correspond to the codes.)
- d. Manufacturer's part number.

e. Total quantity of each part used in the respective assembly (tables 6-1 through 6-10).

f. Total quantity of each part used in the instrument (tables 6-11 and 6-12 only).

6-5. Items in the DESCRIPTION column of the replaceable parts lists are indented to indicate item relationships, as follows:

### DESCRIPTION

#### MAJOR ASSEMBLY

\*Subassembly

\*Attaching Parts for Subassembly

\*\*Subassembly Parts

\*\*Attaching Parts for Subassembly Parts

## 6-6. ORDERING INFORMATION.

6-7. To order replacement parts, address the order or inquiry to the local Hewlett-Packard Sales and Service Office. (Refer to list at the end of this manual for addresses.) Specify the following information for each part ordered:

- a. Power supply part number and date code.
- b. Hewlett-Packard stock number for each part.
- c. Description of each part.
- d. Circuit reference designation (if applicable).

Table 6-1. Power Supply Assembly, Replaceable Parts

| FIG & INDEX NO. | HP PART NO.   | DESCRIPTION   | MFR CODE | MFR PART NO. | UNITS PER ASSY |
|-----------------|---------------|---|----------|--------------|----------------|
| 6-1-1           | 02100-60053   | POWER SUPPLY ASSEMBLY   | 28480    | 02100-60053  | 1              |
|                 | 02100-60096   | * Rear Fan Panel Assembly (see figure 6-2) (Attaching Parts)  | 28480    | 02100-60096  | 1              |
| 2               | 2360-0190     | * Screw, Machine, flh, No. 6-32, 1/4 in.<br>---- x ----       | 00000    | OBD          | 13             |
| 3               | 02100-00157   | * Cover, Access, bottom (Attaching Parts)                     | 28480    | 02100-00157  | 1              |
| 4               | 2360-0197     | * Screw, Machine, ph, No. 6-32, 3/8 in.                       | 00000    | OBD          | 8              |
| 5               | 2190-0851     | * Washer, Lock, split, No. 6<br>---- x ----                   | 00000    | OBD          | 8              |
| 6               | ◆ 02100-60046 | * Preregulator Control Card (A1) (see figure 7-3, sheet 1) or | 28480    | 02100-60046  | 1              |
|                 | ● 02100-60108 | * Preregulator Control Card (A1) (see figure 7-4, sheet 1)    | 28480    | 02100-60108  | 1              |

NOTES: ◆ Indicates used on power supply date codes 1229 and prior.  
● Indicates used on power supply date codes 1240 and later.

Table 6-1. Power Supply Assembly, Replaceable Parts (Continued)

| FIG & INDEX NO. | HP PART NO.  | DESCRIPTION  | MFR CODE | MFR PART NO. | UNITS PER ASSY |
|-----------------|--------------|--|----------|--------------|----------------|
| 6-1-7           | 02100-60058  | * Inverter Driver Card (A2) (see figure 7-3, sheet 2 or figure 7-4, sheet 2) | 28480    | 2100-60058   | 1              |
| 8               | ◆02100-60047 | * Protection and Control Card (A3) (see figure 7-3, sheet 3) or              | 28480    | 02100-60047  | 1              |
|                 | ◆02100-60109 | * Protection and Control Card (A3) (see figure 7-4, sheet 3)                 | 28480    | 02100-60109  | 1              |
| 9               | ◆02100-60061 | * Current Limit Card (A4) (see figure 7-3, sheet 4) or                       | 28480    | 02100-60061  | 1              |
|                 | ◆02100-60110 | * Current Limit Card (A4) (see figure 7-4, sheet 4)                          | 28480    | 02100-60110  | 1              |
| 10              | 02100-0161   | * Cover, Access, top<br>(Attaching Parts)                                    | 28480    | 02100-00161  | 1              |
| 11              | 2360-0197    | * Screw, Machine, ph, No. 6-32, 3/8 in.                                      | 00000    | OBD          | 12             |
| 12              | 2190-0851    | * Washer, Lock, split, No. 6<br>--- x ---                                    | 00000    | OBD          | 12             |
| 13              | 02100-00164  | * Cover, front<br>(Attaching Parts)  | 28480    | 02100-00164  | 1              |
| 14              | 2360-0197    | * Screw, Machine, ph, No. 6-32, 3/8 in.                                      | 00000    | OBD          | 6              |
| 15              | 2190-0851    | * Washer, Lock, split, No. 6<br>--- x ---                                    | 00000    | OBD          | 6              |
| 16■             | 02100-60095  | * Inverter Assembly (A7) (see figure 6-3)<br>(Attaching Parts)               | 28480    | 02100-60095  | 1              |
| 17■             | 2360-0197    | * Screw, Machine, ph, No. 6-32, 3/8 in.                                      | 00000    | OBD          | 4              |
| 18■             | 2190-0851    | * Washer, Lock, split, No. 6   | 00000    | OBD          | 4              |
| 19■             | 3050-0227    | * Washer, Flat, No. 6<br>--- x ---   | 00000    | OBD          | 4              |
| 19A●            | 02100-60114  | * Inverter Assembly (A7) (see figure 6-4)<br>(Attaching Parts)               | 28480    | 02100-60114  | 1              |
| 19B●            | 2360-0219    | * Screw, Machine, ph, No. 6-32, 1-3/8 in.                                    | 00000    | OBD          | 4              |
| 19C●            | 2190-0006    | * Washer, Lock, split, No. 6   | 00000    | OBD          | 4              |
| 19D●            | 3050-0228    | * Washer, Flat, No. 6<br>--- x ---   | 00000    | OBD          | 4              |
| 20■             | 02100-00141  | * Bracket, Mounting<br>(Attaching Parts)                                     | 28480    | 02100-00141  | 2              |
| 21■             | 2360-0209    | * Screw, Machine, flh, No. 10-32, 1 in.                                      | 00000    | OBD          | 2              |
| 22■             | 0340-0089    | * Grommet, plastic, 1/4 in. ID, 3/4 in. OD                                   | 28480    | 0340-0089    | 4              |
| 23■             | 2190-0851    | * Washer, Lock, split, No. 6   | 00000    | OBD          | 2              |
| 24■             | 3050-0227    | * Washer, Flat, No. 6  | 00000    | OBD          | 2              |
| 25■             | 2420-0002    | * Nut, Plain, Hexagon, No. 6-32<br>--- x ---                                 | 00000    | OBD          | 2              |
| 25A●            | 02100-00143  | * Bracket, Mounting<br>(Attaching Parts)                                     | 28480    | 02100-00143  | 2              |
| 25B●            | 2360-0197    | * Screw, Machine, ph, No. 6-32, 3/8 in.                                      | 00000    | OBD          | 2              |
| 25C●            | 2190-0006    | * Washer, Lock, split, No. 6   | 00000    | OBD          | 2              |
| 25D●            | 2420-0002    | * Nut, Plain, Hexagon, No. 6<br>--- x ---                                    | 00000    | OBD          | 2              |
| 26              | 02100-60094  | * +160 Volt Output Assembly (A5) (see figure 6-5)<br>(Attaching Parts)       | 28480    | 02100-60094  | 1              |
| 27              | 2360-0197    | * Screw, Machine, ph, No. 6-32, 3/8 in.                                      | 00000    | OBD          | 4              |
| 28              | 2190-0851    | * Washer, Lock, No. 6  | 00000    | OBD          | 4              |
| 29              | 3050-0227    | * Washer, Flat, No. 6<br>--- x ---   | 00000    | OBD          | 4              |
| 30              | 02100-00142  | * Bracket, Mounting<br>(Attaching Parts)                                     | 28480    | 02100-00142  | 1              |
|                 | 2360-0197    | * Screw, Machine, ph, No. 6-32, 3/8 in.                                      | 00000    | OBD          | 2              |
|                 | 2190-0851    | * Washer, Lock, split, No. 6   | 00000    | OBD          | 2              |
|                 | 2420-0002    | * Nut, Plain, Hexagon, No. 6-32<br>--- x ---                                 | 00000    | OBD          | 2              |
| 31              | 02100-00143  | * Bracket, Mounting<br>(Attaching Parts)                                     | 28480    | 02100-00143  | 1              |
|                 | 2360-0197    | * Screw, Machine, ph, No. 6-32, 3/8 in.                                      | 00000    | OBD          | 2              |
|                 | 2190-0851    | * Washer, Lock, split, No. 6   | 00000    | OBD          | 2              |
|                 | 2420-0002    | * Nut, Plain, Hexagon, No. 6-32<br>--- x ---                                 | 00000    | OBD          | 2              |
| 32              | 02100-60097  | * Preregulator Assembly (A6) (see figure 6-6)<br>(Attaching Parts)           | 28480    | 02100-60097  | 1              |
| 33              | 2360-0197    | * Screw, Machine, ph, No. 6-32, 3/8 in.                                      | 00000    | OBD          | 4              |
| 34              | 3050-0227    | * Washer, Lock, split, No. 6   | 00000    | OBD          | 4              |
| 35              | 2190-0851    | * Washer, Flat, No. 6<br>--- x ---   | 00000    | OBD          | 4              |

NOTES: ◆ Indicates used on power supply date codes 1229 and prior. ■ Indicates used on power supply date codes 1250 and prior.  
 ◆ Indicates used on power supply date codes 1240 and later. ● Indicates used on power supply date codes 1314 and later.



Table 6-1. Power Supply Assembly, Replaceable Parts (Continued)

| FIG & INDEX NO. | HP PART NO. | DESCRIPTION   | MFR CODE | MFR PART NO.   | UNITS PER ASSY |
|-----------------|-------------|---|----------|----------------|----------------|
| 6-1-36          | 02100-00142 | * Bracket, Mounting<br>(Attaching Parts)                          | 28480    | 02100-00142    | 1              |
|                 | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                           | 00000    | OBD            | 2              |
|                 | 2190-0851   | * Washer, Lock, split, No. 6                                      | 00000    | OBD            | 2              |
|                 | 2420-0002   | * Nut, Plain, Hexagon, No. 6-32<br>---- x ----                    | 00000    | OBD            | 2              |
| 37              | 02100-00143 | * Bracket, Mounting<br>(Attaching Parts)                          | 28480    | 02100-00143    | 1              |
|                 | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                           | 00000    | OBD            | 2              |
|                 | 2190-0851   | * Washer, Lock, split, No. 6                                      | 00000    | OBD            | 2              |
|                 | 2420-0002   | * Nut, Plain, Hexagon, No. 6-32<br>---- x ----                    | 00000    | OBD            | 2              |
| 38              | 1901-0164   | * Diode, Si, 200 PIV, 3A  | 04713    | 1N4721         | 4              |
|                 | 02100-60064 | * Terminal Board and Bracket Assembly<br>(Attaching Parts)        | 28480    | 02100-60064    | 1              |
| 39              | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                           | 00000    | OBD            | 2              |
| 40              | 2190-0851   | * Washer, Lock, split, No. 6<br>---- x ----                       | 00000    | OBD            | 2              |
| 41              | 5020-0096   | ** Terminal Board (TB3)   | 28480    | 5020-0096      | 1              |
| 42              | 5020-0241   | ** Bracket  | 28480    | 5020-0241      | 2              |
| 43              | 02100-00148 | * Bus Bar<br>(Attaching Parts)                                    | 28480    | 02100-00148    | 2              |
|                 | 2680-0099   | * Screw, Machine, ph, No. 10-32, 1/4 in.                          | 00000    | OBD            | 2              |
|                 | 2190-0077   | * Washer, Lock, split, No. 10<br>---- x ----                      | 00000    | OBD            | 2              |
| 44              | 2360-0201   | * Screw, Machine, ph, No. 6-32, 1/2 in.                           | 00000    | OBD            | 2              |
| 45              | 0590-0077   | * Nut, Self-Locking, Hexagon, No. 6-32                            | 00000    | OBD            | 2              |
| 46              | 0180-2417   | * Capacitor, Fxd, Elect, 430 mF, -10 +50%,<br>200 VDCW (C19, C20) | 14659    | 36D431F200AB2A | 2              |
| 47              | 9100-2921   | * Transformer, 8 mH (T6)<br>(Attaching Parts)                     | 28480    | 9100-2921      | 1              |
|                 | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                           | 00000    | OBD            | 4              |
|                 | 2190-0851   | * Washer, Lock, split, No. 6<br>---- x ----                       | 00000    | OBD            | 4              |
| 48              | 9100-2922   | * Transformer, Control (T5)<br>(Attaching Parts)                  | 28480    | 9100-2922      | 1              |
|                 | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                           | 00000    | OBD            | 2              |
|                 | 2190-0851   | * Washer, Lock, split, No. 6                                      | 00000    | OBD            | 2              |
|                 | 2420-0002   | * Nut, Plain, Hexagon, No. 6-32<br>---- x ----                    | 00000    | OBD            | 2              |
| 49              | 9100-2920   | * Inductor, Choke, 1.6 mH (L9)<br>(Attaching Parts)               | 28480    | 9100-2920      | 1              |
|                 | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                           | 00000    | OBD            | 2              |
|                 | 2190-0851   | * Washer, Lock, split, No. 6                                      | 00000    | OBD            | 2              |
|                 | 2420-0002   | * Nut, Plain, Hexagon, No. 6-32<br>---- x ----                    | 00000    | OBD            | 2              |
| 50              | 9100-2923   | * Transformer, Inverter (T3, T4)<br>(Attaching Parts)             | 28480    | 9100-2923      | 2              |
|                 | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                           | 00000    | OBD            | 4              |
|                 | 2190-0851   | * Washer, Lock, split, No. 6                                      | 00000    | OBD            | 4              |
|                 | 2420-0002   | * Nut, Plain, Hexagon, No. 6-32<br>---- x ----                    | 00000    | OBD            | 4              |
|                 | 02100-60093 | * Output Junction Assembly<br>(Attaching Parts)                   | 28480    | 02100-60093    | 1              |
| 51              | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                           | 00000    | OBD            | 4              |
| 52              | 2190-0851   | * Washer, Lock, split, No. 6                                      | 00000    | OBD            | 4              |
| 53              | 3050-0227   | * Washer, Flat, No. 6<br>---- x ----                              | 00000    | OBD            | 4              |

Table 6-1. Power Supply Assembly, Replaceable Parts (Continued)

| FIG & INDEX NO. | HP PART NO. | DESCRIPTION  | MFR CODE | MFR PART NO.  | UNITS PER ASSY |
|-----------------|-------------|--|----------|---------------|----------------|
| 6-1-54          | 0360-1128   | ** Terminal Board (TB1)<br>(Attaching Parts)                               | 71785    | 353-11-09-001 | 1              |
| 55              | 2360-0197   | ** Screw, Machine, ph, No. 6-32, 3/8 in.                                   | 00000    | OBD           | 2              |
| 56              | 2190-0851   | ** Washer, Lock, split, No. 6  | 00000    | OBD           | 2              |
| 57              | 3050-0227   | ** Washer, Flat, No. 6<br>-----x-----                                      | 00000    | OBD           | 2              |
| 58              | 0360-1699   | ** Terminal Board (TB2)<br>(Attaching Parts)                               | 98410    | 39007         | 1              |
| 59              | 2360-0197   | ** Screw, Machine, ph, No. 6-32, 3/8 in.                                   | 00000    | OBD           | 2              |
| 60              | 2190-0851   | ** Washer, Lock, split, No. 6  | 00000    | OBD           | 2              |
| 61              | 3050-0227   | ** Washer, Flat, No. 6<br>-----x-----                                      | 00000    | OBD           | 2              |
| 62              | No Number   | ** Output Crowbar Assembly (A10) (see figure 6-7)<br>(Attaching Parts)     |          |               | 1              |
| 63              | 2360-0196   | ** Screw, Machine, flh, No. 6-32, 3/8 in.                                  | 00000    | OBD           | 1              |
| 64              | 2360-0197   | ** Screw, Machine, ph, No. 6-32, 3/8 in.                                   | 00000    | OBD           | 1              |
| 65              | 2190-0851   | ** Washer, Lock, split, No. 6<br>-----x-----                               | 00000    | OBD           | 1              |
| 66              | No Number   | ** ±20 Volt Regulator Assembly (A11) (see figure 6-8)<br>(Attaching Parts) |          |               | 1              |
| 67              | 2190-0851   | ** Screw, Machine, ph, No. 6-32, 3/8 in.                                   | 00000    | OBD           | 2              |
| 68              | 3050-0227   | ** Washer, Lock, split, No. 6<br>-----x-----                               | 00000    | OBD           | 2              |
| 69              | 05210-4001  | ** Guide, Printed-Circuit<br>(Attaching Parts)                             | 28480    | 05210-4001    | 1              |
| 70              | 2360-0209   | ** Screw, Machine, ph, No. 6-32, 1 in.                                     | 00000    | OBD           | 2              |
| 71              | 0380-0010   | ** Spacer, Sleeve, 1/4 in. OD, 5/8 in. long                                | 28480    | 0380-0010     | 2              |
| 72              | 2420-0003   | ** Nut, Plain, Hexagon, No. 6-32<br>-----x-----                            | 00000    | OBD           | 2              |
| 73              | 02100-00156 | ** Plate, Terminal Board Mounting  | 28480    | 02100-00156   | 1              |
| 74              | 02100-60098 | * +4.85 Volt Rectifier Assembly (A9) (see figure 6-9)<br>(Attaching Parts) | 28480    | 02100-60098   | 1              |
| 75              | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                                    | 00000    | OBD           | 4              |
| 76              | 2190-0851   | * Washer, Lock, split, No. 6   | 00000    | OBD           | 4              |
| 77              | 3050-0227   | * Washer, Flat, No. 6<br>-----x-----                                       | 00000    | OBD           | 4              |
| 78              | 0380-0091   | * Spacer, Hexagon, int-thread, No. 6-32, 3/4 in. long<br>(Attaching Parts) | 28480    | 0380-0091     | 4              |
|                 | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                                    | 00000    | OBD           | 2              |
|                 | 2190-0851   | * Washer, Lock, split, No. 6   | 00000    | OBD           | 2              |
|                 | 3050-0227   | * Washer, Flat, No. 6<br>-----x-----                                       | 00000    | OBD           | 2              |
| 79              | 02100-60099 | * Rectifier Assembly (A8) (see figure 6-10)<br>(Attaching Parts)           | 28480    | 02100-60099   | 1              |
| 80              | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                                    | 00000    | OBD           | 4              |
| 81              | 2190-0851   | * Washer, Lock, split, No. 6   | 00000    | OBD           | 4              |
| 82              | 3050-0227   | * Washer, Flat, No. 6<br>-----x-----                                       | 00000    | OBD           | 4              |
| 83              | 02100-00143 | * Bracket, Mounting<br>(Attaching Parts)                                   | 28480    | 02100-00143   | 2              |
|                 | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                                    | 00000    | OBD           | 2              |
|                 | 2190-0851   | * Washer, Lock, split, No. 6   | 00000    | OBD           | 2              |
|                 | 3050-0227   | * Washer, Flat, No. 6<br>-----x-----                                       | 00000    | OBD           | 2              |
| 84▲             | 9100-2918   | * Inductor, 8 uH (L7)<br>(Attaching Parts)                                 | 28480    | 9100-2918     | 1              |
| 85▲             | 2360-0133   | * Screw, Machine, flh, No. 4-40, 1-1/4 in.                                 | 00000    | OBD           | 1              |
| 86▲             | 3050-0760   | * Plate, Electrical Shield, 1/8 in. ID, 1-1/4 in. OD                       | 28480    | 3050-0760     | 2              |
| 87▲             | 3050-0761   | * Insulator, Neoprene, 1/8 in. ID, 1-1/4 in. OD                            | 28480    | 3050-0761     | 2              |
| 88▲             | 2190-0003   | * Washer, Lock, split, No. 4   | 00000    | OBD           | 1              |
| 89▲             | 2260-0001   | * Nut, Plain, Hexagon, No. 4-40<br>-----x-----                             | 00000    | OBD           | 1              |


Table 6-1. Power Supply Assembly, Replaceable Parts (Continued)

| FIG & INDEX NO. | HP PART NO. | DESCRIPTION  | MFR CODE | MFR PART NO. | UNITS PER ASSY |
|-----------------|-------------|--|----------|--------------|----------------|
| 6-1-89A★        | 9100-2932   | * Inductor, 8 uH (L7)<br>(Attaching Parts)               | 28480    | 9100-2932    | 1              |
| 89B★            | 2680-0100   | * Screw, Machine, flh, No. 10-32, 3/8 in.<br>---- x ---- | 00000    | OBD          | 1              |
| 90▲             | 9100-2919   | * Inductor, 9 uH (L8)<br>(Attaching Parts)               | 28480    | 9100-2919    | 1              |
| 91▲             | 2200-0155   | * Screw, Machine, ph, No. 4-40, 1 in.                    | 00000    | OBD          | 1              |
| 92▲             | 3050-0760   | * Plate, Electrical Shield, 1/8 in. ID, 1-1/4 in. OD     | 28480    | 3050-0760    | 2              |
| 93▲             | 3050-0761   | * Insulator, Neoprene, 1/8 in. ID, 1-1/4 in. OD          | 28480    | 3050-0761    | 2              |
| 94▲             | 2190-0003   | * Washer, Lock, split, No. 4                             | 00000    | OBD          | 1              |
| 95▲             | 2260-0001   | * Nut, Plain, Hexagon, No. 4-40<br>---- x ----           | 00000    | OBD          | 1              |
| 95A★            | 9100-2933   | * Inductor, 9 uH (L8)<br>(Attaching Parts)               | 28480    | 9100-2933    | 1              |
| 95B★            | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                  | 00000    | OBD          | 1              |
| 95C★            | 2190-0851   | * Washer, Lock, split, No. 6<br>---- x ----              | 00000    | OBD          | 1              |
| 96              | 02100-20052 | * Standoff, ceramic<br>(Attaching Parts)                 | 28480    | 02100-20052  | 1              |
|                 | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                  | 00000    | OBD          | 1              |
|                 | 2190-0851   | * Washer, Lock, split, No. 6<br>---- x ----              | 00000    | OBD          | 1              |
| 97▲             | 9100-2917   | * Inductor, 50 uH (L6)<br>(Attaching Parts)              | 28480    | 9100-2917    | 1              |
| 98▲             | 2200-0155   | * Screw, Machine, flh, No. 4-40, 1 in.                   | 00000    | OBD          | 1              |
| 99▲             | 3050-0760   | * Plate, Electrical Shield, 1/8 in. ID, 1-1/4 in. OD     | 28480    | 3050-0760    | 2              |
| 100▲            | 3050-0761   | * Insulator, Neoprene, 1/8 in. ID, 1-1/4 in. OD          | 28480    | 3050-0761    | 2              |
| 101▲            | 2190-0003   | * Washer, Lock, split, No. 4                             | 00000    | OBD          | 1              |
| 102▲            | 2260-0001   | * Nut, Plain, Hexagon, No. 4-40<br>---- x ----           | 00000    | OBD          | 1              |
| 102A★           | 9100-2931   | * Inductor, 50 uH (L6)<br>(Attaching Parts)              | 28480    | 9100-2931    | 1              |
| 102B★           | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                  | 00000    | OBD          | 1              |
| 102C★           | 2190-0851   | * Washer, Lock, split, No. 6<br>---- x ----              | 00000    | OBD          | 1              |
| 103▲            | 9100-2917   | * Inductor, 50 uH (L5)<br>(Attaching Parts)              | 28480    | 9100-2917    | 1              |
| 104▲            | 2200-0155   | * Screw, Machine, ph, No. 4-40, 1 in.                    | 00000    | OBD          | 1              |
| 105▲            | 3050-0760   | * Plate, Electrical Shield, 1/8 in. ID, 1-1/4 in. OD     | 28480    | 3050-0760    | 2              |
| 106▲            | 3050-0761   | * Insulator, Neoprene, 1/8 in. ID, 1-1/4 in. OD          | 28480    | 3050-0761    | 2              |
| 107▲            | 2190-0003   | * Washer, Lock, split, No. 4                             | 00000    | OBD          | 1              |
| 108▲            | 2260-0001   | * Nut, Plain, Hexagon, No. 4-40<br>---- x ----           | 00000    | OBD          | 1              |
| 108A★           | 9100-2931   | * Inductor, 50 uH (L5)<br>(Attaching Parts)              | 28480    | 9100-2931    | 1              |
| 108B★           | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                  | 00000    | OBD          | 1              |
| 108C★           | 2190-0851   | * Washer, Lock, split, No. 6<br>---- x ----              | 00000    | OBD          | 1              |
| 109             | 02100-00153 | * Strap, Bus Bar<br>(Attaching Parts)                    | 28480    | 02100-00153  | 1              |
| 110             | 3030-0248   | * Setscrew, Socket Head, No. 10-32, 3/4 in.              | 00000    | OBD          | 1              |
| 111             | 2190-0077   | * Washer, Lock, split, No. 10                            | 00000    | OBD          | 3              |
| 112             | 2740-0002   | * Nut, Plain, Hexagon, No. 10-32                         | 00000    | OBD          | 1              |
| 113             | 2680-0099   | * Screw, Machine, ph, No. 10-32, 3/8 in.                 | 00000    | OBD          | 2              |
| 114             | 2680-0128   | * Screw, Machine, ph, No. 10-32, 1/4 in.                 | 00000    | OBD          | 1              |
| 115             | 2190-0074   | * Washer, Lock, split, No. 10<br>---- x ----             | 00000    | OBD          | 1              |

NOTES: ▲ Indicates non-encapsulated inductors and attaching parts used on original equipment. Replace with same part numbers.  
★ Indicates encapsulated inductors and attaching parts used on later equipment. Replace with same part numbers.

Table 6-1. Power Supply Assembly, Replaceable Parts (Continued)

| FIG & INDEX NO. | HP PART NO. | DESCRIPTION  | MFR CODE | MFR PART NO.      | UNITS PER ASSY |
|-----------------|-------------|--|----------|-------------------|----------------|
| 6-1-116         | 02100-00149 | * Bus Bar<br>(Attaching Parts)                                 | 28480    | 02100-00149       | 1              |
| 117             | 3030-0248   | * Setscrew, Socket Head, No. 10-32, 3/4 in.                    | 00000    | OBD               | 1              |
| 118             | 2190-0077   | * Washer, Lock, split, No. 10                                  | 00000    | OBD               | 3              |
| 119             | 2740-0002   | * Nut, Plain, Hexagon, No. 10-32                               | 00000    | OBD               | 1              |
| 120             | 2680-0099   | * Screw, Machine, ph, No. 10-32, 3/8 in.                       | 00000    | OBD               | 2              |
| 121             | 2680-0128   | * Screw, Machine, ph, No. 10-32, 1/4 in.                       | 00000    | OBD               | 1              |
| 122             | 2190-0074   | * Washer, Lock, split, No. 10<br>--- x ---                     | 00000    | OBD               | 1              |
| 123             | 02100-00152 | * Terminal Strip, Grounding<br>(Attaching Parts)               | 28480    | 02100-00152       | 1              |
| 124             | 2360-0200   | * Screw, Machine, flh, No. 6-32, 1/4 in.                       | 00000    | OBD               | 2              |
| 125             | 02100-00151 | * Insulator, Sheet, electrical                                 | 28480    | 02100-00151       | 1              |
| 126             | 3050-0249   | * Washer, Insulating, shoulder, 3/8 in. OD, 1/8 in. thick      | 28480    | 3050-0249         | 4              |
| 127             | 3050-0227   | * Washer, Flat, No. 6  | 00000    | OBD               | 2              |
| 128             | 2190-0851   | * Washer, Lock, split, No. 6                                   | 00000    | OBD               | 2              |
| 129             | 2420-0002   | * Nut, Plain, Hexagon, No. 6-32<br>--- x ---                   | 00000    | OBD               | 2              |
| 130             | 2680-0099   | * Screw, Machine, ph, No. 10-32, 1/4 in.                       | 00000    | OBD               | 1              |
| 131             | 2190-0077   | * Washer, Lock, split, No. 10                                  | 00000    | OBD               | 1              |
| 132             | 0180-2412   | * Capacitor, Fxd, Elect, 37000 mF, -10 +75%, 5VDCW (C25)       | 14659    | 60D20D373G5R0AF2A | 1              |
| 133             | 2740-0002   | * Nut, Plain, Hexagon, No. 10-32                               | 00000    | OBD               | 1              |
| 134             | 2190-0077   | * Washer, Lock, split, No. 10                                  | 00000    | OBD               | 1              |
| 135             | 3030-0248   | * Setscrew, Socket Head, No. 10-32, 3/4 in.                    | 00000    | OBD               | 1              |
| 136             | 0180-2411   | * Capacitor, Fxd, Elect, 22000 uF, -10 +75%, 10 VDCW (C24)     | 14659    | 602D223G010AF2A   | 1              |
| 137             | 2680-0099   | * Screw, Machine, ph, No. 10-32, 3/8 in.                       | 00000    | OBD               | 1              |
| 138             | 2190-0077   | * Washer, Lock, split, No. 10                                  | 00000    | OBD               | 1              |
| 139             | 0180-2416   | * Capacitor, Fxd, Elect, 9900 uF, -10 +75%, 30 VDCW (C16)      | 14659    | 602D992G030AF2A   | 1              |
| 140             | 3030-0248   | * Setscrew, Socket Head, No. 10-32, 3/4 in.                    | 00000    | OBD               | 1              |
| 141             | 2680-0099   | * Screw, Machine, ph, No. 10-32, 3/8 in.                       | 00000    | OBD               | 1              |
| 142             | 2190-0077   | * Washer, Lock, split, No. 10                                  | 00000    | OBD               | 2              |
| 143             | 2740-0002   | * Nut, Plain, Hexagon, No. 10-32                               | 00000    | OBD               | 1              |
| 144             | 0180-2410   | * Capacitor, Fxd, Elect, 18000 uF, -10 +75%, 15 VDCW (C23,C26) | 14659    | 602D183G015AF2A   | 2              |
| 145             | 3030-0248   | * Setscrew, Socket Head, No. 10-32, 3/4 in.                    | 00000    | OBD               | 1              |
| 146             | 2740-0002   | * Nut, Plain, Hexagon, No. 10-32                               | 00000    | OBD               | 1              |
| 147             | 2190-0077   | * Washer, Lock, split, No. 10                                  | 00000    | OBD               | 1              |
| 148             | 0180-2413   | * Capacitor, Fxd, Elect, 7500 uF, -10 +75%, 15 VDCW (C21)      | 14659    | 36D752G015AA2A    | 1              |
| 149             | 3030-0248   | * Setscrew, Socket Head, No. 10-32, 3/4 in.                    | 00000    | OBD               | 1              |
| 150             | 2740-0002   | * Nut, Plain, Hexagon, No. 10-32                               | 00000    | OBD               | 1              |
| 151             | 2190-0077   | * Washer, Lock, split, No. 10                                  | 00000    | OBD               | 2              |
| 152             | 2680-0099   | * Screw, Machine, ph, No. 10-32, 3/8 in.                       | 00000    | OBD               | 1              |
| 153             | 0180-2414   | * Capacitor, Fxd, Elect, 2900 uF, -10 +75%, 40 VDCW (C22)      | 14659    | 36D292G040AA2A    | 1              |
| 154             | 1251-0233   | * PC Card Connector, 44 Contact<br>(Attaching Parts)           | 76530    | 251-22-30-261     | 4              |
|                 | 2360-0203   | * Screw, Machine, ph, No. 6-32, 1/2 in.                        | 00000    | OBD               | 2              |
|                 | 2190-0851   | * Washer, Lock, split, No. 6                                   | 00000    | OBD               | 2              |
|                 | 3050-0010   | * Washer, Flat, No. 6<br>--- x ---                             | 00000    | OBD               | 2              |
| 155             | 02100-20045 | * Mounting Block, PC Connector<br>(Attaching Parts)            | 28480    | 02100-20045       | 2              |
|                 | 2360-0203   | * Screw, Machine, ph, No. 6-32, 1/2 in.                        | 00000    | OBD               | 1              |
|                 | 2190-0851   | * Washer, Lock, split, No. 6<br>--- x ---                      | 00000    | OBD               | 1              |
| 156             | 02100-00146 | * Panel, left side<br>(Attaching Parts)                        | 28480    | 02100-00146       | 1              |
| 157             | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                        | 00000    | OBD               | 3              |
| 158             | 2190-0851   | * Washer, Lock, split, No. 6<br>--- x ---                      | 00000    | OBD               | 3              |
| 159             | 02100-00145 | * Panel, right side<br>(Attaching Parts)                       | 28480    | 02100-00145       | 1              |
| 160             | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                        | 00000    | OBD               | 3              |
| 161             | 2190-0851   | * Washer, Lock, split, No. 6<br>--- x ---                      | 00000    | OBD               | 3              |
| 162             | 02100-00167 | * Pad, foam rubber, 2-3/4 in. long, 2-3/4 in. wide             | 28480    | 02100-00167       | 2              |
| 163             | 02100-00144 | * Plate, Mounting  | 28480    | 02100-00144       | 1              |







Figure 6-1. Power Supply Assembly, Exploded View

Table 6-2. Rear Fan Panel Assembly, Replaceable Parts

| FIG & INDEX NO. | HP PART NO. | DESCRIPTION  | MFR CODE | MFR PART NO.    | UNITS PER ASSY |
|-----------------|-------------|--|----------|-----------------|----------------|
| 6-2-            | 02100-60096 | REAR FAN PANEL ASSEMBLY (1, figure 6-1)                | 28480    | 02100-60096     | 1              |
| 1               | 02100-00021 | * Filter, rear   | 28480    | 02100-00021     | 1              |
| 2               | 1251-0013   | ** Fastener, Spring Tension, Trim<br>(Attaching Parts) | 78947    | 152239          | 4              |
| 3               | 2190-0006   | ** Washer, Lock, split, No. 6                          | 00000    | OBD             | 1              |
| 4               | 0570-1029   | ** Stud, threaded, 1/4 in. long<br>--- x ---           | 00000    | OBD             | 1              |
| 5               | 3160-0224   | * Fan, Tubeaxial (B1)<br>(Attaching Parts)             | 28480    | 3160-0224       | 1              |
|                 | 2360-0205   | * Screw, Machine, ph, No. 6-32, 3/4 in.                | 00000    | OBD             | 4              |
|                 | 2190-0006   | * Washer, Lock, split, No. 6                           | 00000    | OBD             | 4              |
|                 | 2420-0002   | * Nut, Plain, Hexagon, No. 6-32<br>--- x ---           | 00000    | OBD             | 4              |
| 6               | 5000-8015   | * Guard, Fan   | 28480    | 5000-8015       | 1              |
| 7               | 2420-0001   | * Nut, Assembled Washer, No. 6-32                      | 00000    | OBD             | 2              |
| 7A              | 3050-0228   | * Washer, flat, No. 6                                  | 00000    | OBD             | 2              |
| 8               | 2360-0205   | * Screw, Machine, ph, No. 6-32, 3/4 in.                | 00000    | OBD             | 1              |
| 9               | 2360-0196   | * Screw, Machine, flh, No. 6-32, 3/8 in.               | 00000    | OBD             | 2              |
| 10              | 2420-0003   | * Nut, Plain, Hexagon, No. 6-32                        | 00000    | OBD             | 2              |
| 11              | 05210-4001  | * Guide, Printed-Circuit                               | 28480    | 05210-4001      | 1              |
| 12              | 2360-0204   | * Screw, Machine, flh, No. 6-32, 3/4 in.               | 00000    | OBD             | 1              |
| 12A             | 3050-0228   | * Washer, flat, No. 6                                  | 00000    | OBD             | 2              |
| 13              | 02100-00154 | * Bracket, Printed-Circuit Guide                       | 28480    | 02100-00154     | 1              |
| 14              | 3160-0224   | * Fan, Tubeaxial (B2)<br>(Attaching Parts)             | 28480    | 3160-0224       | 1              |
| 15■             | 2360-0205   | * Screw, Machine, ph, No. 6-32, 3/4 in.                | 00000    | OBD             | 4              |
| 16■             | 2190-0006   | * Washer, Lock, split, No. 6                           | 00000    | OBD             | 4              |
| 17■             | 2420-0002   | * Nut, Plain, Hexagon, No. 6-32<br>--- x ---           | 00000    | OBD             | 4              |
| 18              | 5000-8015   | * Guard, Fan   | 28480    | 5000-8015       | 1              |
| 19              | 2110-0004   | * Fuse, 1/4A, 250V (F5)                                | 75915    | 3AC/CAT.312.250 | 1              |
| 20              | 1400-0084   | * Fuseholder (XF5)<br>(Attaching Parts)                | 75915    | 34204           | 1              |
| 21              | 2950-0038   | * Nut, Plain, Hexagon, No. 5-24, 11/16 in. OD          | 00000    | OBD             | 1              |
| 22              | 2190-0068   | * Washer, Lock, int-tooth                              | 00000    | OBD             | 1              |
| 23              | 1400-0090   | * Gasket, Neoprene, 5/8 in. OD<br>--- x ---            | 00000    | OBD             | 1              |
| 24              | 02100-00147 | * Panel, rear fan                                      | 28480    | 02100-00147     | 1              |

NOTE: ■ Items 15, 16, and 17 may be replaced by a tapping screw, No. 8-32, 3/4 in.




2135-13B

Figure 6-2. Rear Fan Panel Assembly, Exploded View



Table 6-3. Inverter Assembly (02100-60095), Replaceable Parts

| FIG & INDEX NO. | HP PART NO. | DESCRIPTION  | MFR CODE | MFR PART NO. | UNITS PER ASSY |
|-----------------|-------------|--|----------|--------------|----------------|
| 6-3-            | 02100-60095 | INVERTER ASSEMBLY (A7) (16, figure 6-1)                                  |          | 02100-60095  | 1              |
| 1               | 1854-0080   | * Transistor, Si, NPN (Q3 thru Q10)<br>(Attaching Parts)                 | 28480    | 1854-0080    | 8              |
| 2               | 2360-0205   | * Screw, Machine, ph, No. 6-32, 3/4 in.                                  | 71785    | 293011       | 2              |
|                 | 2190-0851   | * Washer, Lock, split, No. 6   | 00000    | OBD          | 2              |
|                 | 1200-0043   | * Insulator, Transistor Mounting<br>--- x ---                            | 00000    | OBD          | 1              |
| 3               | 2200-0143   | * Screw, Machine, ph, No. 4-40, 3/8 in.                                  | 00000    | OBD          | 4              |
| 4               | 2190-0003   | * Washer, Lock, split, No. 4   | 00000    | OBD          | 4              |
| 5               | 9100-2924   | * Transformer, Pulse (T1,T2)<br>(Attaching Parts)                        | 28480    | 9100-2924    | 2              |
|                 | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                                  | 00000    | OBD          | 2              |
|                 | 2190-0851   | * Washer, Lock, split, No. 6<br>--- x ---                                | 00000    | OBD          | 2              |
| 6               | 0340-0078   | * Insulator, Standoff  | 83330    | 93-2001      | 2              |
| 7               | 02100-00155 | * Bracket, Angle   | 28480    | 02100-00155  | 1              |
| 8               | 1901-1065   | * Diode, Si (CR3 thru CR10)  | 04713    | 1N4936       | 8              |
| 9               | 0160-0303   | * Capacitor, Fxd, My, 0.15 $\mu$ F, 10%, 200 VDCW (C12,C13)              | 28480    | 0160-0303    | 2              |
| 10              | 0160-0174   | * Capacitor, Fxd, Cer, 0.47 $\mu$ F, +80 - 20%, 25 VDCW<br>(C4 thru C11) | 26289    | 5C11B7S-CML  | 8              |
| 11              | 1200-0452   | * Socket, Transistor (XQ3 thru XQ10)<br>(Attaching Parts)                | 91506    | 8080-1G1     | 8              |
| 12              | 2200-0149   | * Screw, Machine, ph, No. 4-40, 5/8 in.                                  | 00000    | OBD          | 1              |
|                 | 2190-0003   | * Washer, Lock, split, No. 4   | 00000    | OBD          | 1              |
|                 | 3050-0229   | * Washer, Flat, No. 4  | 00000    | OBD          | 1              |
|                 | 2260-0002   | * Nut, Plain, Hexagon, No. 4-40<br>--- x ---                             | 00000    | OBD          | 1              |
| 13              | 02100-20048 | * Heat Sink  | 28480    | 02100-20048  | 1              |




2135-4A

Figure 6-3. Inverter Assembly (02100-60095), Exploded View

Table 6-4. Inverter Assembly (02100-60114), Replaceable Parts

| FIG & INDEX NO. | HP PART NO. | DESCRIPTION   | MFR CODE | MFR PART NO. | UNITS PER ASSY |
|-----------------|-------------|---|----------|--------------|----------------|
| 6-4-            | 02100-60114 | Inverter Assembly (A7) (19A figure 6-1)                       | 28480    | 02100-60114  | 1              |
| 1               | 02100-60113 | * Inverter Board Assembly                                     | 28480    | 02100-60113  | 1              |
| 2               | 0160-0174   | ** Capacitor, Fxd, Cer, 0.47 $\mu$ F, +80 -20%, 25 VDCW (C6)  | 56289    | SC11B7S-CML  | 1              |
| 3               | 1901-1065   | ** Diode 1N4936 (CR5)   | 28480    | 1901-1065    | 1              |
| 4               | 1901-1065   | ** Diode 1N4936 (CR6)   | 28480    | 1901-1065    | 1              |
| 5               | 0160-0174   | ** Capacitor, Fxd, Cer, 0.47 $\mu$ F, +80 -20%, 25 VDCW (C7)  | 56289    | SC11B7S-CML  | 1              |
| 6               | 1854-0080   | ** Transistor, Si, NPN (Q3, Q4, Q5, Q6)<br>(Attaching Parts)  | 28480    | 1854-0080    | 4              |
|                 | 2360-0115   | ** Screw, Machine, ph, No. 6-32, 5/16 in.                     | 00000    | OBD          | 2              |
|                 | 2190-0851   | ** Washer, Lock, split, No. 6<br>---- x ----                  | 00000    | OBD          | 2              |
| 7               | 9100-2924   | ** Transformer, Pulse (T1)<br>(Attaching Parts)               | 28480    | 9100-2924    | 1              |
|                 | 2360-0115   | ** Screw, Machine, ph, No. 6-32, 5/16 in.                     | 00000    | OBD          | 2              |
|                 | 3050-0228   | ** Washer, Flat, No. 6  | 00000    | OBD          | 2              |
|                 | 2420-0001   | ** Nut, assembled washer, hexagon, No. 6<br>---- x ----       | 00000    | OBD          | 2              |
| 8               | 0360-1149   | ** Terminal, solder (E39, E40, E67, E68, E69, E70)            | 28480    | 0360-1149    | 6              |
| 9               | 1901-1065   | ** Diode 1N4936 (CR3)   | 28480    | 1901-1065    | 1              |
| 10              | 0160-0174   | ** Capacitor, Fxd, Cer, 0.47 $\mu$ F, +80 -20%, 25 VDCW (C4)  | 56289    | SC11B7S-CML  | 1              |
| 11              | 1901-1065   | ** Diode 1N4936 (CR4)   | 28480    | 1901-1065    | 1              |
| 12              | 0160-0174   | ** Capacitor, Fxd, Cer, 0.47 $\mu$ F, +80 -20%, 25 VDCW (C5)  | 56289    | SC11B7S-CML  | 1              |
| 13              | 0160-0303   | ** Capacitor, Fxd, My, 0.15 $\mu$ F, 10%, 200 VDCW (C12)      | 28480    | 0160-0303    | 1              |
| 14              | 0360-0295   | ** Terminal, Solder (E71, E72, E73, E74)                      | 28480    | 0360-0295    | 4              |
| 15              | 02100-60113 | * Inverter Board Assembly                                     | 28480    | 02100-60113  | 1              |
| 16              | 0160-0174   | ** Capacitor, Fxd, Cer, 0.47 $\mu$ F, +80 -20%, 25 VDCW (C10) | 56289    | SC11B7S-CML  | 1              |
| 17              | 1901-1065   | ** Diode 1N4936 (CR9)   | 28480    | 1901-1065    | 1              |
| 18              | 1901-1065   | ** Diode 1N4936 (CR10)  | 28480    | 1901-1065    | 1              |
| 19              | 0160-0174   | ** Capacitor, Fxd, Cer, 0.47 $\mu$ F, +80 -20%, 25 VDCW (C11) | 56289    | SC11B7S-CML  | 1              |
| 20              | 1854-0080   | ** Transistor, Si, NPN (Q7, Q8, Q9, Q10)<br>(Attaching Parts) | 28480    | 1854-0080    | 4              |
|                 | 2360-0115   | ** Screw, Machine, ph, No. 6-32, 5/16 in.                     | 00000    | OBD          | 2              |
|                 | 2190-0851   | ** Washer, Lock, split, No. 6<br>---- x ----                  | 00000    | OBD          | 2              |
| 21              | 9100-2924   | ** Transformer, Pulse (T2)<br>(Attaching Parts)               | 28480    | 9100-2924    | 1              |
|                 | 2360-0115   | ** Screw, Machine, ph, No. 6-32, 5/16 in.                     | 00000    | OBD          | 2              |
|                 | 3050-0228   | ** Washer, Flat, No. 6  | 00000    | OBD          | 2              |
|                 | 2420-0001   | ** Nut, assembled washer, hexagon, No. 6<br>---- x ----       | 00000    | OBD          | 2              |
| 22              | 0360-1149   | ** Terminal, Solder (E37, E38, E75, E76, E77, E78)            | 28480    | 0360-1149    | 6              |
| 23              | 1901-1065   | ** Diode 1N4936 (CR7)   | 28480    | 1901-1065    | 1              |
| 24              | 0160-0174   | ** Capacitor, Fxd, Cer, 0.47 $\mu$ F, +80 -20%, 25 VDCW (C8)  | 56289    | SC11B7S-CML  | 1              |
| 25              | 1901-1065   | ** Diode 1N4936 (CR8)   | 28480    | 1901-1065    | 1              |
| 26              | 0160-0174   | ** Capacitor, Fxd, Cer, 0.47 $\mu$ F, +80 -20%, 25 VDCW (C9)  | 56289    | SC11B7S-CML  | 1              |
| 27              | 0160-0303   | ** Capacitor, Fxd, My, 0.15 $\mu$ F, 10%, 200 VDCW (C13)      | 28480    | 0160-0303    | 1              |
| 28              | 0360-0295   | ** Terminal, Solder (E79, E80, E81, E82)                      | 28480    | 0360-0295    | 4              |




2135-100

Figure 6-4. Inverter Assembly (02100-60114), Exploded View

Table 6-5. +160 Volt Output Board, Replaceable Parts

| FIG & INDEX NO. | HP PART NO. | DESCRIPTION  | MFR CODE | MFR PART NO.   | UNITS PER ASSY |
|-----------------|-------------|--|----------|----------------|----------------|
| 6-5-            | 02100-60094 | +160 VOLT OUTPUT BOARD (A5) (26, figure 6-1)   | 28480    | 02100-60094    | 1              |
| 1               | 2110-0083   | * Fuse, 2-1/2A, 250V, 3AG (F1,F2)  | 28480    | 2110-0083      | 2              |
| 2               | 0180-2418   | * Capacitor, Fxd, Elect, 9800 uF, -10 +75%,<br>100 VDCW (C17,C18)<br>(Attaching Parts) | 14659    | 36D982G100CC2A | 2              |
|                 | 3030-0248   | * Setscrew, Socket Head, No. 10-32, 3/4 in.  | 00000    | OBD            | 1              |
|                 | 2740-0002   | * Nut, Plain, Hexagon, No. 10-32   | 00000    | OBD            | 1              |
|                 | 2680-0103   | * Screw, Machine, ph, No. 10-32, 1/2 in.   | 00000    | OBD            | 1              |
|                 | 2190-0034   | * Washer, Lock, split, No. 10<br>--- x ---   | 00000    | OBD            | 2              |
| 3               | 02100-00165 | * Bus Bar  | 28480    | 02100-00165    | 1              |
|                 | 02100-60048 | * Capacitor Board Assembly   | 28480    | 02100-60048    | 1              |
| 4               | 1884-0219   | ** Thyristor, scr, IF, 20A, 600V (Q1)<br>(Attaching Parts)                             | 86684    | 2N3899         | 1              |
|                 | 2950-0036   | ** Nut, Plain, Hexagon, 1/4-28   | 00000    | OBD            | 1              |
|                 | 0360-0040   | ** Terminal, Lug, 1/4 in. ID   | 00000    | OBD            | 1              |
|                 | 3050-0225   | ** Washer, Flat, 1/4 in. ID<br>--- x ---   | 00000    | OBD            | 1              |
| 5               | 9100-2927   | ** Transformer, Pulse (T1)<br>(Attaching Parts)  | 28480    | 9100-2927      | 1              |
|                 | 2200-0143   | ** Screw, Machine, ph, No. 4-40, 3/8 in.   | 00000    | OBD            | 2              |
|                 | 2050-0229   | ** Washer, Flat, No. 4   | 00000    | OBD            | 2              |
|                 | 2190-0004   | ** Washer, Lock, int-tooth, No. 4  | 00000    | OBD            | 2              |
|                 | 2260-0001   | ** Nut, Plain, Hexagon, No. 4-40<br>--- x ---  | 00000    | OBD            | 2              |
| 6               | 0764-0018   | ** Resistor, Fxd, Met Flm, 4700 ohms, 5%, 2W (R1,R2)                                   | 28480    | 0764-0018      | 2              |
| 7               | 1901-0164   | ** Diode, Si, 200 PIV, 3A (CR1, CR2)   | 04713    | 1N4721         | 2              |
| 8               | 0811-3108   | ** Resistor, Fxd, WW, 2.0 ohms, 10% (R7)   | 20940    | R7-100         | 1              |
| 9               | 1902-3416   | ** Diode, Breakdown, 90.9V 5%, 400 mW (CR3,CR4) (used on<br>card rev. 1125 only)       | 07910    | CD35982        | 2              |
|                 | 1902-3428   | ** Diode, Breakdown, 100V, 5%, 400 mW (CR3,CR4) (first used<br>on card rev. 1139)      | 07910    | CD35994        | 2              |
| 10              | 0757-0316   | ** Resistor, Fxd, Met Flm, 4.2 ohms, 1%, 1/8W (R4,R6)                                  | 28480    | 0757-0316      | 2              |
| 11              | 0757-0284   | ** Resistor, Fxd, Met Flm, 150 ohms, 1%, 1/8W (R3)                                     | 28480    | 0757-0284      | 1              |
| 12              | 1901-0050   | ** Diode, Si, 200 mA at 1V (CR5)   | 07263    | FDA6308        | 1              |
| 13              | 0689-0275   | ** Resistor, Fxd, Comp, 2.7 ohms, 5%, 1W (R5)  | 01121    | GB27G5         | 1              |
| 14              | 0160-0127   | ** Capacitor, Fxd, Cer, 1.0 uF, 20%, 25 VDCW (C1)                                      | 56289    | 5C13CS-CML     | 1              |
| 15              | 2110-0257   | ** Fuseholder (XF1,XF2)<br>(Attaching Parts)   | 75915    | 121001         | 4              |
| 16              | 0361-1032   | ** Rivet, Tubular, 0.121 in. OD, 0.200 in. long<br>--- x ---                           | 00000    | OBD            | 1              |
| 17              | 0360-1529   | ** Stud, Terminal, fork style  | 71279    | 1025-4         | 15             |
| 18              | 0360-1656   | ** Stud, Terminal, single turret style   | 71279    | 1457-4         | 19             |
| 19              | 02100-80048 | ** Printed-Circuit Board   | 28480    | 02100-80048    | 1              |




2135-14A

Figure 6-5. +160 Volt Output Board, Exploded View

Table 6-6. Preregulator Assembly, Replaceable Parts

| FIG. & INDEX NO. | HP PART NO. | DESCRIPTION  | MFR CODE | MFR PART NO. | UNITS PER ASSY |
|------------------|-------------|--|----------|--------------|----------------|
| 6-6-             | 02100-60097 | PREREGULATOR ASSEMBLY (A6) (32, figure 6-1)                  |          | 02100-60097  | 1              |
| 1                | 0160-0904   | * Capacitor, Fxd, Cer, 0.50 uF, 20%, 1000 VDCW (C1,C2,C3)    | 56289    | 169A4-CDH    | 3              |
| 2                | 0698-3402   | * Resistor, Fxd, Met Flm, 316 ohms, 1%, 1/2W (R1)            | 28480    | 0698-3402    | 1              |
| 3                | 1884-0219   | * Thyristor, scr, 1F, 20A, 600V (Q1,Q2)<br>(Attaching Parts) | 86684    | 2N3899       | 2              |
| 4                | 2950-0036   | * Nut, Plain, Hexagon, 1/4-28                                | 00000    | OBD          | 1              |
| 5                | 0360-0040   | * Lug, Terminal, 1/4 in. ID                                  | 00000    | OBD          | 2              |
| 6                | 3050-0225   | * Washer, Flat, 1/4 in. ID                                   | 00000    | OBD          | 1              |
| 7                | 1200-0088   | * Insulator, Diode<br>--- x ---                              | 76530    | 293201       | 2              |
| 8                | 1901-1061   | * Diode, Rectifier, 12A, 600V (CR1,CR2)<br>(Attaching Parts) | 04713    | MR886        | 2              |
| 9                | 2740-0002   | * Nut, Plain, Hexagon, No. 10-32                             | 00000    | OBD          | 1              |
| 10               | 0360-0220   | * Lug, Terminal, No. 10                                      | 00000    | OBD          | 2              |
| 11               | 3050-0226   | * Washer, Flat, No. 10                                       | 00000    | OBD          | 1              |
| 12               | 1200-0080   | * Insulator, Transistor Mounting<br>--- x ---                | 76530    | 294834       | 2              |
| 13               | 3103-0015   | * Switch, Thermal (S1)<br>(Attaching Parts)                  | 14604    | 3001         | 1              |
|                  | 2420-0003   | * Nut, Plain, Hexagon, No. 6-32<br>--- x ---                 | 00000    | OBD          | 1              |
| 14               | 0340-0078   | * Insulator, Standoff  | 83330    | 93-2001      | 3              |
| 15               | 0340-0077   | * Insulator, Feedthru  | 98291    | FT-1000-SL   | 3              |
| 16               | 02100-00140 | * Insulator, Heat Sink<br>(Attaching Parts)                  | 28480    | 02100-00140  | 2              |
| 17               | 0361-0134   | * Rivet, 9/64 in. dia, 1/4 in. long<br>--- x ---             | 00000    | OBD          | 2              |
|                  | 02100-60059 | * Preregulator Driver Board (A1)<br>(Attaching Parts)        | 28480    | 02100-60059  | 1              |
|                  | 2200-0149   | * Screw, Machine, ph, No. 4-40, 5/8 in.                      | 00000    | OBD          | 4              |
| 18               | 2260-0001   | * Nut, Plain, Hexagon, No. 4-40                              | 00000    | OBD          | 4              |
|                  | 2190-0003   | * Washer, Lock, split, No. 4                                 | 00000    | OBD          | 4              |
|                  | 3050-0229   | * Washer, Flat, No. 4  | 00000    | OBD          | 8              |
|                  | 0390-0019   | * Spacer, Sleeve, 1/4 in. long<br>--- x ---                  | 00000    | OBD          | 4              |
| 19               | 0757-0316   | ** Resistor, Fxd, Met Flm, 42.2 ohms, 1%, 1/8W (R1,R3)       | 28480    | 0757-0316    | 2              |
| 20               | 0757-0284   | ** Resistor, Fxd, Met Flm, 150 ohms, 1%, 1/8W (R2,R4)        | 28480    | 0757-0284    | 2              |
| 21               | 9100-2925   | ** Power Transformer (T1)<br>(Attaching Parts)               | 28480    | 9100-2925    | 1              |
|                  | 2200-0139   | ** Screw, Machine, ph, No. 4-40, 1/4 in.                     | 00000    | OBD          | 2              |
|                  | 2190-0078   | ** Washer, Lock, split, No. 4                                | 00000    | OBD          | 2              |
|                  | 3050-0229   | ** Washer, Flat, No. 4                                       | 00000    | OBD          | 4              |
|                  | 2260-0002   | ** Nut, Plain, Hexagon, No. 4-40<br>--- x ---                | 00000    | OBD          | 2              |
| 22               | 02100-80059 | ** Printed-Circuit Board                                     | 28480    | 02100-80059  | 1              |
| 23               | 02100-20046 | * Heat Sink  | 28480    | 02100-20046  | 1              |




2135-3A

Figure 6-6. Preregulator Assembly, Exploded View



Table 6-7. Output Crowbar Assembly, Replaceable Parts

| FIG. & INDEX NO. | HP PART NO. | DESCRIPTION   | MFR CODE | MFR PART NO. | UNITS PER ASSY |
|------------------|-------------|---|----------|--------------|----------------|
| 6-7-             | No Number   | OUTPUT CROWBAR ASSEMBLY (A10) (62, figure 6-1)                        |          | No Number    | 1              |
| 1                | 0757-0316   | * Resistor, Fxd, Met Flm, 42.2 ohms, 1%, 1/8W (R3,R4)                 | 28480    | 0757-0316    | 2              |
| 2                | 0757-0284   | * Resistor, Fxd, Met Flm, 150 ohms, 1%, 1/8W (R2,R5)                  | 28480    | 0757-0284    | 2              |
| 3                | 0698-3180   | * Resistor, Fxd, Met Ox, 68 ohms, 2%, 2W (R6)                         | 28480    | 0698-3180    | 1              |
| 4                | 1884-0208   | * Thyristor, 35A rms, 100V (Q11,Q12)<br>(Attaching Parts)             | 12040    | NL570A       | 2              |
| 5                | 2950-0036   | * Nut, Plain, Hexagon, 1/4-28   | 00000    | OBD          | 1              |
| 6                | 0360-0271   | * Lug, Terminal, 1/4 in. ID   | 00000    | OBD          | 1              |
| 7                | 3050-0226   | * Washer, Flat, 1/4 in. ID  | 00000    | OBD          | 1              |
| 8                | 1200-0088   | * Insulator, Diode<br>--- x ---                                       | 76530    | 293201       | 2              |
| 9                | 1901-0315   | * Diode, Si, 50 PIV, 40A, 150°C (CR40)                                | 05277    | 1N1183A      | 1              |
| 10               | 1901-0496   | * Diode, Rectifier, Si (CR39)<br>(Attaching Parts for items 9 and 10) | 04713    | SR2080-2     | 1              |
| 11               | 2950-0036   | * Nut, Plain, Hexagon, 1/4-28   | 00000    | OBD          | 1              |
| 12               | 0360-0271   | * Lug, Terminal, 1/4 in. ID   | 00000    | OBD          | 1              |
| 13               | 3050-0226   | * Washer, Flat, 1/4 in. ID  | 00000    | OBD          | 1              |
| 14               | 1200-0088   | * Insulator, Diode<br>--- x ---                                       | 76530    | 293201       | 2              |
| 15               | 0340-0077   | * Insulator, Feedthru   | 98291    | FT-1000-SL   | 4              |
| 16               | 02100-20047 | * Heat Sink   | 28480    | 02100-20047  | 1              |




2135-7

Figure 6-7. Output Crowbar Assembly, Exploded View

Table 6-8.  $\pm 20$  Volt Regulator Assembly, Replaceable Parts

| FIG & INDEX NO. | HP PART NO.   | DESCRIPTION   | MFR CODE                                  | MFR PART NO.                         | UNITS PER ASSY        |
|-----------------|---|---|---|--------------------------------------|-----------------------|
| 6-8-1▲          | No Number<br>9100-2926  | $\pm 20$ VOLT REGULATOR ASSEMBLY (A11) (66, figure 6-1)<br>* Inductor, 200 $\mu$ H (L4)<br>(Attaching Parts)  | 28480                                     | No Number<br>9100-2926               | 1<br>1                |
| 2▲              | 2360-0131   | * Screw, Machine, ph, No. 6-32, 1-1/8 in.   | 00000                                     | OBD                                  | 1                     |
| 3▲              | 2190-0851   | * Washer, Lock, split, No. 6  | 00000                                     | OBD                                  | 1                     |
| 4▲              | 3050-0760   | * Plate, Electrical Shield  | 00000                                     | OBD                                  | 2                     |
| 5▲              | 3050-0761   | * Insulator, Neoprene<br>---- x ----  | 00000                                     | OBD                                  | 2                     |
| 5A★             | 9100-2934   | * Inductor, 200 $\mu$ H (L4)<br>(Attaching Parts)   | 28480                                     | 9100-2934                            | 1                     |
| 5B★             | 2360-0209   | * Screw, Machine, ph, No. 6-32, 1 in.   | 00000                                     | OBD                                  | 1                     |
| 5C★             | 2190-0006   | * Washer, Lock, split, No. 6  | 00000                                     | OBD                                  | 1                     |
| 5D★             | 3050-0227   | * Washer, Flat, No. 6<br>---- x ----  | 00000                                     | OBD                                  | 1                     |
| 6◆              | 9100-2928   | * Inductor, 4 $\mu$ H (L1, L2, L3)  | 76493                                     | 5230                                 | 3                     |
| 7               | 1835-0310   | * Transistor, Si, PNP (Q13)<br>(Attaching Parts)  | 04713                                     | 2N4398                               | 1                     |
| 8               | 2360-0205<br>2190-0851<br>1200-0043                           | * Screw, Machine, ph, No. 6-32, 3/4 in.<br>* Washer, Lock, split, No. 6<br>* Insulator Plate, Transistor<br>---- x ----   | 00000<br>00000<br>71785                   | OBD<br>OBD<br>293011                 | 2<br>2<br>1           |
| 9               | 1835-0310   | * Transistor, Si, PNP (Q14)<br>(Attaching Parts)  | 04713                                     | 2N4398                               | 1                     |
| 10              | 2360-0205<br>0360-0268<br>2190-0851<br>1200-0043              | * Screw, Machine, ph, No. 6-32, 3/4 in.<br>* Terminal, Lug, No. 6<br>* Washer, Lock, split, No. 6<br>* Insulator Plate, Transistor<br>---- x ----   | 00000<br>00000<br>00000<br>71785          | OBD<br>OBD<br>OBD<br>293011          | 2<br>1<br>1<br>1      |
| 11♣             | 0180-0141   | * Capacitor, Fxd, Elect, 50 $\mu$ F, +75 - 10%, 50 VDCW (C14)   | 56289                                     | 30D506G050DD2-DSM                    | 1                     |
| 12              | 1901-1036<br>2740-0002<br>0360-0270<br>3050-0226<br>1200-0080 | * Diode, Rectifier, Si (CR41)<br>(Attaching Parts)<br>* Nut, Plain, Hexagon, No. 10-32, 3/8 in.<br>* Terminal, Lug, No. 10<br>* Washer, Flat, 1/4-in. ID<br>* Insulator, Transistor Mounting .<br>---- x ---- | 04713<br>00000<br>00000<br>00000<br>71785 | MR881<br>OBD<br>OBD<br>OBD<br>294834 | 1<br>1<br>1<br>1<br>2 |
| 13■             | 0180-2546   | * Capacitor, Fxd, Elect, 770 $\mu$ F, -10 +75%, 40 VDCW (C15)   | 56289                                     | 601D777G040GP4-DAC                   | 1                     |
| 14              | 1200-0452   | * Socket, Transistor<br>(Attaching Parts)   | 91506                                     | 8080-1G1                             | 2                     |
| 15              | 2200-0149<br>2190-0003<br>3050-0229<br>2260-0002              | * Screw, Machine, ph, No. 4-40, 5/8 in.<br>* Washer, Lock, split, No. 4<br>* Washer, Flat, No. 4<br>* Nut, Plain, Hexagon, No. 4-40<br>---- x ----  | 00000<br>00000<br>00000<br>00000          | OBD<br>OBD<br>OBD<br>OBD             | 1<br>1<br>1<br>1      |
| 16              | 0340-0078   | * Insulator, Standoff   | 83330                                     | 93-2001                              | 9                     |
| 17              | 02100-20049   | * Heat Sink   | 28480                                     | 02100-20049                          | 1                     |

NOTES: ▲ Indicates non-encapsulated inductors and attaching parts used on original equipment. Replace with same part numbers.  
 ★ Indicates encapsulated inductors and attaching parts used on later equipment. Replace with same part number.  
 ◆ L1 and L3 not used on power supply date code 1229 and higher.  
 ♣ C15 (see index no. 13) is part no. 0180-0141 on power supply date codes prior to 1229.  
 ■ First used on power supply date code 1229.




2135-5B

Figure 6-8.  $\pm 20$  Volt Regulator Assembly, Exploded View

Table 6-9. +4.85 Volt Rectifier Assembly, Replaceable Parts

| FIG & INDEX NO. | HP PART NO. | DESCRIPTION   | MFR CODE | MFR PART NO. | UNITS PER ASSY |
|-----------------|-------------|---|----------|--------------|----------------|
| 6-9-1           | 02100-60098 | +4.85 VOLT RECTIFIER ASSEMBLY (A9) (74, figure 6-1)             |          | 02100-60098  | 1              |
|                 | 1400-0053   | * Clamp, Cable (Attaching Parts)                                | 95987    | WC-34NA      | 4              |
|                 | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                         | 00000    | OBD          | 1              |
|                 | 2190-0851   | * Washer, Lock, split, No. 6                                    | 00000    | OBD          | 1              |
|                 | 3050-0228   | * Washer, Flat, No. 6<br>--- x ---                              | 00000    | OBD          | 1              |
| 2               | 0150-0121   | * Capacitor, Fxd, Cer, 0.1 uF, +80 -20%, 50 VDCW (C27 thru C30) | 56289    | 5C50BIS-CML  | 4              |
| 3               | 1902-0202   | * Diode, Breakdown, 15V, 5%, 1W (CR46 thru CR49)                | 28480    | 1902-0202    | 4              |
| 4               | 1901-1062   | * Diode, Schottky Barrier (CR35 thru CR38) (Attaching Parts)    | 04713    | MBD-5400     | 4              |
|                 | 2740-0003   | * Nut, Assembled Washer, No. 10-32<br>--- x ---                 | 00000    | OBD          | 1              |
| 5               | 02100-00140 | * Insulator, Heat Sink (Attaching Parts)                        | 28480    | 02100-00140  | 2              |
| 6               | 2360-0003   | * Screw, Machine, ph, No. 6-32, 1/2 in.                         | 00000    | OBD          | 2              |
| 7               | 3050-0228   | * Washer, Flat, No. 6   | 00000    | OBD          | 2              |
| 8               | 2360-0851   | * Washer, Lock, split, No. 6                                    | 00000    | OBD          | 2              |
| 9               | 2420-0003   | * Nut, Plain, Hexagon, No. 6-32<br>--- x ---                    | 00000    | OBD          | 2              |
| 10              | 3103-0015   | * Switch, Thermal (S2) (Attaching Parts)                        | 14604    | 3001         | 1              |
|                 | 2420-0003   | * Nut, Plain, Hexagon, No. 6-32<br>--- x ---                    | 00000    | OBD          | 1              |
| 11              | 0360-0042   | * Terminal, Lug, No. 6 (Attaching Parts)                        | 00000    | OBD          | 3              |
|                 | 2360-0197   | * Screw, Machine, ph, No. 6-32, 3/8 in.                         | 00000    | OBD          | 1              |
|                 | 2360-0851   | * Washer, Lock, split, No. 6<br>--- x ---                       | 00000    | OBD          | 1              |
| 12              | 02100-20050 | * Heat Sink   | 28480    | 02100-20050  | 1              |





2135-6B

Figure 6-9. +4.85 Volt Rectifier Assembly, Exploded View

Table 6-10. Rectifier Assembly, Replaceable Parts

| FIG. & INDEX NO. | HP PART NO. | DESCRIPTION   | MFR CODE | MFR PART NO. | UNITS PER ASSY |
|------------------|-------------|---|----------|--------------|----------------|
| 6-10-            | 02100-60099 | RECTIFIER ASSEMBLY (A8) (79, figure 6-1)  |          | 02100-60099  | 1              |
| 1                | 0761-0021   | * Resistor, Fxd, Met Ox, 1000 ohms, 5%, 1W (R7)                                       | 28480    | 0761-0021    | 1              |
| 2                | 1901-0159   | * Diode, Si, 0.75A, 400 PIV (CR11 thru CR18)  | 04713    | SR1358-4     | 8              |
| 3                | 1901-1035   | * Diode, Rectifier, 12A, 100V (CR31 thru CR34)  | 28480    | 1901-1035    | 4              |
| 4                | 1901-1036   | * Diode, Rectifier, 12A, 100V (CR19 thru CR26)<br>(Attaching Parts for items 3 and 4) | 04713    | MR881        | 8              |
| 5                | 2740-0003   | * Nut, Assembled Washer, No. 10-32  | 00000    | OBD          | 1              |
| 6                | 02100-00150 | * Bus Bar   | 28480    | 02100-00150  | 3              |
| 7                | 1200-0080   | * Insulator, Transistor Mounting<br>--- x ---   | 76530    | 294834       | 2              |
| 8                | 1901-1062   | * Diode, Schottsky Barrier (CR27 thru CR30)<br>(Attaching Parts)                      | 04713    | MBD-5400     | 4              |
| 9                | 2740-0003   | * Nut, Assembled Washer, No. 10-32  | 00000    | OBD          | 1              |
| 10               | 3050-0225   | * Washer, Flat, 1/4 in. ID  | 00000    | OBD          | 1              |
| 11               | 1200-0088   | * Insulator, Transistor Mounting<br>--- x ---   | 76530    | 294834       | 2              |
| 12               | 0340-0078   | * Insulator, Standoff   | 83330    | 93-2001      | 4              |
| 13               | 0340-0077   | * Insulator, Feedthru   | 98291    | FT1000-SL    | 2              |
| 14               | 02100-20051 | * Heat Sink   | 28480    | 02100-20051  | 1              |



2135-8

Figure 6-10. Rectifier Assembly, Exploded View

Table 6-11. Numerical Listing of Electrical Parts

| HP PART NO. | DESCRIPTION  | MFR CODE | MFR PART NO.         | TQ |
|-------------|--|----------|----------------------|----|
| 0150-0050   | C: Fxd Cer 1000 PF +80 -20% 1000 VDCW              | 56289    | C067B102E1022S26-CDH | 12 |
| 0150-0093   | C: Fxd Cer 0.01 uF +80 -20% 100 VDCW               | 72982    | 801-K800011          | 2  |
| 0150-0096   | C: Fxd Cer 0.05 uF +80 -20%, 100 VDCW              | 91418    | TA                   | 5  |
| 0150-0121   | C: Fxd Cer 0.1 uF +80 -20% 50 VDCW                 | 56289    | 5C50BIS-CML          | 5  |
| 0160-0127   | C: Fxd Cer 1.0 uF 20% 25 VDCW                      | 56289    | 5C13CS-CML           | 1  |
| 0160-0134   | C: Fxd Mica 220 PF 5% 300 VDCW                     | 14655    | RDM15F221J3C         | 1  |
| 0160-0153   | C: Fxd My 0.001 uF 10% 200 VDCW                    | 56289    | 192P10292-PTS        | 3  |
| 0160-0158   | C: Fxd My 0.0056 uF 10% 200 VDCW                   | 56289    | 192P56292-PTS        | 1  |
| 0160-0161   | C: Fxd My 0.01 uF 10% 200 VDCW                     | 56289    | 192P10392-PTS        | 3  |
| 0160-0162   | C: Fxd My 0.22 uF 10% 200 VDCW                     | 56289    | 192P22392-PTS        | 1  |
| 0160-0168   | C: Fxd My 0.1 uF 10% 200 VDCW                      | 56289    | 192P10492-PTS        | 3  |
| 0160-0174   | C: Fxd Cer 0.47 uF +80 -20% 25 VDCW                | 56289    | 5C11B7S-CML          | 9  |
| 0160-0194   | C: Fxd My 0.015 uF 10%                             | 56289    | 192P15392-PTS        | 5  |
| 0160-0298   | C: Fxd My 0.0015 uF 10% 200 VDCW                   | 56289    | 192P15292-PTS        | 1  |
| 0160-0303   | C: Fxd My 0.15 uF 10% 200 VDCW                     | 28480    | 0160-0303            | 2  |
| 0160-0904   | Capacitor, Fxd, Cer, 0.05 uF, 20%, 1000 VDCW       | 56289    | 169A4-CDH            | 3  |
| 0160-2055   | C: Fxd Cer 0.01 uF +80 -20% 100 VDCW               | 56289    | C023F101F103ZS22-CDH | 6  |
| 0160-2143   | C: Fxd Cer 2000 PF +80 -20% 1000 VDCW              | 91418    | Type B               | 3  |
| 0160-2940   | C: Fxd Mica 470 PF 5% 300 VDCW                     | 72136    | RDM15F471J3C         | 1  |
| 0170-0024   | C: Fxd My 0.022 uF 20% 200 VDCW                    | 56289    | 192P22302            | 2  |
| 0170-0040   | C: Fxd My 0.047 uF 10% 200 VDCW                    | 56289    | 192P47392-PTS        | 2  |
| 0180-0049   | C: Fxd Elect 20 uF +75 -10% 50 VDCW                | 56289    | 30D206G050CC2-DSM    | 4  |
| 0180-0097   | C: Fxd Tant 47 uF 10% 35 VDCW                      | 56289    | 150D476X9035S2-DYS   | 3  |
| 0180-0098   | C: Fxd Elect 100 uF 20% 20 VDCW                    | 56289    | 150D107X0020S2-DYS   | 1  |
| 0180-0100   | C: Fxd Elect 4.7 uF 10% 35 VDCW                    | 56289    | 150D475X9035B2-DYS   | 1  |
| 0180-0141   | C: Fxd Elect 50 uF +75 -10% 50 VDCW                | 56289    | 30D506G050DD2-DSM    | 4  |
| 0180-0161   | C: Fxd Elect 3.3 uF 20% 35 VDCW                    | 56289    | 150D335X0035B2-DYS   | 1  |
| 0180-0197   | C: Fxd Elect 2.2 uF 10% 20 VDCW                    | 56289    | 150D225X9020A2-DYS   | 4  |
| 0180-0228   | C: Fxd Elect 22 uF 10% 15 VDCW                     | 56289    | 150D226X9015B2-DYS   | 2  |
| 0180-0291   | C: Fxd Elect 1.0 uF 10% 35 VDCW                    | 56289    | 150D105X9035A2-DYS   | 9  |
| 0180-0376   | C: Fxd Elect 0.47 uF 10% 35 VDCW                   | 56289    | 150D474X9035A2-DYS   | 1  |
| 0180-1746   | C: Fxd Elect 15 uF 10% 20 VDCW                     | 28480    | 0180-1746            | 7  |
| 0180-1794   | C: Fxd Elect 22 uF 10% 35 VDCW                     | 56289    | 150D226X9035R2-DYS   | 1  |
| 0180-2410   | Capacitor, Fxd, Elect, 18000 uF, -10 +75%, 15 VDCW | 14659    | 602D183G015AF2A      | 2  |
| 0180-2411   | Capacitor, Fxd, Elect, 22000 uF, -10 +75%, 10 VDCW | 14659    | 602D223G010AF2A      | 1  |
| 0180-2412   | Capacitor, Fxd, Elect, 37000 uF, -10 +75%, 5 VDCW  | 14659    | 60D20D373G5R0AF2A    | 1  |
| 0180-2413   | Capacitor, Fxd, Elect, 7500 uF, -10 +75%, 15 VDCW  | 14659    | 36D752G015AA2A       | 1  |
| 0180-2414   | Capacitor, Fxd, Elect, 2900 uF, -10 +75%, 40 VDCW  | 14659    | 36D292G040AA2A       | 1  |
| 0180-2415   | C: Fxd Al Elect 200 uF +75 -10% 40 VDCW            | 56289    | 39D207G040EL4        | 1  |
| 0180-2416   | Capacitor, Fxd, Elect, 9900 uF, -10 +75%, 10 VDCW  | 14659    | 602D992G030AF2A      | 1  |
| 0180-2417   | Capacitor, Fxd, Elect, 430 uF, -10 +50%, 200 VDCW  | 14659    | 36D431F200AB2A       | 2  |
| 0180-2418   | Capacitor, Fxd, Elect, 9800 uF, -10 +75%, 100 VDCW | 14659    | 36D982G100CC2A       | 2  |
| 0683-0275   | R: Fxd Comp 2.7 ohms 5% 1/4W                       | 01121    | CB27G5               | 3  |
| 0683-8245   | R: Fxd Comp 820K ohms 5% 1/4W                      | 01121    | CB8245               | 1  |
| 0689-0275   | Resistor, Fxd, Comp, 2.7 ohms, 5%, 1W              | 01121    | GB27G5               | 1  |
| 0698-0082   | R: Fxd Met Flm 464 ohms 1% 1/8W                    | 28480    | 0698-0082            | 11 |
| 0698-0083   | R: Fxd Met Flm 1.96K ohms 1% 1/8W                  | 28480    | 0698-0083            | 1  |
| 0698-0084   | R: Fxd Met Flm 2.15K ohms 1% 1/8W                  | 28480    | 0698-0084            | 5  |
| 0698-3136   | R: Fxd Met Flm 17.8K ohms 1% 1/8W                  | 28480    | 0698-3136            | 1  |
| 0698-3150   | R: Fxd Met Flm 2.37K ohms 1% 1/8W                  | 28480    | 0698-3150            | 3  |
| 0698-3151   | R: Fxd Met Flm 2.87K ohms 1% 1/8W                  | 28480    | 0698-3151            | 1  |

■ See tables 7-2 and 7-3 for usage.

Table 6-11. Numerical Listing of Electrical Parts (Continued)

| HP PART NO. | DESCRIPTION                       | MFR CODE | MFR PART NO. | TO |
|-------------|-----------------------------------|----------|--------------|----|
| 0698-3152   | R: Fxd Met Flm 3.48K ohms 1% 1/8W | 28480    | 0698-3152    | 1  |
| 0698-3155   | R: Fxd Met Flm 4.64K ohms 1% 1/8W | 28480    | 0698-3155    | 18 |
| 0698-3156   | R: Fxd Met Flm 14.7 ohms 1% 1/8W  | 28480    | 0698-3156    | 1  |
| 0698-3157   | R: Fxd Met Flm 19.6K ohms 1% 1/8W | 28480    | 0698-3157    | 1  |
| 0698-3158   | R: Fxd Met Flm 23.7K ohms 1% 1/8W | 28480    | 0698-3158    | 4  |
| 0698-3159   | R: Fxd Met Flm 26.1K ohms 1% 1/8W | 28480    | 0698-3159    | 2  |
| 0698-3160   | R: Fxd Met Flm 31.6K ohms 1% 1/8W | 28480    | 0698-3160    | 6  |
| 0698-3161   | R: Fxd Met Flm 38.3K ohms 1% 1/8W | 28480    | 0698-3161    | 1  |
| 0698-3162   | R: Fxd Met Flm 46.4K ohms 1% 1/8W | 28480    | 0698-3162    | 13 |
| 0698-3180   | R: Fxd Met Ox 68 ohms 2% 2W       | 28480    | 0698-3180    | 3  |
| 0698-3260   | R: Fxd Met Flm 464K ohms 1% 1/8W  | 28480    | 0698-3260    | 3  |
| 0698-3266   | R: Fxd Met Flm 237K ohms 1% 1/8W  | 28480    | 0698-3266    | 1  |
| 0698-3388   | R: Fxd Met Flm 14.7 ohms 1% 1/2W  | 28480    | 0698-3388    | 1  |
| 0698-3398   | R: Fxd Met Flm 46.4 ohms 1% 1/2W  | 28480    | 0698-3398    | 1  |
| 0698-3402   | R: Fxd Met Flm 316 ohms 1% 1/2W   | 28480    | 0698-3402    | 9  |
| 0698-3410   | R: Fxd Met Flm 3.16K ohms 1% 1/2W | 28480    | 0698-3410    | 1  |
| 0698-3438   | R: Fxd Met Flm 147 ohms 1% 1/8W   | 28480    | 0698-3438    | 5  |
| 0698-3441   | R: Fxd Met Flm 215 ohms 1% 1/8W   | 28480    | 0698-3441    | 1  |
| 0698-3445   | R: Fxd Met Flm 348 ohms 1% 1/8W   | 28480    | 0698-3445    | 2  |
| 0698-3447   | R: Fxd Met Flm 422 ohms 1% 1/8W   | 28480    | 0698-3447    | 2  |
| 0698-3449   | R: Fxd Met Flm 28.7K ohms 1% 1/8W | 28480    | 0698-3449    | 1  |
| 0698-3450   | R: Fxd Met Flm 42.2K ohms 1% 1/8W | 28480    | 0698-3450    | 1  |
| 0698-3452   | R: Fxd Met Flm 147K ohms 1% 1/8W  | 28480    | 0698-3452    | 3  |
| 0698-3454   | R: Fxd Met Flm 215K ohms 1% 1/8W  | 28480    | 0698-3454    | 1  |
| 0698-3455   | R: Fxd Met Flm 216K ohms 1% 1/8W  | 28480    | 0698-3455    | 2  |
| 0698-3456   | R: Fxd Met Flm 287K ohms 1% 1/8W  | 28480    | 0698-3456    | 1  |
| 0698-3459   | R: Fxd Met Flm 383K ohms 1% 1/8W  | 28480    | 0698-3459    | 2  |
| 0698-4037   | R: Fxd Met Flm 46.4 ohms 1% 1/8W  | 28480    | 0698-4037    | 5  |
| 0698-4442   | R: Fxd Met Flm 4.42K ohms 1% 1/8W | 28480    | 0698-4442    | 1  |
| 0698-7398   | R: Fxd Flm 6.124K ohms 0.1% 1/8W  | 28480    | 0698-7398    | 2  |
| 0757-0123   | R: Fxd Met Flm 34.8K ohms 1% 1/8W | 28480    | 0757-0123    | 2  |
| 0757-0198   | R: Fxd Met Flm 100 ohms 1% 1/2W   | 28480    | 0757-0198    | 2  |
| 0757-0199   | R: Fxd Met Flm 21.5K ohms 1% 1/8W | 28480    | 0757-0199    | 7  |
| 0757-0200   | R: Fxd Met Flm 5.62K ohms 1% 1/8W | 28480    | 0757-0200    | 1  |
| 0757-0274   | R: Fxd Met Flm 1.21K ohms 1% 1/8W | 28480    | 0757-0274    | 5  |
| 0757-0279   | R: Fxd Met Flm 3.16K ohms 1% 1/8W | 28480    | 0757-0279    | 2  |
| 0757-0280   | R: Fxd Flm 1K ohms 1% 1/8W        | 28480    | 0757-0280    | 9  |
| 0757-0284   | R: Fxd Flm 150 ohms 1% 1/8W       | 28480    | 0757-0284    | 5  |
| 0757-0288   | R: Fxd Met Flm 9.09K ohms 1% 1/8W | 28480    | 0757-0288    | 1  |
| 0757-0290   | R: Fxd Met Flm 6.19K ohms 1% 1/8W | 28480    | 0757-0290    | 1  |
| 0757-0316   | R: Fxd Met Flm 42.2 ohms 1% 1/8W  | 28480    | 0757-0316    | 6  |
| 0757-0346   | R: Fxd Met Flm 10 ohms 1% 1/8W    | 28480    | 0757-0346    | 3  |
| 0757-0394   | R: Fxd Met Flm 51.1 ohms 1% 1/8W  | 28480    | 0757-0394    | 2  |
| 0757-0401   | R: Fxd Met Flm 100 ohms 1% 1/8W   | 28480    | 0757-0401    | 8  |
| 0757-0416   | R: Fxd Met Flm 511 ohms 1% 1/8W   | 28480    | 0757-0416    | 1  |
| 0757-0418   | R: Fxd Met Flm 619 ohms 1% 1/8W   | 28480    | 0757-0418    | 1  |
| 0757-0421   | R: Fxd Met Flm 825 ohms 1% 1/8W   | 28480    | 0757-0421    | 1  |
| 0757-0422   | R: Fxd Met Flm 909 ohms 1% 1/8W   | 28480    | 0757-0422    | 1  |
| 0757-0428   | R: Fxd Met Flm 1.62K ohms 1% 1/8W | 28480    | 0757-0428    | 3  |
| 0757-0438   | R: Fxd Met Flm 5.11K ohms 1% 1/8W | 28480    | 0757-0438    | 3  |



Table 6-11. Numerical Listing of Electrical Parts (Continued)

| HP PART NO. | DESCRIPTION                              | MFR CODE | MFR PART NO.  | TQ |
|-------------|--|----------|---------------|----|
| 0757-0439   | R: Fxd Met Flm 6.81K ohms 1% 1/8W        | 28480    | 0757-0439     | 1  |
| 0757-0440   | R: Fxd Met Flm 7.50K ohms 1% 1/8W        | 28480    | 0757-0440     | 4  |
| 0757-0441   | R: Fxd Met Flm 8.25K ohms 1% 1/8W        | 28480    | 0757-0441     | 2  |
| 0757-0442   | R: Fxd Met Flm 10.0K ohms 1% 1/8W        | 28480    | 0757-0442     | 19 |
| 0757-0444   | R: Fxd Met Flm 12.1K ohms 1% 1/8W        | 28480    | 0757-0444     | 1  |
| 0757-0446   | R: Fxd Met Flm 15.0K ohms 1% 1/8W        | 28480    | 0757-0446     | 7  |
| 0757-0458   | R: Fxd Met Flm 51.1K ohms 1% 1/8W        | 28480    | 0757-0458     | 1  |
| 0757-0459   | R: Fxd Met Flm 58.2K ohms 1% 1/8W        | 28480    | 0757-0459     | 10 |
| 0757-0460   | R: Fxd Met Flm 61.9K ohms 1% 1/8W        | 28480    | 0757-0460     | 2  |
| 0757-0461   | R: Fxd Met Flm 68.1K ohms 1% 1/8W        | 28480    | 0757-0461     | 4  |
| 0757-0462   | R: Fxd Met Flm 75.0K ohms 1% 1/8W        | 28480    | 0757-0462     | 2  |
| 0757-0463   | R: Fxd Met Flm 82.5K ohms 1% 1/8W        | 28480    | 0757-0463     | 1  |
| 0757-0464   | R: Fxd Met Flm 90.9K ohms 1% 1/8W        | 28480    | 0757-0464     | 1  |
| 0757-0465   | R: Fxd Met Flm 100K ohms 1% 1/8W         | 28480    | 0757-0465     | 8  |
| 0757-1078   | R: Fxd Met Flm 1.47K ohms 1% 1/2W        | 28480    | 0757-1078     | 1  |
| 0757-1094   | R: Fxd Met Flm 1.47K ohms 1% 1/8W        | 28480    | 0757-1094     | 1  |
| 0761-0021   | Resistor, Fxd, Met Ox, 1000 ohms, 5%, 1W | 28480    | 0761-0021     | 1  |
| 0764-0018   | Resistor, Fxd, Met Flm 4700 ohms, 5%, 2W | 28480    | 0764-0018     | 2  |
| 0811-1668   | R: Fxd WW 1.5 ohms 5% 2W                 | 28480    | 0811-1668     | 1  |
| 0811-3108   | Resistor, Fxd, WW, 2.0 ohms, 10%         | 20940    | R7-100        | 1  |
| 1200-0452   | Socket, Transistor                       | 91506    | 8080-1G1      | 10 |
| 1251-0232   | PC Card Connector, 44 contact            | 76530    | 251-22-30-261 | 4  |
| 1400-0084   | Fuseholder                               | 75915    | 342014        | 1  |
| 1820-0054   | IC: TTL Quad 2-Inpt Nand Gate            | 01295    | SN74004       | 1  |
| 1820-0141   | IC: TTL Quad 2-Inpt And Gate             | 28480    | 1820-0141     | 1  |
| 1820-0256   | IC: DTL Quad 2-Inpt Power Gate           | 04713    | MC858P        | 1  |
| 1820-0449   | IC: TTL Dual D F/F                       | 04713    | MC3060P       | 1  |
| 1821-0001   | Transistor Array: Si NPN                 | 02735    | CA3045        | 3  |
| 1826-0049   | IC: Voltage Regulator Programmable       | 07263    | U6A7723393    | 1  |
| 1826-0069   | IC: Linear Oper Ampl                     | 12040    | LM301AD       | 4  |
| 1826-0070   | IC: Linear Oper Ampl                     | 07263    | U6A7741393    | 13 |
| 1853-0052   | Tstr: Si PNP                             | 80131    | 2N3740        | 2  |
| 1853-0281   | Tstr: Si PNP                             | 80131    | 2N2907A       | 12 |
| 1853-0310   | Transistor, Si, PNP                      | 04713    | 2N4398        | 2  |
| 1854-0039   | Tstr: Si NPN                             | 80131    | 2N3053        | 13 |
| 1854-0072   | Tstr: Si NPN                             | 80131    | 2N3054        | 2  |
| 1854-0080   | Transistor, Si, NPN                      | 28480    | 1854-0080     | 8  |
| 1854-0477   | Tstr: Si NPN                             | 80131    | 2N2222A       | 12 |
| 1855-0050   | Tstr: Si FET Dual                        | 28480    | 1855-0050     | 1  |
| 1855-0062   | Tstr: Si FET 30V                         | 01295    | 2N1595        | 1  |
| 1884-0208   | Thyristor, 35A rms, 100V                 | 12040    | NL570A        | 2  |
| 1884-0219   | Thyristor, scr, IF, 20A, 600V            | 86684    | 40576         | 3  |
| 1901-0033   | Diode: Silicon 100 MA 180 WV             | 07263    | FD3369        | 26 |
| 1901-0040   | Diode: Silicon 30 MA 30 WV               | 07263    | FDG1088       | 9  |
| 1901-0050   | Diode: Si 200 MA 1V                      | 07263    | FDA6308       | 16 |
| 1901-0159   | Diode: Silicon 0.75A 400 PIV             | 04713    | SR1358-4      | 15 |
| 1901-0164   | Diode: Si 200 PIV 3A                     | 28480    | 1901-0164     | 6  |
| 1901-0315   | Diode, Si, 50 PIV, 40A, 150°C            | 05277    | 1N1183A       | 2  |
| 1901-0496   | Diode, Rectifier, Si                     | 04713    | SR2080-2      | 1  |
| 1901-1035   | Diode, Rectifier, 12A, 100V              | 28480    | 1901-1035     | 4  |
| 1901-1036   | Diode, Rectifier, 12A, 100V              | 04713    | MR881         | 9  |

Table 6-11. Numerical Listing of Electrical Parts (Continued)

| HP PART NO.  | DESCRIPTION                         | MFR CODE | MFR PART NO.    | TO |
|--------------|-------------------------------------|----------|-----------------|----|
| 1901-1061    | Diode, Rectifier, 12A, 600V         | 04713    | MR886           | 2  |
| 1901-1062    | Diode, Schottsky Barrier            | 04713    | MBD5400         | 8  |
| 1901-1065    | Diode: 1N4936                       | 28480    | 1901-1065       | 12 |
| 1902-0033    | Diode: Breakdown                    | 04713    | 1N823           | 2  |
| 1902-0041    | Diode: Breakdown 5.11V 5%           | 04713    | SZ10939-98      | 1  |
| 1902-0202    | Diode: Breakdown 15.0V 5% 1/8W      | 28480    | 1902-0202       | 4  |
| 1902-3139    | Diode: Breakdown 8.25V 5%           | 04713    | SZ10939-158     | 1  |
| 1902-3149    | Diode: Breakdown 9.09V 5%           | 28480    | 1902-3149       | 1  |
| 1902-3171    | Diode: Breakdown 11.0V 5%           | 28480    | 1902-3171       | 3  |
| 1902-3245    | Diode: Breakdown Silicon 21.5V 5%   | 28480    | 1902-3245       | 1  |
| 1902-3290    | Diode: Breakdown Silicon 31.6V 5%   | 28480    | 1902-3290       | 2  |
| 1902-3416    | Diode: Breakdown, 90.9V, 5%, 400W   | 07910    | CDB5982         | 2  |
| 1902-3428    | Diode: Breakdown Silicon 100V 5%    | 28480    | 1902-3428       | 2  |
| 2100-2413    | R: Var Flm 200 ohms 10% lin 1/2W    | 28480    | 2100-2413       | 1  |
| 2100-2521    | R: Var Flm 2000 ohms 10% lin 1/2W   | 28480    | 2100-2521       | 2  |
| 2100-2522    | R: Var Cermet 10 ohms 10% lin 1/2W  | 28480    | 2100-2522       | 1  |
| 2100-2574    | R: Var Cermet 500 ohms 10% lin 1/2W | 28480    | 2100-2574       | 1  |
| 2110-0004    | Fuse, 1/4A, 250V                    | 75915    | 3AC/CAT.312.250 | 1  |
| 2110-0083    | Fuse, 2-1/2A, 250V, 3 AG            | 28480    | 2110-0083       | 2  |
| 2110-0257    | Fuseholder                          | 75915    | 121001          | 4  |
| 3103-0015    | Switch, Thermal                     | 14604    | 3001            | 2  |
| 3160-0224    | Fan: Tubeaxial                      | 28480    | 3160-0224       | 2  |
| 9100-2917▲   | Inductor, 50 uH                     | 28480    | 9100-2917       | 2  |
| 9100-2918▲   | Inductor, 8 uH                      | 28480    | 9100-2918       | 1  |
| 9100-2919▲   | Inductor, 9 uH                      | 28480    | 9100-2919       | 1  |
| 9100-2920    | Inductor, Choke, 16 mH              | 28480    | 9100-2920       | 1  |
| 9100-2921    | Transformer, 8 mH                   | 28480    | 9100-2921       | 1  |
| 9100-2922    | Transformer, Control                | 28480    | 9100-2922       | 1  |
| 9100-2923    | Transformer, inverter               | 28480    | 9100-2923       | 2  |
| 9100-2924    | Transformer, Pulse                  | 28480    | 9100-2924       | 2  |
| 9100-2925    | Power Transformer                   | 28480    | 9100-2925       | 1  |
| 9100-2926★   | Inductor, 200 uH                    | 28480    | 9100-2926       | 1  |
| 9100-2927    | Transformer, Pulse                  | 28480    | 9100-2927       | 1  |
| 9100-2928    | Inductor, 4 uH                      | 76493    | 5230            | 3  |
| 9100-2931▲   | Inductor, 50 uH                     | 28480    | 9100-2931       | 2  |
| 9100-2932▲   | Inductor, 8 uH                      | 28480    | 9100-2932       | 1  |
| 9100-2933▲   | Inductor, 9 uH                      | 28480    | 9100-2933       | 1  |
| 9100-2934★   | Inductor, 200 uH                    | 28480    | 9100-2931       | 1  |
| 9140-0098    | Coil/Choke 2.20 uH 10%              | 99800    | 1537-20         | 1  |
| 9140-0131    | Coil: Fxd RF 10 MH                  | 28480    | 9140-0131       | 2  |
| 9140-0210    | Coil/Choke 100 uH 5%                | 82142    | 15-1315-12J     | 1  |
| 02100-60046▲ | Pregulator Control Card             | 28480    | 02100-60046     | 1  |
| 02100-60047▲ | Protection and Control Card         | 28480    | 02100-60047     | 1  |
| 02100-60048  | +160 Volt Output Board              | 28480    | 02100-60048     | 1  |
| 02100-60058  | Inverter Driver Card                | 28480    | 02100-60058     | 1  |
| 02100-60059  | Preregulator Driver Board           | 28480    | 02100-60059     | 1  |
| 02100-60061▲ | Current Limit Card                  | 28480    | 02100-60061     | 1  |
| 02100-60093  | Output Junction Assembly            | 28480    | 02100-60093     | 1  |
| 02100-60094  | +160 Volt Output Assembly           | 28480    | 02100-60094     | 1  |
| 02100-60095■ | Inverter Assembly                   | 28480    | 02100-60095     | 1  |
| 02100-60096  | Rear Fan Panel Assembly             | 28480    | 02100-60096     | 1  |
| 02100-60097  | Preregulator Assembly               | 28480    | 02100-60097     | 1  |
| 02100-60098  | +4.85 Volt Rectifier Assembly       | 28480    | 02100-60098     | 1  |
| 02100-60099  | Rectifier Assembly                  | 28480    | 02100-60099     | 1  |
| 02100-60108▲ | Preregulator Control Card           | 28480    | 02100-60108     | 1  |
| 02100-60109▲ | Protection and Control Card         | 28480    | 02100-60109     | 1  |
| 02100-60110▲ | Current Limit Card                  | 28480    | 02100-60110     | 1  |
| 02100-60113● | Inverter Assembly                   | 28480    | 02100-60113     | 2  |
| 02100-60114● | Inverter Assembly                   | 28480    | 02100-60114     | 1  |

NOTES: ▲ See table 6-1 for usage.

■ Used on power supply date codes 1250 and prior.

★ See table 6-7 for usage.

● Used on power supply date codes 1314 and later.

Table 6-12. Numerical Listing of Mechanical Parts

| HP PART NO. | DESCRIPTION   | MFR CODE | MFR PART NO.  | TQ  |
|-------------|---|----------|---------------|-----|
| 0340-0077   | Insulator, Feedthru                                 | 98291    | FT-1000-SL    | 9   |
| 0340-0078   | Insulator, Standoff                                 | 83330    | 93-2001       | 18  |
| 0340-0089   | Grommet, Plastic, 1/4 in. ID, 3/4 in. OD            | 28480    | 0340-0089     | 4   |
| 0360-0040   | Terminal, Lug, 1/4 in. ID                           | 00000    | OBD           | 3   |
| 0360-0042   | Terminal, Lug, No. 6                                | 00000    | OBD           | 2   |
| 0360-0220   | Terminal, Lug, No. 10                               | 00000    | OBD           | 2   |
| 0360-0268   | Terminal, Lug, No. 6                                | 00000    | OBD           | 1   |
| 0360-0270   | Terminal, Lug, No. 10                               | 00000    | OBD           | 1   |
| 0360-0271   | Terminal, Lug, 1/4 in. ID                           | 00000    | OBD           | 2   |
| 0360-1128   | Terminal Board                                      | 71785    | 353-11-09-001 | 1   |
| 0360-1529   | Stud, Terminal, Fork style                          | 71279    | 1025-4        | 15  |
| 0360-1656   | Stud, Terminal, single turret style                 | 71279    | 1457-4        | 19  |
| 0360-1699   | Terminal Board                                      | 98410    | 39007         | 1   |
| 0361-0134   | Rivet, 9/64 in. dia, 1/4 in. long                   | 00000    | OBD           | 4   |
| 0361-1032   | Rivet, Tubular, 0.121 in. OD, 0.200 in. long        | 00000    | OBD           | 4   |
| 0380-0010   | Spacer, Sleeve, 1/4 in. OD, 5/8 in. long            | 28480    | 0380-0010     | 2   |
| 0380-0091   | Spacer, Hexagon, int-thread, No. 6-32, 3/4 in. long | 28480    | 0380-0091     | 4   |
| 0390-0019   | Spacer, Sleeve, 1/4 in. long                        | 00000    | OBD           | 4   |
| 0570-1029   | Stud, threaded, 1/4 in. long                        | 00000    | OBD           | 4   |
| 0590-0077   | Nut, Self-Locking, Hexagon, No. 6-32                | 00000    | OBD           | 2   |
| 1200-0043   | Insulator Plate, Transistor                         | 71785    | 293011        | 10  |
| 1200-0080   | Insulator, Transistor Mounting                      | 76530    | 294834        | 32  |
| 1200-0088   | Insulator, Diode                                    | 76530    | 293201        | 16  |
| 1251-0013   | Fastener, Spring Tension, trim                      | 78947    | 152239        | 4   |
| 1400-0053   | Clamp, Cable  | 95987    | WC-34NA       | 4   |
| 1400-0090   | Gasket, Neoprene, 5/8 in. OD                        | 00000    | OBD           | 1   |
| 2190-0003   | Washer, Lock, split, No. 4                          | 00000    | OBD           | 14  |
| 2190-0004   | Washer, Lock, int-tooth, No. 4                      | 00000    | OBD           | 2   |
| 2190-0006   | Washer, Lock, split, No. 6                          | 00000    | OBD           | 17  |
| 2190-0034   | Washer, Lock, split, No. 6                          | 00000    | OBD           | 2   |
| 2190-0068   | Washer, Lock, int-tooth, 1/2 in. ID                 | 00000    | OBD           | 1   |
| 2190-0074   | Washer, Lock, split, No. 10                         | 00000    | OBD           | 2   |
| 2190-0077   | Washer, Lock, split, No. 10                         | 00000    | OBD           | 16  |
| 2190-0078   | Washer, Lock, split, No. 4                          | 00000    | OBD           | 2   |
| 2190-0851   | Washer, Lock, split, No. 6                          | 00000    | OBD           | 123 |
| 2200-0139   | Screw, Machine, ph, No. 4-40, 1/4 in.               | 00000    | OBD           | 2   |
| 2200-0143   | Screw, Machine, ph, No. 4-40, 3/8 in.               | 00000    | OBD           | 6   |
| 2200-0149   | Screw, Machine, ph, No. 4-40, 5/8 in.               | 00000    | OBD           | 6   |
| 2200-0155   | Screw, Machine, flh, No. 4-40, 1 in.                | 00000    | OBD           | 3   |
| 2260-0001   | Nut, Plain, Hexagon, No. 4-40                       | 00000    | OBD           | 10  |
| 2260-0002   | Nut, Plain, Hexagon, No. 4-40                       | 00000    | OBD           | 5   |
| 2360-0003   | Screw, Machine, ph, No. 6-32, 1/2 in.               | 00000    | OBD           | 2   |
| 2360-0131   | Screw, Machine, ph, No. 6-32, 1-1/8 in.             | 00000    | OBD           | 1   |
| 2360-0133   | Screw, Machine, ph, No. 4-40, 1-1/4 in.             | 00000    | OBD           | 1   |
| 2360-0190   | Screw, Machine, flh, No. 6-32, 1/4 in.              | 00000    | OBD           | 13  |
| 2360-0115   | Screw, Machine, ph, No. 6-32, 5/16 in.              | 00000    | OBD           | 20  |
| 2360-0196   | Screw, Machine, flh, No. 6-32, 3/8 in.              | 00000    | OBD           | 3   |
| 2360-0197   | Screw, Machine, ph, No. 6-32, 3/8 in.               | 00000    | OBD           | 97  |
| 2360-0200   | Screw, Machine, flh, No. 6-32, 1/2 in.              | 00000    | OBD           | 2   |
| 2360-0201   | Screw, Machine, ph, No. 6-32, 1/2 in.               | 00000    | OBD           | 2   |
| 2360-0203   | Screw, Machine, ph, No. 6-32, 5/8 in.               | 00000    | OBD           | 2   |

Table 6-12. Numerical Listing of Mechanical Parts (Continued)

| HP PART NO. | DESCRIPTION  | MFR CODE | MFR PART NO. | TQ |
|-------------|--|----------|--------------|----|
| 2360-0204   | Screw, Machine, flh, No. 6-32, 3/4 in.             | 00000    | OBD          | 1  |
| 2360-0205   | Screw, Machine, ph, No. 6-32, 3/4 in.              | 00000    | OBD          | 15 |
| 2360-0209   | Screw, Machine, flh, No. 10-32, 1 in.              | 00000    | OBD          | 4  |
| 2360-0219   | Screw, Machine, ph, No. 6-32, 1-3/8 in.            | 00000    | OBD          | 4  |
| 2420-0001   | Nut, Assembled Washer, No. 6-32                    | 00000    | OBD          | 6  |
| 2420-0002   | Nut, Plain, Hexagon, No. 6-32                      | 00000    | OBD          | 32 |
| 2420-0003   | Nut, Plain, Hexagon, No. 6-32                      | 00000    | OBD          | 8  |
| 2680-0099   | Screw, Machine, ph, No. 10-32, 3/8 in.             | 00000    | OBD          | 10 |
| 2680-0103   | Screw, Machine, ph, No. 10-32, 1/2 in.             | 00000    | OBD          | 1  |
| 2680-0128   | Screw, Machine, ph, No. 10-32, 1/4 in.             | 00000    | OBD          | 2  |
| 2740-0002   | Nut, Plain, Hexagon, No. 10-32                     | 00000    | OBD          | 9  |
| 2740-0003   | Nut, Assembled Washer, No. 10-32                   | 00000    | OBD          | 20 |
| 2950-0036   | Nut, Plain, Hexagon, 1/4-28                        | 00000    | OBD          | 7  |
| 2950-0038   | Nut, Plain, Hexagon, 1/2-24                        | 00000    | OBD          | 1  |
| 3030-0248   | Setscrew, Socket Head, No. 10-32, 3/4 in.          | 00000    | OBD          | 7  |
| 3050-0010   | Washer, Flat, No. 6                                | 00000    | OBD          | 4  |
| 3050-0225   | Washer, Flat, 1/4 in. ID                           | 00000    | OBD          | 9  |
| 3050-0226   | Washer, Flat, No. 10                               | 00000    | OBD          | 5  |
| 3050-0227   | Washer, Lock, split, No. 6                         | 00000    | OBD          | 38 |
| 3050-0228   | Washer, Flat, No. 6                                | 00000    | OBD          | 18 |
| 3050-0229   | Washer, Flat, No. 4                                | 00000    | OBD          | 32 |
| 3050-0760   | Plate, Electrical Shield, 1/8 in. ID, 1-1/4 in. OD | 28480    | 3050-0760    | 10 |
| 3050-0761   | Insulator, Neoprene, 1/8 in. ID, 1-1/4 in. OD      | 28480    | 3050-0761    | 10 |
| 5000-8015   | Guard, Fan   | 28480    | 5000-8015    | 2  |
| 5020-0096   | Terminal Board                                     | 28480    | 5020-0096    | 1  |
| 5020-0241   | Bracket  | 28480    | 5020-0241    | 2  |
| 02100-00021 | Filter, Rear                                       | 28480    | 02100-00021  | 1  |
| 02100-00140 | Insulator, Heat Sink                               | 28480    | 02100-00140  | 4  |
| 02100-00141 | Bracket, Mounting                                  | 28480    | 02100-00141  | 2  |
| 02100-00142 | Bracket, Mounting                                  | 28480    | 02100-00142  | 2  |
| 02100-00143 | Bracket, Mounting                                  | 28480    | 02100-00143  | 6  |
| 02100-00144 | Plate, Mounting                                    | 28480    | 02100-00144  | 1  |
| 02100-00145 | Panel, right side                                  | 28480    | 02100-00145  | 1  |
| 02100-00146 | Panel, left side                                   | 28480    | 02100-00146  | 1  |
| 02100-00147 | Panel, rear fan                                    | 28480    | 02100-00147  | 1  |
| 02100-00148 | Bus Bar  | 28480    | 02100-00148  | 2  |
| 02100-00149 | Bus Bar  | 28480    | 02100-00149  | 1  |
| 02100-00150 | Bus Bar  | 28480    | 02100-00150  | 3  |
| 02100-00151 | Insulator, Sheet, electrical                       | 28480    | 02100-00151  | 1  |
| 02100-00152 | Terminal Strip, Grounding                          | 28480    | 02100-00152  | 1  |
| 02100-00153 | Strap, Bus Bar                                     | 28480    | 02100-00153  | 1  |
| 02100-00154 | Bracket, Printed-Circuit Guide                     | 28480    | 02100-00154  | 1  |
| 02100-00155 | Bracket, Angle                                     | 28480    | 02100-00155  | 1  |
| 02100-00156 | Plate, Terminal Board Mounting                     | 28480    | 02100-00156  | 1  |
| 02100-00157 | Cover, Access, bottom                              | 28480    | 02100-00157  | 1  |
| 02100-00161 | Cover, Access, top                                 | 28480    | 02100-00161  | 1  |
| 02100-00164 | Cover, front                                       | 28480    | 02100-00164  | 1  |
| 02100-00165 | Bus Bar  | 28480    | 02100-00165  | 1  |
| 02100-00167 | Pad, foam rubber, 2-3/4 in. long, 2-1/2 in. wide   | 28480    | 02100-00167  | 2  |
| 02100-20045 | Mounting Block, PC Connector                       | 28480    | 02100-20045  | 2  |
| 02100-20046 | Heat Sink  | 28480    | 02100-20046  | 1  |

Table 6-12. Numerical Listing of Mechanical Parts (Continued)

| HP PART NO. | DESCRIPTION                      | MFR CODE | MFR PART NO. | TQ |
|-------------|----------------------------------|----------|--------------|----|
| 02100-20047 | Heat Sink                        | 28480    | 02100-20047  | 1  |
| 02100-20048 | Heat Sink                        | 28480    | 02100-20048  | 1  |
| 02100-20049 | Heat Sink                        | 28480    | 02100-20049  | 1  |
| 02100-20050 | Heat Sink                        | 28480    | 02100-20050  | 1  |
| 02100-20051 | Heat Sink                        | 28480    | 02100-20051  | 1  |
| 02100-20052 | Standoff, ceramic                | 28480    | 02100-20052  | 1  |
| 02100-60064 | Diode Board and Bracket Assembly | 28480    | 02100-60064  | 1  |
| 05210-4001  | Guide, Printed-Circuit           | 28480    | 05210-4001   | 2  |

Table 6-13. Reference Designations and Abbreviations

| REFERENCE DESIGNATIONS               |   |   |
|--------------------------------------|---|---|
| A = assembly                         | K = relay   | TB = terminal board                             |
| B = motor, synchro                   | L = inductor  | TP = test point                                 |
| BT = battery                         | M = meter   | U = integrated circuit, non-repairable assembly |
| C = capacitor                        | MC = microcircuit   | V = vacuum tube, photocell, etc.                |
| CB = circuit breaker                 | P = plug connector  | VR = voltage regulator                          |
| CR = diode                           | Q = semiconductor device other than diode or microcircuit   | W = cable, jumper                               |
| DL = delay line                      | R = resistor  | X = socket                                      |
| DS = indicator                       | RT = thermistor   | Y = crystal                                     |
| E = Misc electrical parts            | S = switch  | Z = tuned cavity, network                       |
| F = fuse                             | T = transformer   |   |
| FL = filter                          |   |   |
| J = receptacle connector             |   |   |
| ABBREVIATIONS                        |   |   |
| A = amperes                          | gra = gray  | ph = Phillips head                              |
| ac = alternating current             | grn = green   | pk = peak                                       |
| ad = anode                           |   | p-p = peak-to-peak                              |
| Al = aluminum                        | H = henries   | pt = point                                      |
| AR = as required                     | Hg = mercury  | PIV = peak inverse voltage                      |
| adj = adjust                         | hr = hour(s)  | PNP = positive-negative-positive                |
| assy = assembly                      | Hz = hertz  | PWV = peak working voltage                      |
|                                      | hdw = hardware  | porc = porcelain                                |
| B = base                             | hex = hexagon, hexagonal                                    | posn = position(s)                              |
| bp = bandpass                        |   | pozi = pozidrive                                |
| blk = black                          | IC = integrated circuit                                     |   |
| blu = blue                           | ID = inside diameter  |   |
| brn = brown                          | in. = inch, inches  | rf = radio frequency                            |
| brs = brass                          | I/O = input/output  | rdh = round head                                |
| Btu = British thermal unit           | int = internal  | rmo = rack mount only                           |
| Be Cu = beryllium copper             | incl = include(s)   | rms = root-mean-square                          |
|                                      | insul = insulation, insulated                               | RWV = reverse working voltage                   |
| C = collector                        | impgrg = impregnated  | rect = rectifier                                |
| cw = clockwise                       | incand = incandescent                                       | r/min = revolutions per minute                  |
| ccw = counterclockwise               |   | RTL = resistor-transistor logic                 |
| cer = ceramic                        | k = kilo (10 <sup>3</sup> ), kilohm                         |   |
| cmo = cabinet mount only             |   | s = second                                      |
| com = common                         | lp = low pass   | SB = slow blow                                  |
| crt = cathode-ray tube               |   | Se = selenium                                   |
| CTL = complementary-transistor logic | m = milli (10 <sup>-3</sup> )                               | Si = silicon                                    |
| cath = cathode                       | M = mega (10 <sup>6</sup> ), megohm                         | scr = silicon controlled rectifier              |
| cd pl = cadmium plate                | My = Mylar  | sil = silver                                    |
| Comp = composition                   | mfr = manufacturer  | sst = stainless steel                           |
| conn = connector                     | mom = momentary   | stl = steel                                     |
| compl = complete                     | mtg = mounting  | spcl = special                                  |
|                                      | misc = miscellaneous  | spdt = single-pole, double-throw                |
| dc = direct current                  | Met Ox = metal oxide  | spst = single-pole, single-throw                |
| dia = diameter                       | mintr = miniature   | semicond = semiconductor                        |
| DTL = diode-transistor logic         |   |   |
| depc = deposited carbon              | n = nano (10 <sup>-9</sup> )                                | Ta = tantalum                                   |
| dpdt = double-pole, double-throw     | n.c. = normally closed or no connection                     | td = time delay                                 |
| dpst = double-pole, single-throw     | Ne = neon   | Ti = titanium                                   |
|                                      | no. = number  | tgl = toggle                                    |
| E = emitter                          | n.o. = normally open  | thd = thread                                    |
| ECL = emitter-coupled logic          | np. = nickel plated   | tol = tolerance                                 |
| ext = external                       | NPN = negative-positive-negative                            | TTL = transistor transistor logic               |
| encap = encapsulated                 | NPO = negative-positive zero (zero temperature coefficient) |   |
| elctlt = electrolytic                | NSR = not separately replaceable                            | U(μ) = micro (10 <sup>-6</sup> )                |
|                                      | NRFR = not recommended for field replacement                | V = volt(s)                                     |
| F = farads                           |   | var = variable                                  |
| FF = flip-flop                       | OD = outside diameter                                       | vio = violet                                    |
| flh = flat head                      | OBD = order by description                                  | VDCW = direct current working volts             |
| Fim = film                           | orn = orange  |   |
| Fxd = fixed                          | ovh = oval head   | W = watts                                       |
| filh = fillister head                | oxd = oxide   | WW = wirewound                                  |
|                                      |   | wht = white                                     |
| G = giga (10 <sup>9</sup> )          | p = pico (10 <sup>-12</sup> )                               | WIV = working inverse voltage                   |
| Ge = germanium                       | PC = printed circuit  |   |
| gl = glass                           |   | yel = yellow                                    |
| gnd = ground(ed)                     |   |   |

Table 6-14. Code List of Manufacturers

| The following code numbers are from the Federal Supply Code for Manufacturers<br>Cataloging Handbooks H4-1 and H4-2, and the latest supplements. |   |                        |          |   |                    |
|--|---|------------------------|----------|---|--------------------|
| Code No.   | Manufacturer  | Address                | Code No. | Manufacturer  | Address            |
| 00779  | Amp. Inc.   | Harrisburg, Pa.        | 71279    | Cambride Thermionics Corp.  | Cambridge, Mass.   |
| 00866  | Goe Engineering Co.   | City of Industry, Cal. | 71785    | Chinch Mfg. Co., Howard B. Jones Div.                                   | Chicago, Ill.      |
| 01121  | Allen Bradley Co.   | Milwaukee, Wis.        | 72136    | Electro Motive Mfg. Co., Inc.   | Willimantic, Conn. |
| 01295  | Texas Instruments, Inc., Transistor Products Div.             | Dallas, Texas          | 74201    | Racon Corp.   | New York, N.Y.     |
| 01961  | Pulse Engineering Co.   | Santa Clara, Cal.      | 75915    | Littlefuse, Inc.  | Des Plaines, Ill.  |
| 02735  | Radio Corp. of America, Semiconductor and Materials Div.      | Somerville, N.J.       | 76493    | J.W. Miller Co.   | Los Angeles, Cal.  |
| 04713  | Motorola, Inc., Semiconductor Prod. Div.                      | Phoenix, Arizona       | 76530    | Chinch-Monadnock, Div. of United Carr Fastener Corp.                    | San Leandro, Cal.  |
| 05245  | Components Corp.  | Chicago, Ill.          | 76854    | Oak Manufacturing Co.   | Crystal Lake, Ill. |
| 05277  | Westinghouse Electric Corp., Semiconductor Dept.              | Youngwood, Pa.         | 78189    | Shakeproof Division of Illinois Tool Works                              | Elgin, Ill.        |
| 07263  | Fairchild Camera & Instr. Corp., Semiconductor Div.           | Mountain View, Cal.    | 78947    | Ucinite Co.   | Newtonville, Mass. |
| 07910  | Continental Device Corp.                                      | Hawthorne, Cal.        | 79727    | Continental-Wirt Electronics Corp.                                      | Philadelphia, Pa.  |
| 09922  | Burndy Corp.  | Norwalk, Conn.         | 79963    | Zierick Mfg. Corp.  | New Rochelle, N.Y. |
| 11237  | Chicago Telephone of California, Inc.                         | So. Pasadena, Cal.     | 80131    | Electronic Industries Association. Any brand part meeting EIA Standards | Washington, D.C.   |
| 12010  | National Semiconductor  | Danbury, Conn.         | 81640    | Controls Co. of America, Control Switch Division                        | Folcroft, Pa.      |
| 14268  | Lidco, Inc.   | Freeport, N.Y.         | 81741    | Chicago Lock Co.  | Chicago, Ill.      |
| 14433  | ITT Semiconductor, A Div. of Int. Telephone & Telegraph Corp. | West Palm Beach, Fla.  | 82142    | Jeffers Electronics, Div. of Speer Carbon Co.                           | DuBois, Pa.        |
| 14604  | Elmwood Sensors Inc.  | Cranston, R.I.         | 83330    | Smith, Herman H., Inc.  | Brooklyn, N.Y.     |
| 14655  | Cornell Dublier Electric Corp.                                | Newark, N.J.           | 86684    | Radio Corp. of America, Electronic Corp. & Devices Div.                 | Harrison, N.Y.     |
| 14659  | Sprague Electric Co.  | Visalia, Cal.          | 91418    | Radio Materials Co.   | Chicago, Ill.      |
| 19701  | Electra/Midland Corp.   | Mineral Wells, Texas   | 91506    | Augat Inc.  | Attleboro, Mass.   |
| 20940  | Micro-Ohm Corp.   | El Monte, Cal.         | 93332    | Sylvania Electric Prod. Inc., Semiconductor Div.                        | Woburn, Mass.      |
| 22421  | Tomas and Betts Ltd.  | Quebec, Canada         | 95987    | Wechesser Co.   | Chicago, Ill.      |
| 24446  | General Electric Co.  | Schenectady, N.Y.      | 98291    | Sealectro Corp.   | Mamaroneck, N.Y.   |
| 24931  | Specialty Connector Co.                                       | Indianapolis, Ind.     | 98410    | Etc, Inc.   | Cleveland, Ohio    |
| 28480  | Hewlett-Packard Co.   | Palo Alto, Cal.        | 99800    | Delevan Electronics Corp.   | East Aurora, N.Y.  |
| 49367  | Pyle-National Co.   | Chicago, Ill.          |          |   |                    |
| 56289  | Sprague Electric Co.  | North Adams, Mass.     |          |   |                    |

### 7-1. INTRODUCTION.

7-2. This section contains diagrams and tables of reference data for troubleshooting and repair of the power supply. The information consists of integrated-circuit diagrams and characteristics, wiring information, schematic diagrams, and parts information.

### 7-3. INTEGRATED CIRCUIT DIAGRAMS

7-4. The integrated circuit diagrams in figure 7-1 show each type of integrated circuit used in the power supply, together with characteristics.

### 7-5. WIRING INFORMATION.

7-6. Table 7-1 lists the point-to-point wiring between the assemblies in the power supply. The list is in alphanumeric order of reference designations. Each connection is listed twice to enable determining leadwire terminations from either end of the leadwire. For example, the blue leadwire from A5E41 to XA3-16 is also listed as from XA3-16 to A5E41.

7-7. The wiring diagram, figure 7-2, supports table 7-1 by identifying the power supply assemblies and their connecting points.

### 7-8. REPLACEABLE PARTS LISTS.

7-9. Table 7-2 is the replaceable parts list for power supplies having date codes prior to 1240.

7-10. Tables 7-3 through 7-5 are the replaceable parts lists for the new version of A1, A3, and A4 plug-in cards used in power supplies having date codes 1240 and higher. Use table 7-2 for replaceable parts for A2 plug-in card and for all other assemblies.

7-11. Tables 7-2 and 7-3 are included in this section to supplement the parts location and schematic diagrams. Section VI provides a complete list of replaceable parts for the power supply, descriptions of the table columns, and parts ordering information.

7-12. Parts in tables 7-2 and 7-3 are listed by complete reference designation and include an HP part number, quantity, description, manufacturer's code, and manufacturer's part number. The total quantity of a part used is listed with the first entry for that part number.

### 7-13. PARTS LOCATION AND SCHEMATIC DIAGRAMS.

7-14. Figure 7-3, sheets 1 through 4, are the parts location and schematic diagrams for power supplies having date codes prior to 1240.

7-15. Figure 7-4, sheets 1 through 4, are the parts location and schematic diagrams for power supplies having date codes 1240 and higher.

7-16. The parts location diagram for each card is located adjacent to the schematic diagram and shows the location and appearance of the electrical parts on each card. The parts location diagrams for the other assemblies are located on figure 7-2. The parts are identified by the reference designations used on the schematic diagrams. The card part number and identification code is shown on the parts location diagram as it is marked on the card itself. Refer to paragraph 1-36 for a description of the identification code.

7-17. The schematic diagrams use either conventional schematic symbols or logic symbols. The logic symbols are described in the Logic Symbolism section of the 2100A Computer Diagrams Manual, part no. 02100-90003.






Figure 7-1. Integrated Circuit Diagrams and Characteristics

Table 7-1. Point-to-Point Wiring List

| FROM    | TO       | COLOR       | FROM     | TO       | COLOR       |
|---------|----------|-------------|----------|----------|-------------|
| A5E41   | XA3-16   | blu         | A7Q3-C   | A5E50    | red         |
| A5E42   | XA3-13   | red         | A7Q3-E   | A7Q4-C   | bare        |
| A5E43   | XA3-11   | grn         | A7Q3-E   | A7T1*    | yel         |
| A5E44   | A10E26   | wht-yel     | A7Q4-B   | A7T1*    | grn         |
| A5E45   | A10E27   | wht-grn     | A7Q4-C   | A7Q3-E   | bare        |
| A5E46   | A10E24   | wht         | A7Q4-C   | T3-10    | grn         |
| A5E47   | A10E25   | blk         | A7Q4-E   | A7T1*    | blk-gra     |
| A5E48   | C20-     | wht-vio     | A7Q4-E   | C19-     | wht-vio     |
| A5E49   | A6E3     | wht-blu-gra | A7Q4-E   | A7T1*    | blk-red     |
| A5E50   | A7Q3-C   | red         | A7Q5-B   | A7Q6-E   | bare        |
| A5E51   | L9*      | blu         | A7Q5-C   | T3-11    | wht-grn     |
| A5E51   | T6*      | blu         | A7Q5-C   | A7T1*    | red         |
| A5E52   | C19+     | wht-orn-gra | A7Q5-E   | A7T1*    | wht         |
| A5E53   | T6*      | blk-red*    | A7Q6-B   | A7Q5-C   | bare        |
| A5E54   | A7Q7-C   | orn         | A7Q6-E   | A7T1*    | wht-blk     |
| A6CR1-A | A6E4     | wht         | A7Q7-B   | A7T2*    | wht         |
| A6CR1-A | A6Q1-A   | wht         | A7Q7-C   | A5E54    | orn         |
| A6CR1-C | A6E2     | wht-red-gra | A7Q7-E   | A7Q8-C   | bare        |
| A6CR1-C | A6CR2-A  | wht-red-gra | A7Q7-E   | A7T2*    | wht-blk     |
| A6CR2-A | A6CR1-C  | wht-red-gra | A7Q8-B   | A7T2*    | blk-red     |
| A6CR2-C | A6E6     | wht-gra     | A7Q8-C   | A7Q7-E   | bare        |
| A6CR2-C | A6Q2-C   | wht-gra     | A7Q8-C   | T4-10    | grn         |
| A6CR2-C | T6*      | blk         | A7Q8-E   | A7T2*    | red         |
| A6E1    | A6Q2-A   | gra         | A7Q9-B   | A7T2*    | grn         |
| A6E2    | A6CR1-C  | wht-red-gra | A7Q9-C   | A7Q10-E  | bare        |
| A6E3    | A5E49    | wht-blu-gra | A7Q9-C   | T4-11    | wht-grn     |
| A6E4    | A6CR1-A  | wht         | A7Q9-E   | A7T2*    | blk-grn     |
| A6E6    | A6CR2-C  | wht-gra     | A7Q10-B  | A7T2*    | blk-yel     |
| A6E7    | XA1-20   | wht-blk-grn | A7Q10-E  | A7T2*    | yel         |
| A6E8    | XA1-21   | red         | A7T1*    | A7E39    | blk         |
| A6E9    | XA1-19   | blu         | A7T1*    | A7Q4-E   | blk-grn     |
| A6E10   | A6Q1-G   | wht         | A7T1*    | A7Q5-B   | blk-red     |
| A6E11   | A6Q1-C   | gra         | A7T1*    | A7Q3-B   | blk-yel     |
| A6E12   | A6Q2-C   | wht-gra     | A7T1*    | A7E40    | gra         |
| A6E13   | A6Q2-G   | wht         | A7T1*    | A7Q4-B   | grn         |
| A6Q1-A  | A6CR1-A  | wht         | A7T1*    | A7Q5-E   | red         |
| A6Q1-A  | T6*      | wht         | A7T1*    | A7Q6-B   | wht         |
| A6Q1-C  | A6E11    | gra         | A7T1*    | A7Q6-E   | wht-blk     |
| A6Q1-C  | A6Q2-A   | gra         | A7T2*    | A7Q3-E   | yel         |
| A6Q1-G  | A6E10    | wht         | A7T2*    | A7E38    | blk         |
| A6Q2-A  | A6E1     | gra         | A7T2*    | A7Q9-E   | blk-grn     |
| A6Q2-A  | A6Q1-C   | gra         | A7T2*    | A7Q8-B   | blk-red     |
| A6Q2-C  | A6E12    | wht-gra     | A7T2*    | A7Q10-B  | blk-yel     |
| A6Q2-C  | A6CR2-C  | wht-gra     | A7T2*    | A7E37    | gra         |
| A6Q2-G  | A6E13    | wht         | A7T2*    | A7Q9-B   | grn         |
| A6S1-1  | A9S2-2   | wht         | A7T2*    | A7Q8-E   | red         |
| A6S1-2  | TB2-8    | brn         | A7T2*    | A7Q7-B   | wht         |
| A7E37   | A7T2*    | gra         | A7T2*    | A7Q7-E   | wht-blk     |
| A7E37   | XA2-14,R | wht         | A7T2*    | A7Q10-E  | grn         |
| A7E38   | A7T2*    | blk         | A8CR19-A | T3-6     | wht-yel-grn |
| A7E38   | XA2-17,U | wht-blk-blu | A8CR20-A | T3-9     | wht-yel-blu |
| A7E39   | A7T1*    | blk         | A8CR21-A | T4-6     | wht-red-yel |
| A7E39   | XA2-20,X | wht-blk-yel | A8CR22-A | T4-9     | wht-brn-yel |
| A7E40   | A7T1*    | gra         | A8CR23-A | **       | **          |
| A7E40   | XA2-21,Y | wht         | A8CR23-A | T3-7     | wht         |
| A7Q3-B  | A7T1*    | blk-yel     | A8CR24-A | A8CR32-C | **          |
|         |          |             | A8CR24-A | T3-8     | yel         |
|         |          |             | A8CR25-A | A8CR33-C | **          |
|         |          |             | A8CR25-A | T4-7     | wht-yel     |

\* Indicates leadwire is part of component.

\*\* Denotes insulating tubing over bare leadwire.

Table 7-1. Point-to-Point Wiring List (Continued)

| FROM      | TO        | COLOR       | FROM     | TO        | COLOR       |
|-----------|-----------|-------------|----------|-----------|-------------|
| A8CR26-A  | A8CR34-C  | **          | A11E28   | A8E20     | brn         |
| A8CR26-A  | T4-8      | brn         | A11E29   | C16+      | red         |
| A8CR27-A  | E66       | blu         | A11E30   | E60       | blk         |
| A8CR27-C  | T3-2      | vio         | A11E31   | A11Q14-E  | wht-brn-yel |
| A8CR28-A  | E66       | blu         | A11E32   | A11E35    | wht-red-yel |
| A8CR28-C  | T3-4      | orn         | A11E32   | A11L4*    | brn         |
| A8CR29-A  | E66       | blu         | A11E33   | A11E36    | wht-grn     |
| A8CR29-C  | T4-2      | orn         | A11E34   | A11L4*    | red         |
| A8CR30-A  | E66       | blu         | A11E34   | XA2-3     | wht-red-orn |
| A8CR30-C  | T4-4      | vio         | A11E35   | A11E32    | wht-red-yel |
| A8CR31-C  | A8CR23-A  | **          | A11E35   | XA4-W     | wht-red-yel |
| A8CR32-C  | A8CR24-A  | **          | A11E36   | A11CR41-A | bare        |
| A8CR33-C  | A8CR25-A  | **          | A11E36   | A11E33    | wht-grn     |
| A8CR34-C  | A8CR26-A  | **          | A11L4*   | A11E32    | brn         |
| A8E14     | A8E16     | **          | A11L4*   | A11Q14-C  | orn         |
| A8E15     | A8E17     | **          | A11L4*   | A11E34    | red         |
| A8E15     | A8E18     | wht-brn-vio | A11Q13-B | XA2-13,P  | wht-blk-grn |
| A8E16     | A8E14     | **          | A11Q13-C | A8E19     | wht-red-vio |
| A8E16     | A8E19     | wht-red-vio | A11Q13-C | XA4-8,J   | wht-red-vio |
| A8E17     | A8E15     | **          | A11Q13-E | XA2-19,W  | wht-orn-blu |
| A8E18     | A8E15     | wht-brn-vio | A11Q14-B | XA2-C     | wht-brn-grn |
| A8E18     | XA1-16,T  | wht-brn-vio | A11Q14-C | XA2-E     | wht-red-blu |
| A8E19     | A8E16     | wht-red-vio | A11Q14-C | A11L4*    | orn         |
| A8E19     | A11Q13-C  | wht-red-vio | A11Q14-C | A11CR41-C | bare        |
| A8E20     | A11E28    | brn         | A11Q14-E | XA2-5     | wht-brn-yel |
| A8E20     | XA4-5,E   | brn         | A11Q14-E | A11E31    | wht-brn-yel |
| A8E21     | L5*       | yel         | B1-J1    | TB3-5     | blk         |
| A8E21     | XA4-2,B   | wht-red-grn | B1-J1    | TB3-6     | blk         |
| A8E22     | L6*       | yel         | B2-J1    | TB3-5     | blk         |
| A8E22     | XA4-H     | wht-orn-grn | B2-J1    | TB3-6     | blk         |
| A9CR35-A  | T3-5      | blu         | C16+     | A11E29    | red         |
| A9CR36-A  | T3-1      | blu         | C16+     | TB1-1     | blu         |
| A9CR37-A  | T4-1      | blu         | C16-     | E55       | bus         |
| A9CR38-A  | T4-5      | blu         | C19+     | C20+      | bus         |
| A9E23     | XA4-21,Y  | wht-red-blu | C19+     | L9*       | red         |
| A9E23     | L7*       | blk         | C19+     | A5E52     | wht-orn-gra |
| A9S2-1    | XA4-L     | wht-brn     | C19-     | C20,-     | bus         |
| A9S2-2    | A6S1-1    | wht-brn     | C19-     | T6*       | yel         |
| A10CR39-A | A10CR40-C | blk         | C19-     | A7Q4-E    | wht-vio     |
| A10CR39-C | A10Q12-A  | bare        | C20+     | C19+      | bus         |
| A10CR39-C | TB1-1     | red         | C19-     | C19-      | bus         |
| A10CR40-A | A10Q12-C  | bare        | C20-     | A5E48     | wht-vio     |
| A10CR40-C | A10CR39-A | blk         | C21+     | XA1-6,F   | wht-brn-red |
| A10CR40-C | E60       | blk         | C21+     | TB3-10    | wht-brn-red |
| A10E24    | A10Q12-C  | bare        | C21-     | E65       | blk         |
| A10E24    | TB2-1     | wht-grn     | C21-     | T5*       | blk         |
| A10E24    | A5E46     | wht         | C22+     | XA1-5,E   | wht-brn-orn |
| A10E25    | A5E47     | blk         | C22+     | TB3-8     | wht-brn-orn |
| A10E26    | A10Q11-C  | bare        | C22-     | E65       | bus         |
| A10E26    | TB1-3     | vio         | C23+     | L5*       | yel         |
| A10E26    | A5E44     | wht-yel     | C23+     | TB2-3     | wht-red     |
| A10E27    | A5E45     | wht-grn     | C23-     | E63       | bus         |
| A10Q11-A  | TB1-5     | brn         | C24+     | L7*       | blk         |
| A10Q11-C  | A10E26    | bare        | C24+     | TB1-4     | blu         |
| A10Q12-A  | A10CR39-C | bare        | C24+     | TB1-5     | blu         |
| A10Q12-C  | A10E24    | bare        | C24-     | E56       | bus         |
| A10Q12-C  | A10CR40-A | bare        | C25+     | E57       | bus         |
| A11CR41-A | A11E36    | bare        | C25-     | L8*       | grn         |
| A11CR41-C | A11Q14-C  | bare        | C25-     | TB1-2     | blu         |

\* Indicates leadwire is part of component.

\*\* Denotes insulating tubing over bare leadwire.

Table 7-1. Point-to-Point Wiring List (Continued)

| FROM  | TO        | COLOR       | FROM   | TO       | COLOR       |
|-------|-----------|-------------|--------|----------|-------------|
| C25-  | TB1-3     | blu         | TB2-3  | C23+     | wht-red     |
| C26+  | E64       | bus         | TB2-4  | XF5-2    | wht-orn     |
| C26-  | TB2-2     | wht-vio     | TB2-5  | XA3-E,5  | wht-blk-brn |
| C26-  | L6*       | yel         | TB2-6  | XA1-N,12 | wht-blu     |
| E55   | C16-      | bus         | TB2-7  | XA2-H    | wht-yel     |
| E56   | C24-      | bus         | TB2-8  | A6S1-2   | wht-brn     |
| E57   | C25+      | bus         | TB2-9  | XA2-7    | wht-blk     |
| E58   | TB1-7     | blu         | TB3-1  | T5*      | red         |
| E58   | TB1-6     | blu         | TB3-1  | XA1-3,C  | wht-grn-blu |
| E59   | T3-3      | wht-blu     | TB3-2  | T5*      | blk-red     |
| E60   | A10CR40-C | blk         | TB3-2  | XA1-2,B  | wht-grn-vio |
| E60   | A11E30    | blk         | TB3-3  | T5*      | grn-blk     |
| E60   | XA3-22,Z  | blk         | TB3-4  | T5*      | grn         |
| E60   | XA4-A,1   | blk         | TB3-5  | T5*      | yel         |
| E60   | XA4-22,Z  | blk         | TB3-5  | B1-J1    | blk         |
| E61   | XA1-8,J   | blk         | TB3-5  | B2-J1    | blk         |
| E61   | XA1-22,Z  | blk         | TB3-6  | T5*      | yel-blk     |
| E61   | XA2-11,M  | blk         | TB3-6  | B1-J1    | blk         |
| E61   | XA2-22,Z  | blk         | TB3-6  | B2-J1    | blk         |
| E62   | T4-3      | wht-blu     | TB3-8  | C22+     | wht-brn-orn |
| E63   | C23-      | bus         | TB3-10 | C21+     | wht-brn-red |
| E64   | C26+      | bus         | TB3-11 | T5*      | blu-wht     |
| E65   | C21-      | bus         | TB3-12 | T5*      | blu         |
| E65   | C22-      | bus         | T3-1   | A9CR36-A | blu         |
| E66   | A8CR27-A  | blu         | T3-2   | A8CR27-C | vio         |
| E66   | A8CR28-A  | blu         | T3-3   | E59      | wht         |
| E66   | A8CR29-A  | blu         | T3-4   | A8CR28-C | orn         |
| E66   | A8CR30-A  | blu         | T3-5   | A9CR35-A | blu         |
| E66   | L8*       | grn         | T3-6   | A8CR19-A | wht-yel-grn |
| E66   | XA4-13,P  | wht-orn-yel | T3-7   | A8CR23-A | wht         |
| L5*   | A8E21     | yel         | T3-8   | A8CR24-A | yel         |
| L5*   | C23+      | yel         | T3-9   | A8CR20-A | wht-yel-blu |
| L6*   | A8E22     | yel         | T3-10  | A7Q4-C   | grn         |
| L6*   | C26-      | yel         | T3-11  | A7Q5-C   | wht-grn     |
| L7*   | A9E23     | blk         | T4-1   | A9CR37-A | blu         |
| L7*   | C24+      | blk         | T4-2   | A8CR29-C | vio         |
| L8*   | C25-      | grn         | T4-3   | E62      | wht         |
| L8*   | E66       | grn         | T4-4   | A8CR30-C | orn         |
| L9*   | A5E51     | blu         | T4-5   | A9CR38-A | blu         |
| L9*   | C19+      | red         | T4-6   | A8CR21-A | wht-red-yel |
| TB1-1 | C16+      | blu         | T4-7   | A8CR25-A | wht-yel     |
| TB1-1 | XA2-F,6   | red         | T4-8   | A8CR26-A | brn         |
| TB1-1 | A10CR39-C | red         | T4-9   | A8CR22-A | wht-brn-yel |
| TB1-2 | C25-      | blu         | T4-10  | A7Q8-C   | grn         |
| TB1-3 | C25-      | blu         | T4-11  | A7Q9-C   | wht-grn     |
| TB1-3 | XA4-M,11  | vio         | T5*    | C21-     | blk         |
| TB1-3 | A10E26    | vio         | T5*    | TB3-2    | blk-red     |
| TB1-4 | C24+      | blu         | T5*    | TB3-12   | blu         |
| TB1-4 | XA3-Y,21  | orn         | T5*    | TB3-11   | wht-blu     |
| TB1-5 | C24+      | blu         | T5*    | TB3-4    | grn         |
| TB1-5 | A10Q11-A  | orn         | T5*    | TB3-3    | blk-grn     |
| TB1-5 | XA4-X,20  | orn         | T5*    | TB3-1    | red         |
| TB1-6 | E58       | blu         | T5*    | TB3-5    | yel         |
| TB1-7 | E58       | blu         | T5*    | TB3-6    | blk-yel     |
| TB2-1 | XA2-10,L  | wht-grn     | T6*    | A6CR1-C  | blk         |
| TB2-1 | A10E24    | wht-grn     |        |          |             |
| TB2-2 | XA3-H,7   | wht-vio     |        |          |             |
| TB2-2 | C26-      | wht-vio     |        |          |             |
| TB2-3 | XA4-C,3   | wht-red     |        |          |             |

\*Indicates leadwire is part of component.

\*\*Denotes insulating tubing over bare leadwire.

Table 7-1. Point-to-Point Wiring List (Continued)

| FROM     | TO       | COLOR       | FROM     | TO       | COLOR       |
|----------|----------|-------------|----------|----------|-------------|
| T6*      | A5E53    | blk-red     | XA2-X,20 | A7E39    | wht-blk-yel |
| T6*      | A5E51    | blu         | XA2-Y,21 | A7E40    | wht         |
| T6*      | A6Q1-A   | wht         | XA2-Z,22 | E61      | blk         |
| T6*      | C19-     | yel         | XA2-3    | A11E34   | wht-red-orn |
| XA1-A,1  | XA2-A,1  | bare        | XA2-5    | A11Q14-E | wht-brn-yel |
| XA1-B,2  | TB3-2    | wht-grn-vio | XA2-7    | TB2-9    | wht-blk     |
| XA1-B,2  | XA3-2    | wht-grn-vio | XA3-A,1  | XA2-A,1  | bare        |
| XA1-C,3  | TB3-1    | wht-grn-blu | XA3-A,1  | XA4-A,1  | bare        |
| XA1-C,3  | XA3-6    | wht-grn-blu | XA3-B    | XA1-11,M | blu         |
| XA1-D,4  | XA2-D,4  | bare        | XA3-C,3  | XA4-C,3  | bare        |
| XA1-E,5  | C22+     | wht-brn-orn | XA3-C,3  | XA1-H,7  | wht-red     |
| XA1-E,5  | XA2-16,T | wht-brn-orn | XA3-D,4  | XA2-D,4  | bare        |
| XA1-F,6  | C21+     | wht-brn-red | XA3-D,4  | XA4-D,4  | bare        |
| XA1-H,7  | XA3-C,3  | wht-red     | XA3-E,5  | TB2-5    | wht-blk-brn |
| XA1-J,8  | E61      | blk         | XA3-F    | XA1-13,P | wht         |
| XA1-K,9  | XA2-K,9  | bare        | XA3-H,7  | XA4-7    | bare        |
| XA1-L,10 | XA2-L,10 | bare        | XA3-H,7  | TB2-2    | wht-vio     |
| XA1-M,11 | XA3-B    | blu         | XA3-J,8  | XA2-J,8  | bare        |
| XA1-N,12 | XA2-N,12 | bare        | XA3-J,8  | XA4-J,8  | bare        |
| XA1-N,12 | TB2-6    | wht-blu     | XA3-K,9  | XA2-K,9  | bare        |
| XA1-P,13 | XA3-F    | wht         | XA3-K,9  | XA4-K,9  | bare        |
| XA1-R    | XA4-6,F  | yel         | XA3-L,10 | XA4-10   | bare        |
| XA1-S,15 | XA2-S,15 | bare        | XA3-M    | XA4-M,11 | bare        |
| XA1-T,16 | A8E18    | wht-brn-vio | XA3-N,12 | XA2-N,12 | bare        |
| XA1-V,18 | XA2-V,18 | bare        | XA3-N,12 | XA4-N,12 | bare        |
| XA1-X    | XA3-20   | brn         | XA3-R,14 | XA4-R,14 | bare        |
| XA1-Z,22 | E61      | blk         | XA3-S,15 | XA2-S,15 | bare        |
| XA1-19   | A6E9     | blu         | XA3-U,17 | XA4-U,17 | bare        |
| XA1-20   | A6E7     | wht-blk-grn | XA3-V,18 | XA2-V,18 | bare        |
| XA1-21   | A6E8     | red         | XA3-V,18 | XA4-V,18 | bare        |
| XA2-A,1  | XA1-A,1  | bare        | XA3-W,19 | XA4-W,19 | bare        |
| XA2-A,1  | XA3-A,1  | bare        | XA3-W,19 | XA2-6,F  | red         |
| XA2-B,2  | XA4-16   | wht         | XA3-X    | XA4-X,20 | bare        |
| XA2-C    | A11Q14-B | wht-brn-grn | XA3-Y,21 | TB1-5    | orn         |
| XA2-D,4  | XA1-D,4  | bare        | XA3-Z,22 | E60      | blk         |
| XA2-D,4  | XA3-D,4  | bare        | XA3-2    | XA1-2,B  | wht-grn-vio |
| XA2-E    | A11Q14-C | wht-brn-blu | XA3-6    | XA1-3,C  | wht-grn-blu |
| XA2-F,6  | XA3-W    | red         | XA3-11   | A5E43    | grn         |
| XA2-F,6  | TB1-1    | red         | XA3-13   | A5E42    | red         |
| XA2-H    | TB2-7    | wht-yel     | XA3-16   | A5E41    | blu         |
| XA2-J,8  | XA3-J,8  | bare        | XA3-20   | XA1-X    | brn         |
| XA2-K,9  | XA1-K,9  | bare        | XA4-A,1  | XA3-A,1  | bare        |
| XA2-K,9  | XA3-K,9  | bare        | XA4-A,1  | E60      | blk         |
| XA2-L,10 | XA1-L,10 | bare        | XA4-B,2  | A8E21    | wht-red-grn |
| XA2-L,10 | TB2-1    | wht-grn     | XA4-C,3  | XA3-C,3  | bare        |
| XA2-L,10 | XA4-R,14 | wht-grn     | XA4-C,3  | TB2-3    | wht-red     |
| XA2-M,11 | E61      | blk         | XA4-D,4  | XA3-D,4  | bare        |
| XA2-N,12 | XA1-N,12 | bare        | XA4-E,5  | A8E20    | brn         |
| XA2-N,12 | XA3-N,12 | bare        | XA4-E,5  | XF5-1    | brn         |
| XA2-P,13 | A11Q13-B | wht-blk-grn | XA4-F,6  | XA1-R    | yel         |
| XA2-R,14 | A7E37    | wht         | XA4-H    | A8E22    | wht-orn-grn |
| XA2-S,15 | XA1-S,15 | bare        | XA4-J,8  | XA3-J,8  | bare        |
| XA2-S,15 | XA3-S,15 | bare        | XA4-J,8  | A11Q13-C | wht-red-vio |
| XA2-T,16 | XA1-5,E  | wht-brn-orn | XA4-K,9  | XA3-K,9  | bare        |
| XA2-U,17 | A7E38    | wht-blk-blu | XA4-L    | A9S2-1   | wht-brn     |
| XA2-V,18 | XA1-V,18 | bare        | XA4-M,11 | XA3-M    | bare        |
| XA2-V,18 | XA3-V,18 | bare        | XA4-N,12 | TB1-3    | vio         |
| XA2-W,19 | A11Q13-E | wht-orn-blu | XA4-N,12 | XA3-N,12 | bare        |
| XA2-W,19 | XA4-S    | wht-orn-blu | XA4-P,13 | E66      | wht-orn-yel |



\*Indicates leadwire is part of component.

Power Supply




Table 7-1. Point-to-Point Wiring List (Continued)

| FROM     | TO       | COLOR       | FROM     | TO       | COLOR       |
|----------|----------|-------------|----------|----------|-------------|
| XA4-R,14 | XA3-R,14 | bare        | XA4-Y,21 | A9E23    | wht-red-blu |
| XA4-R,14 | XA2-10,L | wht-brn     | XA4-Z,22 | E60      | blk         |
| XA4-S    | XA2-19,W | wht-orn-blu | XA4-7    | XA3-H,7  | bare        |
| XA4-U,17 | XA3-U,17 | bare        | XA4-10   | XA3-L,10 | bare        |
| XA4-V,18 | XA3-V,18 | bare        | XA4-16   | XA2-B,2  | wht         |
| XA4-W    | A11E35   | wht-red-yel | XA4-19   | XA3-W,19 | bare        |
| XA4-X,20 | XA3-X,20 | bare        | XF5-1    | XA4-E,5  | brn         |
| XA4-X,20 | TB1-5    | orn         | XF5-2    | TB2-4    | wht-orn     |


LEFT SIDE PANEL










NOTE: A11L1 AND A11L3 ARE REPLACED WITH JUMPER WIRES STARTING WITH POWER SUPPLY DATE CODE 1229.



REAR PANEL



RIGHT SIDE PANEL






Figure 7-2. Power Supply, Wiring Diagram



Table 7-2. Power Supply, Replaceable Parts

| Reference Designation | HP Part Number | Qty | Description                          | Mfr Code | Mfr Part Number      |
|-----------------------|----------------|-----|--------------------------------------|----------|----------------------|
| A1                    | 02100-60046    | 1   | PREREGULATOR CONTROL CARD            | 28480    | 02100-60046          |
| A1C1(NOTE 1)          | 0180-1794      | 1   | C:FXD ELECT 22 UF 10% 35VDCW         | 56289    | 150D226X9035R2-DYS   |
| A1C1(NOTE 2)          | 0180-0228      | 2   | C:FXD ELECT 22 UF 10% 15VDCW         | 56289    | 150D226X9015B2-DYS   |
| A1C2                  | 0180-0097      | 3   | C:FXD TANT. 47 UF 10% 35VDCW         | 56289    | 150D476X9035S2-DYS   |
| A1C3                  | 0170-0040      | 2   | C:FXD MY 0.047 UF 10% 200VDCW        | 56289    | 192P47392-PTS        |
| A1C4                  | 0160-0162      | 1   | C:FXD MY 0.022 UF 10% 200VDCW        | 56289    | 192P22392-PTS        |
| A1C5                  | 0160-2055      | 6   | C:FXD CER 0.01 UF +80-20% 100VDCW    | 56289    | C023F101F103ZS22-CDH |
| A1C6                  | 0160-2055      |     | C:FXD CER 0.01 UF +80-20% 100VDCW    | 56289    | C023F101F103ZS22-CDH |
| A1C7                  | 0180-0197      | 4   | C:FXD ELECT 2.2 UF 10% 20VDCW        | 56289    | 150D225X9020A2-DYS   |
| A1C8                  | 0180-0291      | 9   | C:FXD ELECT 1.0 UF 10% 35VDCW        | 56289    | 150D105X9035A2-DYS   |
| A1C9                  | 0160-0158      | 1   | C:FXD MY 0.0056 UF 10% 200VDCW       | 56289    | 192P56292-PTS        |
| A1C10                 | 0150-0096      | 5   | C:FXD CER 0.05 UF +80-20% 100VDCW    | 91418    | TA                   |
| A1C11                 | 0150-0121      | 5   | C:FXD CER 0.1 UF +80-20% 50VDCW      | 56289    | 5C508IS-CML          |
| A1C12                 | 0180-0291      |     | C:FXD ELECT 1.0 UF 10% 35VDCW        | 56289    | 150D105X9035A2-DYS   |
| A1C13                 | 0160-0161      | 3   | C:FXD MY 0.01 UF 10% 200VDCW         | 56289    | 192P10392-PTS        |
| A1C14                 | 0150-0096      |     | C:FXD CER 0.05 UF +80-20% 100VDCW    | 91418    | TA                   |
| A1C15                 | 0150-0096      |     | C:FXD CER 0.05 UF +80-20% 100VDCW    | 91418    | TA                   |
| A1C16                 | 0150-0096      |     | C:FXD CER 0.05 UF +80-20% 100VDCW    | 91418    | TA                   |
| A1C17                 | 0150-0096      |     | C:FXD CER 0.05 UF +80-20% 100VDCW    | 91418    | TA                   |
| A1C18                 | 0180-0100      | 1   | C:FXD ELECT 4.7 UF 10% 35VDCW        | 56289    | 150D475X9035B2-DYS   |
| A1C19                 | 0180-0161      | 1   | C:FXD ELECT 3.3 UF 20% 35VDCW        | 56289    | 150D335X0035B2-DYS   |
| A1C20                 | 0160-2940      | 1   | C:FXD MICA 470 PF 5% 300VDCW         | 72136    | RD1M15F471J3C        |
| A1C21                 | 0180-0197      |     | C:FXD ELECT 2.2 UF 10% 20VDCW        | 56289    | 150D225X9020A2-DYS   |
| A1C22                 | 0180-0197      |     | C:FXD ELECT 2.2 UF 10% 20VDCW        | 56289    | 150D225X9020A2-DYS   |
| A1C23                 | 0160-0153      | 3   | C:FXD MY 0.001 UF 10% 200VDCW        | 56289    | 192P10292-PTS        |
| A1C24                 | 0160-0153      |     | C:FXD MY 0.001 UF 10% 200VDCW        | 56289    | 192P10292-PTS        |
| A1C25                 | 0160-0153      |     | C:FXD MY 0.001 UF 10% 200VDCW        | 56289    | 192P10292-PTS        |
| A1C26                 | 0180-0197      |     | C:FXD ELECT 2.2 UF 10% 20VDCW        | 56289    | 150D225X9020A2-DYS   |
| A1C27                 | 0180-2415      | 1   | C:FXD AL ELECT 200 UF +75-10% 40VDCW | 56289    | 39D207G04OEL4        |
| A1CR1                 | 1901-0040      | 9   | DIODE:SILICON 30MA 30WV              | 07263    | FDG1088              |
| A1CR2                 | 1901-0040      |     | DIODE:SILICON 30MA 30WV              | 07263    | FDG1088              |
| A1CR3                 | 1901-0040      |     | DIODE:SILICON 30MA 30WV              | 07263    | FDG1088              |
| A1CR4                 | 1901-0159      | 15  | DIODE:SILICON 0.75A 400PIV           | 04713    | SR1358-4             |
| A1CR5                 | 1901-0040      |     | DIODE:SILICON 30MA 30WV              | 07263    | FDG1088              |
| A1CR6                 | 1901-0040      |     | DIODE:SILICON 30MA 30WV              | 07263    | FDG1088              |
| A1CR7                 | 1902-3171      | 3   | DIODE BREAKDOWN:11.0V 5%             | 28480    | 1902-3171            |
| A1CR8                 | 1901-0040      |     | DIODE:SILICON 30MA 30WV              | 07263    | FDG1088              |
| A1CR9                 | 1901-0040      |     | DIODE:SILICON 30MA 30WV              | 07263    | FDG1088              |
| A1CR10                | 1901-0040      |     | DIODE:SILICON 30MA 30WV              | 07263    | FDG1088              |
| A1CR11                | 1901-0040      |     | DIODE:SILICON 30MA 30WV              | 07263    | FDG1088              |
| A1CR12                | 1901-0159      |     | DIODE:SILICON 0.75A 400PIV           | 04713    | SR1358-4             |
| A1CR13                | 1901-0159      |     | DIODE:SILICON 0.75A 400PIV           | 04713    | SR1358-4             |
| A1CR14                | 1902-3171      |     | DIODE BREAKDOWN:11.0V 5%             | 28480    | 1902-3171            |
| A1CR15                | 1902-3171      |     | DIODE BREAKDOWN:11.0V 5%             | 28480    | 1902-3171            |
| A1CR16                | 1901-0159      |     | DIODE:SILICON 0.75A 400PIV           | 04713    | SR1358-4             |
| A1CR17                | 1901-0159      |     | DIODE:SILICON 0.75A 400PIV           | 04713    | SR1358-4             |
| A1CR18(NOTE 3)        | 1901-0159      |     | DIODE:SILICON 0.75A 400PIV           | 04713    | SR1358-4             |
| A1Q1                  | 9140-0131      |     | COIL:FXD RF 10 MH                    | 28480    | 9140-0131            |
| A1Q1                  | 1854-0039      | 13  | TSTR:SI NPN                          | 80131    | 2N3053               |
| A1Q2                  | 1854-0477      | 12  | TSTR:SI NPN                          | 80131    | 2N2222A              |
| A1Q3                  | 1853-0281      | 12  | TSTR:SI PNP                          | 80131    | 2N2907A              |
| A1Q4                  | 1855-0050      | 1   | TSTR:SI FET DUAL                     | 28480    | 1855-0050            |
| A1Q5                  | 1855-0062      | 1   | TSTR:SI FET 30V                      | 01295    | 2N1595               |
| A1Q6                  | 1854-0477      |     | TSTR:SI NPN                          | 80131    | 2N2222A              |
| A1Q7                  | 1854-0477      |     | TSTR:SI NPN                          | 80131    | 2N2222A              |
| A1Q8                  | 1854-0477      |     | TSTR:SI NPN                          | 80131    | 2N2222A              |
| A1Q9                  | 1854-0477      |     | TSTR:SI NPN                          | 80131    | 2N2222A              |
| A1Q10                 | 1853-0281      |     | TSTR:SI PNP                          | 80131    | 2N2907A              |
| A1Q11                 | 1853-0281      |     | TSTR:SI PNP                          | 80131    | 2N2907A              |
| A1Q12                 | 1853-0281      |     | TSTR:SI PNP                          | 80131    | 2N2907A              |
| A1Q13                 | 1854-0477      |     | TSTR:SI NPN                          | 80131    | 2N2222A              |
| A1Q14                 | 1854-0072      | 2   | TSTR:SI NPN                          | 80131    | 2N3054               |
| A1Q15                 | 1853-0052      | 2   | TSTR:SI PNP                          | 80131    | 2N3740               |
| A1Q16                 | 1854-0477      |     | TSTR:SI NPN                          | 80131    | 2N2222A              |
| A1Q17                 | 1853-0281      |     | TSTR:SI PNP                          | 80131    | 2N2907A              |
| A1Q18                 | 1854-0072      |     | TSTR:SI NPN                          | 80131    | 2N3054               |
| A1Q19                 | 1854-0477      |     | TSTR:SI NPN                          | 80131    | 2N2222A              |
| A1R1                  | 0698-3160      | 6   | R:FXD MET FLM 31.6K OHM 1% 1/8W      | 28480    | 0698-3160            |
| A1R2                  | 0757-0460      | 2   | R:FXD MET FLM 61.9K OHM 1% 1/8W      | 28480    | 0757-0460            |
| A1R3                  | 0757-0199      | 7   | R:FXD MET FLM 21.5K OHM 1% 1/8W      | 28480    | 0757-0199            |
| A1R4                  | 0757-0442      | 19  | R:FXD MET FLM 10.0K OHM 1% 1/8W      | 28480    | 0757-0442            |
| A1R5                  | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W      | 28480    | 0757-0442            |
| A1R6                  | 0757-0458      | 1   | R:FXD MET FLM 51.1K OHM 1% 1/8W      | 28480    | 0757-0458            |
| A1R7                  | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W      | 28480    | 0757-0442            |
| A1R8                  | 0757-0394      | 2   | R:FXD MET FLM 51.1 OHM 1% 1/8W       | 28480    | 0757-0394            |

NOTES: 1. First used on card rev. 1140.  
 2. Used on card rev. 1133 and 1139.  
 3. Used on card rev. 1133 only.

Table 7-2. Power Supply, Replaceable Parts (Continued)

| Reference Designation | HP Part Number | Qty | Description                        | Mfr Code | Mfr Part Number      |
|-----------------------|----------------|-----|------------------------------------|----------|----------------------|
| A1R9                  | 0757-0401      | 8   | R:FXD MET FLM 100 OHM 1% 1/8W      | 28480    | 0757-0401            |
| A1R10                 | 0757-0401      |     | R:FXD MET FLM 100 OHM 1% 1/8W      | 28480    | 0757-0401            |
| A1R11                 | 2100-2413      | 1   | R:VAR FLM 200 OHM 10% LIN 1/2W     | 28480    | 2100-2413            |
| A1R12                 | 0757-0280      | 9   | R:FXD MET FLM 1K OHM 1% 1/8W       | 28480    | 0757-0280            |
| A1R13                 | 0757-0394      |     | R:FXD MET FLM 51.1 OHM 1% 1/8W     | 28480    | 0757-0394            |
| A1R14                 | 0757-0440      | 4   | R:FXD MET FLM 7.50K OHM 1% 1/8W    | 28480    | 0757-0440            |
| A1R15                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W    | 28480    | 0757-0442            |
| A1R16                 | 0698-3162      | 13  | R:FXD MET FLM 46.4K OHM 1% 1/8W    | 28480    | 0698-3162            |
| A1R17                 | 0757-0461      | 4   | R:FXD MET FLM 68.1K OHM 1% 1/8W    | 28480    | 0757-0461            |
| A1R18                 | 0757-0279      | 2   | R:FXD MET FLM 3.16K OHM 1% 1/8W    | 28480    | 0757-0279            |
| A1R19                 | 0757-0440      |     | R:FXD MET FLM 7.50K OHM 1% 1/8W    | 28480    | 0757-0440            |
| A1R20                 | 0698-3160      |     | R:FXD MET FLM 31.6K OHM 1% 1/8W    | 28480    | 0698-3160            |
| A1R21                 | 0757-0439      | 1   | R:FXD MET FLM 6.81K OHM 1% 1/8W    | 28480    | 0757-0439            |
| A1R22                 | 0698-3410      | 1   | R:FXD MET FLM 3.16K OHM 1% 1/2W    | 28480    | 0698-3410            |
| A1R23                 | 0757-0199      |     | R:FXD MET FLM 21.5K OHM 1% 1/8W    | 28480    | 0757-0199            |
| A1R24                 | 0757-0438      | 3   | R:FXD MET FLM 5.11K OHM 1% 1/8W    | 28480    | 0757-0438            |
| A1R25                 | 0757-0440      |     | R:FXD MET FLM 7.50K OHM 1% 1/8W    | 28480    | 0757-0440            |
| A1R26                 | 0757-0465      | 8   | R:FXD MET FLM 100K OHM 1% 1/8W     | 28480    | 0757-0465            |
| A1R27                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W    | 28480    | 0757-0442            |
| A1R28                 | 0698-3441      | 1   | R:FXD MET FLM 21.5 OHM 1% 1/8W     | 28480    | 0698-3441            |
| A1R29                 | 0757-1094      | 1   | R:FXD MET FLM 1.47K OHM 1% 1/8W    | 28480    | 0757-1094            |
| A1R30                 | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W    | 28480    | 0698-3162            |
| A1R31                 | 0698-3160      |     | R:FXD MET FLM 31.6K OHM 1% 1/8W    | 28480    | 0698-3160            |
| A1R32                 | 0757-0438      |     | R:FXD MET FLM 5.11K OHM 1% 1/8W    | 28480    | 0757-0438            |
| A1R33                 | 0698-3159      | 2   | R:FXD MET FLM 26.1K OHM 1% 1/8W    | 28480    | 0698-3159            |
| A1R34                 | 0757-0401      |     | R:FXD MET FLM 100 OHM 1% 1/8W      | 28480    | 0757-0401            |
| A1R35                 | 0757-0401      |     | R:FXD MET FLM 100 OHM 1% 1/8W      | 28480    | 0757-0401            |
| A1R36                 | 2100-2521      | 2   | R:VAR FLM 2000 OHM 10% LIN 1/2W    | 28480    | 2100-2521            |
| A1R37                 | 0757-0290      | 1   | R:FXD MET FLM 6.19K OHM 1% 1/8W    | 28480    | 0757-0290            |
| A1R38                 | 0757-0199      |     | R:FXD MET FLM 21.5K OHM 1% 1/8W    | 28480    | 0757-0199            |
| A1R39                 | 0698-3454      | 1   | R:FXD MET FLM 215K OHM 1% 1/8W     | 28480    | 0698-3454            |
| A1R40                 | 0698-3156      | 1   | R:FXD MET FLM 14.7K OHM 1% 1/8W    | 28480    | 0698-3156            |
| A1R41                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W    | 28480    | 0757-0442            |
| A1R42                 | 0698-3159      |     | R:FXD MET FLM 26.1K OHM 1% 1/8W    | 28480    | 0698-3159            |
| A1R43                 | 0698-3155      | 18  | R:FXD MET FLM 4.64K OHM 1% 1/8W    | 28480    | 0698-3155            |
| A1R44                 | 0683-0275      | 3   | R:FXD COMP 2.7 OHM 5% 1/4W         | 01121    | CB 27G5              |
| A1R45                 | 0757-0279      |     | R:FXD MET FLM 3.16K OHM 1% 1/8W    | 28480    | 0757-0279            |
| A1R46                 | 0757-0288      | 1   | R:FXD MET FLM 9.09K OHM 1% 1/8W    | 28480    | 0757-0288            |
| A1R47                 | 0757-0199      |     | R:FXD MET FLM 21.5K OHM 1% 1/8W    | 28480    | 0757-0199            |
| A1R48                 | 0683-0275      |     | R:FXD COMP 2.7 OHM 5% 1/4W         | 01121    | CB 27G5              |
| A1R49                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W    | 28480    | 0757-0442            |
| A1R50                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W    | 28480    | 0757-0442            |
| A1R51                 | 0757-0199      |     | R:FXD MET FLM 21.5K OHM 1% 1/8W    | 28480    | 0757-0199            |
| A1R52                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W    | 28480    | 0698-3155            |
| A1R53                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W    | 28480    | 0698-3155            |
| A1R54                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W    | 28480    | 0698-3155            |
| A1R55                 | 0757-0459      | 10  | R:FXD MET FLM 56.2K OHM 1% 1/8W    | 28480    | 0757-0459            |
| A1R56                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W    | 28480    | 0698-3155            |
| A1R57                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W    | 28480    | 0698-3155            |
| A1R58                 | 0683-0275      |     | R:FXD COMP 2.7 OHM 5% 1/4W         | 01121    | CB 27G5              |
| A1R59                 | 0757-0280      |     | R:FXD MET FLM 1K OHM 1% 1/8W       | 28480    | 0757-0280            |
| A1U1                  | 1826-0070      | 13  | IC:LINEAR OPER. AMPL.              | 07263    | U6A7741393           |
| A1U2                  | 1826-0049      | 1   | IC:VOLTAGE REGULATOR PROGRAMMABLE  | 07263    | U6A772393            |
| A1U3                  | 1826-0069      | 4   | IC:LINEAR OPER. AMPL.              | 12040    | LM301AD              |
| A1U4                  | 1826-0069      |     | IC:LINEAR OPER. AMPL.              | 12040    | LM301AD              |
| A2                    | 02100-60058    | 1   | INVERTER DRIVER CARD               | 28480    | 02100-60058          |
| A2C1                  | 0180-1746      | 7   | C:FXD ELECT 15 UF 10% 20VDCW       | 28480    | 0180-1746            |
| A2C2                  | 0180-1746      |     | C:FXD ELECT 15 UF 10% 20VDCW       | 28480    | 0180-1746            |
| A2C3                  | 0180-1746      |     | C:FXD ELECT 15 UF 10% 20VDCW       | 28480    | 0180-1746            |
| A2C4                  | 0180-1746      |     | C:FXD ELECT 15 UF 10% 20VDCW       | 28480    | 0180-1746            |
| A2C5                  | 0180-0141      | 4   | C:FXD ELECT 50 UF +75-10% 50VDCW   | 56289    | 30D5066050DD2-DSM    |
| A2C6                  | 0180-0141      |     | C:FXD ELECT 50 UF +75-10% 50VDCW   | 56289    | 30D5066050DD2-DSM    |
| A2C7                  | 0160-2055      |     | C:FXD CER 0.01 UF +80-20% 100VDCW  | 56289    | C023F101F103ZS22-CDH |
| A2C8                  | 0160-0298      | 1   | C:FXD MY 0.0015 UF 10% 200VDCW     | 56289    | 192P15292-PTS        |
| A2C9                  | 0160-0194      | 5   | C:FXD MY 0.015 UF 10%              | 56289    | 192P15392-PTS        |
| A2C10                 | 0160-0194      |     | C:FXD MY 0.015 UF 10%              | 56289    | 192P15392-PTS        |
| A2C11                 | 0160-0194      |     | C:FXD MY 0.015 UF 10%              | 56289    | 192P15392-PTS        |
| A2C12                 | 0160-0194      |     | C:FXD MY 0.015 UF 10%              | 56289    | 192P15392-PTS        |
| A2C13                 | 0180-0291      |     | C:FXD ELECT 1.0 UF 10% 35VDCW      | 56289    | 150D105X9035A2-DYS   |
| A2C14                 | 0160-0134      |     | C:FXD MICA 220PF 5% 300VDCW        | 14655    | RDM15F221J3C         |
| A2C15                 | 0160-0194      | 1   | C:FXD MY 0.015 UF 10%              | 56289    | 192P15392-PTS        |
| A2C16(NOTE 19)        | 0150-0093      | 1   | C:FXD CER 0.01 UF +80 -20% 100VDCW | 72982    | 801-K800011          |
| A2CR1                 | 1901-1065      | 12  | DIODE:1N4936                       | 28480    | 1901-1065            |
| A2CR2                 | 1901-1065      |     | DIODE:1N4936                       | 28480    | 1901-1065            |
| A2CR3                 | 1901-1065      |     | DIODE:1N4936                       | 28480    | 1901-1065            |
| A2CR4                 | 1901-1065      |     | DIODE:1N4936                       | 28480    | 1901-1065            |

NOTES: 19. First used on card rev. 1249.

Table 7-2. Power Supply, Replaceable Parts (Continued)

| Reference Designation | HP Part Number | Qty | Description                     | Mfr Code | Mfr Part Number |
|-----------------------|----------------|-----|---------------------------------|----------|-----------------|
| A2CR5                 | 1901-0050      | 16  | DIODE:SI 200 MA AT 1V           | 07263    | FDA 6308        |
| A2CR6                 | 1901-0050      |     | DIODE:SI 200 MA AT 1V           | 07263    | FDA 6308        |
| A2CR7                 | 1901-0050      |     | DIODE:SI 200 MA AT 1V           | 07263    | FDA 6308        |
| A2CR8                 | 1902-3149      | 1   | DIODE BREAKDOWN:9.09V 5%        | 28480    | 1902-3149       |
| A2CR9                 | 1901-0050      |     | DIODE:SI 200 MA AT 1V           | 07263    | FDA 6308        |
| A2CR10                | 1901-0050      |     | DIODE:SI 200 MA AT 1V           | 07263    | FDA 6308        |
| A2CR11(NOTE 4)        | 1901-0159      |     | DIODE:SILICON 0.75A 400PIV      | 04713    | SR1358-4        |
| A2E1                  | 0360-0294      | 11  | TERMINAL:SOLDER POINT           | 28480    | 0360-0294       |
| A2L1                  | 9140-0098      | 1   | COIL/CHOKE 2.20 UH 10%          | 99800    | 1537-20         |
| A2L2                  | 9140-0210      | 1   | COIL/CHOKE 100 UH 5%            | 82142    | 15-1315-12J     |
| A2L3                  | 9140-0131      |     | COIL:FXD RF 10 MH               | 28480    | 9140-0131       |
| A2Q1                  | 1854-0039      |     | TSTR:SI NPN                     | 80131    | 2N3053          |
| A2Q2                  | 1854-0039      |     | TSTR:SI NPN                     | 80131    | 2N3053          |
| A2Q3                  | 1854-0039      |     | TSTR:SI NPN                     | 80131    | 2N3053          |
| A2Q4                  | 1854-0039      |     | TSTR:SI NPN                     | 80131    | 2N3053          |
| A2Q5                  | 1854-0039      |     | TSTR:SI NPN                     | 80131    | 2N3053          |
| A2Q6                  | 1854-0039      |     | TSTR:SI NPN                     | 80131    | 2N3053          |
| A2Q7                  | 1854-0039      |     | TSTR:SI NPN                     | 80131    | 2N3053          |
| A2Q8                  | 1854-0039      |     | TSTR:SI NPN                     | 80131    | 2N3053          |
| A2Q9                  | 1854-0477      |     | TSTR:SI NPN                     | 80131    | 2N2222A         |
| A2Q10(NOTE 5)         | 1853-0281      |     | TSTR:SI PNP                     | 80131    | 2N2907A         |
| A2Q10(NOTE 6)         | 1854-0477      |     | TSTR:SI NPN                     | 80131    | 2N2222A         |
| A2Q11                 | 1854-0477      |     | TSTR:SI NPN                     | 80131    | 2N2222A         |
| A2Q12                 | 1854-0039      |     | TSTR:SI NPN                     | 80131    | 2N3053          |
| A2Q13                 | 1853-0281      |     | TSTR:SI PNP                     | 80131    | 2N2907A         |
| A2Q14                 | 1853-0281      |     | TSTR:SI PNP                     | 80131    | 2N2907A         |
| A2Q15                 | 1854-0477      |     | TSTR:SI NPN                     | 80131    | 2N2222A         |
| A2Q16                 | 1853-0052      |     | TSTR:SI PNP                     | 80131    | 2N3740          |
| A2R1                  | 0698-3402      | 9   | R:FXD MET FLM 316 OHM 1% 1/2W   | 28480    | 0698-3402       |
| A2R2                  | 0698-3402      |     | R:FXD MET FLM 316 OHM 1% 1/2W   | 28480    | 0698-3402       |
| A2R3                  | 0698-3438      | 5   | R:FXD MET FLM 147 OHM 1% 1/8W   | 28480    | 0698-3438       |
| A2R4                  | 0698-3402      |     | R:FXD MET FLM 316 OHM 1% 1/2W   | 28480    | 0698-3402       |
| A2R5                  | 0698-3402      |     | R:FXD MET FLM 316 OHM 1% 1/2W   | 28480    | 0698-3402       |
| A2R6                  | 0698-3438      |     | R:FXD MET FLM 147 OHM 1% 1/8W   | 28480    | 0698-3438       |
| A2R7                  | 0698-3402      |     | R:FXD MET FLM 316 OHM 1% 1/2W   | 28480    | 0698-3402       |
| A2R8                  | 0698-3402      |     | R:FXD MET FLM 316 OHM 1% 1/2W   | 28480    | 0698-3402       |
| A2R9                  | 0698-3438      |     | R:FXD MET FLM 147 OHM 1% 1/8W   | 28480    | 0698-3438       |
| A2R10                 | 0698-3402      |     | R:FXD MET FLM 316 OHM 1% 1/2W   | 28480    | 0698-3402       |
| A2R11                 | 0698-3402      |     | R:FXD MET FLM 316 OHM 1% 1/2W   | 28480    | 0698-3402       |
| A2R12                 | 0698-3438      |     | R:FXD MET FLM 147 OHM 1% 1/8W   | 28480    | 0698-3438       |
| A2R13                 | 0757-0401      |     | R:FXD MET FLM 100 OHM 1% 1/8W   | 28480    | 0757-0401       |
| A2R14                 | 0698-0084      | 5   | R:FXD MET FLM 2.15K OHM 1% 1/8W | 28480    | 0698-0084       |
| A2R15                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W | 28480    | 0757-0442       |
| A2R16                 | 0757-0465      |     | R:FXD MET FLM 100K OHM 1% 1/8W  | 28480    | 0757-0465       |
| A2R17                 | 0757-0280      |     | R:FXD MET FLM 1K OHM 1% 1/8W    | 28480    | 0757-0280       |
| A2R18                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W | 28480    | 0698-3155       |
| A2R19                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W | 28480    | 0698-3155       |
| A2R20                 | 0698-0084      |     | R:FXD MET FLM 2.15K OHM 1% 1/8W | 28480    | 0698-0084       |
| A2R21                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W | 28480    | 0757-0442       |
| A2R22                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W | 28480    | 0757-0442       |
| A2R23                 | 0698-3449      | 1   | R:FXD MET FLM 28.7K OHM 1% 1/8W | 28480    | 0698-3449       |
| A2R24                 | 0698-0082      | 11  | R:FXD MET FLM 464 OHM 1% 1/8W   | 28480    | 0698-0082       |
| A2R25                 | 0698-3180      | 3   | R:FXD MET OX 68 OHM 2% 2W       | 28480    | 0698-3180       |
| A2R26                 | 0698-3180      |     | R:FXD MET OX 68 OHM 2% 2W       | 28480    | 0698-3180       |
| A2R27                 | 0811-1668      | 1   | R:FXD WW 1.5 OHM 5% 2W          | 28480    | 0811-1668       |
| A2R28                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W | 28480    | 0757-0442       |
| A2R29                 | 0698-7398      | 2   | R:FXD FLM 6.124K OHM 0.1% 1/8W  | 28480    | 0698-7398       |
| A2R30                 | 0698-4037      | 5   | R:FXD MET FLM 46.4 OHM 1% 1/8W  | 28480    | 0698-4037       |
| A2R31                 | 0698-7398      |     | R:FXD FLM 6.124K OHM 0.1% 1/8W  | 28480    | 0698-7398       |
| A2R32                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W | 28480    | 0757-0442       |
| A2R33                 | 0698-3445      | 2   | R:FXD MET FLM 348 OHM 1% 1/8W   | 28480    | 0698-3445       |
| A2R34                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W | 28480    | 0698-3155       |
| A2R35                 | 2100-2521      |     | R:VAR FLM 2000 OHM 10% LIN 1/2W | 28480    | 2100-2521       |
| A2R36                 | 0757-0200      | 1   | R:FXD MET FLM 5.62K OHM 1% 1/8W | 28480    | 0757-0200       |
| A2R37                 | 0698-3160      |     | R:FXD MET FLM 31.6K OHM 1% 1/8W | 28480    | 0698-3160       |
| A2R38                 | 0757-0401      |     | R:FXD MET FLM 100 OHM 1% 1/8W   | 28480    | 0757-0401       |
| A2R39                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W | 28480    | 0757-0442       |
| A2R40                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W | 28480    | 0698-3155       |
| A2R41                 | 0757-0465      |     | R:FXD MET FLM 100K OHM 1% 1/8W  | 28480    | 0757-0465       |
| A2R42                 | 0757-0274      | 5   | R:FXD MET FLM 1.21K OHM 1% 1/8W | 28480    | 0757-0274       |
| A2K43                 | 0698-0084      |     | R:FXD MET FLM 2.15K OHM 1% 1/8W | 28480    | 0698-0084       |
| A2R44                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W | 28480    | 0757-0442       |
| A2R45                 | 0757-1078      | 1   | R:FXD MET FLM 1.47K OHM 1% 1/2W | 28480    | 0757-1078       |
| A2R46                 | 0698-3452      | 3   | R:FXD MET FLM 147K OHM 1% 1/8W  | 28480    | 0698-3452       |
| A2R47                 | 0698-3438      |     | R:FXD MET FLM 147 OHM 1% 1/8W   | 28480    | 0698-3438       |
| A2U1                  | 1820-0256      | 1   | IC:DTL QUAD 2-INPUT POWER GATE  | 04713    | MC858P          |

NOTES: 4. Used on card rev. 1126 only.  
5. First used on card rev. 1140.  
6. Used on card rev. 1126 only. Use 1853-0281 for replacement.

Table 7-2. Power Supply, Replaceable Parts (Continued)

| Reference Designation | HP Part Number | Qty | Description                        | Mfr Code | Mfr Part Number      |
|-----------------------|----------------|-----|------------------------------------|----------|----------------------|
| A2U2                  | 1820-0054      | 1   | IC:TTL QUAD 2-INPT NAND GATE       | 01295    | SN7400N              |
| A2U3                  | 1820-0141      | 1   | IC:TTL QUAD 2-INPT AND GATE        | 04713    | MC3001P              |
| A2U4                  | 1820-0512      | 1   | IC:TTL DUAL D F/F                  | 01295    | SN74H74N             |
| A2U5                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.              | 07263    | U6A7741393           |
| A2U6                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.              | 07263    | U6A7741393           |
| A2U7                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.              | 07263    | U6A7741393           |
| A2U8                  | 1826-0069      |     | IC:LINEAR OPER. AMPL.              | 12040    | LM301AD              |
| A2U9                  | 1826-0069      |     | IC:LINEAR OPER. AMPL.              | 12040    | LM301AD              |
| A3                    | 02100-60047    | 1   | PROTECTION AND CONTROL CARD        | 28480    | 02100-60047          |
| A3C1                  | 0160-3456      | 12  | C:FXD CER 1000 PF 10% 250VDCW      | 56289    | C067F251F102KS22-CD  |
| A3C2                  | 0160-2143      | 3   | C:FXD CER 2000 PF +80-20% 1000VDCW | 91418    | TYPE B               |
| A3C3                  | 0170-0040      |     | C:FXD HY 0.047 UF 10% 200VDCW      | 56289    | 192P47392-PTS        |
| A3C4                  | 0160-2143      |     | C:FXD CER 2000 PF +80-20% 1000VDCW | 91418    | TYPE B               |
| A3C5                  | 0180-1746      |     | C:FXD ELECT 15 UF 10% 20VDCW       | 28480    | 0180-1746            |
| A3C6                  | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW      | 56289    | C067F251F102KS22-CD  |
| A3C7                  | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW      | 56289    | C067F251F102KS22-CD  |
| A3C8                  | 0180-1746      |     | C:FXD ELECT 15 UF 10% 20VDCW       | 28480    | 0180-1746            |
| A3C9                  | 0180-0376      | 1   | C:FXD ELECT 0.47 UF 10% 35VDCW     | 56289    | 150D474X9035A2-DYS   |
| A3C10                 | 0160-2143      |     | C:FXD CER 2000 PF +80-20% 1000VDCW | 91418    | TYPE B               |
| A3C11                 | 0160-2055      |     | C:FXD CER 0.01 UF +80-20% 100VDCW  | 56289    | C023F101F103Z522-CDH |
| A3C12                 | 0180-1746      |     | C:FXD ELECT 15 UF 10% 20VDCW       | 28480    | 0180-1746            |
| A3C13                 | 0180-0097      |     | C:FXD TANT. 47 UF 10% 35VDCW       | 56289    | 150D474X9035S2-DYS   |
| A3C14                 | 0160-2055      |     | C:FXD CER 0.01 UF +80-20% 100VDCW  | 56289    | C023F101F103Z522-CDH |
| A3C15                 | 0180-0098      | 1   | C:FXD ELECT 100 UF 20% 20VDCW      | 56289    | 150D107X0020S2-DYS   |
| A3C16                 | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW      | 56289    | C067F251F102KS22-CD  |
| A3C17                 | 0180-0228      |     | C:FXD ELECT 22 UF 10% 15VDCW       | 56289    | 150D226X9015B2-DYS   |
| A3C18                 | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW      | 56289    | C067F251F102KS22-CD  |
| A3C19                 | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW      | 56289    | C067F251F102KS22-CD  |
| A3C20                 | 0180-0291      |     | C:FXD ELECT 1.0 UF 10% 35VDCW      | 56289    | 150D105X9035A2-DYS   |
| A3C21                 | 0160-2055      |     | C:FXD CER 0.01 UF +80-20% 100VDCW  | 56289    | C023F101F103Z522-CDH |
| A3C22                 | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW      | 56289    | C067F251F102KS22-CD  |
| A3C23                 | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW      | 56289    | C067F251F102KS22-CD  |
| A3C24                 | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW      | 56289    | C067F251F102KS22-CD  |
| A3C25                 | 0160-0174      | 9   | C:FXD CER 0.47 UF +80-20% 25VDCW   | 56289    | 5C11875-CML          |
| A3C26                 | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW      | 56289    | C067F251F102KS22-CD  |
| A3C27                 | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW      | 56289    | C067F251F102KS22-CD  |
| A3C28                 | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW      | 56289    | C067F251F102KS22-CD  |
| A3CR1                 | 1901-0033      | 26  | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR2                 | 1902-3245      | 1   | DIODE BREAKDOWN:SILICON 21.5V 5%   | 28480    | 1902-3245            |
| A3CR3                 | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR4                 | 1902-0041      | 1   | DIODE:BREAKDOWN 5.11V 5%           | 04713    | SZ10939-98           |
| A3CR5                 | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR6                 | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR7                 | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR8                 | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR9                 | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR10                | 1902-0033      | 2   | DIODE:BREAKDOWN 6.2V               | 04713    | 1N823                |
| A3CR11                | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR12                | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR13                | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR14                | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR15                | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR16                | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR17                | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR18                | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR19                | 1902-0033      |     | DIODE:BREAKDOWN 6.2V               | 04713    | 1N823                |
| A3CR20 (NOTE 20)      | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR21                | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR22                | 1902-3139      | 1   | DIODE:BREAKDOWN 8.25V 5%           | 04713    | SZ10939-158          |
| A3CR23                | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR24                | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR25                | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR26                | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR27                | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR28                | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR29                | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR30                | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3CR31                | 1901-0033      |     | DIODE:SILICON 100MA 180WV          | 07263    | F03369               |
| A3E1                  | 0360-0294      |     | TERMINAL:SOLDER POINT              | 28480    | 0360-0294            |
| A3E2                  | 0360-0294      |     | TERMINAL:SOLDER POINT              | 28480    | 0360-0294            |
| A3E3                  | 0360-0294      |     | TERMINAL:SOLDER POINT              | 28480    | 0360-0294            |
| A3Q1                  | 1854-0039      |     | TSTR:SI NPN                        | 80131    | 2N3053               |
| A3Q2                  | 1853-0281      |     | TSTR:SI PNP                        | 80131    | 2N2907A              |
| A3Q3                  | 1854-0039      |     | TSTR:SI NPN                        | 80131    | 2N3053               |
| A3Q4                  | 1853-0281      |     | TSTR:SI PNP                        | 80131    | 2N2907A              |

NOTES: 20. Used only on card rev. 1132 and 1147.

Table 7-2. Power Supply, Replaceable Parts (Continued)

| Reference Designation | HP Part Number | Qty | Description                       | Mfr Code | Mfr Part Number |
|-----------------------|----------------|-----|-----------------------------------|----------|-----------------|
| A3Q5                  | 1854-0039      |     | TSTR:SI NPN                       | 80131    | 2N3053          |
| A3Q6                  | 1853-0281      |     | TSTR:SI PNP                       | 80131    | 2N2907A         |
| A3R1                  | 0698-0083      | 1   | R:FXD MET FLM 1.96K OHM 1% 1/8W   | 28480    | 0698-0083       |
| A3R2                  | 0698-3445      |     | R:FXD MET FLM 348 OHM 1% 1/8W     | 28480    | 0698-3445       |
| A3R3                  | 0757-0428      | 3   | R:FXD MET FLM 1.62K OHM 1% 1/8W   | 28480    | 0757-0428       |
| A3R4                  | 2100-2574      | 1   | R:VAR CERMET 500 OHM 10% LIN 1/2W | 28480    | 2100-2574       |
| A3R5                  | 0757-0441      | 2   | R:FXD MET FLM 8.25K OHM 1% 1/8W   | 28480    | 0757-0441       |
| A3R6                  | 0757-0428      |     | R:FXD MET FLM 1.62K OHM 1% 1/8W   | 28480    | 0757-0428       |
| A3R7                  | 0757-0438      |     | R:FXD MET FLM 5.11K OHM 1% 1/8W   | 28480    | 0757-0438       |
| A3R8                  | 0757-0459      |     | R:FXD MET FLM 56.2K OHM 1% 1/8W   | 28480    | 0757-0459       |
| A3R9                  | 0698-3136      | 1   | R:FXD MET FLM 17.8K OHM 1% 2/8W   | 19701    | MF4C T-0        |
| A3R10                 | 0757-0428      |     | R:FXD MET FLM 1.62K OHM 1% 1/3W   | 28480    | 0757-0428       |
| A3R11                 | 0757-0401      |     | R:FXD MET FLM 100 OHM 1% 1/8W     | 28480    | 0757-0401       |
| A3R12                 | 0757-0274      |     | R:FXD MET FLM 1.21K OHM 1% 1/8W   | 28480    | 0757-0274       |
| A3R13                 | 0757-0198      | 2   | R:FXD MET FLM 100 OHM 1% 1/2W     | 28480    | 0757-0198       |
| A3R14                 | 0757-0459      |     | R:FXD MET FLM 56.2K OHM 1% 1/8W   | 28480    | 0757-0459       |
| A3R15                 | 0698-3150      | 3   | R:FXD MET FLM 2.37K OHM 1% 1/8W   | 28480    | 0698-3150       |
| A3R16                 | 0757-0346      | 3   | R:FXD MET FLM 10 OHM 1% 1/8W      | 28480    | 0757-0346       |
| A3R17                 | 0757-0440      |     | R:FXD MET FLM 7.50K OHM 1% 1/8W   | 28480    | 0757-0440       |
| A3R18                 | 0698-3152      | 1   | R:FXD MET FLM 3.48K OHM 1% 1/8W   | 28480    | 0698-3152       |
| A3R19                 | 0757-0274      |     | R:FXD MET FLM 1.21K OHM 1% 1/8W   | 28480    | 0757-0274       |
| A3R20                 | 0757-0422      | 1   | R:FXD MET FLM 909 OHM 1% 1/8W     | 28480    | 0757-0422       |
| A3R21                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W   | 28480    | 0698-3155       |
| A3R22                 | 0757-0401      |     | R:FXD MET FLM 100 OHM 1% 1/8W     | 28480    | 0757-0401       |
| A3R23                 | 0757-0446      | 7   | R:FXD MET FLM 15.0K OHM 1% 1/8W   | 28480    | 0757-0446       |
| A3R24                 | 0757-0465      |     | R:FXD MET FLM 100K OHM 1% 1/8W    | 28480    | 0757-0465       |
| A3R25                 | 0757-0418      | 1   | R:FXD MET FLM 619 OHM 1% 1/8W     | 28480    | 0757-0418       |
| A3R26                 | 0757-0459      |     | R:FXD MET FLM 56.2K OHM 1% 1/8W   | 28480    | 0757-0459       |
| A3R27                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W   | 28480    | 0698-3155       |
| A3R28                 | 0757-0459      |     | R:FXD MET FLM 56.2K OHM 1% 1/8W   | 28480    | 0757-0459       |
| A3R29                 | 0698-3455      | 3   | R:FXD MET FLM 261K OHM 1% 1/8W    | 28480    | 0698-3455       |
| A3R30                 | 0698-4442      | 1   | R:FXD MET FLM 4.42K OHM 1% 1/8W   | 28480    | 0698-4442       |
| A3R31                 | 0698-3455      |     | R:FXD MET FLM 261K OHM 1% 1/8W    | 28480    | 0698-3455       |
| A3R32                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W   | 28480    | 0698-3155       |
| A3R33                 | 0757-0462      | 2   | R:FXD MET FLM 75.0K OHM 1% 1/8W   | 28480    | 0757-0462       |
| A3R34                 | 0757-0123      | 2   | R:FXD MET FLM 34.8K OHM 1% 1/8W   | 28480    | 0757-0123       |
| A3R35                 | 0757-0346      |     | R:FXD MET FLM 10 OHM 1% 1/8W      | 28480    | 0757-0346       |
| A3R36                 | 0757-0459      |     | R:FXD MET FLM 56.2K OHM 1% 1/8W   | 28480    | 0757-0459       |
| A3R37                 | 0698-3158      | 4   | R:FXD MET FLM 23.7K OHM 1% 1/8W   | 28480    | 0698-3158       |
| A3R38                 | 0757-0446      |     | R:FXD MET FLM 15.0K OHM 1% 1/8W   | 28480    | 0757-0446       |
| A3R39                 | 0698-3398      | 1   | R:FXD MET FLM 46.4 OHM 1% 1/2W    | 28480    | 0698-3398       |
| A3R40(NOTE 7)         | 0757-0416      | 1   | R:FXD MET FLM 511 OHM 1% 1/8W     | 28480    | 0757-0416       |
| A3R40(NOTE 8)         | 0757-0274      |     | R:FXD MET FLM 1.21K OHM 1% 1/8W   | 28480    | 0757-0274       |
| A3R41                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W   | 28480    | 0698-3155       |
| A3R42                 | 0698-3151      | 1   | R:FXD MET FLM 2.87K OHM 1% 1/8W   | 28480    | 0698-3151       |
| A3R43                 | 0698-3157      | 2   | R:FXD MET FLM 19.6K OHM 1% 1/8W   | 28480    | 0698-3157       |
| A3R44                 | 0757-0465      |     | R:FXD MET FLM 100K OHM 1% 1/8W    | 28480    | 0757-0465       |
| A3R45(NOTE 21)        | 0698-3388      | 1   | R:FXD MET FLM 14.7 OHM 1% 1/2W    | 28480    | 0698-3388       |
| A3R45(NOTE 22)        | 0757-0984      | 1   | R:FXD MET FLM 10.0 OHM 1% 1/2W    | 28480    | 0757-0984       |
| A3R46                 | 0757-0198      |     | R:FXD MET FLM 100 OHM 1% 1/2W     | 28480    | 0757-0198       |
| A3R47(NOTE 23)        | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W   | 28480    | 0757-0442       |
| A3R47(NOTE 23)        | 0698-3160      |     | R:FXD MET FLM 31.6K OHM 1% 1/8W   | 28480    | 0698-3160       |
| A3R48                 | 0698-3150      |     | R:FXD MET FLM 2.37K OHM 1% 1/8W   | 28480    | 0698-3150       |
| A3R49(NOTE 21)        | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W   | 28480    | 0698-3155       |
| A3R49(NOTE 22)        | 0757-0290      | 2   | R:FXD MET FLM 6.19K OHM 1% 1/8W   | 28480    | 0757-0290       |
| A3R50                 | 0757-0346      |     | R:FXD MET FLM 10 OHM 1% 1/8W      | 28480    | 0757-0346       |
| A3R51                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W   | 28480    | 0698-3155       |
| A3R52                 | 0757-0446      |     | R:FXD MET FLM 15.0K OHM 1% 1/8W   | 28480    | 0757-0446       |
| A3R53(NOTE 7)         | 0757-0123      |     | R:FXD MET FLM 34.8K OHM 1% 1/8W   | 28480    | 0757-0123       |
| A3R53(NOTE 8)         | 0757-0465      |     | R:FXD MET FLM 100K OHM 1% 1/8W    | 28480    | 0757-0465       |
| A3R54                 | 0698-3447      | 2   | R:FXD MET FLM 422 OHM 1% 1/8W     | 28480    | 0698-3447       |
| A3R55(NOTE 21)        | 0757-0459      |     | R:FXD MET FLM 56.2K OHM 1% 1/8W   | 28480    | 0757-0459       |
| A3R55(NOTE 22)        | 0698-3455      |     | R:FXD MET FLM 261K OHM 1% 1/8W    | 28480    | 0698-3455       |
| A3R56                 | 0698-3447      |     | R:FXD MET FLM 422 OHM 1% 1/8W     | 28480    | 0698-3447       |
| A3R57(NOTE 21)        | 0757-0421      | 1   | R:FXD MET FLM 825 OHM 1% 1/8W     | 28480    | 0757-0421       |
| A3R57(NOTE 22)        | 0698-3157      |     | R:FXD MET FLM 19.6K OHM 1% 1/8W   | 28480    | 0698-3157       |
| A3R58                 | 0757-0446      |     | R:FXD MET FLM 15.0K OHM 1% 1/8W   | 28480    | 0757-0446       |
| A3R59(NOTE 7)         | 0698-3158      |     | R:FXD MET FLM 23.7K OHM 1% 1/8W   | 28480    | 0698-3158       |
| A3R59(NOTE 8)         | 0757-0446      |     | R:FXD MET FLM 15.0K OHM 1% 1/8W   | 28480    | 0757-0446       |
| A3R60(NOTE 21)        | 0698-3150      |     | R:FXD MET FLM 2.37K OHM 1% 1/8W   | 28480    | 0698-3150       |
| A3R60(NOTE 22)        | 0757-0442      | 1   | R:FXD MET FLM 10K OHMS 15 1/8W    | 28480    | 0757-0442       |
| A3R61(NOTE 7)         | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W   | 28480    | 0698-3155       |
| A3R61(NOTE 8)         | 0757-0441      |     | R:FXD MET FLM 8.25K OHM 1% 1/8W   | 28480    | 0757-0441       |
| A3R61(NOTE 22)        | 0757-0290      |     | R:FXD MET FLM 6.19K OHM 1% 1/8W   | 28480    | 0757-0290       |
| A3R62                 | 0757-0446      |     | R:FXD MET FLM 15.0K OHM 1% 1/8W   | 28480    | 0757-0446       |
| A3R63                 | 0757-0446      |     | R:FXD MET FLM 15.0K OHM 1% 1/8W   | 28480    | 0757-0446       |
| A3R64                 | 2100-2522      | 1   | R:VAR CERMET 10K OHM 10% LIN 1/2W | 28480    | 2100-2522       |
| A3R65                 | 0757-0199      |     | R:FXD MET FLM 21.5K OHM 1% 1/8W   | 28480    | 0757-0199       |
| A3R66                 | 0698-3158      |     | R:FXD MET FLM 23.7K OHM 1% 1/8W   | 28480    | 0698-3158       |
| A3R67                 | 0757-0274      |     | R:FXD MET FLM 1.21K OHM 1% 1/8W   | 28480    | 0757-0274       |
| A3R68                 | 0757-0465      |     | R:FXD MET FLM 100K OHM 1% 1/8W    | 28480    | 0757-0465       |

NOTES: 7. First used on card rev. 1147.  
8. Used on card rev. 1132 only.

21. Used on card rev. 1132 and 1147 only.  
22. First used on card rev. 1215.

23. Replaced with jumper on card rev. 1215.

Table 7-2. Power Supply, Replaceable Parts (Continued)

| Reference Designation | HP Part Number | Qty | Description                      | Mfr Code | Mfr Part Number    |
|-----------------------|----------------|-----|----------------------------------|----------|--------------------|
| A3R69                 | 0757-0444      | 1   | R:FXD MET FLM 12.1K OHM 1% 1/8W  | 28480    | 0757-0444          |
| A3R70                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W  | 28480    | 0698-3155          |
| A3R71                 | 0698-3158      |     | R:FXD MET FLM 23.7K OHM 1% 1/8W  | 28480    | 0698-3158          |
| A3R72                 | 0757-0465      |     | R:FXD MET FLM 100K OHM 1% 1/8W   | 28480    | 0757-0465          |
| A3R73                 | 0757-0460      |     | R:FXD MET FLM 61.9K OHM 1% 1/8W  | 28480    | 0757-0460          |
| A3U1                  | 1821-0001      | 3   | TRANSISTOR ARRAY:SI NPN          | 02735    | CA3046             |
| A3U2                  | 1821-0001      |     | TRANSISTOR ARRAY:SI NPN          | 02735    | CA3046             |
| A3U3                  | 1821-0001      |     | TRANSISTOR ARRAY:SI NPN          | 02735    | CA3046             |
| A3W1(NOTE 22)         | 8159-0005      | 2   | JUMPER WIRE                      | 28480    | 8159-0005          |
| A3W2(NOTE 22)         | 8159-0005      |     | JUMPER WIRE                      | 28480    | 8159-0005          |
| A4                    | 02100-60061    | 1   | CURRENT LIMIT CARD               | 28480    | 02100-60061        |
| A4C1                  | 0160-0168      | 3   | C:FXD MY 0.1 UF 10% 200VDCW      | 56289    | 192P10492-PTS      |
| A4C2                  | 0180-0291      |     | C:FXD ELECT 1.0 UF 10% 35VDCW    | 56289    | 150D105X9035A2-DYS |
| A4C3                  | 0160-0161      |     | C:FXD MY 0.01 UF 10% 200VDCW     | 56289    | 192P10392-PTS      |
| A4C4                  | 0160-0168      |     | C:FXD MY 0.1 UF 10% 200VDCW      | 56289    | 192P10492-PTS      |
| A4C5                  | 0180-0291      |     | C:FXD ELECT 1.0 UF 10% 35VDCW    | 56289    | 150D105X9035A2-DYS |
| A4C6                  | 0170-0024      | 2   | C:FXD MY 0.022UF 20% 200VDCW     | 56289    | 192P22302          |
| A4C7                  | 0180-0291      |     | C:FXD ELECT 1.0 UF 10% 35VDCW    | 56289    | 150D105X9035A2-DYS |
| A4C8                  | 0180-0097      |     | C:FXD TANT. 47 UF 10% 35VDCW     | 56289    | 1500476X9035S2-DYS |
| A4C9                  | 0180-0049      | 4   | C:FXD ELECT 20 UF +75-10% 50VDCW | 56289    | 30D206G050CC2-DSM  |
| A4C10                 | 0180-0049      |     | C:FXD ELECT 20 UF +75-10% 50VDCW | 56289    | 30D206G050CC2-DSM  |
| A4C11                 | 0180-0291      |     | C:FXD ELECT 1.0 UF 10% 35VDCW    | 56289    | 150D105X9035A2-DYS |
| A4C12                 | 0170-0024      |     | C:FXD MY 0.022UF 20% 200VDCW     | 56289    | 192P22302          |
| A4C13                 | 0180-0291      |     | C:FXD ELECT 1.0 UF 10% 35VDCW    | 56289    | 150D105X9035A2-DYS |
| A4C14                 | 0180-0049      |     | C:FXD ELECT 20 UF +75-10% 50VDCW | 56289    | 30D206G050CC2-DSM  |
| A4C15                 | 0180-0049      |     | C:FXD ELECT 20 UF +75-10% 50VDCW | 56289    | 30D206G050CC2-DSM  |
| A4C16                 | 0160-0168      |     | C:FXD MY 0.1 UF 10% 200VDCW      | 56289    | 192P10492-PTS      |
| A4C17                 | 0160-0161      |     | C:FXD MY 0.01 UF 10% 200VDCW     | 56289    | 192P10392-PTS      |
| A4CR2                 | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4CR3                 | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4CR4                 | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4CR5                 | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4CR6                 | 1902-3290      | 2   | DIODE BREAKDOWN:SILICON 31.6V 5% | 28480    | 1902-3290          |
| A4CR7                 | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4CR8                 | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4CR9                 | 1902-3290      |     | DIODE BREAKDOWN:SILICON 31.6V 5% | 28480    | 1902-3290          |
| A4CR10                | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4CR11                | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4CR12                | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4CR13                | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4E1                  | 0360-0294      |     | TERMINAL:SOLDER POINT            | 28480    | 0360-0294          |
| A4E2                  | 0360-0294      |     | TERMINAL:SOLDER POINT            | 28480    | 0360-0294          |
| A4E3                  | 0360-0294      |     | TERMINAL:SOLDER POINT            | 28480    | 0360-0294          |
| A4E4                  | 0360-0294      |     | TERMINAL:SOLDER POINT            | 28480    | 0360-0294          |
| A4E5                  | 0360-0294      |     | TERMINAL:SOLDER POINT            | 28480    | 0360-0294          |
| A4E6                  | 0360-0294      |     | TERMINAL:SOLDER POINT            | 28480    | 0360-0294          |
| A4E7                  | 0360-0294      |     | TERMINAL:SOLDER POINT            | 28480    | 0360-0294          |
| A4Q1                  | 1853-0281      |     | TSTR:SI PNP                      | 80131    | 2N2907A            |
| A4R1                  | 0757-0280      |     | R:FXD MET FLM 1K OHM 1% 1/8W     | 28480    | 0757-0280          |
| A4R2                  | 0757-0461      |     | R:FXD MET FLM 68.1K OHM 1% 1/8W  | 28480    | 0757-0461          |
| A4R3                  | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W    | 28480    | 0698-0082          |
| A4R4                  | 0757-0459      |     | R:FXD MET FLM 56.2K OHM 1% 1/8W  | 28480    | 0757-0459          |
| A4R5                  | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W    | 28480    | 0698-0082          |
| A4R7                  | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W  | 28480    | 0757-0442          |
| A4R8                  | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W  | 28480    | 0757-0442          |
| A4R9                  | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W  | 28480    | 0698-3162          |
| A4R10                 | 0698-3452      |     | R:FXD MET FLM 147K OHM 1% 1/8W   | 28480    | 0698-3452          |
| A4R11                 | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W  | 28480    | 0698-3162          |
| A4R12                 | 0757-0464      | 1   | R:FXD MET FLM 90.9K OHM 1% 1/8W  | 28480    | 0757-0464          |
| A4R13                 | 0698-3260      | 3   | R:FXD MET FLM 464K OHM 1% 1/8W   | 28480    | 0698-3260          |
| A4R14                 | 0757-0280      |     | R:FXD MET FLM 1K OHM 1% 1/8W     | 28480    | 0757-0280          |
| A4R15                 | 0757-0461      |     | R:FXD MET FLM 68.1K OHM 1% 1/8W  | 28480    | 0757-0461          |
| A4R16                 | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W    | 28480    | 0698-0082          |
| A4R17(NOTE 9)         | 0698-3450      | 1   | R:FXD MET FLM 42.2K OHM 1% 1/8W  | 28480    | 0698-3450          |
| A4R17(NOTE 10)        | 0757-0459      |     | R:FXD MET FLM 56.2K OHM 1% 1/8W  | 28480    | 0757-0459          |
| A4R18                 | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W    | 28480    | 0698-0082          |
| A4R19                 | 0698-3266      | 1   | R:FXD MET FLM 237K OHM 1% 1/8W   | 28480    | 0698-3266          |
| A4R20                 | 0698-3459      | 2   | R:FXD MET FLM 383K OHM 1% 1/8W   | 28480    | 0698-3459          |
| A4R21                 | 0698-3452      |     | R:FXD MET FLM 147K OHM 1% 1/8W   | 28480    | 0698-3452          |
| A4R22                 | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W  | 28480    | 0698-3162          |
| A4R23                 | 0757-0280      |     | R:FXD MET FLM 1K OHM 1% 1/8W     | 28480    | 0757-0280          |
| A4R24                 | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W  | 28480    | 0698-3162          |
| A4R25                 | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W    | 28480    | 0698-0082          |
| A4R26                 | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W    | 28480    | 0698-0082          |
| A4R27                 | 0698-3161      | 1   | R:FXD MET FLM 38.3K OHM 1% 1/8W  | 28480    | 0698-3161          |
| A4R28                 | 0757-0280      |     | R:FXD MET FLM 1K OHM 1% 1/8W     | 28480    | 0757-0280          |
| A4R29                 | 0757-0199      |     | R:FXD MET FLM 21.5K OHM 1% 1/8W  | 28480    | 0757-0199          |

NOTES: 9. First used on card rev. 1144.  
10. Used on card rev. 1126 only.

Table 7-2. Power Supply, Replaceable Parts (Continued)

| Reference Designation | HP Part Number | Qty | Description                            | Mfr Code | Mfr Part Number |
|-----------------------|----------------|-----|--|----------|-----------------|
| A4R30                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W        | 28480    | 0757-0442       |
| A4R31                 | 0757-0280      |     | R:FXD MET FLM 1K OHM 1% 1/8W           | 28480    | 0757-0280       |
| A4R32                 | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W        | 28480    | 0698-3162       |
| A4R33                 | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W          | 28480    | 0698-0082       |
| A4R34                 | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W          | 28480    | 0698-0082       |
| A4R35                 | 0698-3160      |     | R:FXD MET FLM 31.6K OHM 1% 1/8W        | 28480    | 0698-3160       |
| A4R36                 | 0698-3260      |     | R:FXD MET FLM 464K OHM 1% 1/8W         | 28480    | 0698-3260       |
| A4R37                 | 0757-0280      |     | R:FXD MET FLM 1K OHM 1% 1/8W           | 28480    | 0757-0280       |
| A4R38                 | 0757-0461      |     | R:FXD MET FLM 68.1K OHM 1% 1/8W        | 28480    | 0757-0461       |
| A4R39                 | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W          | 28480    | 0698-0082       |
| A4R40                 | 0757-0459      |     | R:FXD MET FLM 56.2K OHM 1% 1/8W        | 28480    | 0757-0459       |
| A4R41                 | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W          | 28480    | 0698-0082       |
| A4R42                 | 0698-4037      |     | R:FXD MET FLM 46.4 OHM 1% 1/8W         | 28480    | 0698-4037       |
| A4R43                 | 0698-4037      |     | R:FXD MET FLM 46.4 OHM 1% 1/8W         | 28480    | 0698-4037       |
| A4R44                 | 0698-0084      |     | R:FXD MET FLM 2.15K OHM 1% 1/8W        | 28480    | 0698-0084       |
| A4R45                 | 0698-4037      |     | R:FXD MET FLM 46.4 OHM 1% 1/8W         | 28480    | 0698-4037       |
| A4R46                 | 0698-0084      |     | R:FXD MET FLM 2.15K OHM 1% 1/8W        | 28480    | 0698-0084       |
| A4R47                 | 0698-4037      |     | R:FXD MET FLM 46.4 OHM 1% 1/8W         | 28480    | 0698-4037       |
| A4R48                 | 0683-8245      | 1   | R:FXD COMP 820K OHM 5% 1/4W            | 01121    | CB 8245         |
| A4R49                 | 0698-3459      |     | R:FXD MET FLM 383K OHM 1% 1/8W         | 28480    | 0698-3459       |
| A4R50                 | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W        | 28480    | 0698-3162       |
| A4R51                 | 0698-3456      | 1   | R:FXD MET FLM 287K OHM 1% 1/8W         | 28480    | 0698-3456       |
| A4R52                 | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W        | 28480    | 0698-3162       |
| A4R53                 | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W        | 28480    | 0698-3162       |
| A4R54                 | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W        | 28480    | 0698-3162       |
| A4R55                 | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W        | 28480    | 0698-3162       |
| A4R56                 | 0757-0462      |     | R:FXD MET FLM 75.0K OHM 1% 1/8W        | 28480    | 0757-0462       |
| A4R57                 | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W        | 28480    | 0698-3162       |
| A4R58                 | 0757-0463      | 1   | R:FXD MET FLM 82.5K OHM 1% 1/8W        | 28480    | 0757-0463       |
| A4R59                 | 0698-3260      |     | R:FXD MET FLM 464K OHM 1% 1/8W         | 28480    | 0698-3260       |
| A4U1                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.                  | 07263    | U6A7741393      |
| A4U2                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.                  | 07263    | U6A7741393      |
| A4U3                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.                  | 07263    | U6A7741393      |
| A4U4                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.                  | 07263    | U6A7741393      |
| A4U5                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.                  | 07263    | U6A7741393      |
| A4U6                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.                  | 07263    | U6A7741393      |
| A4U7                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.                  | 07263    | U6A7741393      |
| A4U8                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.                  | 07263    | U6A7741393      |
| A4U9                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.                  | 07263    | U6A7741393      |
| A5                    | 02100-60048    | 1   | OUTPUT BOARD ASSY:+160V                | 28480    | 02100-60048     |
| A5C1                  | 0160-0127      | 1   | C:FXD CER 1.0 UF 20% 25VDCW            | 56289    | 5C13CS-CML      |
| A5C17                 | 0180-2418      | 2   | C:FXD AL ELECT 9800 UF +75-10% 100VDCW | 56289    | 36D982G100CC2A  |
| A5C18                 | 0180-2418      |     | C:FXD AL ELECT 9800 UF +75-10% 100VDCW | 56289    | 36D982G100CC2A  |
| A5CR1                 | 1901-0164      | 6   | DIODE:SILICON 200PIV 3A                | 04713    | 1N4721          |
| A5CR2                 | 1901-0164      |     | DIODE:SILICON 200PIV 3A                | 04713    | 1N4721          |
| A5CR3(NOTE 11)        | 1902-3428      | 2   | DIODE BREAKDOWN:SILICON 100V 5%        | 28480    | 1902-3428       |
| A5CR3(NOTE 12)        | 1902-3416      | 2   | DIODE BREAKDOWN:90.9V 5% 400 MW        | 07910    | CD35982         |
| A5CR4(NOTE 11)        | 1902-3428      |     | DIODE BREAKDOWN:SILICON 100V 5%        | 28480    | 1902-3428       |
| A5CR4(NOTE 12)        | 1902-3416      |     | DIODE BREAKDOWN:90.9V 5% 400 MW        | 07910    | CD35982         |
| A5CR5                 | 1901-0050      |     | DIODE:SI 200 MA AT 1V                  | 07263    | FDA 6308        |
| A5F1                  | 2110-0083      | 2   | FUSE:2/2.5A(FOR 230V OPERATION)        | 28480    | 2110-0083       |
| A5F2                  | 2110-0083      |     | FUSE:2/2.5A(FOR 230V OPERATION)        | 28480    | 2110-0083       |
| A5Q1(NOTE 13)         | 1884-0219      | 3   | THYRISTOR                              | 28480    | 1884-0219       |
| A5Q1(NOTE 14)         | 1884-0211      | 3   | THYRISTOR:SCR SI NPN                   | 04713    | 2N5171          |
| A5R1                  | 0764-0018      | 2   | R:FXD MET FLM 4700 OHM 5% 2W           | 28480    | 0764-0018       |
| A5R2                  | 0764-0018      |     | R:FXD MET FLM 4700 OHM 5% 2W           | 28480    | 0764-0018       |
| A5R3                  | 0757-0284      | 5   | R:FXD MET FLM 150 OHM 1% 1/8W          | 28480    | 0757-0284       |
| A5R4                  | 0757-0316      | 6   | R:FXD MET FLM 42.2 OHM 1% 1/8W         | 28480    | 0757-0316       |
| A5R5                  | 0689-0275      | 1   | R:FXD COMP 2.7 OHM 5% 1W               | 01121    | GB 27G5         |
| A5R6                  | 0757-0316      |     | R:FXD MET FLM 42.2 OHM 1% 1/8W         | 28480    | 0757-0316       |
| A5R7                  | 0811-3108      | 1   | R:FXD WW 2 OHM 10%                     | 28480    | 0811-3108       |
| A5T1                  | 9100-2927      | 1   | TRANSFORMER:PULSE                      | 28480    | 9100-2927       |
| A6C1                  | 0160-0904      | 3   | C:FXD CER 0.05 UF 20% 1000VDCW         | 56289    | 41C 169A4-CDH   |
| A6C2                  | 0160-0904      |     | C:FXD CER 0.05 UF 20% 1000VDCW         | 56289    | 41C 169A4-CDH   |
| A6C3                  | 0160-0904      |     | C:FXD CER 0.05 UF 20% 1000VDCW         | 56289    | 41C 169A4-CDH   |
| A6CR1                 | 1901-1061      | 2   | DIODE:RECTIFIER 12A 600V               | 04713    | MR886           |
| A6CR2                 | 1901-1061      |     | DIODE:RECTIFIER 12A 600V               | 04713    | MR886           |
| A6Q1(NOTE 15)         | 1884-0219      |     | THYRISTOR                              | 28480    | 1884-0219       |
| A6Q1(NOTE 16)         | 1884-0211      |     | THYRISTOR:SCR SI NPN                   | 04713    | 2N5171          |
| A6Q2(NOTE 15)         | 1884-0219      |     | THYRISTOR                              | 28480    | 1884-0219       |
| A6Q2(NOTE 16)         | 1884-0211      |     | THYRISTOR:SCR SI NPN                   | 04713    | 2N5171          |
| A6R1                  | 0698-3402      |     | R:FXD MET FLM 316 OHM 1% 1/2W          | 28480    | 0698-3402       |
| A6S1                  | 3103-0015      | 2   | SWITCH:THERMAL FXD SPST                | 28480    | 3103-0015       |
| A6A1                  | 02100-60059    | 1   | PREREGULATOR DRIVER BOARD ASSY         | 28480    | 02100-60059     |
| A6A1R1                | 0757-0316      |     | R:FXD MET FLM 42.2 OHM 1% 1/8W         | 28480    | 0757-0316       |

NOTES: 11. First used on card rev. 1139.  
12. Used on card rev. 1125 only.  
13. First used on card rev. 1150.

14. Used on card rev. 1125 and 1139. Use 1884-0219 for replacement.  
15. First used on power supply with date code 1146.  
16. Used on power supply with date code 1126, 1140, and 1141. Use 1884-0219 for replacement.

Table 7-2. Power Supply, Replaceable Parts (Continued)

| Reference Designation | HP Part Number | Qty           | Description                            | Mfr Code      | Mfr Part Number    |           |
|-----------------------|----------------|---------------|--|---------------|--------------------|-----------|
| A6A1R2                | 0757-0284      | 1             | R:FXD MET FLM 150 OHM 1% 1/8W          | 28480         | 0757-0284          |           |
| A6A1R3                | 0757-0316      |               | R:FXD MET FLM 42.2 OHM 1% 1/8W         | 28480         | 0757-0316          |           |
| A6A1R4                | 0757-0284      |               | R:FXD MET FLM 150 OHM 1% 1/8W          | 28480         | 0757-0284          |           |
| A6A1T1                | 9100-2925      |               | TRANSFORMER:PULSE                      | 28480         | 9100-2925          |           |
| A7C4 THRU             | 0160-0174      |               | C:FXD CER 0.47 UF +80-20% 25VDCW       | 56289         | 5C11B7S-CML        |           |
| A7C11                 |                |               |  |               |                    |           |
| A7C12                 | 0160-0303      | 2             | C:FXD MYLAR .15 UF 10% 200VDCW         | 28480         | 0160-0303          |           |
| A7C13                 | 0160-0303      |               | C:FXD MYLAR .15 UF 10% 200VDCW         | 28480         | 0160-0303          |           |
| A7CR3 THRU            | 1901-1065      |               | DIODE:1N4936                           | 28480         | 1901-1065          |           |
| A7CR10                |                |               |  |               |                    |           |
| A7Q3 THRU             | 1854-0080      | 8             | TSTR:SI NPN                            | 28480         | 1854-0080          |           |
| A7Q10                 |                |               |  |               |                    |           |
| A7T1                  | 9100-2924      | 2             | TRANSFORMER:PULSE                      | 28480         | 9100-2924          |           |
| A7T2                  | 9100-2924      |               | TRANSFORMER:PULSE                      | 28480         | 9100-2924          |           |
| A8C411 THRU           | 1901-0159      | 1             | DIODE:SILICON 0.75A 400PIV             | 04713         | SP1358-4           |           |
| A8CR18                |                |               |  |               |                    |           |
| A8CR19 THRU           | 1901-1036      | 9             | DIODE:RECTIFIER 12A 100V               | 04713         | MF881              |           |
| A8CR26                |                |               |  |               |                    |           |
| A8CR27 THRU           | 1901-1062      | 8             | DIODE:POWER RECTIFIER                  | 04713         | M9D-5400           |           |
| A8CR30                |                |               |  |               |                    |           |
| A8CR31 THRU           | 1901-1035      | 4             | DIODE:FXD 100V 12 AMP                  | 28480         | 1901-1035          |           |
| A8CR34                |                |               |  |               |                    |           |
| A8R7                  | 0761-0021      | 1             | R:FXD MET OX 1000 OHM 5% 1W            | 28480         | 0761-0021          |           |
| A9C27 THRU            | 0150-0121      |               | C:FXD CER 0.1 UF +80-20% 50VDCW        | 56289         | 5C50BIS-CML        |           |
| A9C30                 |                |               |  |               |                    |           |
| A9CR35 THRU           | 1901-1062      | 4             | DIODE:POWER RECTIFIER                  | 04713         | M8D-5400           |           |
| A9CR38                |                |               |  |               |                    |           |
| A9CR46 THRU           | 1902-0202      |               | DIODE BREAKDOWN:15.0V 5% 1W            | 28480         | 1902-0202          |           |
| A9CR49                |                |               |  |               |                    |           |
| A9S2                  | 3103-0015      |               | SWITCH:THERMAL FXD SPST                | 28480         | 3103-0015          |           |
| A10CR39               | 1901-0315      | 2             | DIODE:SI 50 PIV 40A                    | 80131         | 1M1183A            |           |
| A10CR40               | 1901-0315      |               | DIODE:SI 50 PIV 40A                    | 80131         | 1N1183A            |           |
| A10Q11                | 1884-0208      | 2             | THYRISTOR:35 AMP RMS 100V              | 12040         | NL570A             |           |
| A10Q12                | 1884-0208      |               | THYRISTOR:35 AMP RMS 100V              | 12040         | NL570A             |           |
| A10R2                 | 0757-0284      |               | R:FXD MET FLM 150 OHM 1% 1/8W          | 28480         | 0757-0284          |           |
| A10R3                 | 0757-0316      | 1             | R:FXD MET FLM 42.2 OHM 1% 1/8W         | 28480         | 0757-0316          |           |
| A10R4                 | 0757-0316      |               | R:FXD MET FLM 42.2 OHM 1% 1/8W         | 28480         | 0757-0316          |           |
| A10K5                 | 0757-0284      |               | R:FXD MET FLM 150 OHM 1% 1/8W          | 28480         | 0757-0284          |           |
| A10R6                 | 0698-3180      |               | R:FXD MET OX 68 OHM 2% 2W              | 28480         | 0698-3180          |           |
| A11C14                | 0180-0141      |               | C:FXD ELECT 50 UF +75-10% 50VDCW       | 56289         | 30D5066050DD2-DSM  |           |
| A11C15(NOTE 24)       | 0180-0141      |               | C:FXD ELECT 50 UF +75-10% 50VDCW       | 56289         | 30D5066050DD2-DSM  |           |
| A11C15(NOTE 25)       | 0180-2546      |               | C:FXD ELECT 770 UF #75-10% 40VDCW      | 56289         | 601D777G040CP4-DAC |           |
| A11CR41               | 1901-1036      |               | DIODE:RECTIFIER 12A 100V               | 04713         | MR881              |           |
| A11L1(NOTE 24)        | 9100-2928      |               | 3                                      | INDUCTOR:4 UH | 28480              | 9100-2928 |
| A11L2                 | 9100-2928      |               |  | INDUCTOR:4 UH | 28480              | 9100-2928 |
| A11L3(NOTE 24)        | 9100-2928      | INDUCTOR:4 UH |  | 28480         | 9100-2928          |           |
| A11L4(NOTE 17)        | 9100-2934      | 1             | INDUCTOR                               | 28480         | 9100-2934          |           |
| A11L4(NOTE 17)        | 9100-2926      |               | INDUCTOR:200 UH                        | 28480         | 9100-2926          |           |
| A11Q13                | 1853-0310      | 2             | TSTR:SI PNP                            | 04713         | 2N4398             |           |
| A11Q14                | 1853-0310      |               | TSTR:SI PNP                            | 04713         | 2N4398             |           |
| B1                    | 3160-0224      | 2             | FAN:TUBE AXIAL                         | 28480         | 3160-0224          |           |
| B2                    | 3160-0224      |               | FAN:TUBE AXIAL                         | 28480         | 3160-0224          |           |
| C16                   | 0180-2416      | 1             | C:FXD AL ELECT 9900 UF +75-10% 30VDCW  | 56289         | 602D992G030AF2A    |           |
| C19                   | 0180-2417      |               | C:FXD AL ELECT 430 UF +50-10% 200VDCW  | 56289         | 36D431F200A82A     |           |
| C20                   | 0180-2417      | 1             | C:FXD AL ELECT 430 UF +50-10% 200VDCW  | 56289         | 36D431F200A82A     |           |
| C21                   | 0180-2413      |               | C:FXD AL ELECT 7500 UF +75-10% 15VDCW  | 56289         | 36D752G015AA2A     |           |
| C22                   | 0180-2414      | 1             | C:FXD AL ELECT 2900 UF +75-10% 40VDCW  | 56289         | 36D292G040AA2A     |           |
| C23                   | 0180-2410      |               | C:FXD ELECT 18000 UF +75-10% 15VDCW    | 56289         | 602D183G015AF2A    |           |
| C24                   | 0180-2411      | 1             | C:FXD AL ELECT 22000 UF +75-10% 10VDCW | 56289         | 602D223G010AF2A    |           |
| C25                   | 0180-2412      |               | C:FXD AL ELECT 37000 UF +75-10% 5VDCW  | 56289         | 602D373G5P0AF2A    |           |
| C26                   | 0180-2410      |               | C:FXD ELECT 18000 UF +75-10% 15VDCW    | 56289         | 602D183G015AF2A    |           |
| CR42 THRU             | 1901-0164      | 1             | DIODE:SILICON 200PIV 3A                | 04713         | 1N4721             |           |
| CR45                  |                |               |  |               |                    |           |
| F5                    | 2110-0004      | 1             | FUSE:CARTRIDGE 1/4 AMP 250V            | 75915         | 3AG/CAT. 312.250   |           |
| L5 (NOTE 18)          | 9100-2931      |               | INDUCTOR                               | 28480         | 9100-2931          |           |
| L5 (NOTE 18)          | 9100-2917      | 2             | INDUCTOR:50 UH                         | 28480         | 9100-2917          |           |
| L6 (NOTE 18)          | 9100-2931      |               | INDUCTOR                               | 28480         | 9100-2931          |           |
| L6 (NOTE 18)          | 9100-2917      | 1             | INDUCTOR:50 UH                         | 28480         | 9100-2917          |           |
| L7 (NOTE 18)          | 9100-2932      |               | INDUCTOR                               | 28480         | 9100-2932          |           |
| L7 (NOTE 18)          | 9100-2918      | 1             | INDUCTOR:8 UH                          | 28480         | 9100-2918          |           |
| L8 (NOTE 18)          | 9100-2933      |               | INDUCTOR                               | 28480         | 9100-2933          |           |
| L8 (NOTE 18)          | 9100-2919      | 1             | INDUCTOR:9 UH                          | 28480         | 9100-2919          |           |
| L9                    | 9100-2920      |               | INDUCTOR:1.6 UH                        | 28480         | 9100-2920          |           |
| T3                    | 9100-2923      | 2             | TRANSFORMER:POWER                      | 28480         | 9100-2923          |           |
| T4                    | 9100-2923      |               | TRANSFORMER:POWER                      | 28480         | 9100-2923          |           |
| T5                    | 9100-2922      | 1             | TRANSFORMER:POWER                      | 28480         | 9100-2922          |           |
| T6                    | 9100-2921      |               | INDUCTOR:DUAL 8 MH                     | 28480         | 9100-2921          |           |

NOTES: 17. Encapsulated (9100-2934) and open (9100-2927) inductors are electrically but not mechanically interchangeable. See Section VI for replacement information.


18. Note 17 applies (9100-2931, 9100-2932, and 9100-2933 are encapsulated inductors).

24. Used only on power supplies prior to date code 1229.

25. First used on power supply date code 1229.




Power Supply




DWG REV. E

- NOTES:
1. CR18 USED ON CARD REV. 1133 ONLY.
  2. C1 LOCATED HERE ON CARD REV. 1133 AND 1139.
  3. R59 USED ON CARD REV. 1133, 1139, AND 1140 ONLY.



NOTES:


1. RESISTANCE VALUES ARE IN OHMS AND CAPACITANCE VALUES ARE IN UF UNLESS OTHERWISE SPECIFIED.
2. A3CR9 IS OPTIONAL. REMOVE FOR THERMAL AUTO-RESTART.
3. A1CR18 USED ON CARD REV. 1133 ONLY.
4. VOLTAGE FOR A5CR3 AND A5CR4 IS 90.9V ON CARD REV. 1125.
5. A4R17 IS 56.2K ON CARD REV. 1126.
6. A2CR11 USED ON CARD REV. 1126 ONLY.
7. A3R40 IS 1.21K, A3R53 IS 100K, AND A3R59 IS 15K, ON CARD REV. 1132.
8. A1R59 REPLACED BY STRAIGHT CONNECTION TO E1 STARTING WITH CARD REV. 1148.
9. L1 AND L3 ARE REPLACED WITH JUMPER WIRES AND C15 IS REPLACED WITH A 770 UF CAPACITOR STARTING WITH POWER SUPPLY DATE CODE 1229.
10. ON A3 CARD REV. 1132 AND 1147, A3R45 IS 14.7 OHMS, A3R49 IS 4.64K, A3R55 IS 56.2K, A3R57 IS 825 OHMS, A3R60 IS 2.37K, AND A3CR20 IS INSTALLED WHERE A3W1 IS SHOWN (ANODE ON RIGHT).
11. ON A3 CARD REV. 1132 AND 1147, A3R47 IS INSTALLED WHERE A3W2 IS SHOWN. ON CARD REV. 1132, A3R47 IS 31.6K. ON CARD REV. 1147, A3R47 IS 10.0K.
12. ON CARD REV. 1132, A3R61 IS 8.25K. ON CARD REV. 1147, A3R61 IS 4.64K.





DWG. REV. E2 (02100-60053)

(THIS DRAWING IS APPLICABLE TO POWER SUPPLY BUILT PRIOR TO DATE CODE)

COMPUTER OR EXTENDER PLENUM CHAMBER




A1 PREREGULATOR CONTROL CARD (02100-60046, REV. 1133, 1139, 1140, 1148)



NOTES:

1. RESISTANCE VALUES ARE IN OHMS AND CAPACITANCE VALUES ARE IN UF UNLESS OTHERWISE SPECIFIED.
2. A3CR9 IS OPTIONAL. REMOVE FOR THERMAL AUTO-RESTART.
3. A1CR18 USED ON CARD REV. 1133 ONLY.
4. VOLTAGE FOR A5CR3 AND A5CR4 IS 90.9V ON CARD REV. 1125.
5. A4R17 IS 56.2K ON CARD REV. 1126.
6. A2CR11 USED ON CARD REV. 1126 ONLY.
7. A3R40 IS 1.21K, A3R53 IS 100K, AND A3R59 IS 15K, ON CARD REV. 1132.
8. A1R59 REPLACED BY STRAIGHT CONNECTION TO E1 STARTING WITH CARD REV. 1148.
9. L1 AND L3 ARE REPLACED WITH JUMPER WIRES AND C15 IS REPLACED WITH A 770 UF CAPACITOR STARTING WITH POWER SUPPLY DATE CODE 1229.
10. ON A3 CARD REV. 1132 AND 1147, A3R45 IS 14.7 OHMS, A3R49 IS 4.64K, A3R55 IS 56.2K, A3R57 IS 825 OHMS, A3R60 IS 2.37K, AND A3CR20 IS INSTALLED WHERE A3W1 IS SHOWN (ANODE ON RIGHT).
11. ON A3 CARD REV. 1132 AND 1147, A3R47 IS INSTALLED WHERE A3W2 IS SHOWN. ON CARD REV. 1132, A3R47 IS 31.6K. ON CARD REV. 1147, A3R47 IS 10.0K.
12. ON CARD REV. 1132, A3R61 IS 8.25K. ON CARD REV. 1147, A3R61 IS 4.64K.



DWG. REV. E2 (02100-60053, SHEET 1 OF 4)

(THIS DRAWING IS APPLICABLE TO POWER SUPPLIES BUILT PRIOR TO DATE CODE 1240)

R1  
R2  
R3  
R4  
Q2  
R6  
02100-60046  
C-1148-22

R7  
R8  
R9  
R6  
10










Figure 7-3. Power Supply (Preregulator Control) Parts Location and Schematic Diagrams, Date Codes Prior to 1240 (Sheet 1 of 4)

Power Supply



A2 INVERTER DRIVER CARD (02)










Figure 7-3. Power Supply (Inverter Driver) Parts Location and Schematic Diagrams, Date Codes Prior to 1240 (Sheet 2 of 4)



NOTE:  
EXCEPT FOR W1 AND W2, THIS DIAGRAM ALSO APPLIES TO CARD REV. 3-1132-22 AND B-1147-22. ON THESE CARD REV., CR20 IS INSTALLED WHERE W1 IS SHOWN (ANODE ON BOTTOM) AND R47 IS INSTALLED WHERE W2 IS SHOWN.








Figure 7-3. Power Supply (Protection and Control) Parts Location and Schematic Diagrams, Date Codes Prior to 1240 (Sheet 3 of 4)






DWG REV. C



NOTE: THIS DIAGRAM ALSO APPLIES TO CARD REV. A-1126-22.



DWG. REV. E (SHEET 4 OF 4) SEE SHEET 1 FOR NOTES.  
 (THIS DRAWING IS APPLICABLE TO POWER SUPPLIES  
 BUILT PRIOR TO DATE CODE 1240)




Figure 7-3. Power Supply (Current Limit) Parts Location and Schematic Diagrams, Date Codes Prior to 1240 (Sheet 4 of 4)

Table 7-3. Preregulator Control Card A1 (02100-60108), Replaceable Parts


| Reference Designation | HP Part Number | Qty | Description                          | Mfr Code | Mfr Part Number      |
|-----------------------|----------------|-----|--------------------------------------|----------|----------------------|
| A1                    | 02100-60108    | 1   | PREREGULATOR CONTROL CARD            | 28483    | 02100-60108          |
| A1C1                  | 0160-2147      | 2   | C:FXD CER 0.025 UF +80-20% 100VDCW   | 91418    | TA                   |
| A1C2                  | 0180-0291      | 7   | C:FXD ELECT 1.0 UF 10% 35VDCW        | 56289    | 1500105X9035A2-DYS   |
| A1C3                  | 0160-2055      | 3   | C:FXD CER 0.01 UF +80-20% 100VDCW    | 56289    | C023F101F103ZS22-CDH |
| A1C4                  | 0180-0291      |     | C:FXD ELECT 1.0 UF 10% 35VDCW        | 56289    | 1500105X9035A2-DYS   |
| A1C5                  | 0170-0040      | 2   | C:FXD MY 0.047 UF 10% 200VDCW        | 56289    | 192P47392-PTS        |
| A1C6                  | 0160-2147      |     | C:FXD CER 0.025 UF +80-20% 100VDCW   | 91413    | TA                   |
| A1C7                  | 0180-0197      | 4   | C:FXD ELECT 2.2 UF 10% 20VDCW        | 56289    | 1500225X9020A2-DYS   |
| A1C8                  | 0180-0197      |     | C:FXD ELECT 2.2 UF 10% 20VDCW        | 56289    | 1500225X9020A2-DYS   |
| A1C9                  | 0180-0161      | 1   | C:FXD ELECT 3.3 UF 20% 35VDCW        | 56289    | 1500335X0035B2-DYS   |
| A1C10                 | 0160-0160      | 1   | C:FXD ELECT 4.7 UF 10% 35VDCW        | 56289    | 1500475X9035B2-DYS   |
| A1C11                 | 0160-0197      |     | C:FXD ELECT 2.2 UF 10% 20VDCW        | 56289    | 1500225X9020A2-DYS   |
| A1C12                 | 0180-0141      | 1   | C:FXD ELECT 50 UF +75-10% 50VDCW     | 56289    | 30D506G050DD2-DSM    |
| A1C13                 | 0180-0097      | 3   | C:FXD TANT. 47 UF 10% 35VDCW         | 56289    | 1500476X9035S2-DYS   |
| A1C14                 | 0180-2415      | 1   | C:FXD AL ELECT 200 UF +75-10% 40VDCW | 56289    | 39D207G040EL         |
| A1C15(NOTE 1)         | 0150-0093      | 1   | C:FXD CER 0.01 UF +80-20% 100VDCW    | 72982    | 801-K800011          |
| A1C16                 | 1902-3094      | 1   | DIODE BREAKDOWN:5.11V 2%             | 29480    | 1902-3094            |
| A1C17                 | 1901-0040      | 30  | DIODE:SILICON 30MA 30MV              | G7263    | FDG1088              |
| A1C18                 | 1901-0159      | 9   | DIODE:SILICON 0.75A 400PIV           | 04713    | SR1358-4             |
| A1C19                 | 1901-0159      |     | DIODE:SILICON 0.75A 400PIV           | 04713    | SR1358-4             |
| A1C20                 | 1901-0159      |     | DIODE:SILICON 0.75A 400PIV           | 04713    | SR1358-4             |
| A1C21                 | 1901-0159      |     | DIODE:SILICON 0.75A 400PIV           | 04713    | SR1358-4             |
| A1E1                  | 0683-0275      | 8   | R:FXD COMP 2.7 OHM 5% 1/4W           | 01121    | CB 27G5              |
| A1E2                  | 0683-0275      |     | R:FXD COMP 2.7 OHM 5% 1/4W           | 01121    | CB 27G5              |
| A1E3                  | 0683-0275      |     | R:FXD COMP 2.7 OHM 5% 1/4W           | 01121    | CB 27G5              |
| A1E4                  | 0683-0275      |     | R:FXD COMP 2.7 OHM 5% 1/4W           | 01121    | CB 27G5              |
| A1E5                  | 0683-0275      |     | R:FXD COMP 2.7 OHM 5% 1/4W           | 01121    | CB 27G5              |
| A1L1                  | 9140-0131      | 1   | COIL:FXD RF 10 MH                    | 28480    | 9140-0131            |
| A1Q1                  | 1854-0477      | 12  | TSTR:SI NPN                          | 80131    | 2N2222A              |
| A1Q2                  | 1853-0281      | 14  | TSTR:SI PNP                          | 80131    | 2N2907A              |
| A1Q3                  | 1853-0281      |     | TSTR:SI PNP                          | 80131    | 2N2907A              |
| A1Q4                  | 1853-0281      |     | TSTR:SI PNP                          | 80131    | 2N2907A              |
| A1Q5                  | 1854-0477      |     | TSTR:SI NPN                          | 80131    | 2N2222A              |
| A1Q6                  | 1853-0281      |     | TSTR:SI PNP                          | 80131    | 2N2907A              |
| A1Q7                  | 1854-0672      | 2   | TSTR:SI NPN                          | 80131    | 2N3054               |
| A1Q8                  | 1854-0477      | 5   | TSTR:SI NPN                          | 80131    | 2N2222A              |
| A1Q9                  | 1854-0477      |     | TSTR:SI NPN                          | 80131    | 2N2222A              |
| A1Q10                 | 1854-0672      | 3   | TSTR:SI NPN                          | 80131    | 2N3053               |
| A1Q11                 | 1854-0672      |     | TSTR:SI NPN                          | 80131    | 2N3054               |
| A1Q12                 | 1854-0477      |     | TSTR:SI NPN                          | 80131    | 2N222A               |
| A1Q13                 | 1853-0281      |     | TSTR:SI PNP                          | 80131    | 2N2907A              |
| A1Q14                 | 1854-0477      |     | TSTR:SI NPN                          | 80131    | 2N2222A              |
| A1Q15                 | 1854-0477      |     | TSTR:SI NPN                          | 80131    | 2N2222A              |
| A1Q16                 | 1853-0281      |     | TSTR:SI PNP                          | 80131    | 2N2907A              |
| A1Q17                 | 1853-0281      |     | TSTR:SI PNP                          | 80131    | 2N2907A              |
| A1Q18                 | 1854-0672      |     | TSTR:SI NPN                          | 80131    | 2N3053               |
| A1R1                  | 0757-0199      | 4   | R:FXD MET FLM 21.5K OHM 1% 1/8W      | 28480    | 0757-0199            |
| A1R2                  | 0757-0279      | 2   | R:FXD MET FLM 3.61K OHM 1% 1/8W      | 28480    | 0757-0279            |
| A1R3                  | 0757-0442      | 14  | R:FXD MET FLM 10.0K OHM 1% 1/8W      | 28480    | 0757-0442            |
| A1R4                  | 0757-0200      | 1   | R:FXD MET FLM 5.63K OHM 1% 1/8W      | 28480    | 0757-0200            |
| A1R5                  | 0757-0280      | 10  | R:FXD MET FLM 1K OHM 1% 1/8W         | 28480    | 0757-0280            |
| A1R6                  | 0757-0280      |     | R:FXD MET FLM 1K OHM 1% 1/8W         | 28480    | 0757-0280            |
| A1R7                  | 0683-0275      |     | R:FXD COMP 2.7 OHM 5% 1/4W           | 01121    | CB 27G5              |
| A1R8                  | 0757-0290      | 1   | R:FXD MET FLM 6.19K OHM 1% 1/8W      | 28480    | 0757-0290            |
| A1R9                  | 2100-2521      | 1   | R:VAR FLM 2000 OHM 10% LIN 1/2W      | 28480    | 2100-2521            |
| A1R10                 | 0757-0438      | 6   | R:FXD MET FL4 5.11K OHM 1% 1/8W      | 28480    | 0757-0438            |
| A1R11                 | 0698-3449      | 2   | R:FXD MET FLM 28.7K OHM 1% 1/8W      | 28480    | 0698-3449            |
| A1R12                 | 0757-0438      |     | R:FXD MET FL4 5.11K OHM 1% 1/8W      | 28480    | 0757-0438            |
| A1R13                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W      | 28480    | 0757-0442            |
| A1R14                 | 0698-0085      | 1   | R:FXD MET FLM 2.61K OHM 1% 1/8W      | 28480    | 0698-0085            |
| A1R15                 | 0757-0280      | 1   | R:FXD MET FLM 13.5K OHM 1% 1/8W      | 28480    | 0757-0280            |
| A1R16                 | 0757-0280      |     | R:FXD MET FLM 1K OHM 1% 1/8W         | 28480    | 0757-0280            |
| A1R17                 | 0757-0199      |     | R:FXD MET FLM 21.5K OHM 1% 1/8W      | 28480    | 0757-0199            |
| A1R18                 | 0757-0419      | 1   | R:FXD MET FLM 681 OHM 1% 1/8W        | 28480    | 0757-0419            |
| A1R19                 | 0757-0280      |     | R:FXD MET FL4 1K OHM 1% 1/8W         | 28480    | 0757-0280            |
| A1R20                 | 0757-0431      | 5   | R:FXD MET FLM 100 OHM 1% 1/8W        | 28480    | 0757-0431            |
| A1R21                 | 0698-3613      | 1   | R:FXD MET OX 39 OHM 5% 2W            | 28480    | 0698-3613            |
| A1R22                 | 0698-3153      | 1   | R:FXD MET FLM 3.63K OHM 1% 1/8W      | 28480    | 0698-3153            |
| A1R24                 | 0683-0275      |     | R:FXD COMP 2.7 OHM 5% 1/4W           | 01121    | CB 27G5              |
| A1R25                 | 0757-0424      | 1   | R:FXD MET FLM 1.10K OHM 1% 1/8W      | 28480    | 0757-0424            |
| A1R26                 | 0757-0421      | 1   | R:FXD MET FLM 825 OHM 1% 1/8W        | 28480    | 0757-0421            |
| A1R26                 | 0757-0461      | 4   | R:FXD MET FLM 68.1K OHM 1% 1/8W      | 28480    | 0757-0461            |
| A1R28                 | 0757-0199      |     | R:FXD MET FLM 21.5K OHM 1% 1/8W      | 28480    | 0757-0199            |
| A1R29                 | 0757-0401      | 1   | R:FXD MET FLM 100 OHM 1% 1/8W        | 28480    | 0757-0401            |

NOTES: 1. First used on card rev. 1249.

Table 7-3. Preregulator Control Card A1 (02100-60108), Replaceable Parts (Continued)

| Reference Designation | HP Part Number | Qty | Description                      | Mfr Code | Mfr Part Number |
|-----------------------|----------------|-----|----------------------------------|----------|-----------------|
| A1R30                 | 0757-0438      |     | R:F XD MET FLM 5.11K OHM 1% 1/8W | 28480    | 0757-0438       |
| A1R31                 | 0683-0275      |     | R:F XD CCMP 2.7 OHM 5% 1/4W      | 01121    | CB 27G5         |
| A1R32                 | 0698-3449      |     | R:F XD MET FLM 28.7K OHM 1% 1/8W | 28480    | 0698-3449       |
| A1R33                 | 0757-1094      | 1   | R:F XD MET FLM 1.47K OHM 1% 1/8W | 28480    | 0757-1094       |
| A1R34                 | 0698-3154      | 1   | R:F XD MET FLM 4.22K OHM 1% 1/8W | 28480    | 0698-3154       |
| A1R35                 | 0757-0442      |     | R:F XD MET FLM 10.0K OHM 1% 1/8W | 28480    | 0757-0442       |
| A1R36                 | 0698-3156      | 5   | R:F XD MET FLM 14.7K OHM 1% 1/8W | 28480    | 0698-3156       |
| A1R37                 | 0757-0442      |     | R:F XD MET FLM 10.0K OHM 1% 1/8W | 28480    | 0757-0442       |
| A1R38                 | 0698-3162      | 9   | R:F XD MET FLM 45.4K OHM 1% 1/8W | 28480    | 0698-3162       |
| A1R39                 | 0757-0442      |     | R:F XD MET FLM 10.0K OHM 1% 1/8W | 28480    | 0757-0442       |
| A1R40                 | 0698-3159      | 1   | R:F XD MET FLM 26.1K OHM 1% 1/8W | 28480    | 0698-3159       |
| A1R41                 | 0757-0442      |     | R:F XD MET FLM 10.0K OHM 1% 1/8W | 28480    | 0757-0442       |
| A1R42                 | 0698-3156      |     | R:F XD MET FLM 14.7K OHM 1% 1/8W | 28480    | 0698-3156       |
| A1R43                 | 0757-0416      | 3   | R:F XD MET FLM 511 OHM 1% 1/8W   | 28480    | 0757-0416       |
| A1R44                 | 0757-0279      |     | R:F XD MET FLM 3.15K OHM 1% 1/8W | 28480    | 0757-0279       |
| A1R27                 | 0757-0438      |     | R:F XD MET FLM 5.11K OHM 1% 1/8W | 28480    | 0757-0438       |
| A1U1                  | 1826-0070      | 8   | IC: LINEAR OPER. AMPL.           | 07263    | U6A7741393      |

Power Supply




2233-1A

|                |   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |    |    |
|----------------|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|
| COMPONENT SIDE | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 |
| SOLDER SIDE    | A | B | C | D | E | F | H | J | K | L  | M  | N  | P  | R  | S  | T  | U  | V  | W  | X  | Y  | Z  |

NOTE: C15 NOT USED ON CARD REV. A-1224-22.

NOTE: Refer to table 7-2 for replaceable parts for assemblies other than A1.


COMPUTER OR EXTENDER PLENUM CHAMBER



- NOTES:
1. RESISTANCE VALUES ARE IN OHMS AND CAPACITANCE VALUES ARE IN UF UNLESS OTHERWISE SPECIFIED.
  2. A3CR24 IS OPTIONAL. REMOVE FOR THERMAL AUTORESTART.
  3. A3C27 FIRST USED ON CARD REV. 1250.
  4. A1C15 FIRST USED ON CARD REV. 1249.
  5. A2C16 FIRST USED ON CARD REV. 1249.


DWG REV. J (02100-60053)  
(THIS DRAWING IS APPLICABLE WITH A DATE CODE OF 1249)

COMPUTER OR EXTENDER PLENUM CHAMBER




- NOTES:
1. RESISTANCE VALUES ARE IN OHMS AND CAPACITANCE VALUES ARE IN UF UNLESS OTHERWISE SPECIFIED.
  2. A3CR24 IS OPTIONAL. REMOVE FOR THERMAL AUTORESTART.
  3. A3C27 FIRST USED ON CARD REV. 1250.
  4. A1C15 FIRST USED ON CARD REV. 1249.
  5. A2C16 FIRST USED ON CARD REV. 1249.

A1 PREREGULATOR CONTROL CARD (02100-60108, REV. 1224,1249)



DWG REV. J (02100-60053) (SHEET 1 OF 4)  
 (THIS DRAWING IS APPLICABLE TO POWER SUPPLIES WITH A DATE CODE OF 1240 OR HIGHER)



- NOTES:
1. RESISTANCE VALUES ARE IN OHMS AND CAPACITANCE VALUES ARE IN UF UNLESS OTHERWISE SPECIFIED.
  2. A3CR24 IS OPTIONAL. REMOVE FOR THERMAL AUTORESTART.
  3. A3C27 FIRST USED ON CARD REV. 1250.
  4. A1C15 FIRST USED ON CARD REV. 1249.
  5. A2C16 FIRST USED ON CARD REV. 1249.

DWG REV. J (02100-60053) (SHEET 1 OF 4)  
 (THIS DRAWING IS APPLICABLE TO POWER SUPPLIES WITH A DATE CODE OF 1240 OR HIGHER)





Figure 7-4. Power Supply (Preregulator Control) Parts Location and Schematic Diagrams, Date Codes 1240 and Higher (Sheet 1 of 4)

Power Supply




DWG REV. D

| COMPONENT SIDE | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 |
|----------------|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|
| SOLDER SIDE    | A | B | C | D | E | F | H | J | K | L  | M  | N  | P  | R  | S  | T  | U  | V  | W  | X  | Y  | Z  |

NOTE: C16 NOT USED ON CARD REV. B-1140-22.


NOTE: Refer to table 7-2 for replaceable parts.

A2 INVERTER DRIVER CARD (02100-60058)




DWG REV. G (SHEET 2 OF 4) SEE SHEET 1 FOR CONNECTIONS  
 (THIS DRAWING IS APPLICABLE TO PARTS WITH A DATE CODE OF 1240 OR HIGHER)





A2 INVERTER DRIVER CARD (02100-60058, REV. 1140,1249)



A7 INVERTER ASSEMBLY

DWG REV. G (SHEET 2 OF 4) SEE SHEET 1 FOR NOTES.  
(THIS DRAWING IS APPLICABLE TO POWER SUPPLIES  
WITH A DATE CODE OF 1240 OR HIGHER)




Figure 7-4. Power Supply (Inverter Driver) Parts Location and Schematic Diagrams, Date Codes 1240 and Higher (Sheet 2 of 4)

Table 7-4. Protection and Control Card A3 (02100-60109), Replaceable Parts

| Reference Designation | HP Part Number | Qty | Description                         | Mfr Code | Mfr Part Number      |
|-----------------------|----------------|-----|-------------------------------------|----------|----------------------|
| A3                    | 02100-60109    | 1   | PROTECTION AND CONTROL CARD         | 28480    | 02100-60109          |
| A3C1                  | 0160-3456      | 11  | C:FXD CER 1000 PF 10% 250VDCW       | 56289    | C067F251F102KS22-CDH |
| A3C2                  | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW       | 56289    | C067F251F102KS22-CDH |
| A3C3                  | 0180-0229      | 1   | C:FXD ELECT 33 UF 10% 10VDCW        | 28480    | 0180-0229            |
| A3C4                  | 0180-0197      |     | C:FXD ELECT 2.2 UF 10% 20VDCW       | 56289    | 150D225X9020A2-DYS   |
| A3C5                  | 0180-0106      | 2   | C:FXD ELECT 60 UF 20% 6VDCW         | 28480    | 0180-0106            |
| A3C6                  | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW       | 56289    | C067F251F102KS22-CDH |
| A3C7                  | 0180-1743      | 1   | C:FXD ELECT 0.1 UF 10% 35VDCW       | 56289    | 150D104X9035A2-DYS   |
| A3C8                  | 0160-0174      | 1   | C:FXD CER 0.47 UF +80-20% 25VDCW    | 56289    | 5C11B75-CML          |
| A3C9                  | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW       | 56289    | C067F251F102KS22-CDH |
| A3C10                 | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW       | 56289    | C067F251F102KS22-CDH |
| A3C11                 | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW       | 56289    | C067F251F102KS22-CDH |
| A3C12                 | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW       | 56289    | C067F251F102KS22-CDH |
| A3C13                 | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW       | 56289    | C067F251F102KS22-CDH |
| A3C13                 | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW       | 56289    | C067F251F102KS22-CDH |
| A3C14                 | 0160-2055      |     | C:FXD CER 0.01 UF +80-20% 100VDCW   | 56289    | C023F101F103ZS22-CDH |
| A3C15                 | 0180-0097      |     | C:FXD TANT. 47 UF 10% 35VDCW        | 56289    | 150D476X9035S2-DYS   |
| A3C16                 | 0180-0098      | 1   | C:FXD ELECT 100 UF 20% 20VDCW       | 56289    | 150D107X9020S2-DYS   |
| A3C17                 | 0180-0174      | 2   | C:FXD ELECT 15 UF 10% 20VDCW        | 28480    | 0180-1746            |
| A3C18                 | 0160-0171      | 1   | C:FXD CER 0.1 UF +80-20% 50VDCW     | 56289    | 5C50B15-CML          |
| A3C20                 | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW       | 56289    | C067F251F102KS22-CDH |
| A3C21                 | 0180-0376      | 1   | C:FXD ELECT 0.47 UF 10% 35VDCW      | 56289    | 150D476X9035A2-DYS   |
| A3C22                 | 0180-1746      |     | C:FXD ELECT 15 UF 10% 20VDCW        | 28480    | 0180-1746            |
| A3C23                 | 0160-3456      |     | C:FXD CER 1000 PF 10% 250VDCW       | 56289    | C067F251F102KS22-CDH |
| A3C24                 | 0170-0040      |     | C:FXD MY 0.047 UF 10% 200VDCW       | 56289    | 192P47392-PTS        |
| A3C25                 | 0160-2055      |     | C:FXD CER 0.01 UF +90-20% 100VDCW   | 56289    | C023F101F103ZS22-CDH |
| A3C26                 | 0180-0106      |     | C:FXD ELECT 60 UF 20% 6VDCW         | 28480    | 0180-0106            |
| A3C27(NOTE 1)         | 0160-2143      | 1   | C:FXD CER 2000 PF +80-20% 1000 VDCW | 91418    | TYPE B               |
| A3CR1                 | 1901-0040      | 30  | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR2                 | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR3                 | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR4                 | 1901-0159      |     | DIODE:SILICON 0.75A 400PIV          | 04713    | SR1358-4             |
| A3CR5                 | 1901-0159      |     | DIODE:SILICON 0.75A 400PIV          | 04713    | SR1358-4             |
| A3CR6                 | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR7                 | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR8                 | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR9                 | 1901-0159      |     | DIODE:SILICON 0.75A 400PIV          | 04713    | SR1358-4             |
| A3CR9                 | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR10                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR11                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR12                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR13                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR14                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR15                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR16                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR17                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR18                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR19                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR20                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR21                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR22                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR23                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR24                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR25                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR26                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR27                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR28                | 1902-0033      | 1   | DIODE: BREAKDOWN 6.2V               | 04713    | 1N823                |
| A3CR29                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR30                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR31                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR32                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3CR33                | 1902-0126      | 1   | DIODE: BREAKDOWN 2.61V 5%           | 04713    | SZ10939-14           |
| A3CR34                | 1901-0040      |     | DIODE:SILICON 30MA 30VV             | 07263    | FDG1088              |
| A3E1                  | 0360-0294      | 3   | TERMINAL: SOLDER POINT              | 28480    | 0360-0294            |
| A3E2                  | 0360-0294      |     | TERMINAL: SOLDER POINT              | 28480    | 0360-0294            |
| A3E3                  | 0360-0294      |     | TERMINAL: SOLDER POINT              | 28480    | 0360-0294            |
| A3Q1                  | 1854-0477      |     | TSTR:SI NPN                         | 80131    | 2N2222A              |
| A3Q2                  | 1853-0281      |     | TSTR:SI PNP                         | 80131    | 2N2907A              |
| A3Q3                  | 1854-0477      |     | TSTR:SI NPN                         | 80131    | 2N2222A              |
| A3Q4                  | 1854-0477      |     | TSTR:SI NPN                         | 80131    | 2N2222A              |
| A3Q5                  | 1853-0281      |     | TSTR:SI PNP                         | 80131    | 2N2907A              |
| A3Q6                  | 1853-0281      |     | TSTR:SI PNP                         | 80131    | 2N2907A              |
| A3Q7                  | 1854-0477      |     | TSTR:SI NPN                         | 80131    | 2N2222A              |
| A3Q8                  | 1854-0477      |     | TSTR:SI NPN                         | 80131    | 2N2222A              |
| A3Q9                  | 1854-0477      |     | TSTR:SI NPN                         | 80131    | 2N2222A              |
| A3Q10                 | 1854-0477      |     | TSTR:SI NPN                         | 80131    | 2N2222A              |
| A3Q11                 | 1854-0477      |     | TSTR:SI NPN                         | 80131    | 2N2222A              |
| A3Q12                 | 1854-0477      |     | TSTR:SI NPN                         | 80131    | 2N2222A              |

NOTES: 1. First used on card rev. 1250.


Table 7-4. Protection and Control Card A3 (02100-60109), Replaceable Parts (Continued)

| Reference Designation | HP Part Number | Qty | Description                       | Mfr Code | Mfr Part Number |
|-----------------------|----------------|-----|-----------------------------------|----------|-----------------|
| A3013                 | 1853-0281      |     | TSTR:SI PNP                       | 80131    | 2N2907A         |
| A3014                 | 1854-0477      |     | TSTR:SI NPN                       | 80131    | 2N2222A         |
| A3015                 | 1853-0281      |     | TSTR:SI PNP                       | 80131    | 2N2907A         |
| A3016                 | 1854-0C34      |     | TSTR:SI NPN                       | 80131    | 2N3053          |
| A3017                 | 1853-0281      |     | TSTR:SI PNP                       | 80131    | 2N2907A         |
| A3R1                  | 0698-3136      | 1   | R:FXD MET FLM 17.8K OHM 1% 1/8W   | 28480    | 0698-3136       |
| A3R2                  | 2100-2574      | 2   | R:VAR CERMET 500 OHM 10% LIN 1/2W | 28480    | 2100-2574       |
| A3R3                  | 0698-3158      | 7   | R:FXD MET FLM 23.7K OHM 1% 1/8W   | 28480    | 0698-3158       |
| A3R4                  | 0698-3158      |     | R:FXD MET FLM 23.7K OHM 1% 1/8W   | 28480    | 0698-3158       |
| A3R5                  | 0757-0416      |     | R:FXD MET FLM 511 OHM 1% 1/8W     | 28480    | 0757-0416       |
| A3R6                  | 0757-0316      | 1   | R:FXD MET FLM 42.2 OHM 1% 1/8W    | 28480    | 0757-0316       |
| A3R7                  | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W   | 28480    | 0757-0442       |
| A3R8                  | 0757-0280      | 5   | R:FXD MET FLM 1K OHM 1% 1/8W      | 28480    | 0757-0280       |
| A3R9                  | 0698-3150      | 2   | R:FXD MET FLM 2.37K OHM 1% 1/8W   | 28480    | 0698-3150       |
| A3R10                 | 0757-0280      |     | R:FXD MET FLM 1K OHM 1% 1/8W      | 28480    | 0757-0280       |
| A3R11                 | 0757-0465      | 4   | R:FXD MET FLM 100K OHM 1% 1/8W    | 28480    | 0757-0465       |
| A3R12                 | 0698-3158      |     | R:FXD MET FLM 23.7K OHM 1% 1/8W   | 28480    | 0698-3158       |
| A3R13                 | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W   | 28480    | 0698-3162       |
| A3R14                 | 0698-3155      | 7   | R:FXD MET FLM 4.64K OHM 1% 1/8W   | 28480    | 0698-3155       |
| A3R15                 | 0757-0444      | 1   | R:FXD MET FLM 12.1K OHM 1% 1/8W   | 28480    | 0757-0444       |
| A3R16                 | 0698-3158      |     | R:FXD MET FLM 23.7K OHM 1% 1/8W   | 28480    | 0698-3158       |
| A3R17                 | 0757-0459      | 8   | R:FXD MET FLM 56.2K OHM 1% 1/8W   | 28480    | 0757-0459       |
| A3R18                 | 0757-0459      |     | R:FXD MET FLM 56.2K OHM 1% 1/8W   | 28480    | 0757-0459       |
| A3R19                 | 0757-0346      | 4   | R:FXD MET FLM 10 OHM 1% 1/8W      | 28480    | 0757-0346       |
| A3R20                 | 0698-3156      |     | R:FXD MET FLM 14.7K OHM 1% 1/8W   | 28480    | 0698-3156       |
| A3R21                 | 0698-0084      | 3   | R:FXD MET FLM 2.15K OHM 1% 1/8W   | 28480    | 0698-0084       |
| A3R22                 | 0757-0465      |     | R:FXD MET FLM 100K OHM 1% 1/8W    | 28480    | 0757-0465       |
| A3R23                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W   | 28480    | 0757-0442       |
| A3R24                 | 0757-0465      |     | R:FXD MET FLM 100K OHM 1% 1/8W    | 28480    | 0757-0465       |
| A3R25                 | 0757-0465      |     | R:FXD MET FLM 100K OHM 1% 1/8W    | 28480    | 0757-0465       |
| A3R26                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W   | 28480    | 0757-0442       |
| A3R27                 | 0757-0280      |     | R:FXD MET FLM 1K OHM 1% 1/8W      | 28480    | 0757-0280       |
| A3R28                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W   | 28480    | 0698-3155       |
| A3R29                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W   | 28480    | 0757-0442       |
| A3R30                 | 0757-0274      | 1   | R:FXD MET FLM 1.02K OHM 1% 1/8W   | 28480    | 0757-0274       |
| A3R31                 | 0698-3158      |     | R:FXD MET FLM 23.7K OHM 1% 1/8W   | 28480    | 0698-3158       |
| A3R32                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W   | 28480    | 0698-3155       |
| A3R33                 | 0757-0346      |     | R:FXD MET FLM 10 OHM 1% 1/8W      | 28480    | 0757-0346       |
| A3R34                 | 0698-3452      | 2   | R:FXD MET FLM 14.7K OHM 1% 1/8W   | 28480    | 0698-3452       |
| A3R35                 | 0698-3151      | 1   | R:FXD MET FLM 2.07K OHM 1% 1/8W   | 28480    | 0698-3151       |
| A3R36                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W   | 28480    | 0698-3155       |
| A3R37                 | 0757-0446      | 1   | R:FXD MET FLM 15.0K OHM 1% 1/8W   | 28480    | 0757-0446       |
| A3R38                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W   | 28480    | 0698-3155       |
| A3R39                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W   | 28480    | 0698-3155       |
| A3R40                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W   | 28480    | 0698-3155       |
| A3R41                 | 0698-3158      |     | R:FXD MET FLM 23.7K OHM 1% 1/8W   | 28480    | 0698-3158       |
| A3R42                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W   | 28480    | 0757-0442       |
| A3R43                 | 0757-0401      |     | R:FXD MET FLM 100 OHM 1% 1/8W     | 28480    | 0757-0401       |
| A3R44                 | 0757-0459      |     | R:FXD MET FLM 56.2K OHM 1% 1/8W   | 28480    | 0757-0459       |
| A3R45                 | 0757-0346      |     | R:FXD MET FLM 10 OHM 1% 1/8W      | 28480    | 0757-0346       |
| A3R46                 | 0757-0428      | 3   | R:FXD MET FLM 1.62K OHM 1% 1/8W   | 28480    | 0757-0428       |
| A3R47                 | 0698-3152      | 1   | R:FXD MET FLM 3.48K OHM 1% 1/8W   | 28480    | 0698-3152       |
| A3R48                 | 0757-0428      |     | R:FXD MET FLM 1.62K OHM 1% 1/8W   | 28480    | 0757-0428       |
| A3R49                 | 0757-0440      | 2   | R:FXD MET FLM 7.50K OHM 1% 1/8W   | 28480    | 0757-0440       |
| A3R50                 | 0698-3455      | 2   | R:FXD MET FLM 261K OHM 1% 1/8W    | 28480    | 0698-3455       |
| A3R51                 | 0757-0459      |     | R:FXD MET FLM 56.2K OHM 1% 1/8W   | 28480    | 0757-0459       |
| A3R52                 | 0757-0401      |     | R:FXD MET FLM 100 OHM 1% 1/8W     | 28480    | 0757-0401       |
| A3R53                 | 0757-0416      |     | R:FXD MET FLM 511 OHM 1% 1/8W     | 28480    | 0757-0416       |
| A3R54                 | 0757-0428      |     | R:FXD MET FLM 1.62K OHM 1% 1/8W   | 28480    | 0757-0428       |
| A3R55                 | 0698-3445      | 1   | R:FXD MET FLM 348 OHM 1% 1/8W     | 28480    | 0698-3445       |
| A3R56                 | 0698-3455      |     | R:FXD MET FLM 261K OHM 1% 1/8W    | 28480    | 0698-3455       |
| A3R57                 | 0757-0438      |     | R:FXD MET FLM 5.11K OHM 1% 1/8W   | 28480    | 0757-0438       |
| A3R58                 | 0698-3150      |     | R:FXD MET FLM 2.37K OHM 1% 1/8W   | 28480    | 0698-3150       |
| A3R59                 | 0757-0459      |     | R:FXD MET FLM 56.2K OHM 1% 1/8W   | 28480    | 0757-0459       |
| A3R60                 | 0698-3156      |     | R:FXD MET FLM 14.7K OHM 1% 1/8W   | 28480    | 0698-3156       |
| A3R61                 | 0698-3155      |     | R:FXD MET FLM 4.64K OHM 1% 1/8W   | 28480    | 0698-3155       |
| A3R62                 | 0757-0280      |     | R:FXD MET FLM 1K OHM 1% 1/8W      | 28480    | 0757-0280       |
| A3R63                 | 0757-0280      |     | R:FXD MET FLM 1K OHM 1% 1/8W      | 28480    | 0757-0280       |
| A3R64                 | 0757-0440      |     | R:FXD MET FLM 7.50K OHM 1% 1/8W   | 28480    | 0757-0440       |
| A3R65                 | 0757-0346      |     | R:FXD MET FLM 10 OHM 1% 1/8W      | 28480    | 0757-0346       |
| A3R66                 | 2100-2574      |     | R:VAR CERMET 500 OHM 10% LIN 1/2W | 28480    | 2100-2574       |
| A3R67                 | 0698-0083      | 1   | R:FXD MET FLM 1.96K OHM 1% 1/8W   | 28480    | 0698-0083       |
| A3R68                 | 0757-0418      | 1   | R:FXD MET FLM 619 OHM 1% 1/8W     | 28480    | 0757-0418       |
| A3R69                 | 0757-0422      | 1   | R:FXD MET FLM 909 OHM 1% 1/8W     | 28480    | 0757-0422       |
| A3R70                 | 0757-0438      |     | R:FXD MET FLM 5.11K OHM 1% 1/8W   | 28480    | 0757-0438       |

Power Supply


Table 7-4. Protection and Control Card A3 (02100-60109), Replaceable Parts (Continued)

| Reference Designation | HP Part Number | Qty | Description                     | Mfr Code | Mfr Part Number |
|-----------------------|----------------|-----|---------------------------------|----------|-----------------|
| A3R71                 | 0698-3156      |     | R:FxD MET FLM 14.7K OHM 1% 1/8W | 28480    | 0698-3156       |
| A3R72                 | 0757-0401      |     | R:FxD MET FLM 100 OHM 1% 1/8W   | 28480    | 0757-0401       |
| A3R73                 | 0698-3158      |     | R:FxD MET FLM 23.7K OHM 1% 1/8W | 28480    | 0698-3158       |
| A3R74                 | 0757-0459      |     | R:FxD MET FLM 56.2K OHM 1% 1/8W | 28480    | 0757-0459       |



NOTE: C27 NOT USED ON CARD REV. A-1243-22.

2233-2B



DWG REV. H (SHEET 3 OF 4) SEE SHEET 1 FOR NOTES. (THIS DRAWING IS APPLICABLE TO POWER SUPPLIES WITH A DATE CODE OF 1240 OR HIGHER)

Parts (Continued)

| Mfr Code | Mfr Part Number |
|----------|-----------------|
| 28480    | 0698-3156       |
| 28480    | 0757-0401       |
| 28480    | 0698-3158       |
| 28480    | 0757-0459       |





Figure 7-4. Power Supply (Protection and Control) Parts Location and Schematic Diagrams, Date Codes 1240 and Higher (Sheet 3 of 4)


Table 7-5. Current Limit Card A4 (02100-60110), Replaceable Parts

| Reference Designation | HP Part Number | Qty | Description                      | Mfr Code | Mfr Part Number    |
|-----------------------|----------------|-----|----------------------------------|----------|--------------------|
| A4                    | 02100-60110    | 1   | CURRENT LIMIT CARD               | 28480    | 02100-60110        |
| A4C1                  | 0160-0168      | 3   | C:FXD MY 0.1 UF 10% 200VDCW      | 56289    | 192P10492-PTS      |
| A4C2                  | 0180-0291      |     | C:FXD ELECT 1.0 UF 10% 35VDCW    | 56289    | 1500105X9035A2-DYS |
| A4C3                  | 0160-0161      | 1   | C:FXD MY 0.01 UF 10% 200VDCW     | 56289    | 192P10392-PTS      |
| A4C4                  | 0160-0168      |     | C:FXD MY 0.1 UF 10% 200VDCW      | 56289    | 192P10492-PTS      |
| A4C5                  | 0180-0291      |     | C:FXD ELECT 1.0 UF 10% 35VDCW    | 56289    | 1500105X9035A2-DYS |
| A4C6                  | 0180-0291      |     | C:FXD ELECT 1.0 UF 10% 35VDCW    | 56289    | 1500105X9035A2-DYS |
| A4C7                  | 0170-0024      | 2   | C:FXD MY 0.022UF 20% 200VDCW     | 56289    | 192P22302          |
| A4C8                  | 0180-0097      |     | C:FXD TANT. .67 UF 10% 35VDCW    | 56289    | 1500476X9035S2-DYS |
| A4C9                  | 0180-0049      | 4   | C:FXD ELECT 20 UF +75-10% 50VDCW | 56289    | 3002066050CC2-DSM  |
| A4C10                 | 0180-0049      |     | C:FXD ELECT 20 UF +75-10% 50VDCW | 56289    | 3002066050CC2-DSM  |
| A4C11                 | 0180-0291      |     | C:FXD ELECT 1.0 UF 10% 35VDCW    | 56289    | 1500105X9035A2-DYS |
| A4C12                 | 0170-0024      |     | C:FXD MY 0.022UF 20% 200VDCW     | 56289    | 192P22302          |
| A4C13                 | 0180-0291      |     | C:FXD ELECT 1.0 UF 10% 35VDCW    | 56289    | 1500105X9035A2-DYS |
| A4C14                 | 0180-0049      |     | C:FXD ELECT 20 UF +75-10% 50VDCW | 56289    | 3002066050CC2-DSM  |
| A4C15                 | 0180-0049      |     | C:FXD ELECT 20 UF +75-10% 50VDCW | 56289    | 3002066050CC2-DSM  |
| A4C16                 | 0160-0168      |     | C:FXD MY 0.1 UF 10% 200VDCW      | 56289    | 192P10492-PTS      |
| A4CR1                 | 1901-0050      | 10  | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4CR2                 | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4CR3                 | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4CR4                 | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4CR5                 | 1902-3290      | 2   | DIODE BREAKDOWN:SILICON 31.6V 5% | 29480    | 1902-3290          |
| A4CR6                 | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4CR7                 | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4CR8                 | 1902-3290      |     | DIODE BREAKDOWN:SILICON 31.6V 5% | 29480    | 1902-3290          |
| A4CR9                 | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4CR10                | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4CR11                | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4CR12                | 1901-0050      |     | DIODE:SI 200 MA AT 1V            | 07263    | FDA 6308           |
| A4D1                  | 1853-0281      |     | TSTR:SI PNP                      | 80131    | 2N2907A            |
| A4R1                  | 0757-0280      | 10  | R:FXD MET FLM 1K OHM 1% 1/8W     | 28480    | 0757-0280          |
| A4R2                  | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W    | 28480    | 0698-0082          |
| A4R3                  | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W    | 28480    | 0698-0082          |
| A4R4                  | 0757-0461      |     | R:FXD MET FLM 68.1K OHM 1% 1/8W  | 28480    | 0757-0461          |
| A4R5                  | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W  | 28480    | 0757-0442          |
| A4R6                  | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W  | 28480    | 0757-0442          |
| A4R7                  | 0698-3162      | 8   | R:FXD MET FLM 46.4K OHM 1% 1/8W  | 28480    | 0698-3162          |
| A4R8                  | 0698-3452      |     | R:FXD MET FLM 147K OHM 1% 1/8W   | 28480    | 0698-3452          |
| A4R9                  | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W  | 28480    | 0698-3162          |
| A4R10                 | 0757-0464      | 1   | R:FXD MET FLM 90.9K OHM 1% 1/8W  | 28480    | 0757-0464          |
| A4R11                 | 0698-3260      | 5   | R:FXD MET FLM 464K OHM 1% 1/8W   | 28480    | 0698-3260          |
| A4R12                 | 0757-0280      |     | R:FXD MET FLM 1K OHM 1% 1/8W     | 28480    | 0757-0280          |
| A4R13                 | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W    | 28480    | 0698-0082          |
| A4R14                 | 0698-3450      | 1   | R:FXD MET FLM 42.2K OHM 1% 1/8W  | 28480    | 0698-3450          |
| A4R15                 | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W    | 28480    | 0698-0082          |
| A4R16                 | 0757-0459      |     | R:FXD MET FLM 56.2K OHM 1% 1/8W  | 28480    | 0757-0459          |
| A4R17                 | 0757-0461      |     | R:FXD MET FLM 68.1K OHM 1% 1/8W  | 28480    | 0757-0461          |
| A4R18                 | 0757-0280      |     | R:FXD MET FLM 1K OHM 1% 1/8W     | 28480    | 0757-0280          |
| A4R19                 | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W    | 28480    | 0698-0082          |
| A4R20                 | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W    | 28480    | 0698-0082          |
| A4R21                 | 0698-3161      | 1   | R:FXD MET FLM 38.3K OHM 1% 1/8W  | 28480    | 0698-3161          |
| A4R22                 | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W  | 28480    | 0698-3162          |
| A4R23                 | 0757-0280      |     | R:FXD MET FLM 1K OHM 1% 1/8W     | 28480    | 0757-0280          |
| A4R24                 | 0757-0199      |     | R:FXD MET FLM 21.5K OHM 1% 1/8W  | 28480    | 0757-0199          |
| A4R25                 | 0757-0442      |     | R:FXD MET FLM 10.0K OHM 1% 1/8W  | 28480    | 0757-0442          |
| A4R26                 | 0757-0290      |     | R:FXD MET FLM 1K OHM 1% 1/8W     | 28480    | 0757-0290          |
| A4R27                 | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W  | 28480    | 0698-3162          |
| A4R28                 | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W    | 28480    | 0698-0082          |
| A4R29                 | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W    | 28480    | 0698-0082          |
| A4R30                 | 0698-3160      | 1   | R:FXD MET FLM 31.6K OHM 1% 1/8W  | 28480    | 0698-3160          |
| A4R31                 | 0698-3260      |     | R:FXD MET FLM 464K OHM 1% 1/8W   | 28480    | 0698-3260          |
| A4R32                 | 0698-3260      |     | R:FXD MET FLM 464K OHM 1% 1/8W   | 28480    | 0698-3260          |
| A4R33                 | 0757-0280      |     | R:FXD MET FLM 1K OHM 1% 1/8W     | 28480    | 0757-0280          |
| A4R34                 | 0757-0461      |     | R:FXD MET FLM 68.1K OHM 1% 1/8W  | 28480    | 0757-0461          |
| A4R35                 | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W    | 28480    | 0698-0082          |
| A4R36                 | 0757-0459      |     | R:FXD MET FLM 56.2K OHM 1% 1/8W  | 28480    | 0757-0459          |
| A4R37                 | 0698-0082      |     | R:FXD MET FLM 464 OHM 1% 1/8W    | 28480    | 0698-0082          |
| A4R38                 | 0698-4037      | 4   | R:FXD MET FLM 46.4 OHM 1% 1/8W   | 28480    | 0698-4037          |
| A4R39                 | 0698-4037      |     | R:FXD MET FLM 46.4 OHM 1% 1/8W   | 28480    | 0698-4037          |
| A4R40                 | 0698-4034      |     | R:FXD MET FLM 2.15K OHM 1% 1/8W  | 28480    | 0698-4034          |
| A4R41                 | 0698-4037      |     | R:FXD MET FLM 46.4 OHM 1% 1/8W   | 28480    | 0698-4037          |
| A4R42                 | 0698-0084      |     | R:FXD MET FLM 2.15K OHM 1% 1/8W  | 28480    | 0698-0084          |
| A4R43                 | 0698-4037      |     | R:FXD MET FLM 46.4 OHM 1% 1/8W   | 28480    | 0698-4037          |
| A4R44                 | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W  | 28480    | 0698-3162          |
| A4R45                 | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W  | 28480    | 0698-3162          |

Table 7-5. Current Limit Card A4 (02100-60110), Replaceable Parts (Continued)

| Reference Designation | HP Part Number | Qty | Description                     | Mfr Code | Mfr Part Number |
|-----------------------|----------------|-----|---------------------------------|----------|-----------------|
| A4R45                 | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W | 28480    | 0698-3162       |
| A4R46                 | C757-0462      | 1   | R:FXD MET FLM 75.0K OHM 1% 1/8W | 28480    | C757-0462       |
| A4R47                 | 0698-3162      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W | 28480    | 0698-3162       |
| A4R48                 | 0757-0463      | 1   | R:FXD MET FLM 82.5K OHM 1% 1/8W | 28480    | 0757-0463       |
| A4R49                 | 0698-3260      |     | R:FXD MET FLM 46.4K OHM 1% 1/8W | 28460    | 0698-3260       |
| A4U1                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.           | 07263    | U6A7741393      |
| A4U2                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.           | 07263    | U6A7741393      |
| A4U3                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.           | 07263    | U6A7741393      |
| A4U4                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.           | 07263    | U6A7741393      |
| A4U5                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.           | 07263    | U6A7741393      |
| A4U6                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.           | 07263    | U6A7741393      |
| A4U7                  | 1826-0070      |     | IC:LINEAR OPER. AMPL.           | 07263    | U6A7741393      |






COMPONENT SIDE  
SOLDER SIDE

|   |   |   |   |   |   |   |   |   |    |    |    |    |    |    |    |    |    |    |    |    |    |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 |
| A | B | C | D | E | F | H | J | K | L  | M  | N  | P  | R  | S  | T  | U  | V  | W  | X  | Y  | Z  |

2233-3A



DWG. REV. F (SHEET 4 OF 4) SEE SHEET 1 FOR NOTES.  
(THIS DRAWING IS APPLICABLE TO POWER SUPPLIES  
WITH A DATE CODE OF 1240 OR HIGHER)




Figure 7-4. Power Supply (Current Limit)  
 Parts Location and Schematic Diagrams,  
 Date Codes 1240 and Higher  
 (Sheet 4 of 4)

**ELECTRONIC**

**SALES & SERVICE OFFICES**

**UNITED STATES**

**ALABAMA**  
P.O. Box 4207  
2003 Byrd Spring Road S.W.  
Huntsville 35802  
Tel: (205) 881-4591  
TWX: 810-726-2204

**ARIZONA**  
2336 E. Magnolia St.  
Phoenix 85034  
Tel: (602) 244-1361  
TWX: 910-951-1330  
  
5737 East Broadway  
Tucson 85711  
Tel: (602) 298-2313  
TWX: 910-952-1162

**CALIFORNIA**  
1430 East Orangethorpe Ave.  
Fullerton 92631  
Tel: (714) 870-1000  
TWX: 910-592-1288  
  
3939 Lankershim Boulevard  
North Hollywood 91604  
Tel: (213) 877-1282  
TWX: 910-499-2170  
  
6305 Arizona Place  
Los Angeles 90045  
Tel: (213) 649-2511  
TWX: 910-328-6148  
  
1101 Embarcadero Road  
Palo Alto 94303  
Tel: (415) 327-6500  
TWX: 910-373-1280  
  
2220 Watt Ave.  
Sacramento 95825  
Tel: (916) 482-1463  
TWX: 910-367-2092  
  
9606 Aero Drive  
San Diego 92123  
Tel: (714) 279-3200  
TWX: 910-335-2000

**COLORADO**  
7965 East Prentice  
Englewood 80110  
Tel: (303) 771-3455  
TWX: 910-935-0705

**CONNECTICUT**  
12 Lunar Drive  
New Haven 06525  
Tel: (203) 389-6551  
TWX: 710-465-2029

**FLORIDA**  
P.O. Box 24210  
2806 W. Oakland Park Blvd.  
Ft. Lauderdale 33307  
Tel: (305) 731-2020  
TWX: 510-955-4099  
  
P.O. Box 13910  
6177 Lake Ellenor Dr.  
Orlando, 32809  
Tel: (305) 859-2900  
TWX: 810-850-0113

**GEORGIA**  
P.O. Box 28234  
450 Interstate North  
Atlanta 30328  
Tel: (404) 436-6181  
TWX: 810-766-4890

**HAWAII**  
2875 So. King Street  
Honolulu 96814  
Tel: (808) 955-4455

**ILLINOIS**  
5500 Howard Street  
Skokie 60076  
Tel: (312) 677-0400  
TWX: 910-223-3613

**INDIANA**  
3839 Meadows Drive  
Indianapolis 46205  
Tel: (317) 546-4891  
TWX: 810-341-3263

**LOUISIANA**  
P.O. Box 856  
3239 Williams Boulevard  
Kenner 70062  
Tel: (504) 721-6201  
TWX: 810-955-5524

**MARYLAND**  
6707 Whitestone Road  
Baltimore 21207  
Tel: (301) 944-5400  
TWX: 710-862-9157  
  
P.O. Box 1648  
2 Choke Cherry Road  
Rockville 20850  
Tel: (301) 948-6370  
TWX: 710-828-9684

**MASSACHUSETTS**  
32 Hartwell Ave.  
Lexington 02173  
Tel: (617) 861-8960  
TWX: 710-326-6904

**MICHIGAN**  
21840 West Nine Mile Road  
Southfield 48075  
Tel: (313) 353-9100  
TWX: 810-224-4882

**MINNESOTA**  
2459 University Avenue  
St. Paul 55114  
Tel: (612) 645-9461  
TWX: 910-563-3734

**MISSOURI**  
11131 Colorado Ave.  
Kansas City 64137  
Tel: (816) 763-8000  
TWX: 910-771-2087  
  
148 Weldon Parkway  
Maryland Heights 63043  
Tel: (314) 567-1455  
TWX: 910-764-0830

**\*NEVADA**  
Las Vegas  
Tel: (702) 382-5777

**NEW JERSEY**  
W. 120 Century Road  
Paramus 07652  
Tel: (201) 265-5000  
TWX: 710-990-4951  
  
1060 N. Kings Highway  
Cherry Hill 08034  
Tel: (609) 667-4000  
TWX: 710-892-4945

**NEW MEXICO**  
P.O. Box 8366  
Station C  
6501 Lomas Boulevard N.E.  
Albuquerque 87108  
Tel: (505) 265-3713  
TWX: 910-989-1665  
  
156 Wyatt Drive  
Las Cruces 88001  
Tel: (505) 526-2485  
TWX: 910-983-0550

**NEW YORK**  
6 Automation Lane  
Computer Park  
Albany 12205  
Tel: (518) 458-1550  
TWX: 710-441-8270  
  
1219 Campville Road  
Endicott 13760  
Tel: (607) 754-0050  
TWX: 510-252-0890  
  
New York City  
Manhattan, Bronx  
Contact Paramus, NJ Office  
Tel: (201) 265-5000  
Brooklyn, Queens, Richmond  
Contact Woodbury, NY Office  
Tel: (516) 921-0300  
  
82 Washington Street  
Poughkeepsie 12601  
Tel: (914) 454-7330  
TWX: 510-248-0012  
  
39 Saginaw Drive  
Rochester 14623  
Tel: (716) 473-9500  
TWX: 510-253-5981  
  
5858 East Molloy Road  
Syracuse 13211  
Tel: (315) 454-2486  
TWX: 710-541-0482  
  
1 Crossways Park West  
Woodbury 11797  
Tel: (516) 921-0300  
TWX: 510-221-2168

**NORTH CAROLINA**  
P.O. Box 5188  
1923 North Main Street  
High Point 27262  
Tel: (919) 885-8101  
TWX: 510-926-1516  
  
**OHIO**  
25575 Center Ridge Road  
Cleveland 44145  
Tel: (216) 835-0300  
TWX: 810-427-9129  
  
3460 South Dixie Drive  
Dayton 45439  
Tel: (513) 298-0351  
TWX: 810-459-1925  
  
1120 Morse Road  
Columbus 43229  
Tel: (614) 846-1300

**OKLAHOMA**  
P.O. Box 32008  
Oklahoma City 73132  
Tel: (405) 721-0200  
TWX: 910-830-6862

**OREGON**  
17890 SW Boones Ferry Road  
Tualatin 97062  
Tel: (503) 620-3350  
TWX: 910-467-8714

**PENNSYLVANIA**  
2500 Moss Side Boulevard  
Monroeville 15146  
Tel: (412) 271-0724  
TWX: 710-797-3650  
  
1021 8th Avenue  
King of Prussia Industrial Park  
King of Prussia 19406  
Tel: (215) 265-7000  
TWX: 510-660-2670

**RHODE ISLAND**  
873 Waterman Ave.  
East Providence 02914  
Tel: (401) 434-5535  
TWX: 710-381-7573

**\*TENNESSEE**  
Memphis  
Tel: (901) 274-7472

**TEXAS**  
P.O. Box 1270  
201 E. Arapaho Rd.  
Richardson 75080  
Tel: (214) 231-6101  
TWX: 910-867-4723  
  
P.O. Box 27409  
6300 Westpark Drive  
Suite 100  
Houston 77027  
Tel: (713) 781-6000  
TWX: 910-881-2645  
  
231 Billy Mitchell Road  
San Antonio 78226  
Tel: (512) 434-4171  
TWX: 910-871-1170

**UTAH**  
2890 South Main Street  
Salt Lake City 84115  
Tel: (801) 487-0715  
TWX: 910-925-5681

**VIRGINIA**  
P.O. Box 6514  
2111 Spencer Road  
Richmond 23230  
Tel: (804) 285-3431  
TWX: 710-956-0157

**WASHINGTON**  
433-108th N.E.  
Bellevue 98004  
Tel: (206) 454-3971  
TWX: 910-443-2303

**\*WEST VIRGINIA**  
Charleston  
Tel: (304) 768-1232

**WISCONSIN**  
9431 W. Beloit Road  
Suite 117  
Milwaukee 53227  
Tel: (414) 541-0550

**FOR U.S. AREAS NOT LISTED:**  
Contact the regional office nearest you: Atlanta, Georgia... North Hollywood, California... Paramus, New Jersey... Skokie, Illinois. Their complete addresses are listed above.  
**\*Service Only**

**CANADA**

**ALBERTA**  
Hewlett-Packard (Canada) Ltd.  
11748 Kingsway Ave.  
Edmonton  
Tel: (403) 452-3670  
TWX: 610-831-2431

**BRITISH COLUMBIA**  
Hewlett-Packard (Canada) Ltd.  
4519 Canada Way  
North Burnaby 2  
Tel: (604) 433-8213  
TWX: 610-922-5059

**MANITOBA**  
Hewlett-Packard (Canada) Ltd.  
513 Century St.  
Winnipeg  
Tel: (204) 786-7581  
TWX: 610-671-3531

**NOVA SCOTIA**  
Hewlett-Packard (Canada) Ltd.  
2745 Dutch Village Rd.  
Suite 206  
Halifax  
Tel: (902) 455-0511  
TWX: 610-271-4482

**ONTARIO**  
Hewlett-Packard (Canada) Ltd.  
1785 Woodward Dr.  
Ottawa 3  
Tel: (613) 255-6180, 255-6530  
TWX: 610-562-8968  
  
Hewlett-Packard (Canada) Ltd.  
50 Galaxy Blvd.  
Rexdale  
Tel: (416) 677-9611  
TWX: 610-492-4246

**QUEBEC**  
Hewlett-Packard (Canada) Ltd.  
275 Hymus Boulevard  
Pointe Claire  
Tel: (514) 697-4232  
TWX: 610-422-3022  
Telex: 01-20607

**FOR CANADIAN AREAS NOT LISTED:**  
Contact Hewlett-Packard (Canada) Ltd. in Pointe Claire, at the complete address listed above.

**CENTRAL AND SOUTH AMERICA**

**ARGENTINA**  
Hewlett-Packard Argentina S.A.C.e.l  
Lavalle 1171 - 3°  
Buenos Aires  
Tel: 35-0436, 35-0627, 35-0341  
Telex: 012-1009  
Cable: HEWPACK ARG

**BOLIVIA**  
Stambuk & Mark (Bolivia) LTDA.  
Av. Mariscal, Santa Cruz 1342  
La Paz  
Tel: 40626, 53163, 52421  
Telex: 3560014  
Cable: BUKMAR

**CHILE**  
Héctor Calcagni y Cia, Ltda.  
Casilla 16.475  
Santiago  
Tel: 423 96  
Cable: CALCAGNI Santiago

**COLOMBIA**  
Instrumentación  
Henrik A. Langebaek & Kier S.A.  
Carrera 7 No. 48-59  
Apartado Aéreo 6287  
Bogotá, 1 D.E.  
Tel: 45-78-06, 45-55-46  
Cable: AARIS Bogota  
Telex: 44400INSTCO

**COSTA RICA**  
Lic. Alfredo Gallegos Gurdian  
Apartado 10159  
San José  
Tel: 21-86-13  
Cable: GALGUR San José

**ECUADOR**  
Laboratorios de Radio-Ingeniería  
Calle Guayaquil 1246  
Post Office Box 3199  
Quito  
Tel: 212-496; 219-185  
Cable: HORVATH Quito

**EL SALVADOR**  
Electronic Associates  
Apartado Postal 1682  
Centro Comercial Gigante  
San Salvador, El Salvador C.A.  
Paseo Escalon 4649-4° Piso  
Tel: 23-44-60, 23-32-37  
Cable: ELECAS

**GUATEMALA**  
IPESA  
5a via 2-01, Zona 4  
Guatemala City  
Tel: 63-6-27 & 64-7-86  
Telex: 4192 TELTRO GU

**MEXICO**  
Hewlett-Packard Mexicana, S.A. de C.V.  
Adolfo Prieto 622  
Col. del Valle  
Mexico 12, D.F.  
Tel: 543-4232; 523-1874  
Telex: 017-74-507

**NICARAGUA**  
Roberto Terán G.  
Apartado Postal 689  
Edificio Terán  
Managua  
Tel: 3451, 3452  
Cable: ROTERAN Managua

**PANAMA**  
Electrónica Balboa, S.A.  
P.O. Box 4929  
Ave. Manuel Espinosa No. 13-50  
Bldg. Alina  
Panama City  
Tel: 230833  
Telex: 3481003, Curundu,  
Canal Zone  
Cable: ELECTRON Panama City

**PARAGUAY**  
Z.J. Melamed S.R.L.  
División: Aparatos y Equipos  
Médicos  
Salón de Exposición y Escritorio:  
Chile 482  
Edificio Victoria—Planta Baja  
Asuncion, Paraguay  
Tel: 4-5069, 4-6272  
Cable: RAMEL

**PERU**  
Compañía Electro Médica S.A.  
Ave. Enrique Canaual 312  
San Isidro  
Casilla 1030  
Lima  
Tel: 22-3900  
Cable: ELMED Lima

**PUERTO RICO**  
San Juan Electronics, Inc.  
P.O. Box 5167  
Ponce de Leon 154  
Pda. 3-PTA de Tierra  
San Juan 00906  
Tel: (809) 725-3342, 722-3342  
Cable: SATRONICS San Juan  
Telex: SATRON 3450 332

**URUGUAY**  
Pablo Ferrando S.A.  
Comercial e Industrial  
Avenida Italia 2877  
Casilla de Correo 370  
Montevideo  
Tel: 40-3102  
Cable: RADIUM Montevideo

**VENEZUELA**  
Hewlett-Packard De Venezuela C.A.  
Apartado 50933  
Caracas  
Tel: 71.88.05, 71.88.69, 71.99.30  
Cable: HEWPACK Caracas  
Telex: 21146 HEWPACK

**FOR AREAS NOT LISTED,**  
**CONTACT:**  
Hewlett-Packard Inter-Americas  
3200 Hillview Ave.  
Palo Alto, California 94304  
Tel: (415) 493-1501  
TWX: 910-373-1267  
Cable: HEWPACK Palo Alto  
Telex: 034-8300, 034-8493





MANUAL PART NO. 5951-3038  
MICROFICHE PART NO. 5951-4427

PRINTED IN U.S.A.